

PROCEDURE FOR DISABLING WEEKLY SELF TEST

1. Press **DSP- 163- ENT**. This will show you if the weekly self test is enabled or disabled. If it is enabled continue on to disable it.
2. Press **PRG- 163- ENT**. Unit will now ask for a password.
3. Press **944944**. This is the user password. Unit now says, "re-enter control code". The control code is already there [163] so ...
4. Press **ENT**. Unit will offer options.
5. Press/choose **2**. Unit will again offer options.
6. Press/choose **2**. Unit should now say "Weekly test disabled". I always like to verify it truly is disabled so ...
7. Press **DSP- 163- ENT**. Unit should display "Weekly test disabled".
8. Press **CLR - CLR - CLR** and display should return to default screen [scrolling]. If you skip this step the display will automatically return to default after a few minutes.

Note: DSP is short for "Display", PRG is short for "Program".
ENT is short for "Enter", CLR is short for "Clear".