

Instructions:

1. Extract and save the file you need from the list below to your PC.

2. Open a web browser and type the IP address of the FieldServer in the address bar.

Default IP Address is 192.168.1.24

Use the FS Toolbox utility if you do not know the IP address

3. Click on the Diagnostics & Debugging button.

4. In the Navigation Tree on the left hand side, do the following

Click on SETUP.

Click on FILE TRANSFER.

Click on the GENERAL tab.

5. In the GENERAL tab, click on Browse and select the WEB.IMG file.

6. Click on submit.

7. When the download is complete, click on the SYSTEM RESTART button.