

How to Use the PM Profile Sample

The Example Profile for PM, is a file to teach you how to program a sample profile into the EZ-ZONE PM controller using the keys of the controller. The Users PM Profile Documentation files are supplied in Microsoft Excel and Adobe PDF formats to allow users to document their EZ-ZONE PM profile settings.

Note:

Parameter visibility is based on the controller part number.

For additional assistance look for training videos of the EZ-ZONE PM controller at the Watlow website:
<http://www.watlow.com/literature/education.cfm>

To view the parameters (within the Excel document) as they are displayed on the controller, place the file LEDREVERSE LT Std.ttf into the Windows font folder. Alternatively, the user may use the free software program called EZ-ZONE Configurator to program and save all settings in electronic format. Version 5.00 of the EZ-ZONE Configurator program provides a method to print all the settings to a printer or to a file in PDF format. This software can be found on this disk as well as on the Watlow web site:
(<http://www.watlow.com>).

A serial connection using EIA-485 is required to make the connection from the PC to the controller.