



DAE Tools Project Documentation

Release 1.3.1

by Dragan Nikolic

May 03, 2013

CONTENTS

1	Getting Started with DAE Tools	1
1.1	Programming language	1
1.2	The main concepts	1
1.2.1	Core module	2
1.2.2	Activity module	3
1.2.3	DataReporting module	3
1.2.4	IDAS module	3
1.2.5	Units module	3
1.3	Running a simulation	3
1.4	Running an optimization	4
1.5	Model development	4
1.5.1	Models	7
1.5.2	Distribution domains	7
1.5.3	Parameters	8
1.5.4	Variables	8
1.5.5	Equations	8
1.5.6	State Transition Networks (discontinuous equations)	10
1.5.7	Ports	11
1.5.8	Event Ports	12
1.5.9	Simulation	12
1.5.10	Running a simulation	13
1.5.11	Optimization	15
1.5.12	Running the optimization	16
1.5.13	Processing the results	17
2	pyDAE User Guide	21
3	pyDAE API Reference	23
3.1	Module pyCore	23
3.1.1	Overview	23
3.1.2	Key modelling concepts	23
3.1.3	Logging support	33
3.1.4	Autodifferentiation and equation evaluation tree support	35
3.1.5	Auxiliary classes	37
3.1.6	Auxiliary functions	38
3.1.7	Enumerations	38
3.1.8	Global constants	42
3.2	Module pyActivity	43
3.2.1	Overview	43
3.2.2	Enumerations	46
3.3	Module pyDataReporting	47
3.3.1	Overview	47
3.3.2	DataReporter classes	47

3.3.3	DataReporter data-containers	48
3.3.4	DataReceiver classes	49
3.3.5	DataReceiver data-containers	49
3.4	Module pyIDAS	50
3.4.1	Overview	50
3.5	Module pyUnits	50
3.5.1	Overview	50
3.5.2	Classes	50
4	Third party solvers	53
4.1	Linear solvers	53
4.2	Optimization solvers	54
4.3	Parameter estimation solvers	55
5	Code generators	57
5.1	Auxiliary classes	57
5.2	Modelica	57
5.3	ANSI C	58
5.4	Functional Mockup Interface (FMI)	58
6	Tutorials	59
6.1	What's the time? (AKA: Hello world!)	59
6.2	Tutorial 1	59
6.3	Tutorial 2	59
6.4	Tutorial 3	59
6.5	Tutorial 4	59
6.6	Tutorial 5	60
6.7	Tutorial 6	60
6.8	Tutorial 7	60
6.9	Tutorial 8	60
6.10	Tutorial 9	60
6.11	Tutorial 10	60
6.12	Tutorial 11	61
6.13	Tutorial 12	61
6.14	Tutorial 13	61
6.15	Tutorial 14	61
6.16	Optimization tutorial 1	61
6.17	Optimization tutorial 2	61
6.18	Optimization tutorial 3	61
6.19	Optimization tutorial 4	62
6.20	Optimization tutorial 5	62
6.21	Optimization tutorial 6	62
7	Indices and tables	63
	Python Module Index	65

GETTING STARTED WITH DAE TOOLS

This chapter gives the basic information about what is needed to develop a model of a process, how to simulate/optimize it and how to obtain and plot the results of a process simulation/optimization. In general, the simulation/optimization of a process consists of three tasks:

1. Modelling of a process
2. Defining a simulation/optimization
3. Processing the results

1.1 Programming language

DAE Tools core libraries are written in standard c++. However, [Python](#) programming language is used as the main modelling language. The main reason for use of Python is (as the authors say): “*Python is an easy to learn, powerful programming language. It has efficient high-level data structures and a simple but effective approach to object-oriented programming. Python’s elegant syntax and dynamic typing, together with its interpreted nature, make it an ideal language for scripting and rapid application development in many areas on most platforms*” [link](#).

And: “*Often, programmers fall in love with Python because of the increased productivity it provides. Since there is no compilation step, the edit-test-debug cycle is incredibly fast*” [link](#). Also, please have a look on [a comparison to the other languages](#). Based on the information available online, and according to the personal experience, the python programs are much shorter and take an order of magnitude less time to develop it. Initially I developed daePlotter module in c++; it took me about one month of part time coding. But, then I moved to python: reimplementing it in PyQt took me just two days (with several new features added), while the code size shrank from 24 cpp modules to four python modules only!

“*Where Python code is typically 3-5 times shorter than equivalent Java code, it is often 5-10 times shorter than equivalent C++ code! Anecdotal evidence suggests that one Python programmer can finish in two months what two C++ programmers can’t complete in a year. Python shines as a glue language, used to combine components written in C++*” [link](#). Obviously, not everything can be developed in python; for complex projects I still prefer the heavy c++ artillery.

1.2 The main concepts

DAE Tools contains 5 modules:

- Core
- Activity
- DataReporting
- IDAS
- Units

1.2.1 Core module

Core module defines the main modelling concepts:

- **Model**

A model of the process is a simplified abstraction of real world process/phenomena describing its most important/driving elements and their interactions. In **DAE Tools** models are created by defining their parameters, distribution domains, variables, equations, and ports.

- **Distribution domain**

Domain is a general term used to define an array of different objects (parameters, variables, equations but models and ports as well).

- **Parameter**

Parameter can be defined as a time invariant quantity that will not change during a simulation.

- **Variable**

Variable can be defined as a time variant quantity, also called a *state variable*.

- **Equation**

Equation can be defined as an expression used to calculate a variable value, which can be created by performing basic mathematical operations (+, -, *, /) and functions (such as sin, cos, tan, sqrt, log, ln, exp, pow, abs etc) on parameter and variable values (and time and partial derivatives as well).

- **State transition network**

State transition networks are used to model a special type of equations: *discontinuous equation*s*. *Discontinuous equations are equations that take different forms subject to certain conditions. They are composed of a finite number of *states*.

- **State**

States can be defined as a set of actions (in our case a set of equations) under current operating conditions. In addition, every state contains a set of state transitions which describe conditions when the state changes occur.

- **State Transition**

State transition can be defined as a transition from the current to some other state, subject to given conditions.

- **Port**

Ports are objects used to connect two model instances and exchange continuous information. Like models, they may contain domains, parameters and variables.

- **EventPort**

Event ports are objects used to connect two model instances and exchange discrete information (events/messages).

- **Simulation**

Simulation of a process can be considered as the model run for certain input conditions. To define a simulation, several tasks are necessary such as: specifying information about domains and parameters, fixing the degrees of freedom by assigning values to certain variables, setting the initial conditions and many other (setting the initial guesses, absolute tolerances, etc).

- **Optimization**

Process optimization can be considered as a process adjustment so as to minimize or maximize a specified goal while satisfying imposed set of constraints. The most common goals are minimizing

cost, maximizing throughput, and/or efficiency. In general there are three types of parameters that can be adjusted to affect optimal performance:

- Equipment optimization
- Operating procedures
- Control optimization

- **Solver**

Solver is a set of mathematical procedures/algorithms necessary to solve a given set of equations. There are several types of solvers: Linear Algebraic solvers (**LA**), used to solve linear systems of equations; Nonlinear Algebraic solvers (**NLA**), used to solve non-linear systems of equations; Differential Algebraic solvers (**DAE**), used to solve mixed systems of differential and algebraic equations; Nonlinear Programming solvers (**NLP**), used to solve nonlinear optimization problems; Mixed-integer Nonlinear Programming solvers (**MINLP**), used to solve mixed-integer nonlinear optimization problems. In **DAE Tools** it is possible to choose **DAE** (currently only [Sundials IDAS](#)), **NLP/MINLP** (currently [IPOPT/BONMIN](#) and [NLOPT](#)), and **LA** solvers (built-in Sundials [LA](#) solvers; [Trilinos Amesos](#); [Trilinos AztecOO](#); [SuperLU/SuperLU_MT](#); [Intel MKL](#); [AMD ACML](#)).

- **Data Reporter**

Data reporter is defined as an object used to report the results of a simulation/optimization. They can either keep the results internally (and export them into a file, for instance) or send them via TCP/IP protocol to the **DAE Tools** plotter.

- **Data Receiver**

Data receiver can be defined as an object which duty is to receive the results from a data reporter. These data can be later plotted or processed in some other ways.

- **Log**

Log is defined as an object used to send messages from the various parts of **DAE Tools** framework (messages from solvers or simulation).

1.2.2 Activity module

1.2.3 DataReporting module

1.2.4 IDAS module

1.2.5 Units module

1.3 Running a simulation

Two steps are needed to run a simulation:

1. Start **daePlotter**:

- **In GNU/Linux and MacOS:**

Go to: **Applications/Programming/daePlotter** or type the following shell command:
daeplotter

- **In Windows:**

Go to: **Start/Programs/DAE Tools/daePlotter** The **daePlotter** main window should appear (given in [Figure 1.](#))

daePlotter can be also added to a panel. Simply add a custom application launcher (command: **daeplotter**).




Figure 1.1: **Figure 1.** daePlotter main window.

2. Start **DAE Tools Examples** program to try some examples:

- **In GNU/Linux and MacOS:**

Go to: **Applications/Programming/DAE Tools Examples** or type the following shell command: **daeexamples**

- **In Windows:**

Go to: **Start/Programs/DAE Tools/DAE Tools Examples**

In general, simulations are started by typing the following shell commands (GNU/Linux and Windows): `figwidth .. code-block:: bash`

`cd "directory where simulation file is located" python mySimulation.py`

The main window of **DAE Tools Examples** application is given in [Figure 2a](#). while the output from the simulation run in [Figure 2b](#). Users can select one of several tutorials, run them, and inspect their source code or model reports. Model reports open in a new window of the system's default web browser (however, only Mozilla Firefox is currently supported because of the MathML rendering issue).




Figure 1.2: **Figure 2a.** DAE Tools Examples main window

The simulation can also be started from the shell. The sample output is given in [Figure 3](#).


1.4 Running an optimization

Running the optimization problems is analogous to running a simulation.

1.5 Model development

In general, three approaches to process modelling exist ⁽¹⁾:

¹ Morton, W., Equation-Oriented Simulation and Optimization. *Proc. Indian Natl. Sci. Acad.* 2003, 317-357.

Figure 1.3: **Figure 2b.** A typical optimization output from DAE Tools

- Sequential Modular (**SeqM**) approach
- Simultaneous Modular (**SimM**) approach
- Equation-Oriented (**EO**) approach

The pros & cons of the first two approaches are extensively studied in the literature. Under the **EO** approach we generate and gather together all equations and variables which constitute the model representing the process. The equations are solved simultaneously using a suitable mathematical algorithm (Morton, 2003¹). Equation-oriented simulation requires simultaneous solution of a set of differential algebraic equations (**DAE**) which itself requires a solution of a set of nonlinear algebraic equations (**NLAE**) and linear algebraic equations (**LAE**). The Newton's method or some variant of it is almost always used to solve problems described by NLAEs. A brief history of Equation-Oriented solvers and comparison of **SeqM** and **EO** approaches as well as descriptions of the simultaneous modular and equation-oriented methods can be found in Morton, 2003⁽¹⁾. Also a good overview of the equation-oriented approach and its application in **gPROMS** is given by Barton & Pantelides^(2, 3, 4).

DAE Tools use the Equation-Oriented approach to process modelling, and the following types of processes can be modelled:

- Lumped and distributed
- Steady-state and dynamic

Problems can be formulated as linear, non-linear, and (partial) differential algebraic systems (of index 1). The most common problems are initial value problems of implicit form. Equations can be ordinary or discontinuous, where discontinuities are automatically handled by the framework. A good overview of discontinuous equations and a procedure for location of equation discontinuities is given by Park & Barton⁽⁵⁾ and in **Sundials IDA** (used in **DAE Tools**).

² Pantelides, C. C., and P. I. Barton, Equation-oriented dynamic simulation current status and future perspectives, *Computers & Chemical Engineering*, vol. 17, no. Supplement 1, pp. 263 - 285, 1993.

³ Barton, P. I., and C. C. Pantelides, **gPROMS** - a Combined Discrete/Continuous Modelling Environment for Chemical Processing Systems, *Simulation Series*, vol. 25, no. 3, pp. 25-34, 1993.

⁴ Barton, P. I., and C. C. Pantelides, Modeling of combined discrete/continuous processes", *AIChE Journal*, vol. 40, pp. 966-979, 1994.

⁵ Park, T., and P. I. Barton, State event location in differential-algebraic models", *ACM Transactions on Modeling and Computer Simulation*, vol. 6, no. 2, New York, NY, USA, ACM, pp. 137-165, 1996.

```
File Edit View Terminal Help
*****
*                                     *
*                                     *
*          @          @          @          @          @          @          *
*          @          @          @          @          @          @          *
*    @@@@@@ @          @          @          @          @          @          *
*    @          @          @          @          @          @          @          *
*    @          @          @          @          @          @          @          *
*    @@@@@@ @@@@@@@ @@@@@@@ @@@@@@@ @@@@@@@ @@@@@@@ @@@@@@@ @@@@@@@ @@@@@@@ *
*                                     *
* DAE Tools is free software: you can redistribute it and/or modify          *
* it under the terms of the GNU General Public License version 3            *
* as published by the Free Software Foundation.                            *
*                                     *
* This program is distributed in the hope that it will be useful,          *
* but WITHOUT ANY WARRANTY; without even the implied warranty of          *
* MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the           *
* GNU General Public License for more details.                             *
*                                     *
* You should have received a copy of the GNU General Public License        *
* along with this program. If not, see <http://www.gnu.org/licenses/>. *
*                                     *
*****
Creating the system...
The system created successfully in: 0 s
Starting initialization of the system...
Initialization completed. Initialization time: 1 s

Starting dynamic simulation...
Integrating from [0] to [50] ...
Integrating from [50] to [100] ...
Integrating from [100] to [150] ...
Integrating from [150] to [200] ...
Integrating from [200] to [250] ...
Integrating from [250] to [300] ...
Integrating from [300] to [350] ...
Integrating from [350] to [400] ...
Integrating from [400] to [450] ...
Integrating from [450] to [500] ...
Integrating from [500] to [550] ...
Integrating from [550] to [600] ...
Integrating from [600] to [650] ...
Integrating from [650] to [700] ...
Integrating from [700] to [750] ...
Integrating from [750] to [800] ...
Integrating from [800] to [850] ...
Integrating from [850] to [900] ...
Integrating from [900] to [950] ...
Integrating from [950] to [1000] ...
Dynamic simulation has finished successfully
Integration time = 14 s
Total run time = 15 s
ciroki@ciroki-desktop:~/Data/dae-tools/trunk/debug$
```

Figure 1.4: **Figure 3.** Shell output from the simulation

1.5.1 Models

In **DAE Tools** models are created by defining its parameters, distribution domains, variables, equations, and ports. Models are developed by deriving a new class from the base model class (`pyCore.daeModel`). The process consists of two steps:

1. Declare all domains, parameters, variables and ports in `__init__()` function (the constructor)
2. Declare equations and state transition networks in `DeclareEquations()` function

Models in **pyDAE** (using python programming language) can be defined by the following statement:

```
class myModel(daeModel):
    def __init__(self, Name, Parent = None, Description = ""):
        daeModel.__init__(self, Name, Parent, Description)
        ... (here go declarations of domains, parameters, variables, ports, etc)

    def DeclareEquations(self):
        ... (here go declarations of equations and state transitions)
```

while in **cDAE** (using c++ programming language):

```
class myModel : public daeModel
{
public:
    myModel(string strName, daeModel* pParent = NULL, string strDescription = "")
    : daeModel(strName, pParent, strDescription)
    {
        ... (here go additional properties of domains, parameters, variables, ports, etc)
    }

    void DeclareEquations(void)
    {
        ... (here go declarations of equations and state transitions)
    }

public:
    ... (here go declarations of domains, parameters, variables, ports, etc)
};
```

More information about developing models can be found in *pyDAE User Guide* and `pyCore.daeModel`. Also, do not forget to have a look on *Tutorials*.

1.5.2 Distribution domains

There are two types of domains in **DAE Tools**: simple arrays and distributed domains (commonly used to distribute variables, parameters and equations in space). The distributed domains can have a uniform (default) or a user specified non-uniform grid. At the moment, only the following finite difference methods can be used to calculate partial derivatives:

- Backward finite difference method (BFD)
- Forward finite difference method (FFD)
- Center finite difference method (CFD)

In **DAE Tools** just anything can be distributed on domains: parameters, variables, equations even models and ports. Obviously it does not have a physical meaning to distribute a model on a domain, However that can be useful for modelling of complex processes where we can create an array of models where each point in a distributed domain have a corresponding model so that a user does not have to take care of number of points in the domain, etc. In addition, domain points values can be obtained as a **NumPy** one-dimensional array; this way **DAE Tools** can be easily used in conjunction with other scientific python libraries **NumPy**, **SciPy**, for instance and many other.

Domains in **pyDAE** can be defined by the following statement:

```
myDomain = daeDomain("myDomain", Parent_Model_or_Port, Description)
```

while in **cDAE**:

```
daeDomain myDomain("myDomain", &Parent_Model_or_Port, Description);
```

More information about domains can be found in *pyDAE User Guide* and `pyCore.daeDomain`. Also, do not forget to have a look on *Tutorials*.

1.5.3 Parameters

There are two types of parameters in **DAE Tools**: ordinary and distributed. Several functions to get a parameter value (function call operator `__call__()`) and array of values (`array()`) have been defined. In addition, distributed parameters have `numpyValues` property to get the values as a numpy multi-dimensional array.

Parameters in **pyDAE** can be defined by the following statement:

```
myParam = daeParameter("myParam", eReal, Parent_Model_or_Port, "Description")
```

while in **cDAE**:

```
daeParameter myParam("myParam", eReal, &Parent_Model_or_Port, "Description");
```

More information about parameters can be found in *pyDAE User Guide* and `pyCore.daeParameter`. Also, do not forget to have a look on *Tutorials*.

1.5.4 Variables

There are two types of variables in **DAE Tools**: ordinary and distributed. Functions to get a variable value (function call operator `__call__()`), a time or a partial derivative (`dt()`, `d()`, or `d2()`) or functions to obtain an array of values, time or partial derivatives (`array()`, `dt_array()`, `d_array()`, or `d2_array()`) have been defined. In addition, distributed variables have `numpyValues` property to get the values as a numpy multi-dimensional array.

Variables in **pyDAE** can be defined by the following statement:

```
myVar = daeVariable("myVar", variableType, Parent_Model_or_Port, "Description")
```

while in **cDAE**:

```
daeVariable myVar("myVar", variableType, &Parent_Model_or_Port, "Description");
```

More information about variables can be found in *pyDAE User Guide* and `pyCore.daeVariable`. Also, do not forget to have a look on *Tutorials*.

1.5.5 Equations

DAE Tools introduce two types of equations: ordinary and distributed. What makes distributed equations special is that an equation expression is valid on every point within the domains that the equations is distributed on. Equations can be distributed on a whole domain, on a part of it or on some of the points in a domain. Equations in **pyDAE** can be defined by the following statement:

```
eq = model.CreateEquation("myEquation", "Description")
```

while in **cDAE**:

```
daeEquation* eq = model.CreateEquation("myEquation", "Description");
```

To define an equation expression (used to calculate its residual and its gradient - which represent a single row in a Jacobian matrix) **DAE Tools** combine the [operator overloading](#) technique for [automatic differentiation](#) (adopted from [ADOL-C](#) library) with the concept of representing equations as **evaluation trees**. Evaluation trees are made of binary or unary nodes, itself representing four basic mathematical operations and frequently used mathematical functions, such as `sin`, `cos`, `tan`, `sqrt`, `pow`, `log`, `ln`, `exp`, `min`, `max`, `floor`, `ceil`, `abs`, `sum`, `product`, These basic mathematical operations and functions are implemented to operate on a **heavily modified ADOL-C** library class `adouble` (which has been extended to contain information about domains/parameters/variables etc). In addition, a new `adouble_array` class has been introduced to apply all above-mentioned operations on arrays of variables. What is different here is that `adouble/adouble_array` classes and mathematical operators/functions work in two modes; they can either **build-up an evaluation tree** or **calculate a value of an expression**. Once built the evaluation trees can be used to calculate equation residuals or derivatives to fill a Jacobian matrix necessary for a Newton-type iteration. A typical evaluation tree is presented in [Figure 4.](#)



Figure 1.5: **Figure 4.** DAE Tools equation evaluation tree

As it has been noted before, domains, parameters, and variables contain functions that return `adouble/adouble_array` objects, which can be used to calculate residuals and derivatives. These functions include functions to get a value of a domain/parameter/variable (function call operator), to get a time or a partial derivative of a variable (functions `dt()`, `d()`, or `d2()`) or functions to obtain an array of values, time or partial derivatives (`array()`, `dt_array()`, `d_array()`, or `d2_array()`). Another useful feature of **DAE Tools** equations is that they can be exported into MathML or Latex format and easily visualized.

For example, the equation F (given in [Figure 4.](#)) can be defined in **pyDAE** by using the following statements:

```
F = model.CreateEquation("F", "F description")
F.Residal = V14.dt() + V1() / (V14() + 2.5) + Sin(3.14 * V3())
```

while in **cDAE** by:

```
daeEquation* F = model.CreateEquation("F", "F description");
F->SetResidal( V14.dt() + V1() / (V14() + 2.5) + sin(3.14 * V3()) );
```

More information about equations can be found in [pyDAE User Guide](#) and `pyCore.daeEquation`. Also, do not forget to have a look on [Tutorials](#).

1.5.6 State Transition Networks (discontinuous equations)

Discontinuous equations are equations that take different forms subject to certain conditions. For example, if we want to model a flow through a pipe we may observe three different flow regimes:

- Laminar: if Reynolds number is less than 2,100
- Transient: if Reynolds number is greater than 2,100 and less than 10,000
- Turbulent: if Reynolds number is greater than 10,000

What we can see is that from any of these three states we can go to any other state. This type of discontinuities is called a **reversible discontinuity** and can be described by the `IF()`, `ELSE_IF()`, `ELSE()` state transient network functions. In **pyDAE** it is given by the following statement:

```
IF(Re() <= 2100)                                # (Laminar flow)
#... (equations go here)

ELSE_IF(Re() > 2100 and Re() < 10000) # (Transient flow)
#... (equations go here)

ELSE()                                           # (Turbulent flow)
#... (equations go here)

END_IF()
```

while in **cDAE** by:

```
IF(Re() <= 2100);                                // (Laminar flow)
//... (equations go here)

ELSE_IF(Re() > 2100 && Re() < 10000); // (Transient flow)
//... (equations go here)

ELSE();                                           // (Turbulent flow)
//... (equations go here)

END_IF();
```

Reversible discontinuities can be **symmetrical** and **non-symmetrical**. The above example is **symmetrical**. However, if we have a CPU and we want to model its power dissipation we may have three operating modes with the following state transitions:

- Normal mode
 - switch to **Power saving mode** if CPU load is below 5%
 - switch to **Fried mode** if the temperature is above 110 degrees
- Power saving mode
 - switch to **Normal mode** if CPU load is above 5%
 - switch to **Fried mode** if the temperature is above 110 degrees
- Fried mode (no escape from here... go to the nearest shop and buy a new one!)

What we can see is that from the **Normal mode** we can either go to the **Power saving mode** or to the **Fried mode**. The same stands for the **Power saving mode**: we can either go to the **Normal mode** or to the **Fried mode**. However, once the temperature exceeds 110 degrees the CPU dies (let's say we heavily overclocked it) and there is no going back. This type of discontinuities is called an **irreversible discontinuity** and can be described by using `STN()`, `STATE()`, `END_STN()` functions while state transitions using `ON_CONDITION()` function. In **pyDAE** this type of state transitions is given by the following statement:

```
STN("CPU")

STATE("Normal")
```

```
#... (equations go here)
ON_CONDITION(CPULoad() < 0.05, switchToState = "PowerSaving")
ON_CONDITION(T() > 110,          switchToState = "Fried")

STATE("PowerSaving")
#... (equations go here)
ON_CONDITION(CPULoad() >= 0.05, switchToState = "Normal")
ON_CONDITION(T() > 110,          switchToState = "Fried")

STATE("Normal")
#... (equations go here)

END_STN()
```

while in **cDAE** by:

```
STN("CPU");

STATE("Normal");
//... (equations go here)
ON_CONDITION(CPULoad() < 0.05, switchToState = "PowerSaving");
ON_CONDITION(T() > 110,          switchToState = "Fried");

STATE("PowerSaving");
//... (equations go here)
ON_CONDITION(CPULoad() >= 0.05, switchToState = "Normal");
ON_CONDITION(T() > 110,          switchToState = "Fried");

STATE("Normal");
//... (equations go here)

END_STN();
```

More information about state transition networks can be found in *pyDAE User Guide* and `pyCore.daeSTN`. Also, do not forget to have a look on *Tutorials*.

1.5.7 Ports

Ports are used to connect two models. Like models, they may contain domains, parameters and variables. For instance, in **pyDAE** ports can be defined by the following statements:

```
class myPort(daePort):
    def __init__(self, Name, Type, Parent = None, Description = ""):
        daePort.__init__(self, Name, Type, Parent, Description)
        #... (here go declarations of domains, parameters and variables)
```

while in **cDAE** by:

```
class myPort : public daePort
{
public:
    myPort(string strName, daePortType eType, daeModel* pParent, string strDescription = "")
        : daePort(strName, eType, pParent, strDescription)
    {
        //... (here go additional properties of domains, parameters and variables)
    }

public:
    //... (here go declarations of domains, parameters and variables)
};
```

More information about ports can be found in *pyDAE User Guide* and `pyCore.daePort`. Also, do not forget to have a look on *Tutorials*.

1.5.8 Event Ports

Event ports are also used to connect two models; however, they allow sending of discrete messages (events) between model instances. Events can be triggered manually or as a result of a state transition in a model. The main difference between event and ordinary ports is that the former allow a discrete communication between model instances while latter allow a continuous exchange of information. A single outlet event port can be connected to unlimited number of inlet event ports. Messages contain a floating point value that can be used by a recipient (these actions are specified in `ON_EVENT()` function); that value might be a simple number or an expression involving model variables/parameters.

More information about event ports can be found in *pyDAE User Guide* and `pyCore.daeEventPort`. Also, do not forget to have a look on *Tutorials*.

1.5.9 Simulation

As it was mentioned before, simulation of a process can be considered as the model run for certain input conditions. To define a simulation in **DAE Tools** the following tasks have to be done:

1. Derive a new simulation class
 - Specify a model to simulate
 - Specify its domains and parameters information
 - Fix the degrees of freedom by assigning the values to certain variables
 - Set the initial conditions for differential variables
 - Set the other variables' information: initial guesses, absolute tolerances, etc
 - Specify the operating procedure. It can be either a simple run for a specified period of time (default) or a complex one where various actions can be taken during the simulation
2. Specify DAE and LA solvers
3. Specify a data reporter and a data receiver, and connect them
4. Set a time horizon, reporting interval, etc
5. Do the initialization of the DAE system
6. Save model report and/or runtime model report (to inspect expanded equations etc)
7. Run the simulation

Simulations in **pyDAE** can be defined by the following construct:

```
class mySimulation(daeSimulation):
    def __init__(self):
        daeSimulation.__init__(self)
        self.m = myModel("myModel", "Description")

    def SetUpParametersAndDomains(self):
        #... (here we set up domains and parameters)

    def SetUpVariables(self):
        #... (here we set up degrees of freedom, initial conditions, initial guesses, etc)

    def Run(self):
        #... (here goes a custom operating procedure, if needed)
```

while in **cDAE** by:


```
class mySimulation : public daeSimulation
{
public:
    mySimulation(void) : m("myModel", "Description")
    {
        SetModel(&m);
    }

public:
    void SetUpParametersAndDomains(void)
    {
        //... (here we set up domains and parameters)
    }

    void SetUpVariables(void)
    {
        //... (here we set up degrees of freedom, initial conditions, initial guesses, etc)
    }

    void Run(void)
    {
        //... (here goes a custom operating procedure, if needed)
    }

public:
    myModel m;
};
```

1.5.10 Running a simulation

Simulations in **pyDAE** can be run in two modes:

1. By using PyQt4 graphical user interface (GUI)
2. From the shell
1. Running a simulation from the GUI (**pyDAE** only)

Here the default log, and data reporter objects will be used, while the user can choose DAE and LA solvers and specify time horizon and reporting interval.

```
# Import modules
import sys
from time import localtime, strftime
from PyQt4 import QtCore, QtGui

# Create QtApplication object
app = QtGui.QApplication(sys.argv)

# Create simulation object
sim = simTutorial()

# Report ALL variables in the model
sim.m.SetReportingOn(True)

# Show the daeSimulator window to choose the other information needed for simulation
simulator = daeSimulator(app, simulation=sim)
simulator.show()

# Execute applications main loop
app.exec_()
```

2. Running a simulation from the shell:

In **pyDAE**:

```
# Import modules
import sys
from time import localtime, strftime

# Create Log, Solver, DataReporter and Simulation object
log          = daeStdOutLog()
solver       = daeIDAS()
datareporter = daeTCPIPDataReporter()
simulation   = simTutorial()

# Set the linear solver (optional)
lasolver     = pyTrilinosAmesos.CreateTrilinosAmesosSolver("Amesos_Superlu")
solver.SetLASolver(eThirdParty, lasolver)

# Report ALL variables in the model
simulation.m.SetReportingOn(True)

# Set the time horizon (1000 seconds) and the reporting interval (10 seconds)
simulation.SetReportingInterval(10)
simulation.SetTimeHorizon(1000)

# Connect data reporter (use the default TCP/IP connection string)
simName = simulation.m.Name + strftime(" [m.%Y %H:%M:%S]", localtime())
if(datareporter.Connect("", simName) == False):
    sys.exit()

# Initialize the simulation
simulation.Initialize(solver, datareporter, log)

# Solve at time = 0 (initialization)
simulation.SolveInitial()

# Run
simulation.Run()
simulation.Finalize()
```

while in **cDAE** by:

```
// Create Log, Solver, DataReporter and Simulation object
boost::scoped_ptr<daeSimulation_t>    pSimulation(new simTutorial());
boost::scoped_ptr<daeDataReporter_t>  pDataReporter(daeCreateTCPIPDataReporter());
boost::scoped_ptr<daeIDASolver>       pDAESolver(daeCreateIDASolver());
boost::scoped_ptr<daeLog_t>           pLog(daeCreateStdOutLog());

// Report ALL variables in the model
pSimulation->GetModel()->SetReportingOn(true);

// Set the time horizon and the reporting interval
pSimulation->SetReportingInterval(10);
pSimulation->SetTimeHorizon(100);

// Connect data reporter
string strName = pSimulation->GetModel()->GetName();
if(!pDataReporter->Connect("", strName))
    return;

// Initialize the simulation
pSimulation->Initialize(pDAESolver.get(), pDataReporter.get(), pLog.get());

// Solve at time = 0 (initialization)
pSimulation->SolveInitial();
```

```
// Run
pSimulation->Run();
pSimulation->Finalize();
```

1.5.11 Optimization

To define an optimization problem it is first necessary to develop a model of the process and to define a simulation (as explained above). Having done these tasks (working model and simulation) the optimization in **DAE Tools** can be defined by specifying the objective function, optimization variables and optimization constraints. It is intentionally chosen to keep simulation and optimization tightly coupled. The optimization problem should be specified in the function `SetUpOptimization()`. The tasks have to be done are:

1. Specify the objective function
 - Objective function is defined by specifying its residual (similarly to specifying an equation residual); Internally the framework will create a new variable (V_obj) and a new equation (F_obj).
2. Specify optimization variables
 - The optimization variables have to be already defined in the model and their values assigned in the simulation; they can be either non-distributed or distributed.
 - Specify a type of optimization variable values. The variables can be **continuous** (floating point values in the given range), **integer** (set of integer values in the given range) or **binary** (integer value: 0 or 1).
 - Specify the starting point (within the range)
3. Specify optimization constraints
 - Two types of constraints exist in DAE Tools: **equality** and **inequality** constraints To define an **equality** constraint its residual and the value has to be specified; To define an **inequality** constraint its residual, the lower and upper bounds have to be specified; Internally the framework will create a new variable (V_constraint[N]) and a new equation (F_constraint[N]) for each defined constraint, where N is the ordinal number of the constraint.
4. Specify NLP/MINLP solver
 - Currently **BONMIN** MINLP solver and **IPOPT** and **NLOPT** solvers are supported (the **BONMIN** solver internally uses **IPOPT** to solve NLP problems)
5. Specify DAE and LA solvers
6. Specify a data reporter and a data receiver, and connect them
7. Set a time horizon, reporting interval, etc
8. Set the options of the (MI)NLP solver
9. Initialize the optimization
10. Save model report and/or runtime model report (to inspect expanded equations etc)
11. Run the optimization

`SetUpOptimization()` function is declared in **pyDAE** as the following:

```
class mySimulation(daeSimulation):
    #... (here we set up a simulation)

    def SetUpOptimization(self):
        #... (here goes a declaration of the obj. function, opt. variables and constraints)
```

while in **cDAE** by:

```
class mySimulation : public daeSimulation
{
    //... (here we set up a simulation)
```

```
void SetUpOptimization(void)
{
    //... (here goes a declaration of the obj. function, opt. variables and constraints)
}
};
```

1.5.12 Running the optimization

Optimizations, like simulations in **pyDAE** can be run in two modes:

1. By using PyQt4 graphical user interface (GUI)
2. From the shell
1. Running an optimization from the GUI (**pyDAE** only)

Here the default log, and data reporter objects will be used, while the user can choose NLP, DAE and LA solvers and specify time horizon and reporting interval:

```
# Import modules
import sys
from time import localtime, strftime
from PyQt4 import QtCore, QtGui

# Create QtApplication object
app = QtGui.QApplication(sys.argv)

# Create simulation object
sim = simTutorial()
nlp = daeBONMIN()

# Report ALL variables in the model
sim.m.SetReportingOn(True)

# Show the daeSimulator window to choose the other information needed for optimization
simulator = daeSimulator(app, simulation=sim, nlpsolver=nlp)
simulator.show()

# Execute applications main loop
app.exec_()
```

2. Running a simulation from the shell:

In **pyDAE**:

```
# Import modules
import sys
from time import localtime, strftime

# Create Log, NLPsSolver, DAEsSolver, DataReporter, Simulation and Optimization objects
log = daePythonStdOutLog()
daesolver = daeIDAS()
nlpsolver = daeBONMIN()
datareporter = daeTCPIPDataReporter()
simulation = simTutorial()
optimization = daeOptimization()

# Enable reporting of all variables
simulation.m.SetReportingOn(True)

# Set the time horizon and the reporting interval
simulation.ReportingInterval = 10
simulation.TimeHorizon = 100
```

```

# Connect data reporter
simName = simulation.m.Name + strftime(" [m.%Y %H:%M:%S]", localtime())
if(datareporter.Connect("", simName) == False):
    sys.exit()

# Initialize the simulation
optimization.Initialize(simulation, nlpsolver, daesolver, datareporter, log)

# Set the MINLP solver options (optional)
#nlpsolver.SetOption('OPTION', VALUE)
#nlpsolver.LoadOptionsFile("")

# Save the model report and the runtime model report
simulation.m.SaveModelReport(simulation.m.Name + ".xml")
simulation.m.SaveRuntimeModelReport(simulation.m.Name + "-rt.xml")

# Run
optimization.Run()
optimization.Finalize()

```

while in **cDAE** by:

```

// Create Log, NLPSolver, DAESolver, DataReporter, Simulation and Optimization objects
boost::scoped_ptr<daeSimulation_t>          pSimulation(new simTutorial);
boost::scoped_ptr<daeDataReporter_t>        pDataReporter(daeCreateTCPIPDataReporter());
boost::scoped_ptr<daeIDASolver_t>           pDAESolver(daeCreateIDASolver());
boost::scoped_ptr<daeLog_t>                 pLog(daeCreateStdOutLog());
boost::scoped_ptr<daeNLPSolver_t>           pNLPSolver(new daeBONMINSolver());
boost::scoped_ptr<daeOptimization_t>        pOptimization(new daeOptimization());

// Report ALL variables in the model
pSimulation->GetModel()->SetReportingOn(true);

// Set the time horizon and the reporting interval
pSimulation->SetReportingInterval(10);
pSimulation->SetTimeHorizon(100);

// Connect data reporter
string strName = pSimulation->GetModel()->GetName();
if(!pDataReporter->Connect("", strName))
    return;

// Initialize the simulation
pOptimization->Initialize(pSimulation.get(),
                        pNLPSolver.get(),
                        pDAESolver.get(),
                        pDataReporter.get(),
                        pLog.get());

// Run
pOptimization.Run();
pOptimization.Finalize();

```

More information about simulation can be found in *pyDAE User Guide* and `daeOptimization`. Also, do not forget to have a look on *Tutorials*.

1.5.13 Processing the results

The simulation/optimization results can be easily plotted by using **DAE Plotter** application. It is possible to choose between 2D and 3D plots. After choosing a desired type, a **Choose variable** (given in *Figure 5.*) dialog appears where a user has to select a variable to plot and specify information about domains - fix some of them

while leaving another free by selecting * from the list (to create a 2D plot you need one domain free, while for a 3D plot you need two free domains).




Figure 1.6: **Figure 5.** Choose variable dialog for a 2D plot

Typical 2D and 3D plots are given in *Figure 6.* and *Figure 7.*




Figure 1.7: **Figure 6.** Example 2D plot (produced by Matplotlib)




Figure 1.8: **Figure 7.** Example 3D plot (produced by Mayavi2)

PYDAE USER GUIDE

PYDAE API REFERENCE

3.1 Module pyCore

3.1.1 Overview

3.1.2 Key modelling concepts

...

Classes

<code>daeVariableType</code>	
<code>daeDomain</code>	
<code>daeParameter</code>	
<code>daeVariable</code>	
<code>daeModel</code>	Base model class.
<code>daeSTN</code>	
<code>daeIF</code>	
<code>daeEquation</code>	
<code>daeState</code>	
<code>daeStateTransition</code>	
<code>daePort</code>	
<code>daeEventPort</code>	
<code>daePortConnection</code>	
<code>daeScalarExternalFunction</code>	
<code>daeVectorExternalFunction</code>	
<code>daeDomainIndex</code>	
<code>daeIndexRange</code>	
<code>daeArrayRange</code>	
<code>daeDEDI</code>	
<code>daeAction</code>	
<code>daeOptimizationVariable</code>	
<code>daeObjectiveFunction</code>	
<code>daeOptimizationConstraint</code>	
<code>daeMeasuredVariable</code>	
<code>daeEquationExecutionInfo</code>	

class `pyCore.daeVariableType`
Bases: `Boost.Python.instance`

```
__init__ ((object)self, (str)name, (object)units, (float)lowerBound, (float)upperBound,  
         (float)initialGuess, (float)absTolerance) → None
```

AbsoluteTolerance

InitialGuess

LowerBound

Name

Units

UpperBound

class `pyCore.daeObject`

Bases: `Boost.Python.instance`

CanonicalName

Description

GetNameRelativeToParentModel ((`daeObject`)self) → str

GetStrippedName ((`daeObject`)self) → str

GetStrippedNameRelativeToParentModel ((`daeObject`)self) → str

ID

Library

Model

Name

Version

class `pyCore.daeDomain`

Bases: `pyCore.daeObject`

```
__init__ ((object)self, (str)name, (daeModel)parentModel, (object)units[, (str)description=''])  
         → None
```

```
__init__ ((object)self, (str)name, (daePort)parentPort, (object)units [, (str)description='']) -> None
```

__getitem__ ((`daeDomain`)self, (int)index) → adouble

__call__ ((`daeDomain`)self, (int)index) → adouble

CreateArray ((`daeDomain`)self, (int)noIntervals) → None

CreateDistributed ((`daeDomain`)self, (`daeDiscretizationMethod`)discretizationMethod,
 (int)discretizationOrder, (int)numberOfIntervals, (float)lowerBound,
 (float)upperBound) → None

DiscretizationMethod

DiscretizationOrder

LowerBound

NumberOfIntervals

NumberOfPoints

Points

Type

Units

UpperBound

numpyPoints

class `pyCore.daeParameter`

Bases: `pyCore.daeObject`

__init__ `((object)self, (str)name, (object)units, (daePort)parentPort[, (str)description='[, (list)domains=[]]) → None`
__init__ `((object)self, (str)name, (object)units, (daeModel)parentModel [, (str)description='[, (list)domains=[]]) → None`

GetValue `((daeParameter)self[, (int)index1[, ...[, (int)index8]]) → float`
 Gets the value of the parameter at the specified domain indexes. How many arguments `index1, ..., index8` are used depends on the number of domains that the parameter is distributed on.

GetQuantity `((daeParameter)self[, (int)index1[, ...[, (int)index8]]) → quantity`
 Gets the value of the parameter at the specified domain indexes as the `quantity` object (with value and units). How many arguments `index1, ..., index8` are used depends on the number of domains that the parameter is distributed on.

SetValue `((daeParameter)self[, (int)index1[, ...[, (int)index8]]], (float)value) → None`
 Sets the value of the parameter at the specified domain indexes. How many arguments `index1, ..., index8` are used depends on the number of domains that the parameter is distributed on.

SetValue `((daeParameter)self[, (int)index1[, ...[, (int)index8]]], (quantity)value) → None`
 Sets the value of the parameter at the specified domain indexes. How many arguments `index1, ..., index8` are used depends on the number of domains that the parameter is distributed on.

SetValues `((daeParameter)self, (float)values) → None`
 Sets all values of the parameter.

SetValues `((daeParameter)self, (quantity)values) → None`
 Sets all values of the parameter.

array `((daeParameter)self[, (object)index1[, ...[, (object)index8]]) → adouble_array`
 Gets the array of parameter's values at the specified domain indexes (used to build equation residuals only). How many arguments `index1, ..., index8` are used depends on the number of domains that the parameter is distributed on. Argument types can be one of the following:

- `daeIndexRange` object
- plain integer (to select a single index from a domain)
- python `list` (to select a list of indexes from a domain)
- python `slice` (to select a range of indexes from a domain: `start_index, end_index, step`)
- character `'*'` (to select all points from a domain)
- integer `-1` (to select all points from a domain)
- empty python list `[]` (to select all points from a domain)

__call__ `((daeParameter)self[, (int)index1[, ...[, (int)index8]]) → adouble`
 Gets the value of the parameter at the specified domain indexes (used to build equation residuals only). How many arguments `index1, ..., index8` are used depends on the number of domains that the parameter is distributed on.

DistributeOnDomain `((daeParameter)self, (daeDomain)domain) → None`

Domains

GetDomainsIndexesMap `((daeParameter)self, (int)indexBase) → dict`

NumberOfPoints

ReportingOn

Units

numpyValues

class `pyCore.daeVariable`

Bases: `pyCore.daeObject`

__init__ `((object)self, (str)name, (daeVariableType)variableType, (daeModel)parentPort[, (str)description='[, (list)domains=[[]]]] → None`
__init__ `((object)self, (str)name, (daeVariableType)variableType, (daePort)parentModel [, (str)description='[, (list)domains=[[]]]] → None`

GetValue `((daeVariable)self[, (int)index1[, ...[, (int)index8]]]) → float`
Gets the value of the variable at the specified domain indexes. How many arguments `index1, ..., index8` are used depends on the number of domains that the variable is distributed on.

GetQuantity `((daeVariable)self[, (int)index1[, ...[, (int)index8]]]) → quantity`
Gets the value of the variable at the specified domain indexes as the `quantity` object (with value and units). How many arguments `index1, ..., index8` are used depends on the number of domains that the variable is distributed on.

SetValue `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (float)value) → None`
Sets the value of the variable at the specified domain indexes. How many arguments `index1, ..., index8` are used depends on the number of domains that the variable is distributed on.

SetValue `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (quantity)value) → None`
Sets the value of the variable at the specified domain indexes. How many arguments `index1, ..., index8` are used depends on the number of domains that the variable is distributed on.

SetValues `((daeVariable)self, (float)values) → None`
Sets all values of the variable.

SetValues `((daeVariable)self, (quantity)values) → None`
Sets all values of the variable.

AssignValue `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (float)value) → None`

AssignValue `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (quantity)value) → None`

AssignValues `((daeVariable)self, (float)values) → None`

AssignValues `((daeVariable)self, (quantity)values) → None`

ReAssignValue `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (float)value) → None`

ReAssignValue `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (quantity)value) → None`

ReAssignValues `((daeVariable)self, (float)values) → None`

ReAssignValues `((daeVariable)self, (quantity)values) → None`

SetInitialCondition `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (float)initialCondition) → None`

SetInitialCondition `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (quantity)initialCondition) → None`

SetInitialConditions `((daeVariable)self, (float)initialConditions) → None`

SetInitialConditions `((daeVariable)self, (quantity)initialConditions) → None`

ReSetInitialCondition `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (float)initialCondition) → None`

ReSetInitialCondition `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (quantity)initialCondition) → None`

ReSetInitialConditions `((daeVariable)self, (float)initialConditions) → None`

ReSetInitialConditions `((daeVariable)self, (quantity)initialConditions) → None`

SetInitialGuess `((daeVariable)self[, (int)index1[, ...[, (int)index8]]], (float)initialGuess) → None`

SetInitialGuess ((*daeVariable*)self[, (int)index1[, ...[, (int)index8]]], (*quantity*)initialGuess) → None

SetInitialGuesses ((*daeVariable*)self, (float)initialGuesses) → None

SetInitialGuesses ((*daeVariable*)self, (*quantity*)initialGuesses) → None

SetAbsoluteTolerances ((*daeVariable*)self, (float)tolerances) → None

array ((*daeVariable*)self[, (object)index1[, ...[, (object)index8]]]) → adouble_array
Gets the array of variable's values at the specified domain indexes (used to build equation residuals only). How many arguments index1, ..., index8 are used depends on the number of domains that the variable is distributed on. Argument types are the same as those described in `pyCore.daeParameter.array()`

d_array ((*daeVariable*)self[, (object)index1[, ...[, (object)index8]]]) → adouble_array
Gets the array of partial derivatives at the specified domain indexes (used to build equation residuals only). How many arguments index1, ..., index8 are used depends on the number of domains that the variable is distributed on. Argument types are the same as those described in `pyCore.daeParameter.array()`.

d2_array ((*daeVariable*)self[, (object)index1[, ...[, (object)index8]]]) → adouble_array
Gets the array of partial derivatives of the second order at the specified domain indexes (used to build equation residuals only). How many arguments index1, ..., index8 are used depends on the number of domains that the variable is distributed on. Argument types are the same as those described in `pyCore.daeParameter.array()`.

dt_array ((*daeVariable*)self[, (object)index1[, ...[, (object)index8]]]) → adouble_array
Gets the array of time derivatives at the specified domain indexes (used to build equation residuals only). How many arguments index1, ..., index8 are used depends on the number of domains that the variable is distributed on. Argument types are the same as those described in `pyCore.daeParameter.array()`.

__call__ ((*daeVariable*)self[, (int)index1[, ...[, (int)index8]]]) → adouble
Gets the value of the variable at the specified domain indexes (used to build equation residuals only). How many arguments index1, ..., index8 are used depends on the number of domains that the variable is distributed on.

d ((*daeVariable*)self, (*daeDomain*)domain[, (int)index1[, ...[, (int)index8]]]) → adouble
Gets the partial derivative of the variable at the specified domain indexes (used to build equation residuals only). How many arguments index1, ..., index8 are used depends on the number of domains that the variable is distributed on.

d2 ((*daeVariable*)self, (*daeDomain*)domain[, (int)index1[, ...[, (int)index8]]]) → adouble
Gets the partial derivative of second order of the variable at the specified domain indexes (used to build equation residuals only). How many arguments index1, ..., index8 are used depends on the number of domains that the variable is distributed on.

dt ((*daeVariable*)self[, (int)index1[, ...[, (int)index8]]]) → adouble
Gets the time derivative of the variable at the specified domain indexes (used to build equation residuals only). How many arguments index1, ..., index8 are used depends on the number of domains that the variable is distributed on.

DistributeOnDomain ((*daeVariable*)self, (*daeDomain*)domain) → None

Domains

GetDomainsIndexesMap ((*daeVariable*)self, (int)indexBase) → dict

NumberOfPoints

OverallIndex

ReportingOn

VariableType

numpyIDs

npvValues**class** `pyCore.daeModel`Bases: `pyCore.daeObject`

Base model class.

__init__ `((object)self, (str)name[, (daeModel)parent=0[, (str)description='']]) → None :`
Constructor...**ComponentArrays**

A list of arrays of components in the model.

Components

A list of components in the model.

ConnectEventPorts `((daeModel)self, (daeEventPort)portFrom, (daeEventPort)portTo) → None`:
Connects two event ports.**ConnectPorts** `((daeModel)self, (daePort)portFrom, (daePort)portTo) → None :`

Connects two ports.

CreateEquation `((daeModel)self, (str)name[, (str)description='',[(float)scaling=1.0]]) →``daeEquation :`

Creates a new equation. Used to add equations to models or states in state transition networks

DeclareEquations `((daeModel)self) → None :`User-defined function where all model equations and state transition networks are declared.
Must be always implemented in derived classes.

DeclareEquations((daeModel)self) -> None

Domains

A list of domains in the model.

ELSE `((daeModel)self) → None :`

Adds the last state to a reversible state transition network.

ELSE_IF `((daeModel)self, (daeCondition)condition[, (float)eventTolerance=0.0]) → None :`

Adds a new state to a reversible state transition network.

END_IF `((daeModel)self) → None :`

Finalises a reversible state transition network.

END_STN `((daeModel)self) → None :`

.

Equations

A list of equations in the model.

EventPorts

A list of event ports in the model.

Export `((daeModel)self, (str)content, (daeModelLanguage)language, (daeModelExportContext)modelExportContext) → None :`

.

ExportObjects `((daeModel)self, (list)objects, (daeModelLanguage)language) → str :`

.

IF `((daeModel)self, (daeCondition)condition[, (float)eventTolerance=0.0]) → None :`

Creates a reversible state transition network and adds the first state.

InitialConditionMode

A mode used to calculate initial conditions ...

IsModelDynamic

Boolean flag that determines whether the model is dynamic or steady-state.

ModelType

A type of the model ().

ON_CONDITION ((*daeModel*)self, (*daeCondition*)condition[, (*str*)switchTo='',
(*list*)setVariableValues=[], (*list*)triggerEvents=[],
(*list*)userDefinedActions=[], (*float*)eventTolerance=0.0])] → None

. :

ON_EVENT ((*daeModel*)self, (*daeEventPort*)eventPort[, (*list*)switchToStates=[][,
(*list*)setVariableValues=[], (*list*)triggerEvents=[], (*list*)userDefinedActions=[]]
)] → None :

. :

OnEventActions

A list of OnEvent actions in the model.

Parameters

A list of parameters in the model.

PortArrays

A list of arrays of ports in the model.

PortConnections

A list of port connections in the model.

Ports

A list of ports in the model.

STATE ((*daeModel*)self, (*str*)stateName) → daeState :

.

STN ((*daeModel*)self, (*str*)stnName) → daeSTN :

.

STNs

A list of state transition networks in the model.

SWITCH_TO ((*daeModel*)self, (*str*)targetState, (*daeCondition*)condition[, (*float*)eventTolerance=0.0
]) → None :

.

SaveModelReport ((*daeModel*)self, (*str*)xmlFilename) → None :

.

SaveRuntimeModelReport ((*daeModel*)self, (*str*)xmlFilename) → None :

.

SetReportingOn ((*daeModel*)self, (*bool*)reportingOn) → None :

Switches the reporting of the model variables/parameters to the data reporter on or off.

Variables

A list of variables in the model.

class pyCore.daeSTN

Bases: pyCore.daeObject

ActiveState**States**

class pyCore.daeIF

Bases: pyCore.daeSTN

class pyCore.daeEquation

Bases: pyCore.daeObject

DistributeOnDomain ((*daeEquation*)self, (*daeDomain*)domain, (*daeDomain*-
Bounds)domainBounds) → daeDEDI

DistributeOnDomain((*daeEquation*)self, (*daeDomain*)domain, (*list*)domainIndexes) -> daeDEDI

```
DistributedEquationDomainInfos
EquationExecutionInfos
EquationType
Residual
Scaling

class pyCore.daeState
    Bases: pyCore.daeObject

    Equations
    NestedSTNs
    StateTransitions

class pyCore.daeStateTransition
    Bases: pyCore.daeObject

    Actions
    Condition

class pyCore.daePort
    Bases: pyCore.daeObject

    __init__ ((object)self, (str)name, (daePortType)type, (daeModel)parentModel[,
        (str)description='']) → None

    Domains
    Export ((daePort)self, (str)content, (daeModelLanguage)language, (daeModelExportCon-
        text)context) → None
    Parameters
    SetReportingOn ((daePort)self, (bool)reportingOn) → None
    Type
    Variables

class pyCore.daeEventPort
    Bases: pyCore.daeObject

    __init__ ((object)self, (str)name, (daePortType)type, (daeModel)parentModel[,
        (str)description='']) → None

    EventData
    Events
    ReceiveEvent ((daeEventPort)self, (float)data) → None
    RecordEvents
    SendEvent ((daeEventPort)self, (float)data) → None
    Type

class pyCore.daePortConnection
    Bases: pyCore.daeObject

    Equations
    PortFrom
    PortTo

class pyCore.daeScalarExternalFunction
    Bases: Boost.Python.instance
```

__init__ ((*object*)self, (*str*)name, (*daeModel*)parentModel, (*object*)units, (*dict*)arguments) → None

__call__ ((*daeScalarExternalFunction*)self) → adouble

Calculate ((*daeScalarExternalFunction*)arg1, (*tuple*)self, (*dict*)values) → object
Calculate((*daeScalarExternalFunction*)arg1, (*tuple*)arg2, (*dict*)arg3) -> None

Name

class pyCore.**daeVectorExternalFunction**

Bases: Boost.Python.instance

__init__ ((*object*)self, (*str*)name, (*daeModel*)parentModel, (*object*)units, (*int*)numberOfXXX, (*dict*)arguments) → None

__call__ ((*daeVectorExternalFunction*)self) → adouble_array

Calculate ((*daeVectorExternalFunction*)arg1, (*tuple*)self, (*dict*)values) → list
Calculate((*daeVectorExternalFunction*)arg1, (*tuple*)arg2, (*dict*)arg3) -> None

Name

class pyCore.**daeDomainIndex**

Bases: Boost.Python.instance

__init__ ((*object*)self, (*int*)index) → None

__init__((*object*)self, (*daeDEDI*)dedi) -> None

__init__((*object*)self, (*daeDEDI*)dedi, (*int*)increment) -> None

__init__((*object*)self, (*daeDomainIndex*)domainIndex) -> None

DEDI

Increment

Index

Type

class pyCore.**daeIndexRange**

Bases: Boost.Python.instance

__init__ ((*object*)self, (*daeDomain*)domain) → None

__init__((*object*)arg1, (*daeDomain*)arg2, (*list*)arg3) -> object

__init__((*object*)self, (*daeDomain*)domain, (*int*)startIndex, (*int*)endIndex, (*int*)step) -> None

Domain

EndIndex

NoPoints

StartIndex

Step

Type

class pyCore.**daeArrayRange**

Bases: Boost.Python.instance

__init__ ((*object*)self, (*daeDomainIndex*)domainIndex) → None

__init__((*object*)self, (*daeIndexRange*)indexRange) -> None

DomainIndex

NoPoints

Range

Type

```
class pyCore.daeDEDI
    Bases: pyCore.daeObject
    __init__()
        Raises an exception This class cannot be instantiated from Python
    __call__ ((daeDEDI)self) → adouble
    Domain
    DomainBounds
    DomainPoints

class pyCore.daeAction
    Bases: pyCore.daeObject
    __init__ ((object)self) → None
    Execute ((daeAction)self) → None
        Execute( (daeAction)arg1) -> None
    RuntimeNode
    STN
    SendEventPort
    SetupNode
    StateTo
    Type
    VariableWrapper

class pyCore.daeOptimizationVariable
    Bases: pyCore.daeOptimizationVariable_t
    __init__ ((object)self) → None
    LowerBound
    Name
    StartingPoint
    Type
    UpperBound
    Value

class pyCore.daeObjectiveFunction
    Bases: pyCore.daeObjectiveFunction_t
    __init__ ((object)self) → None
    Gradients
    Name
    Residual
    Value

class pyCore.daeOptimizationConstraint
    Bases: pyCore.daeOptimizationConstraint_t
    __init__ ((object)self) → None
    Gradients
    Name
```

Residual**Type****Value**

```
class pyCore.daeMeasuredVariable
    Bases: pyCore.daeMeasuredVariable_t
```

```
    __init__ ((object)self) → None
```

Gradients**Name****Residual****Value**

```
class pyCore.daeEquationExecutionInfo
    Bases: Boost.Python.instance
```

EquationType**Node****VariableIndexes**

Functions

d
dt
Time
Constant
Array
Sum
Product
Integral
Average

```
pyCore.d ((adouble)arg1, (daeDomain)ad) → adouble
```

```
pyCore.dt ((adouble)ad) → adouble
```

```
pyCore.Time () → adouble
```

```
pyCore.Constant ((float)value) → adouble
    Constant( (object)value) -> adouble
```

```
pyCore.Array ((list)values) → adouble_array
```

```
pyCore.Sum ((adouble_array)adarray) → adouble
```

```
pyCore.Product ((adouble_array)adarray) → adouble
```

```
pyCore.Integral ((adouble_array)adarray) → adouble
```

```
pyCore.Average ((adouble_array)adarray) → adouble
```

3.1.3 Logging support

daeLog_t
daeBaseLog

Continued on next page

Table 3.3 – continued from previous page

<code>daeFileLog</code>
<code>daeStdOutLog</code>
<code>daeTCPIPLog</code>
<code>daeTCPIPLogServer</code>

```
class pyCore.daeLog_t
```

```
    Bases: Boost.Python.instance
```

```
    __init__()
```

```
        Raises an exception This class cannot be instantiated from Python
```

```
    DecreaseIndent ((daeLog_t)self, (int)offset) → None
```

```
        DecreaseIndent( (daeLog_t)arg1, (int)arg2) -> None
```

```
    ETA
```

```
    Enabled
```

```
    IncreaseIndent ((daeLog_t)self, (int)offset) → None
```

```
        IncreaseIndent( (daeLog_t)arg1, (int)arg2) -> None
```

```
    Indent
```

```
    IndentString
```

```
    JoinMessages ((daeLog_t)self[, (str)delimiter='n']) → str
```

```
        JoinMessages( (daeLog_t)arg1, (str)arg2) -> None
```

```
    Message ((daeLog_t)self, (str)message, (int)severity) → None
```

```
        Message( (daeLog_t)arg1, (str)arg2, (int)arg3) -> None
```

```
    PercentageDone
```

```
    PrintProgress
```

```
    Progress
```

```
class pyCore.daeBaseLog
```

```
    Bases: pyCore.daeLog_t
```

```
    __init__ ((object)self) → None
```

```
    DecreaseIndent ((daeBaseLog)self, (int)offset) → None
```

```
    IncreaseIndent ((daeBaseLog)self, (int)offset) → None
```

```
    Message ((daeBaseLog)self, (str)message, (int)severity) → None
```

```
        Message( (daeBaseLog)self, (str)message, (int)severity) -> None
```

```
    SetProgress ((daeBaseLog)self, (float)progress) → None
```

```
        SetProgress( (daeBaseLog)self, (float)progress) -> None
```

```
class pyCore.daeFileLog
```

```
    Bases: pyCore.daeBaseLog
```

```
    __init__ ((object)self, (str)filename) → None
```

```
    Message ((daeFileLog)self, (str)message, (int)severity) → None
```

```
        Message( (daeFileLog)self, (str)message, (int)severity) -> None
```

```
class pyCore.daeStdOutLog
```

```
    Bases: pyCore.daeBaseLog
```

```
    __init__ ((object)self) → None
```

```
    Message ((daeStdOutLog)self, (str)message, (int)severity) → None
```

```
        Message( (daeStdOutLog)self, (str)message, (int)severity) -> None
```

```
class pyCore.daeTCPIPLog
    Bases: pyCore.daeBaseLog

    __init__ ((object)self, (str)tcpipAddress, (int)port) → None

    Message ((daeTCPIPLog)self, (str)message, (int)severity) → None
        Message( (daeTCPIPLog)self, (str)message, (int)severity) -> None
```

```
class pyCore.daeTCPIPLogServer
    Bases: Boost.Python.instance

    __init__ ((object)self, (int)port) → None

    MessageReceived ((daeTCPIPLogServer)self, (str)message) → None
        MessageReceived( (daeTCPIPLogServer)arg1, (str)arg2) -> None
```

3.1.4 Autodifferentiation and equation evaluation tree support

Classes

<code>adouble</code>	Class <code>adouble</code> operates on values/derivatives of domains, parameters and variables.
<code>adouble_array</code>	Class <code>adouble_array</code> operates on arrays of values/derivatives of domains, parameters and variables.
<code>daeCondition</code>	

```
class pyCore.adouble
    Bases: Boost.Python.instance

    Class adouble operates on values/derivatives of domains, parameters and variables. It supports basic mathematical operators (+, -, , /, *), comparison operators (<, <=, >, >=, ==, !=), and logical operators (and, or, not). Operands can be instances of adouble or float values.
```

Derivative

Derivative

GatherInfo

Internally used by the framework.

Node

Contains the equation evaluation node.

Value

Value

```
class pyCore.adouble_array
    Bases: Boost.Python.instance

    Class adouble_array operates on arrays of values/derivatives of domains, parameters and variables. It supports basic mathematical operators (+, -, , /, *). Operands can be instances of adouble_array, adouble or float values.
```

```
__len__ ((adouble_array)self) → int :
    Returns the size of the adouble_array object.
```

```
__getitem__ ((adouble_array)self, (int)index) → adouble :
    Gets an adouble object at the specified index.
```

```
__setitem__ ((adouble_array)self, (int)index, (adouble)value) → None :
    Sets an adouble object at the specified index.
```

GatherInfo

Used internally by the framework.

Node

Contains the equation evaluation node.

Resize ((*adouble_array*)*self*, (*int*)*newSize*) → None :

Resizes the *adouble_array* object to the new size.

items ((*object*)*arg1*) → object :

Returns an iterator over *adouble* items in *adouble_array* object.

class `pyCore.daeCondition`

Bases: `Boost.Python.instance`

__or__ ((*daeCondition*)*self*, (*daeCondition*)*right*) → *daeCondition*

Logical operator or

__and__ ((*daeCondition*)*self*, (*daeCondition*)*right*) → *daeCondition*

Logical operator and

EventTolerance

Expressions

RuntimeNode

SetupNode

Mathematical functions

<code>Exp</code>	<code>Exp((adouble_array)arg1)-> adouble_array</code>
<code>Log</code>	<code>Log((adouble_array)arg1)-> adouble_array</code>
<code>Log10</code>	<code>Log10((adouble_array)arg1)-> adouble_array</code>
<code>Sqrt</code>	<code>Sqrt((adouble_array)arg1)-> adouble_array</code>
<code>Sin</code>	<code>Sin((adouble_array)arg1)-> adouble_array</code>
<code>Cos</code>	<code>Cos((adouble_array)arg1)-> adouble_array</code>
<code>Tan</code>	<code>Tan((adouble_array)arg1)-> adouble_array</code>
<code>ASin</code>	<code>ASin((adouble_array)arg1)-> adouble_array</code>
<code>ACos</code>	<code>ACos((adouble_array)arg1)-> adouble_array</code>
<code>ATan</code>	<code>ATan((adouble_array)arg1)-> adouble_array</code>
<code>Sinh</code>	
<code>Cosh</code>	
<code>Tanh</code>	
<code>ASinh</code>	
<code>ACosh</code>	
<code>ATanh</code>	
<code>ATan2</code>	
<code>Ceil</code>	<code>Ceil((adouble_array)arg1)-> adouble_array</code>
<code>Floor</code>	<code>Floor((adouble_array)arg1)-> adouble_array</code>
<code>Pow</code>	<code>Pow((adouble)arg1, (adouble)arg2)-> adouble</code>
<code>Abs</code>	<code>Abs((adouble_array)arg1)-> adouble_array</code>
<code>Min</code>	<code>Min((float)arg1, (adouble)arg2)-> adouble</code>
<code>Max</code>	<code>Max((float)arg1, (adouble)arg2)-> adouble</code>

`pyCore.Exp` ((*adouble*)*arg1*) → *adouble*

`Exp((adouble_array)arg1)-> adouble_array`

`pyCore.Log` ((*adouble*)*arg1*) → *adouble*

`Log((adouble_array)arg1)-> adouble_array`

`pyCore.Log10` ((*adouble*)*arg1*) → *adouble*

`Log10((adouble_array)arg1)-> adouble_array`

`pyCore.Sqrt` ((*adouble*)*arg1*) → *adouble*

`Sqrt((adouble_array)arg1)-> adouble_array`


```
pyCore.Sin ((adouble)arg1) → adouble
    Sin( (adouble_array)arg1) -> adouble_array

pyCore.Cos ((adouble)arg1) → adouble
    Cos( (adouble_array)arg1) -> adouble_array

pyCore.Tan ((adouble)arg1) → adouble
    Tan( (adouble_array)arg1) -> adouble_array

pyCore.ASin ((adouble)arg1) → adouble
    ASin( (adouble_array)arg1) -> adouble_array

pyCore.ACos ((adouble)arg1) → adouble
    ACos( (adouble_array)arg1) -> adouble_array

pyCore.ATan ((adouble)arg1) → adouble
    ATan( (adouble_array)arg1) -> adouble_array

pyCore.Sinh ((adouble)arg1) → adouble

pyCore.Cosh ((adouble)arg1) → adouble

pyCore.Tanh ((adouble)arg1) → adouble

pyCore.ASinh ((adouble)arg1) → adouble

pyCore.ACosh ((adouble)arg1) → adouble

pyCore.ATanh ((adouble)arg1) → adouble

pyCore.ATan2 ((adouble)arg1, (adouble)arg2) → adouble

pyCore.Ceil ((adouble)arg1) → adouble
    Ceil( (adouble_array)arg1) -> adouble_array

pyCore.Floor ((adouble)arg1) → adouble
    Floor( (adouble_array)arg1) -> adouble_array

pyCore.Pow ((adouble)arg1, (float)arg2) → adouble
    Pow( (adouble)arg1, (adouble)arg2) -> adouble
    Pow( (float)arg1, (adouble)arg2) -> adouble

pyCore.Abs ((adouble)arg1) → adouble
    Abs( (adouble_array)arg1) -> adouble_array

pyCore.Min ((adouble)arg1, (adouble)arg2) → adouble
    Min( (float)arg1, (adouble)arg2) -> adouble
    Min( (adouble)arg1, (float)arg2) -> adouble
    Min( (adouble_array)adarray) -> adouble

pyCore.Max ((adouble)arg1, (adouble)arg2) → adouble
    Max( (float)arg1, (adouble)arg2) -> adouble
    Max( (adouble)arg1, (float)arg2) -> adouble
    Max( (adouble_array)adarray) -> adouble
```

3.1.5 Auxiliary classes

`daeVariableWrapper`

`daeConfig`

```
class pyCore.daeVariableWrapper
    Bases: Boost.Python.instance
```

```
__init__ ((object)self, (daeVariable)variable[, (str)name='']) → None
__init__ ( (object)self, (adouble)ad [, (str)name='']) -> None
```

DomainIndexes

Name

OverallIndex

Value

Variable

VariableType

class `pyCore.daeConfig`

Bases: `Boost.Python.instance`

```
__contains__ ((daeConfig)self, (object)propertyPath) → object
__getitem__ ((daeConfig)self, (object)propertyPath) → object
__setitem__ ((daeConfig)self, (object)propertyPath, (object)value) → None
GetBoolean ((daeConfig)self, (str)propertyPath[, (bool)defaultValue]) → bool
GetFloat ((daeConfig)self, (str)propertyPath[, (float)defaultValue]) → float
GetInteger ((daeConfig)self, (str)propertyPath[, (int)defaultValue]) → int
GetString ((daeConfig)self, (str)propertyPath[, (str)defaultValue]) → str
Reload ((daeConfig)self) → None
SetBoolean ((daeConfig)self, (str)propertyPath, (bool)value) → None
SetFloat ((daeConfig)self, (str)propertyPath, (float)value) → None
SetInteger ((daeConfig)self, (str)propertyPath, (int)value) → None
SetString ((daeConfig)self, (str)propertyPath, (str)value) → None
has_key ((daeConfig)self, (object)propertyPath) → object
```

3.1.6 Auxiliary functions

<code>daeGetConfig</code>
<code>daeVersion</code>
<code>daeVersionMajor</code>
<code>daeVersionMinor</code>
<code>daeVersionBuild</code>

```
pyCore.daeGetConfig() → object
pyCore.daeVersion ([ (bool)includeBuild=False ]) → str
pyCore.daeVersionMajor() → int
pyCore.daeVersionMinor() → int
pyCore.daeVersionBuild() → int
```

3.1.7 Enumerations

<code>daeDomainType</code>

Continued on next page

Table 3.8 – continued from previous page

<code>daeParameterType</code>
<code>daePortType</code>
<code>daeDiscretizationMethod</code>
<code>daeDomainBounds</code>
<code>daeInitialConditionMode</code>
<code>daeDomainIndexType</code>
<code>daeRangeType</code>
<code>daeIndexRangeType</code>
<code>daeOptimizationVariableType</code>
<code>daeModelLanguage</code>
<code>daeConstraintType</code>
<code>daeUnaryFunctions</code>
<code>daeBinaryFunctions</code>
<code>daeSpecialUnaryFunctions</code>
<code>daeLogicalUnaryOperator</code>
<code>daeLogicalBinaryOperator</code>
<code>daeConditionType</code>
<code>daeActionType</code>
<code>daeEquationType</code>
<code>daeModelType</code>

```
class pyCore.daeDomainType
```

```
Bases: Boost.Python.enum
```

```
eArray = pyCore.daeDomainType.eArray
```

```
eDTUnknown = pyCore.daeDomainType.eDTUnknown
```

```
eDistributed = pyCore.daeDomainType.eDistributed
```

```
class pyCore.daeParameterType
```

```
Bases: Boost.Python.enum
```

```
eBool = pyCore.daeParameterType.eBool
```

```
eInteger = pyCore.daeParameterType.eInteger
```

```
ePTUnknown = pyCore.daeParameterType.ePTUnknown
```

```
eReal = pyCore.daeParameterType.eReal
```

```
class pyCore.daePortType
```

```
Bases: Boost.Python.enum
```

```
eInletPort = pyCore.daePortType.eInletPort
```

```
eOutletPort = pyCore.daePortType.eOutletPort
```

```
eUnknownPort = pyCore.daePortType.eUnknownPort
```

```
class pyCore.daeDiscretizationMethod
```

```
Bases: Boost.Python.enum
```

```
eBFDM = pyCore.daeDiscretizationMethod.eBFDM
```

```
eCFDM = pyCore.daeDiscretizationMethod.eCFDM
```

```
eCustomDM = pyCore.daeDiscretizationMethod.eCustomDM
```

```
eDMUnknown = pyCore.daeDiscretizationMethod.eDMUnknown
```

```
eFFDM = pyCore.daeDiscretizationMethod.eFFDM
```

```
class pyCore.daeDomainBounds
```

```
Bases: Boost.Python.enum
```

```
eClosedClosed = pyCore.daeDomainBounds.eClosedClosed
eClosedOpen = pyCore.daeDomainBounds.eClosedOpen
eDBUnknown = pyCore.daeDomainBounds.eDBUnknown
eLowerBound = pyCore.daeDomainBounds.eLowerBound
eOpenClosed = pyCore.daeDomainBounds.eOpenClosed
eOpenOpen = pyCore.daeDomainBounds.eOpenOpen
eUpperBound = pyCore.daeDomainBounds.eUpperBound

class pyCore.daeInitialConditionMode
    Bases: Boost.Python.enum

    eAlgebraicValuesProvided = pyCore.daeInitialConditionMode.eAlgebraicValuesProvided
    eDifferentialValuesProvided = pyCore.daeInitialConditionMode.eDifferentialValuesProvided
    eICTUnknown = pyCore.daeInitialConditionMode.eICTUnknown
    eQuasySteadyState = pyCore.daeInitialConditionMode.eQuasySteadyState

class pyCore.daeDomainIndexType
    Bases: Boost.Python.enum

    eConstantIndex = pyCore.daeDomainIndexType.eConstantIndex
    eDITUnknown = pyCore.daeDomainIndexType.eDITUnknown
    eDomainIterator = pyCore.daeDomainIndexType.eDomainIterator
    eIncrementedDomainIterator = pyCore.daeDomainIndexType.eIncrementedDomainIterator

class pyCore.daeRangeType
    Bases: Boost.Python.enum

    eRaTUnknown = pyCore.daeRangeType.eRaTUnknown
    eRange = pyCore.daeRangeType.eRange
    eRangeDomainIndex = pyCore.daeRangeType.eRangeDomainIndex

class pyCore.daeIndexRangeType
    Bases: Boost.Python.enum

    eAllPointsInDomain = pyCore.daeIndexRangeType.eAllPointsInDomain
    eCustomRange = pyCore.daeIndexRangeType.eCustomRange
    eIRTUnknown = pyCore.daeIndexRangeType.eIRTUnknown
    eRangeOfIndexes = pyCore.daeIndexRangeType.eRangeOfIndexes

class pyCore.daeOptimizationVariableType
    Bases: Boost.Python.enum

    eBinaryVariable = pyCore.daeOptimizationVariableType.eBinaryVariable
    eContinuousVariable = pyCore.daeOptimizationVariableType.eContinuousVariable
    eIntegerVariable = pyCore.daeOptimizationVariableType.eIntegerVariable

class pyCore.daeModelLanguage
    Bases: Boost.Python.enum

    eCDAE = pyCore.daeModelLanguage.eCDAE
    eMLNone = pyCore.daeModelLanguage.eMLNone
    ePYDAE = pyCore.daeModelLanguage.ePYDAE
```

```
class pyCore.daeConstraintType
    Bases: Boost.Python.enum

    eEqualityConstraint = pyCore.daeConstraintType.eEqualityConstraint
    eInequalityConstraint = pyCore.daeConstraintType.eInequalityConstraint

class pyCore.daeUnaryFunctions
    Bases: Boost.Python.enum

    eAbs = pyCore.daeUnaryFunctions.eAbs
    eArcCos = pyCore.daeUnaryFunctions.eArcCos
    eArcSin = pyCore.daeUnaryFunctions.eArcSin
    eArcTan = pyCore.daeUnaryFunctions.eArcTan
    eCeil = pyCore.daeUnaryFunctions.eCeil
    eCos = pyCore.daeUnaryFunctions.eCos
    eExp = pyCore.daeUnaryFunctions.eExp
    eFloor = pyCore.daeUnaryFunctions.eFloor
    eLn = pyCore.daeUnaryFunctions.eLn
    eLog = pyCore.daeUnaryFunctions.eLog
    eSign = pyCore.daeUnaryFunctions.eSign
    eSin = pyCore.daeUnaryFunctions.eSin
    eSqrt = pyCore.daeUnaryFunctions.eSqrt
    eTan = pyCore.daeUnaryFunctions.eTan
    eUfUnknown = pyCore.daeUnaryFunctions.eUfUnknown

class pyCore.daeBinaryFunctions
    Bases: Boost.Python.enum

    eBfUnknown = pyCore.daeBinaryFunctions.eBfUnknown
    eDivide = pyCore.daeBinaryFunctions.eDivide
    eMax = pyCore.daeBinaryFunctions.eMax
    eMin = pyCore.daeBinaryFunctions.eMin
    eMinus = pyCore.daeBinaryFunctions.eMinus
    eMulti = pyCore.daeBinaryFunctions.eMulti
    ePlus = pyCore.daeBinaryFunctions.ePlus
    ePower = pyCore.daeBinaryFunctions.ePower

class pyCore.daeSpecialUnaryFunctions
    Bases: Boost.Python.enum

    eAverage = pyCore.daeSpecialUnaryFunctions.eAverage
    eMaxInArray = pyCore.daeSpecialUnaryFunctions.eMaxInArray
    eMinInArray = pyCore.daeSpecialUnaryFunctions.eMinInArray
    eProduct = pyCore.daeSpecialUnaryFunctions.eProduct
    eSufUnknown = pyCore.daeSpecialUnaryFunctions.eSufUnknown
    eSum = pyCore.daeSpecialUnaryFunctions.eSum

class pyCore.daeLogicalUnaryOperator
    Bases: Boost.Python.enum
```

```
eNot = pyCore.daeLogicalUnaryOperator.eNot
eUOUnknown = pyCore.daeLogicalUnaryOperator.eUOUnknown
class pyCore.daeLogicalBinaryOperator
    Bases: Boost.Python.enum
    eAnd = pyCore.daeLogicalBinaryOperator.eAnd
    eBOUnknown = pyCore.daeLogicalBinaryOperator.eBOUnknown
    eOr = pyCore.daeLogicalBinaryOperator.eOr
class pyCore.daeConditionType
    Bases: Boost.Python.enum
    eCTUnknown = pyCore.daeConditionType.eCTUnknown
    eEQ = pyCore.daeConditionType.eEQ
    eGT = pyCore.daeConditionType.eGT
    eGTEQ = pyCore.daeConditionType.eGTEQ
    eLT = pyCore.daeConditionType.eLT
    eLTEQ = pyCore.daeConditionType.eLTEQ
    eNotEQ = pyCore.daeConditionType.eNotEQ
class pyCore.daeActionType
    Bases: Boost.Python.enum
    eChangeState = pyCore.daeActionType.eChangeState
    eReAssignOrReInitializeVariable = pyCore.daeActionType.eReAssignOrReInitializeVariable
    eSendEvent = pyCore.daeActionType.eSendEvent
    eUnknownAction = pyCore.daeActionType.eUnknownAction
    eUserDefinedAction = pyCore.daeActionType.eUserDefinedAction
class pyCore.daeEquationType
    Bases: Boost.Python.enum
    eAlgebraic = pyCore.daeEquationType.eAlgebraic
    eETUnknown = pyCore.daeEquationType.eETUnknown
    eExplicitODE = pyCore.daeEquationType.eExplicitODE
    eImplicitODE = pyCore.daeEquationType.eImplicitODE
class pyCore.daeModelType
    Bases: Boost.Python.enum
    eDAE = pyCore.daeModelType.eDAE
    eMTUnknown = pyCore.daeModelType.eMTUnknown
    eODE = pyCore.daeModelType.eODE
    eSteadyState = pyCore.daeModelType.eSteadyState
```

3.1.8 Global constants

<code>cnAlgebraic</code>	<code>int(x[, base]) -> integer</code>
<code>cnDifferential</code>	<code>int(x[, base]) -> integer</code>
<code>cnAssigned</code>	<code>int(x[, base]) -> integer</code>

```
pyCore.cnAlgebraic = 0
int(x[, base]) -> integer
```

Convert a string or number to an integer, if possible. A floating point argument will be truncated towards zero (this does not include a string representation of a floating point number!) When converting a string, use the optional base. It is an error to supply a base when converting a non-string. If base is zero, the proper base is guessed based on the string content. If the argument is outside the integer range a long object will be returned instead.

```
pyCore.cnDifferential = 1
int(x[, base]) -> integer
```

Convert a string or number to an integer, if possible. A floating point argument will be truncated towards zero (this does not include a string representation of a floating point number!) When converting a string, use the optional base. It is an error to supply a base when converting a non-string. If base is zero, the proper base is guessed based on the string content. If the argument is outside the integer range a long object will be returned instead.

```
pyCore.cnAssigned = 2
int(x[, base]) -> integer
```

Convert a string or number to an integer, if possible. A floating point argument will be truncated towards zero (this does not include a string representation of a floating point number!) When converting a string, use the optional base. It is an error to supply a base when converting a non-string. If base is zero, the proper base is guessed based on the string content. If the argument is outside the integer range a long object will be returned instead.

3.2 Module pyActivity

3.2.1 Overview

`daeSimulation`

`daeOptimization`

daeSimulation

```
class pyActivity.daeSimulation
    Bases: pyActivity.daeSimulation_t
```

Initialization methods

```
__init__ ((object)self) → None
```

```
Initialize ((daeSimulation)self, (object)daeSolver, (object)dataReporter, (object)log[,
    (bool)calculateSensitivities=False]) → None
```

```
SolveInitial ((daeSimulation)self) → None
```

m

model

Model

DAESolver

Log

DataReporter

AbsoluteTolerances

RelativeTolerance

TotalNumberOfVariables

NumberOfEquations

Loading/storing the initialization data

LoadInitializationValues ((*daeSimulation*)self, (*str*)filename) → None

StoreInitializationValues ((*daeSimulation*)self, (*str*)filename) → None

InitialValues

InitialDerivatives

Clean up methods

CleanUpSetupData ((*daeSimulation*)self) → None

Finalize ((*daeSimulation*)self) → None

Simulation setup methods

SetUpParametersAndDomains ((*daeSimulation*)self) → None

SetUpVariables ((*daeSimulation*)self) → None

Optimization setup methods

SetUpOptimization ((*daeSimulation*)self) → None

CreateInequalityConstraint ((*daeSimulation*)self, (*str*)description) → object

CreateEqualityConstraint ((*daeSimulation*)self, (*str*)description) → object

SetContinuousOptimizationVariable ((*daeSimulation*)self, (object)variable,
(float)lowerBound, (float)upperBound,
(float)defaultValue) → object

SetContinuousOptimizationVariable((daeSimulation)self, (object)ad, (float)lowerBound,
(float)upperBound, (float)defaultValue) -> object

SetIntegerOptimizationVariable ((*daeSimulation*)self, (object)variable,
(int)lowerBound, (int)upperBound, (int)defaultValue)
→ object

SetIntegerOptimizationVariable((daeSimulation)self, (object)ad, (int)lowerBound, (int)upperBound,
(int)defaultValue) -> object

SetBinaryOptimizationVariable ((*daeSimulation*)self, (object)variable,
(bool)defaultValue) → object

SetBinaryOptimizationVariable((daeSimulation)self, (object)ad, (bool)defaultValue) -> object

OptimizationVariables

Constraints

ObjectiveFunction

Parameter estimation setup methods**SetUpParameterEstimation** ((*daeSimulation*)self) → None**SetMeasuredVariable** ((*daeSimulation*)self, (*object*)variable) → object
SetMeasuredVariable((*daeSimulation*)self, (*object*)ad) -> object**SetInputVariable** ((*daeSimulation*)self, (*object*)variable) → object
SetInputVariable((*daeSimulation*)self, (*object*)ad) -> object**SetModelParameter** ((*daeSimulation*)self, (*object*)variable, (*float*)lowerBound, (*float*)upperBound, (*float*)defaultValue) → object
SetModelParameter((*daeSimulation*)self, (*object*)ad, (*float*)lowerBound, (*float*)upperBound, (*float*)defaultValue) -> object**InputVariables****MeasuredVariables****ModelParameters****Parameter estimation setup methods****SetUpSensitivityAnalysis** ((*daeSimulation*)self) → None**Operating procedures methods****Run** ((*daeSimulation*)self) → None**ReRun** ((*daeSimulation*)self) → None**Pause** ((*daeSimulation*)self) → None**Resume** ((*daeSimulation*)self) → None**ActivityAction****Integrate** ((*daeSimulation*)self, (*daeStopCriterion*)stopCriterion[, (*bool*)reportDataAroundDiscontinuities=True]) → float**IntegrateForTimeInterval** ((*daeSimulation*)self, (*float*)timeInterval[, (*bool*)reportDataAroundDiscontinuities=True]) → float**IntegrateUntilTime** ((*daeSimulation*)self, (*float*)time, (*daeStopCriterion*)stopCriterion[, (*bool*)reportDataAroundDiscontinuities=True]) → float**Reinitialize** ((*daeSimulation*)self) → None**Reset** ((*daeSimulation*)self) → None**CurrentTime****TimeHorizon****ReportingInterval****NextReportingTime****ReportingTimes****Data reporting methods****RegisterData** ((*daeSimulation*)self, (*str*)iteration) → None**ReportData** ((*daeSimulation*)self, (*float*)currentTime) → None

Various information

IndexMappings

InitialConditionMode

SimulationMode

VariableTypes

daeOptimization

```
class pyActivity.daeOptimization
    Bases: pyActivity.daeOptimization_t
    __init__ ((object)self) → None
    Initialize ((daeOptimization)self, (daeSimulation_t)simulation, (object)nlpSolver, (ob-
        ject)daeSolver, (object)dataReporter, (object)log) → None
    Run ((daeOptimization)self) → None
    Finalize ((daeOptimization)self) → None
```

3.2.2 Enumerations

<code>daeeStopCriterion</code>
<code>daeeActivityAction</code>
<code>daeeSimulationMode</code>

```
class pyActivity.daeStopCriterion
    Bases: Boost.Python.enum
    eDoNotStopAtDiscontinuity = pyActivity.daeStopCriterion.eDoNotStopAtDiscontinuity
    eStopAtGlobalDiscontinuity = pyActivity.daeStopCriterion.eStopAtGlobalDiscontinuity
    eStopAtModelDiscontinuity = pyActivity.daeStopCriterion.eStopAtModelDiscontinuity
class pyActivity.daeActivityAction
    Bases: Boost.Python.enum
    eAAUnknown = pyActivity.daeActivityAction.eAAUnknown
    ePauseActivity = pyActivity.daeActivityAction.ePauseActivity
    eRunActivity = pyActivity.daeActivityAction.eRunActivity
class pyActivity.daeSimulationMode
    Bases: Boost.Python.enum
    eOptimization = pyActivity.daeSimulationMode.eOptimization
    eParameterEstimation = pyActivity.daeSimulationMode.eParameterEstimation
    eSimulation = pyActivity.daeSimulationMode.eSimulation
```

3.3 Module pyDataReporting

3.3.1 Overview

3.3.2 DataReporter classes

daeDataReporter_t
daeDataReporterLocal
daeNoOpDataReporter
daeDataReporterFile
daeTEXTFileDataReporter
daeBlackHoleDataReporter
daeDelegateDataReporter

```
class pyDataReporting.daeDataReporter_t
    Bases: Boost.Python.instance

    Connect ((daeDataReporter_t)self, (str)connectionString, (str)processName) → bool

    Disconnect ((daeDataReporter_t)self) → bool

    IsConnected ((daeDataReporter_t)self) → bool

    StartRegistration ((daeDataReporter_t)self) → bool

    RegisterDomain ((daeDataReporter_t)self, (daeDataReporterDomain)domain) → bool

    RegisterVariable ((daeDataReporter_t)self, (daeDataReporterVariable)variable) → bool

    EndRegistration ((daeDataReporter_t)self) → bool

    StartNewResultSet ((daeDataReporter_t)self, (Float)time) → bool

    SendVariable ((daeDataReporter_t)self, (daeDataReporterVariableValue)variableValue) →
        bool

    EndOfData ((daeDataReporter_t)self) → bool
```

Data reporters that *do not* send data to a data receiver and keep data locally (*local data reporters*)

```
class pyDataReporting.daeDataReporterLocal
    Bases: pyDataReporting.daeDataReporter_t

    Process

class pyDataReporting.daeNoOpDataReporter
    Bases: pyDataReporting.daeDataReporterLocal

class pyDataReporting.daeDataReporterFile
    Bases: pyDataReporting.daeDataReporterLocal

    WriteDataToFile ((daeDataReporterFile)self) → None

class pyDataReporting.daeTEXTFileDataReporter
    Bases: pyDataReporting.daeDataReporterFile

    WriteDataToFile ((daeTEXTFileDataReporter)self) → None
```

Data reporters that *do* send data to a data receiver (*remote data reporters*)

```
class pyDataReporting.daeDataReporterRemote
    Bases: pyDataReporting.daeDataReporter_t
```

SendMessage ((*daeDataReporterRemote*)self, (*str*)message) → bool

class pyDataReporting.daeTCPIPDataReporter
Bases: pyDataReporting.daeDataReporterRemote

SendMessage ((*daeTCPIPDataReporter*)self, (*str*)message) → bool

Special-purpose data reporters

class pyDataReporting.daeBlackHoleDataReporter
Bases: pyDataReporting.daeDataReporter_t

Data reporter that does not process any data and all function calls simply return True. Could be used when no results from the simulation are needed.

class pyDataReporting.daeDelegateDataReporter
Bases: pyDataReporting.daeDataReporter_t

A container-like data reporter, which does not process any data but forwards (delegates) all function calls (`Disconnect()`, `IsConnected()`, `StartRegistration()`, `RegisterDomain()`, `RegisterVariable()`, `EndRegistration()`, `StartNewResultSet()`, `SendVariable()`, `EndOfData()`) to data reporters in the containing list of data reporters. Data reporters can be added by using the `AddDataReporter()`. The list of containing data reporters is in the `DataReporters` attribute.

Connect ((*daeDataReporter_t*)self, (*str*)connectionString, (*str*)processName) → Boolean
Does nothing. Always returns True.

AddDataReporter ((*daeDelegateDataReporter*)self, (*daeDataReporter_t*)dataReporter) → None

DataReporters

3.3.3 DataReporter data-containers

<code>daeDataReporterDomain</code>
<code>daeDataReporterVariable</code>
<code>daeDataReporterVariableValue</code>

class pyDataReporting.daeDataReporterDomain
Bases: Boost.Python.instance

Name

NumberOfPoints

Points

Type

class pyDataReporting.daeDataReporterVariable
Bases: Boost.Python.instance

AddDomain ((*daeDataReporterVariable*)self, (*str*)domainName) → None

Domains

Name

NumberOfDomains

NumberOfPoints

class pyDataReporting.daeDataReporterVariableValue
Bases: Boost.Python.instance

Name
NumberOfPoints
Values

3.3.4 DataReceiver classes

[daeDataReceiver_t](#)
[daeTCPIPDataReceiverServer](#)

```
class pyDataReporting.daeDataReceiver_t
    Bases: Boost.Python.instance

    GetProcess ((daeDataReceiver_t)arg1) → daeDataReceiverProcess
        GetProcess( (daeDataReceiver_t)arg1) -> None

    Start ((daeDataReceiver_t)arg1) → bool
        Start( (daeDataReceiver_t)arg1) -> None

    Stop ((daeDataReceiver_t)arg1) → bool
        Stop( (daeDataReceiver_t)arg1) -> None

class pyDataReporting.daeTCPIPDataReceiverServer
    Bases: Boost.Python.instance

    GetDataReceiver ((daeTCPIPDataReceiverServer)arg1, (int)arg2) → daeDataReceiver_t

    GetProcess ((daeTCPIPDataReceiverServer)arg1, (int)arg2) → daeDataReceiverProcess

    IsConnected ((daeTCPIPDataReceiverServer)arg1) → bool

    NumberOfDataReceivers

    NumberOfProcesses

    Start ((daeTCPIPDataReceiverServer)arg1) → None

    Stop ((daeTCPIPDataReceiverServer)arg1) → None
```

3.3.5 DataReceiver data-containers

[daeDataReceiverDomain](#)
[daeDataReceiverVariable](#)
[daeDataReceiverVariableValue](#)
[daeDataReceiverProcess](#)

```
class pyDataReporting.daeDataReceiverDomain
    Bases: Boost.Python.instance

    Name

    NumberOfPoints

    Points

    Type

class pyDataReporting.daeDataReceiverVariable
    Bases: Boost.Python.instance

    AddDomain ((daeDataReceiverVariable)arg1, (daeDataReceiverDomain)arg2) → None
```

AddVariableValue *((daeDataReceiverVariable)arg1, (daeDataReceiverVariableValue)arg2) → None*

Domains

Name

NumberOfPoints

TimeValues

Values

class `pyDataReporting.daeDataReceiverVariableValue`

Bases: `Boost.Python.instance`

Time

class `pyDataReporting.daeDataReceiverProcess`

Bases: `Boost.Python.instance`

Domains

FindVariable *((daeDataReceiverProcess)arg1, (str)arg2) → daeDataReceiverVariable*

Name

RegisterDomain *((daeDataReceiverProcess)arg1, (daeDataReceiverDomain)arg2) → None*

RegisterVariable *((daeDataReceiverProcess)arg1, (daeDataReceiverVariable)arg2) → None*

Variables

3.4 Module pyIDAS

3.4.1 Overview

Trt mrt.

`daeIDAS`

daeIDAS

class `pyIDAS.daeIDAS`

Bases: `pyIDAS.daeDAESolver_t`

SaveMatrixAsXPM *((daeIDAS)arg1, (str)arg2) → None*

SetLASolver *((daeIDAS)arg1, (daeIDASolverType)arg2) → None*
`SetLASolver((daeIDAS)arg1, (object)arg2) -> None`

3.5 Module pyUnits

3.5.1 Overview

3.5.2 Classes

`unit`

`quantity`

```
class pyUnits.unit
    Bases: Boost.Python.instance

    baseUnit
    unitDictionary

class pyUnits.quantity
    Bases: Boost.Python.instance

    scaleTo ((quantity)arg1, (object)arg2) → quantity
    units
    value
    valueInSIUnits
```


THIRD PARTY SOLVERS

4.1 Linear solvers

```
class pySuperLU.daeIDALASolver_t
    Bases: Boost.Python.instance

    Create ((daeIDALASolver_t)arg1, (object)arg2, (int)arg3, (object)arg4) → int
        Create( (daeIDALASolver_t)arg1, (object)arg2, (int)arg3, (object)arg4) -> None

    Reinitialize ((daeIDALASolver_t)arg1, (object)arg2) → int
        Reinitialize( (daeIDALASolver_t)arg1, (object)arg2) -> None

    SaveAsXPM ((daeIDALASolver_t)arg1, (str)arg2) → int
        SaveAsXPM( (daeIDALASolver_t)arg1, (str)arg2) -> None

class pySuperLU.daeSuperLU_Solver
    Bases: pySuperLU.daeIDALASolver_t

    Create ((daeSuperLU_Solver)arg1, (object)arg2, (int)arg3, (object)arg4) → int

    GetOptions ((daeSuperLU_Solver)arg1) → superlu_options_t

    Name

    Reinitialize ((daeSuperLU_Solver)arg1, (object)arg2) → int

    SaveAsMatrixMarketFile ((daeSuperLU_Solver)arg1, (str)arg2, (str)arg3, (str)arg4) → int

    SaveAsXPM ((daeSuperLU_Solver)arg1, (str)arg2) → int

class pySuperLU_MT.daeSuperLU_MT_Solver
    Bases: pySuperLU_MT.daeIDALASolver_t

    Create ((daeSuperLU_MT_Solver)arg1, (object)arg2, (int)arg3, (object)arg4) → int

    GetOptions ((daeSuperLU_MT_Solver)arg1) → superlumt_options_t

    Name

    Reinitialize ((daeSuperLU_MT_Solver)arg1, (object)arg2) → int

    SaveAsMatrixMarketFile ((daeSuperLU_MT_Solver)arg1, (str)arg2, (str)arg3, (str)arg4) →
        int

    SaveAsXPM ((daeSuperLU_MT_Solver)arg1, (str)arg2) → int

class pyTrilinos.daeTrilinosSolver
    Bases: pyTrilinos.daeIDALASolver_t

    Create ((daeTrilinosSolver)arg1, (object)arg2, (int)arg3, (object)arg4) → int

    GetAmesosOptions ((daeTrilinosSolver)arg1) → TeuchosParameterList

    GetAztecOOOptions ((daeTrilinosSolver)arg1) → TeuchosParameterList

    GetIfpackOptions ((daeTrilinosSolver)arg1) → TeuchosParameterList
```

GetMLOptions ((*daeTrilinosSolver*)arg1) → TeuchosParameterList

Name

NumIters

PreconditionerName

PrintPreconditionerInfo ((*daeTrilinosSolver*)arg1) → None

Reinitialize ((*daeTrilinosSolver*)arg1, (object)arg2) → int

SaveAsMatrixMarketFile ((*daeTrilinosSolver*)arg1, (str)arg2, (str)arg3, (str)arg4) → int

SaveAsXPM ((*daeTrilinosSolver*)arg1, (str)arg2) → int

Tolerance

4.2 Optimization solvers

```
class pyIPOPT.daeIPOPT
    Bases: pyIPOPT.daeNLPSolver_t

    ClearOptions ((daeIPOPT)arg1) → None

    Initialize ((daeIPOPT)arg1, (object)arg2, (object)arg3, (object)arg4, (object)arg5) → None

    LoadOptionsFile ((daeIPOPT)arg1, (str)arg2) → None

    Name

    PrintOptions ((daeIPOPT)arg1) → None

    PrintUserOptions ((daeIPOPT)arg1) → None

    SetOption ((daeIPOPT)arg1, (str)arg2, (str)arg3) → None
        SetOption( (daeIPOPT)arg1, (str)arg2, (float)arg3) -> None
        SetOption( (daeIPOPT)arg1, (str)arg2, (int)arg3) -> None

    Solve ((daeIPOPT)arg1) → None

class pyBONMIN.daeBONMIN
    Bases: pyBONMIN.daeNLPSolver_t

    ClearOptions ((daeBONMIN)arg1) → None

    Initialize ((daeBONMIN)arg1, (object)arg2, (object)arg3, (object)arg4, (object)arg5) → None

    LoadOptionsFile ((daeBONMIN)arg1, (str)arg2) → None

    Name

    PrintOptions ((daeBONMIN)arg1) → None

    PrintUserOptions ((daeBONMIN)arg1) → None

    SetOption ((daeBONMIN)arg1, (str)arg2, (str)arg3) → None
        SetOption( (daeBONMIN)arg1, (str)arg2, (float)arg3) -> None
        SetOption( (daeBONMIN)arg1, (str)arg2, (int)arg3) -> None

    Solve ((daeBONMIN)arg1) → None

class pyNLOPT.daeNLOPT
    Bases: pyNLOPT.daeNLPSolver_t

    Initialize ((daeNLOPT)arg1, (object)arg2, (object)arg3, (object)arg4, (object)arg5) → None

    Name

    PrintOptions ((daeNLOPT)arg1) → None
```

```
Solve ((daeNLOPT)arg1) → None  
ftol_abs  
ftol_rel  
xtol_abs  
xtol_rel
```

4.3 Parameter estimation solvers

```
class daetools.solvers.daeMinpackLeastSq.daeMinpackLeastSq
```

```
Finalize()  
Initialize(simulation, daesolver, datareporter, log, **kwargs)  
Run()  
getConfidenceCoefficient(confidence)  
getConfidenceEllipsoid(x_param_index, y_param_index, **kwargs)  
getFit_Dyn(measured_variable_index, experiment_index, **kwargs)  
getFit_SS(input_variable_index, measured_variable_index, **kwargs)
```


CODE GENERATORS

5.1 Auxiliary classes

```
class daetools.code_generators.analyzer.daeCodeGeneratorAnalyzer
    Bases: object

    analyzeModel (model)
    analyzePort (port)
    analyzeSimulation (simulation)

class daetools.code_generators.formatter.daeExpressionFormatter
    Bases: object

    flattenIdentifier (identifier)
    formatDomain (domainCanonicalName, index, value)
    formatIdentifier (identifier)
    formatNumpyArray (arr)
    formatParameter (parameterCanonicalName, domainIndexes, value)
    formatQuantity (quantity)
    formatRuntimeConditionNode (node)
    formatRuntimeNode (node)
    formatTimeDerivative (variableCanonicalName, domainIndexes, overallIndex, order)
    formatUnits (units)
    formatVariable (variableCanonicalName, domainIndexes, overallIndex)
```

5.2 Modelica

```
class daetools.code_generators.modelica.daeModelicaExpressionFormatter
    Bases: daetools.code_generators.formatter.daeExpressionFormatter

    formatNumpyArray (arr)
    formatQuantity (quantity)
    formatUnits (units)

class daetools.code_generators.modelica.daeCodeGenerator_Modelica (simulation=None)
    Bases: object

    generateModel (model, filename=None)
```

```
generatePort (port, filename=None)  
generateSimulation (simulation, filename=None)
```

5.3 ANSI C

```
class daetools.code_generators.ansi_c.daeANSICExpressionFormatter  
    Bases: daetools.code_generators.formatter.daeExpressionFormatter  
  
    formatNumpyArray (arr)  
    formatQuantity (quantity)  
  
class daetools.code_generators.ansi_c.daeCodeGenerator_ANSI_C (simulation=None)  
    Bases: object  
  
    generateSimulation (simulation, **kwargs)
```

5.4 Functional Mockup Interface (FMI)

```
class daetools.code_generators.fmi.daeCodeGenerator_FMI  
    Bases: daetools.code_generators.fmi_xml_support.fmiModelDescription  
  
    generateSimulation (simulation, **kwargs)
```

TUTORIALS

Note: Currently only Mozilla Firefox and Opera 12+ browsers are supported for viewing model reports (MathML rendering issue).

6.1 What's the time? (AKA: Hello world!)

Model report: [whats_the_time.xml](#)

Runtime model report: [whats_the_time-rt.xml](#)

Source code: [whats_the_time.py](#)

6.2 Tutorial 1

Model report: [tutorial1.xml](#)

Runtime model report: [tutorial1-rt.xml](#)

Source code: [tutorial1.py](#)

6.3 Tutorial 2

Model report: [tutorial2.xml](#)

Runtime model report: [tutorial2-rt.xml](#)

Source code: [tutorial2.py](#)

6.4 Tutorial 3

Model report: [tutorial3.xml](#)

Runtime model report: [tutorial3-rt.xml](#)

Source code: [tutorial3.py](#)

6.5 Tutorial 4

Model report: [tutorial4.xml](#)

Runtime model report: [tutorial4-rt.xml](#)

Source code: tutorial4.py

6.6 Tutorial 5

Model report: tutorial5.xml

Runtime model report: tutorial5-rt.xml

Source code: tutorial5.py

6.7 Tutorial 6

Model report: tutorial6.xml

Runtime model report: tutorial6-rt.xml

Source code: tutorial6.py

6.8 Tutorial 7

Model report: tutorial7.xml

Runtime model report: tutorial7-rt.xml

Source code: tutorial7.py

6.9 Tutorial 8

Model report: tutorial8.xml

Runtime model report: tutorial8-rt.xml

Source code: tutorial8.py

6.10 Tutorial 9

Model report: tutorial9.xml

Runtime model report: tutorial9-rt.xml

Source code: tutorial9.py

6.11 Tutorial 10

Model report: tutorial10.xml

Runtime model report: tutorial10-rt.xml

Source code: tutorial10.py

6.12 Tutorial 11

Model report: tutorial11.xml

Runtime model report: tutorial11-rt.xml

Source code: tutorial11.py

6.13 Tutorial 12

Model report: tutorial12.xml

Runtime model report: tutorial12-rt.xml

Source code: tutorial12.py

6.14 Tutorial 13

Model report: tutorial13.xml

Runtime model report: tutorial13-rt.xml

Source code: tutorial13.py

6.15 Tutorial 14

Model report: tutorial14.xml

Runtime model report: tutorial14-rt.xml

Source code: tutorial14.py

6.16 Optimization tutorial 1

Model report: opt_tutorial1.xml

Runtime model report: opt_tutorial1-rt.xml

Source code: opt_tutorial1.py

6.17 Optimization tutorial 2

Model report: opt_tutorial2.xml

Runtime model report: opt_tutorial2-rt.xml

Source code: opt_tutorial2.py

6.18 Optimization tutorial 3

Model report: opt_tutorial3.xml

Runtime model report: opt_tutorial3-rt.xml

Source code: opt_tutorial3.py

6.19 Optimization tutorial 4

Model report: `opt_tutorial4.xml`

Runtime model report: `opt_tutorial4-rt.xml`

Source code: `opt_tutorial4.py`

6.20 Optimization tutorial 5

Model report: `opt_tutorial5.xml`

Runtime model report: `opt_tutorial5-rt.xml`

Source code: `opt_tutorial5.py`

6.21 Optimization tutorial 6

Model report: `opt_tutorial6.xml`

Runtime model report: `opt_tutorial6-rt.xml`

Source code: `opt_tutorial6.py`

INDICES AND TABLES

- *genindex*
- *modindex*
- *search*

PYTHON MODULE INDEX

d

`daetools.code_generators.analyzer`, 57
`daetools.code_generators.ansi_c`, 58
`daetools.code_generators.fmi`, 58
`daetools.code_generators.formatter`, 57
`daetools.code_generators.modelica`, 57

p

`pyActivity`, 43
`pyCore`, 23
`pyDataReporting`, 47
`pyIDAS`, 50
`pyUnits`, 50

s

`solvers.bonmin.pyBONMIN`, 54
`solvers.ipopt.pyIPOPT`, 54
`solvers.nlopt.pyNLOPT`, 54
`solvers.superlu.pySuperLU`, 53
`solvers.superlu_mt.pySuperLU_MT`, 53
`solvers.trilinos.pyTrilinos`, 53