



D4 - Displays and Dialogs

Table of Contents

1. GENERAL	3
1.1 UPDATE MODES.....	4
1.1.1 Default Mode	2
1.1.2 Select Mode.....	2
2. DESCRIPTION OF DISPLAYS AND DIALOGS	3
2.1 BASIC DATA.....	3
2.1.1 Primary Data.....	3
2.1.2 Roll Inventory.....	5
2.1.3 Mill Stretch.....	13
2.2 ROLLING SETUP DATA.....	17
2.2.1 Table Data Roughing Mill.....	17
2.2.2 Table Data Cooling.....	21
2.2.3 General Model Data	25
2.2.3.1 Parameter Description.....	26
2.2.3.1.1 Types of Values.....	26
2.2.3.1.2 Parameters	27
2.2.4 Steel Grade Reference Table.....	34
2.2.4.1 Rolling Strategy	39
2.2.4.2 Looper Strategy	41
2.2.4.3 Interstand Cooling Strategy	42
2.2.4.4 Descaling Strategy	43
2.2.4.5 SRTclass Rougher	44
2.2.4.6 SRTclass Cooling.....	45
2.2.4.7 Material Law	46
2.2.4.8 Material Properties	49
2.2.5 Setup Data Roughing Mill.....	56
2.2.6 Setup Data Finishing Mill.....	60
2.2.6.1 Parameter Description.....	61
2.2.6.1.1 Types of Values.....	61
2.2.6.1.2 Parameters	61
2.2.6.2 Buttons	66
2.2.6.3 Advanced Strategy Data.....	71
2.2.6.3.1 Parameters	72
2.2.6.3.2 Dialog Modify Advanced	75
2.2.7 Setup Data Cooling	76
2.3 MATERIAL TRACKING.....	78
2.3.1 Material Tracking Overview.....	78
2.3.2 Furnace Map	82
2.4 ACTUAL PRODUCTION DATA	83

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc	Date 1996-02-28	Version as built	Page 1
-----------------	--	--------------------	---------------------	-----------



ARMCO Hot Strip Mill
Documentation Level 2 System
Operator Handbook
D4 - Displays and Dialogs



2.4.1 Primary Edger Area	83
2.4.2 Roughing Mill Area	84
2.4.3 Finishing Mill Area	85
3. REVISION AND DOCUMENT DISTRIBUTION LIST	86

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 2
-----------------	--	--	--------------------	---------------------	-----------

1. General

This chapter describes all displays and dialogs of the HSM Level 2 system.

Summary of displays:

- Basic Data

- Primary Data
- Roll Inventory
- Mill Stretch

- Rolling Setup Data

- Table Data Roughing Mill
- Table Data Cooling
- General Model Data
- Steel Grade Reference Table
- Setup Data Roughing Mill
- Setup Data Finishing Mill
- Setup Data Cooling

- Material Tracking

- Material Tracking Overview
- Furnace Map

- Actual Production Data

- Primary Edger Area
- Roughing Mill Area
- Finishing Mill Area

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 3
-----------------	--	--	--------------------	---------------------	-----------

1.1 Update Modes



For all material related displays which do have the slab identification as a key, there are two different modes for displaying the related data:



You can toggle between these two modes by clicking on with mouse button 1.

Selecting a certain display in the general **Menu Bar**, the window *initially* is displayed in **Default Mode**.

The actual mode is shown by a toggle button in the top left area within the actual display:



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 4
-----------------	--	--	--------------------	---------------------	-----------

1.1.1 Default Mode

The material shown on the display depends on the actual production. This mode additionally depends on the actual (physical) location (station) of your terminal.

For HSM there are following 3 stations:

- *Roughing Mill (RM pulpit)*
- *Finishing Mill (FM pulpit)*
- *Weighing and Banding (Weigher/Bander Shanty)*

For all other located terminals (offices, computerroom,...) the default points to Finishing Mill Station.

That means, whenever a material approaches or enters the production area of a specific station, the data on your display will switch to show information of that particular new material.

1.1.2 Select Mode


In this mode you can obtain information on materials other than the default material.

Setting Select Mode, the actual display keeps the data of the selected material on the screen, independent of the actual production. To view different materials you can click on the slab ID field and modify it to the ID you want to get information on. Pressing the buttons RETURN or ENTER you get the new data on your screen.

If no data exist for your choosen slab ID, all display data fields will be reset.

To get back to the actual production, you just have to set *Default Mode* again.


Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 2
-----------------	--	--	--------------------	---------------------	-----------



2. Description of Displays and Dialogs

2.1 Basic Data

2.1.1 Primary Data



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 3
-----------------	--	--	--------------------	---------------------	-----------




The display describes the actual product to be produced. *General and Analysis Data* give information about the slab coming from the caster and *Target Data* describe the final product.

Dialogs:

Modify Primary Data:

Within this dialog all data can be modified




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 4
-----------------	--	--	--------------------	---------------------	-----------



2.1.2 Roll Inventory

This display shows the actual installed rolls for RM and FM. Stand related information contains roll ID, diameter and tons on roll. The scroll lists on top and bottom of the display contain the available rolls, received from Level 3 system.

Display Layout:




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 5
-----------------	--	--	--------------------	---------------------	-----------

Dialogs:

Modify Edger Diameters:

Should the edger rolls be changed (RM Edger and/or Primary Edger) the corresponding diameters can be set within this dialog



Start Roll Change:

Clicking on this push button the roll change dialog is started



Following window appears to confirm entering *Modify Mode*.



When you press the OK button, you are allowed to select in the lists for top and bottom rolls the new roll you want to insert into the stand.


Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 6
-----------------	--	--	--------------------	---------------------	-----------

To *exit* from *Modify Mode* click on the push button



Note: Exit from *Modify Mode* transmits all diameters of the actual installed rolls to the Level 1 system

After you have selected a roll, the stands where you are allowed to insert the roll will be highlighted (next picture).



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 7
-----------------	--	--	--------------------	---------------------	-----------

After selecting a certain stand (here in this case stand 2) following confirmation box is displayed.



Pushing the OK button, the roll is inserted into the stand and the data will be transmitted to the Level 1 System. Additionally, the roll disappears from the list of available rolls.

The Cancel button cancels the operation without performing any changes.

! WARNING !


From the point of time, the new roll data are confirmed, the Finishing Mill Model considers the new data for the setpoint calculation.

Therefore - a Level 2 Roll Change must not be done in advance to a real manual roll change, while still some slabs are rolled.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 8
-----------------	--	--	--------------------	---------------------	-----------

Create / Modify Roll:

This display shows all available data of a particular roll.



Enter the roll ID and hit the *Return* button.

The roll ID itself is defined to contain two leading ASCII characters and 5 numeric digits (eg. WH08558). Should the entered roll ID be wrong (here A123456), following window appears on your screen.




Click OK and enter the roll ID in the correct format.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 9
-----------------	--	--	--------------------	---------------------	-----------




In following example ID WH31889 was entered.




Roll WH31889 is a designated Finishing Mill Top Work Roll and not yet installed in any stand (Stand Number and Stand-In Date/Time as well as Number of Rolled Coils and Tons and Footage on Roll are empty).

If a roll does not exist in the Level 2 roll inventory, following window pops up.



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 10
-----------------	--	--	--------------------	---------------------	------------



By pressing the button *Modify/Create*, a new roll can be created or the data of an existing roll can be modified (next picture with WH31889).




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 11
-----------------	--	--	--------------------	---------------------	------------



If data for an already installed roll are to be modified, *Stand Type*, *Roll Type* and *Position* can not be changed (following example with WH33124, which is installed at stand 6).



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 12
-----------------	--	--	--------------------	---------------------	------------



2.1.3 Mill Stretch


This display shows the actual mill stretch curves and calibration data for the finishing mill stands.

Display Layout:

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 13
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
Operator Handbook
D4 - Displays and Dialogs



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 14
-----------------	--	--	--------------------	---------------------	------------



Dialogs:

Push Buttons in the Mask:

Stand x	Select a certain stand
OS	Select curve of Operator Side
OS	Select curve of Operator/Drive Side total
DS	Select curve of Drive Side
Actual	Select actual used curve (shown in shades of red)
Measured/Previous	Select measured or previous used curve (shown in shades of blue)


If the automatic mill stretch evaluation sequence has been started at the Level 1 system (calibration with mill stretch) and the calibration is ready (not yet confirmed), the data can be seen on the mill stretch display by pushing the button **Measured/Previous** (can be done in advance).

As soon as the measured mill stretch data are accepted at the Level 1, the so far actual data at the Level 2 are saved as **Previous** (curve changes blue) and the actually recorded data are activated and become the **Actual** values (curve changes to red) in the display.


Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 15
-----------------	--	--	--------------------	---------------------	------------



Following picture shows the previous Operator and Drive Side stretch curves for stand 3.




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 16
-----------------	--	--	--------------------	---------------------	------------



Calibration Data

This display shows the actual and previous used calibration data for all finishing mill stands.

Pushing the button Print, the data are printed at the laser printer in the Finishing Mill Pulpit.



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 17
-----------------	--	--	--------------------	---------------------	------------




2.2 Rolling Setup Data

2.2.1 Table Data Roughing Mill

This display gives information about setup reference table data for Roughing Mill.

Display Layout:



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 18
-----------------	--	--	--------------------	---------------------	------------


Dialogs:

Switching over to Select Mode, a Recipe Number can be entered. If the recipe does not exist, following box appears on the screen.



Modify Table Data:

All data for the selected recipe number can be modified



Descaling patterns can be modified by click on the corresponding toggle buttons ON/OFF.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 19
-----------------	--	--	--------------------	---------------------	------------



Create Table Data:

A new reference table can be created.

To activate an actually created recipe, a reference to a certain steel grade or group of steel grades has to be defined (see chapter Steel Grade Reference Table, SRTclass Rougher).




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 20
-----------------	--	--	--------------------	---------------------	------------



Delete Table Data:

An existing reference table can be deleted



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 21
-----------------	--	--	--------------------	---------------------	------------

2.2.2 Table Data Cooling

This display gives information about reference data for strip cooling.

Display Layout:



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 22
-----------------	--	--	--------------------	---------------------	------------



Dialogs:

Modify Table Data:

Existing reference data can be modified



Cooling patterns can be modified by click on the corresponding toggle buttons ON/OFF.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 23
-----------------	--	--	--------------------	---------------------	------------




Create Table Data:

New reference data can be created


--

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 24
-----------------	--	--	--------------------	---------------------	------------




Delete Table Data:

Existing reference data can be deleted



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 25
-----------------	--	--	--------------------	---------------------	------------




2.2.3 General Model Data

The general model data is a set of parameters, default values, adjustments, limits and switches used by the setup model to calculate the pass schedule.

The General Model Data Mask enables the system administrator to monitor, control and change relevant model parameters in order to tune the model or to react on a change in the mill.

Display Layout:

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 26
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
Operator Handbook
D4 - Displays and Dialogs



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 27
-----------------	--	--	--------------------	---------------------	------------

Dialogs:

Modify General Model Data:

All actual adjusted parameters can be modified

2.2.3.1 Parameter Description

2.2.3.1.1 Types of Values

PD	Piece data Slab data and target values from the level 3 system, transmitted to the level 2 system by the furnace computer.
TD	Lookup Table Data Data coming from a lookup table supplied by the level 2 system administrator and eventually changed by the operators.
SW	Switches Strategic switches set either by the operator or by the level 2 system administrator.
SP	Setpoints Setpoints transmitted to the level 1 system
OP	Operator input Inputs in the operator mask "setup data finishing mill"
PA	Parameters Model parameter
CA	Calculated Values Calculated values from the pass schedule calculation
DC	Adapters used by the calculation Adapter set that is used to create the present pass schedule

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 28
-----------------	--	--	--------------------	---------------------	------------

- AR Actual value RM**
Actual value of roughing mill and upstream
- AF Actual values of finishing mill area and downstreams**
Actual readings from the strip in the finishing mill or downstreams, either the linear average over the entire strip, or the linear average over a given part of the strip as described.
- PO Post calculated of finishing mill area and downstreams**
Recalculated values for strip segments based on the actual readings for this segment. The adaptation uses the same algorithms as the pass schedule calculations, but input data from the readings during rolling. These values are averages over a certain number of strip segments.
- DA Adapters created by the adaptation**
Adapters that are results of the adaptation.
- SI Signals occurred during rolling**
From Level 1 transmitted signal stated during rolling.

2.2.3.1.2 Parameters

General

Maximal Reduction F1 to F6

PA maximum allowed relative reduction on stand F1

Corr.spec.Force F1 to F6

PA correction to specific roll force on F1 stand only used in “force” strategy

Stretch Correct RM

PA linear part of the roughing mill’s millstretch
This value is used for the precalculation and calculation of the transfer bar thickness

Rel Tol Fo/Rad Iter

PA percentage of radius deviation in roll flattening iteration

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 29
-----------------	--	--	--------------------	---------------------	------------



Max Iter Fo/Rad Com

PA maximum allowed iterations in roll flattening calculation

Ave Temp Work Rolls

PA default value for workroll surface temperature

Ambient Temp Top

PA default ambient temperature below the hot strip

Ambient Temp Bottom

PA default ambient temperature below the hot strip

Water Temp

PA default cooling and descaling water temperature

Amb Temp Top RMDT

PA ambient temperature on top of roughing mill delay table

Amb Temp Bot RMDT

PA ambient temperature on bottom of roughing mill delay table

Min Work Roll Rad RM

PA lower limit for work roll radius (= diameter/2) for roughing mill

Max Work Roll Rad RM

PA upper limit for work roll radius (= diameter/2) for roughing mill

Spec Roll Force RM

PA default value for roughing mill roll force prediction in tons per inch of the strip width

Off Pos St Ent Si Gui

OP offset to the side guide position in finishing mill.
Operator change in "Setup Data Finishing Mill" possible.

Miscellaneous

RM Pyrom South

SW pyrometer on south side of roughing mill is valid

RM Pyrom North

SW pyrometer on north side of roughing mill is valid

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 30
-----------------	--	--	--------------------	---------------------	------------

Limitations

Temp Adap Min

PA lower limit for temperature adapter

Temp Adap Max

PA upper limit for temperature adapter

Thick Adap Min

PA lower limit for thickness adapter

Thick Adap Max

PA upper limit for thickness adapter

Force Sta Adap Min

PA lower limit for stand force adapter, obsolete

Force Sta Adap Max

PA upper limit for stand force adapter, obsolete

Force Adap Min

PA lower limit for roll force adapters

Force Adap Max

PA upper limit for roll force adapters

Torque Adap Min

PA lower limit for rolltorque adapters

Torque Adap Max

PA upper limit for rolltorque adapters

Time Adap Min

PA lower limit for transferbar time adapter

Time Adap Max

PA upper limit for transferbar time adapter

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 31
-----------------	--	--	--------------------	---------------------	------------



Adaption Ranges

First Record Recalc

PA first segment used for adaptive threading

Records Recalc

PA number of segments used for adaptive threading

First Record Adapt

PA first segment used for roll force and rolltorque adaptation

Records Adapt

PA number of segments used for roll force and rolltorque adaptation

Striphead Start

PA striphead part excluded from thickness adaptation

Striphead End

PA end of striphead for thickness adaptation

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 32
-----------------	--	--	--------------------	---------------------	------------

Adapters

Temp Act

DA global temperature adapter, obsolete

Temp Prev

DA previous global temperature adapter, obsolete

Time RMDT

DA transferbar time adapter

Speed Values

Def Last Pass RM

PA default value for rolling speed in the last pass in the roughing mill

Default RM to FM

PA default speed on roughing mill delivery table

Default Descaler

PA default speed value for descaler

PR Scale Break

PA default speed in pinch roll scale breaker

Thermal Crown

Work Roll Slices

PA number of slices for the calculation of the thermal crown

Heat Tr Roll-Air

PA heat transfer coefficient for heat transfer roll to air

Heat Tr Roll-Wat

PA heat transfer coefficient for heat transfer roll to roll cooling water

TiStep Ther Crown Mod

PA time slices for thermal crown calculation

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 33
-----------------	--	--	--------------------	---------------------	------------

Cycle Ti Ther Crown Mod

PA invocation cycle for the thermal crown model

Points Approximation

PA number of points for calculation of the thermal crown

Alpha Water F1-F3

PA heat transision coefficient F1 to F3 to cooling water when roll cooling is in state "full cooling"

Alpha Water F4-F6

PA heat transision coefficient F4 to F6 to cooling water when roll cooling is in state "full cooling"

Alpha Water idle F1-F3

PA heat transision coefficient F1 to F3 to cooling water when roll cooling is in state "idle"

Alpha Water idle F4-F6

PA heat transision coefficient F4 to F6 to cooling water when roll cooling is in state "idle"

Roll Wear

Coeff F1 to Coeff F6

PA roll wear coefficients for stands F1 to F6

Learning Rates

Sh Te Adap Fo / To

PA obsolete

Lo Te Adap Fo / To

PA learning rate for force and torque adaptation


Temp Adaption

PA learning rate for temperature adaptation

Adap Temp Int Cool

PA obsolete

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 34
-----------------	--	--	--------------------	---------------------	------------



Thickness Adaption

PA learning rate for thickness adaption

Speed Adaption

PA learning rate for speed adaptation

Interstand Cooling

Width

PA width of cooling spray headers

Flow Rate F1-F2

PA flow rate for spray header after F1

Flow Rate F3-F4

PA flow rate for spray header after F3

Width Scale Breaker

PA width of scale breaker spray headers

Flow Rate Scale Br


PA flow rate for scale breaker

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 35
-----------------	--	--	--------------------	---------------------	------------

2.2.4 Steel Grade Reference Table

This display gives an overview about the available steel grades at the HSM Level 2 system and corresponding references.


Display Layout:




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 36
-----------------	--	--	--------------------	---------------------	------------

Dialogs:

Before *Modify* or *Delete Dialog* can be started, the particular grade has to be selected from the list by clicking on the line, containing the grade.



If the dialog is started without doing so, following box is displayed.




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 37
-----------------	--	--	--------------------	---------------------	------------



Modify Steel Grade Reference:

An existing steel grade entry can be modified




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 38
-----------------	--	--	--------------------	---------------------	------------



Create Steel Grade Reference:

New steel grade entry can be created




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 39
-----------------	--	--	--------------------	---------------------	------------




Delete Steel Grade Reference:

An existing steel grade entry can be deleted




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 40
-----------------	--	--	--------------------	---------------------	------------




2.2.4.1 Rolling Strategy

Information about rolling strategy data

Display Layout:



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 41
-----------------	--	--	--------------------	---------------------	------------



Dialogs:

Modify Rolling Strategy:

An existing record can be modified

Create Rolling Strategy:

New record can be created

Delete Rolling Strategy:

An existing record can be deleted

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 42
-----------------	--	--	--------------------	---------------------	------------

2.2.4.2 Looper Strategy

Information about looper strategy parameters

Display Layout:



Dialogs:

Modify Looper Strategy:

An existing record can be modified

Create Looper Strategy:

New record can be created

Delete Looper Strategy:

An existing record can be deleted

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 43
-----------------	--	--	--------------------	---------------------	------------

2.2.4.3 Interstand Cooling Strategy

Information about interstand cooling strategy parameters

Display Layout:



Dialogs:

Modify Interstand Cooling Strategy:

An existing record can be modified (select list line)

Create Interstand Cooling Strategy:

New record can be created

Delete Interstand Cooling Strategy:


An existing record can be deleted (select list line)

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 44
-----------------	--	--	--------------------	---------------------	------------

2.2.4.4 Descaling Strategy

Information about descaling strategy parameters

Display Layout:



Dialogs:

Modify Descaling Strategy:

An existing record can be modified (select list line)

Create Descaling Strategy:

New record can be created

Delete Descaling Strategy:


An existing record can be deleted (select list line)

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 45
-----------------	--	--	--------------------	---------------------	------------

2.2.4.5 SRTclass Rougher

Information about Setup Reference Table classes for Roughing Mill

Display Layout:



Reference Recipe No. specifies the recipe, which is used for this class at the defined **Slab Width Range** and **Slab Thickness Range**. The corresponding reference pass schedule data can be seen in *Table Data Roughing Mill*.

Dialogs:

Modify SRTclass Rougher:

An existing record can be modified

Create SRTclass Rougher:

New record can be created

Delete SRTclass Rougher:


An existing record can be deleted

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 46
-----------------	--	--	--------------------	---------------------	------------

2.2.4.6 SRTclass Cooling

Information about Cooling Reference Table for strip cooling

Display Layout:



Reference Recipe No. specifies the recipe, which is used for this class at the defined **Strip Width Range** and **Strip Thickness Range**. The corresponding reference cooling data can be seen in *Table Data Cooling*.

Dialogs:

Modify SRTclass Cooling:

An existing record can be modified

Create SRTclass Cooling:

New record can be created

Delete SRTclass Cooling:

An existing record can be deleted

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 47
-----------------	--	--	--------------------	---------------------	------------




2.2.4.7 Material Law

Information about material law parameters

Display Layout:




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 48
-----------------	--	--	--------------------	---------------------	------------



Dialogs:

Copy Material Law:

New record can be created by copying from an existing record




An existing record can not be overwritten by the copy function !


Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 49
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
Operator Handbook
D4 - Displays and Dialogs



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 50
-----------------	--	--	--------------------	---------------------	------------



Modify Material Law:

An existing record can be modified

Create Material Law:

New record can be created

Delete Material Law:

An existing record can be deleted


Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 51
-----------------	--	--	--------------------	---------------------	------------



2.2.4.8 Material Properties

Information about material property parameters

Display Layout:




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 52
-----------------	--	--	--------------------	---------------------	------------



Dialogs:

Modify Material Property:

An existing record can be modified




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 53
-----------------	--	--	--------------------	---------------------	------------



Create Material Property:

New record can be created




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 54
-----------------	--	--	--------------------	---------------------	------------




Delete Material Property:

An existing record can be deleted



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 55
-----------------	--	--	--------------------	---------------------	------------

Before any of the following *Modify Dialogs* can be started, the particular item has to be selected in the corresponding list.




Otherwise following box is displayed



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 56
-----------------	--	--	--------------------	---------------------	------------


Modify Material Property Density:

Density values for the selected line can be modified



Modify Material Property Capacity:


Capacity values for the selected line can be modified



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 57
-----------------	--	--	--------------------	---------------------	------------


Modify Material Property Conductivity:

Conductivity values for the selected line can be modified



Modify Material Property Expansion:

Expansion values for the selected line can be modified



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 58
-----------------	--	--	--------------------	---------------------	------------

2.2.5 Setup Data Roughing Mill

This display gives information about the Roughing Mill setup for a particular slab

Display Layout:



RM pass schedule is downloaded to the Level 1 system at following events:


- ☐ **Furnace discharging (for actual slab)**
- ☐ **Last pass RM finished (for next slab in furnace)**
- ☐ **Push button *Send Pass Schedule***

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 59
-----------------	--	--	--------------------	---------------------	------------

Dialogs:

Modify Descal:

Descaling can be modified by click on the corresponding toggle buttons ON/OFF




Note: Any change in the descaling practice will be updated in the corresponding setup reference table data and will influence all following slabs, rolled with the same recipe number.

Dialog is allowed only, while the slab is still in the furnace.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 60
-----------------	--	--	--------------------	---------------------	------------


Modify Edger Offsets:



Offsets for Primary and RM Edger can be adjusted.

Each time, the *Up* or *Down Arrow* button is clicked on, the actual adjust is increased or decreased by **50 mil**.

Maximum for the offset is **in both directions** (open and close) **950 mil**.



Note: Any change in the edger offsets will be updated in the corresponding setup reference table data and will influence all following slabs, rolled with the same recipe number.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 61
-----------------	--	--	--------------------	---------------------	------------

Push Buttons:



Creates, based on the RM setup reference table, an actual RM pass schedule and starts the FM model afterwards.

When Primary Data where invalid at furnace charging and the automatic RM pass schedule creation failed at this time, after correcting the Primary Data manually, this button can be used.




Downloads the actual RM pass schedule to the Level 1 system (deadline is furnace discharging).

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 62
-----------------	--	--	--------------------	---------------------	------------

2.2.6 Setup Data Finishing Mill

Information about Finishing Mill pass schedule

Display Layout:



A field, kept in color *Tan*, indicates that it can be manually altered.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 63
-----------------	--	--	--------------------	---------------------	------------

2.2.6.1 Parameter Description

2.2.6.1.1 Types of Values

Please see *General Model Data*, chapter *Parameter Description* at page 26.

2.2.6.1.2 Parameters

Strip Identification

Slab ID

PD Strip Identification

Grade

PD steel grade

Strip

Thickness Target

PD target strip thickness (cold value)

Thickness Actual

AF the actual reading of the x-ray gauge (cold value)

Width Target

PD the cold target strip width

Width Actual

AF the actual reading of the width gauge (cold value)

Fin.Temp Target

PD the target strip temperature on the finishing mill exit side

Fin.Temp Actual

AF the actual reading of the pyrometer on the finishing mill exit side

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 64
-----------------	--	--	--------------------	---------------------	------------

Fin.Temp Calculated

CA the calculated exit temperature for the headend on the exit side of the last active stand

DC Temp Target

PD the target strip temperature on the downcoiler

DC Temp Actual

AF the actual reading of the pyrometer on the downcoiler

Scale Breaker

Target Speed

SP target scale breaker speed

State Descaler North/South

SP state (ON or OFF) for FM entry descaler

Time Descaler North/South

SP time period (seconds), FM entry descaler should stay ON; only relevant if state is ON

Transfer Bar

Thick Target

PD the target transfer bar thickness from the piece data, hot

Thick Actual

CA the calculated transfer bar thickness based on the roughing mill pass schedule (for precalculation) or the actual values for screwdown and roll force on the roughing mill (for calculation)

Temp Target

PD the target transfer bar temperature on the roughing mill gap exit side at the last pass in the roughing mill, regardless if it is a load or an unload pass

Temp Actual

AR the actual reading of the pyrometer on the roughing mill north side

F1 Entry Temp. Actual

AF the actual reading of the pyrometer on the finishing mill entry side

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 65
-----------------	--	--	--------------------	---------------------	------------

Calc. Width

CA the transfer bar width calculated from the roughing mill pass schedule (precalculation) or from the actual values of the roughing mill (calculation), warm value

Entry SG Offset

OP offset to calculated entry side guide position;

**Adjusted side guide position itself is defined as:
Calculated transfer bar width (Level 2) + 1.5 inch (Level 1)**

Pass Schedule

F1 to F6 diamonds

SI shows, if stand is active or dummy;
Filled diamond means *Active Stand*
Empty diamond means *Dummy Stand*

Load Gap

SP calculated load gap

Draft

CA calculated absolute thickness reduction

Draft Change

OP draft change request done by the operator;
The draft change request is an input for the pass schedule precalculation respectively the pass schedule calculation.

The requested draft change is added to the draft on the according stand(s). In order to get the required gauge, the model distributes the draft on the remaining stands and resets the draft change request. The resulting relative thickness reductions (see "Relative Draft", below) reductions are stored in overwrite-mode to the corresponding rolling strategy lookup table. Draft change is not possible in "Force" strategy.

Note: In *dummy stand* rolling, the draft change is considered, but not reset and not permanently stored.

Relative Draft

CA relative thickness reduction

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 66
-----------------	--	--	--------------------	---------------------	------------



Rolling Speed

SP rolling speed

Rolling Force

SP preset roll force for the strip headend

Rolling Torque

CA calculated roll torque for the strip headend

Load

CA calculated roll power for the strip headend

Exit Strip Width

CA calculated exit strip width (hot value)

Looper Angle

SP looper angle from lookup table for each looper

Looper Tension

SP specific tension from lookup table for each looper

Speed Offset F1

Actual

OP actual adjusted offset to the model calculated rolling speed of the entire mill. This speed offset is added to the calculated speed on the first active stand. The speeds of the other stands are calculated considering the resulting total rolling speed for the first active stand.

Request

OP requested speed offset. This offset is an operator input and is added to the actual speed offset at the time of a pass schedule precalculation or a pass schedule calculation. If this speed offset request should result in a violation of the minimum or maximum speed on one of the active stands, the requested speed offset is cut back to a value the mill to run fast as respectively as slow as possible without violating the stand speed limits.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 67
-----------------	--	--	--------------------	---------------------	------------



Thickn.Offset

Actual

- OP actual adjusted operator given thickness offset. This offset is added to the target strip thickness.

Request

- OP requested thickness offset. This offset is an operator input and is added to the actual thickness offset at the time of pass schedule precalculation or pass schedule calculation.

Rolling Strategy


- PA rolling strategy mode, "Load" or "Force".

"Load" strategy is based on preset relative thickness reduction each stand which are subject to operator modifications, if necessary.

"Force" strategy is based on a specific roll force on the last active stand and a roll force "slope" which determines the reductions on the upstream stands in order to meet a constant relative strip profile. The slope itself is a subject to operator modifications, but the reduction each stand can not be modified separately.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 68
-----------------	--	--	--------------------	---------------------	------------

2.2.6.2 Buttons



Print generates and prints the model strip report for the strip, identified at *Slab ID*, at the laser printer in the finishing mill pulpit.

On/Off enables or disables the automatic printout of the process report for the actual strip. If enabled, printout is done at end of rolling in FM when the adaptation is finished.



Resets the actual thickness and speed adaptor set, depending on the actual value of the thickness adaptor.

If thickness adaptor (can be seen in window *Advanced*) reaches or exceeds the value of +/-10 mil, the adaptors are reset to half of the actual value.

If the thickness adaptor is below +/-10 mil, the adaptors are reset to 0 (zero).

Note !

After a work roll change in F5 or F6 or in all stands, the adaptors have to be reset.

The thickness adapter and the stand speed adapters compensate load gap

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 69
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
Operator Handbook
D4 - Displays and Dialogs




inaccuracies caused by latent changes in the no-load gaps and in the mill stretch during rolling.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 70
-----------------	--	--	--------------------	---------------------	------------



Opens the window Advanced Strategy Data;
Description please see chapter *Advanced Strategy Data* at page 71.




Starts for the strip, identified at *Slab ID*, the pass schedule precalculation.
If the button is pushed in **Default Mode**, the set points are **transmitted to the Level 1** system.
As soon as rolling in FM is started, the button is for the actually rolled strip disabled (message *Model start not allowed anymore*).

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 71
-----------------	--	--	--------------------	---------------------	------------

Dialogs:


Modify Descale:

Actual descaling practice can be modified;
parameters please see on page 62



Modify Speed Offset:

Speed of actual calculated pass schedule can be influenced;
parameters please see on page 64



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 72
-----------------	--	--	--------------------	---------------------	------------

Modify Thickn. Offset:

Finishing gauge of actual calculated pass schedule can be influenced;
parameters please see on page 65



Modify Draft:


Stand specific drafts of actual calculated pass schedule can be influenced



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 73
-----------------	--	--	--------------------	---------------------	------------

Modify Looper:


Looper strategy table can be modified;
Any modification will stay for the next material, rolled with the same looper strategy (see chapter *Steel Grade Reference Table* on page 34)



After pushing button OK, only the fields that have been modified, will be updated (e.g. if you set *Looper Angle* to 8 but leave *Looper Tension* empty, only the Looper Angle will be stored).

Modify SG Offset:


Pinch Roll Scale Breaker Side Guide and Stand Entry Side Guides can be opened or closed



Each time, the *Up* or *Down Arrow* button is clicked on, the actual side guide offset is increased or decreased by **250 mil.**


Maximum for the offset is **in both directions** (open and close) **1.0 inch.**

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 74
-----------------	--	--	--------------------	---------------------	------------



2.2.6.3 Advanced Strategy Data

Shows strategy parameters and switches, used in FM model.



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 75
-----------------	--	--	--------------------	---------------------	------------

2.2.6.3.1 Parameters

Rolling Strategy

Load

SW rolling strategy mode, "Load Strategy"

Force

SW rolling strategy mode, "Force Strategy"

Rolling Strategy "Force"

Maximum Relative Draft

TD upper limit for relative thickness reduction in "force"-strategy

Roll Force Slope

TD preset roll force slope in "Force Strategy"

Rolling Strategy "Load"

Original Relative Draft

TD preset relative draft from lookup table. This set of parameter can be changed by the operator in order to store an empiric good draft distribution.

Reset Rolling Strategy

OP push button to overwrite the operator changed relative drafts with the original settings shown in "Original Relative Drafts"

Reset action itself is done after confirming following box with OK.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 76
-----------------	--	--	--------------------	---------------------	------------

Switches

Calculation

SW switch pass schedule calculation at last pass RM ON/OFF

Adaption Fo/To

SW switch "force and torque online adaptation ON/OFF"

Adaption Temp

SW switch "temperature adaptation ON/OFF"

Limit Checks

SW switch "limit checks ON/OFF";
only relevant in "Load" strategy; in "Force" strategy the limit check is performed always.

In state "limit checks ON", the model checks not only for stand speed violations, but also for violations of the maximum roll force for each stand and the maximum motor load for each stand based on the limits set in "stand data" and "force utility" in the General Model Data.

If the target thickness can not be rolled without violating a limit, the alternate strip thickness from the piece data is targeted.

If there is no alternate strip thickness, the strip thickness will be increased by 0.04". In both cases, a red information message appears on the screen.

If this higher strip thickness can not be rolled, no pass schedule is created, and an error message appears.

Adaption Thick

SW switch "thickness adaptation ON/OFF"
Controls, if the pass schedule precalculation and the pass schedule calculation consider the actual thickness adapter (see next page) in their calculation.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 77
-----------------	--	--	--------------------	---------------------	------------

Adaption Speed

SW switch "stand speed adaptation ON/OFF"
The pass schedule precalculation and the pass schedule calculation consider the stand speed adapter set in their calculation. The adaptation updates the stand speed adapter set based on the stand speed measurement after the strip is rolled.

Long Term Ada

SW switch "stand speed and thickness long term adaptation ON/OFF".
Obsolete

This function was implemented to classify the thickness and speed adapter sets in to the gauge-, material-, width- and length classes.

Thick.Adapter Act.

DC actual thickness adapter;
The adaptation updates the actual thickness adapter based on the x-ray measurement after the strip is rolled and saves the previous value in *Thick.Adapter Prev.*

Thick.Adapter Prev.

DA thickness adapter of previous material


Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 78
-----------------	--	--	--------------------	---------------------	------------



2.2.6.3.2 Dialog Modify Advanced

Above described parameters and switches can be modified and will be updated and used after pushing *OK*.

Cancel exits the dialog *without* accepting any *changes*.




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 79
-----------------	--	--	--------------------	---------------------	------------

2.2.7 Setup Data Cooling

Shows the cooling setup for the selected slab

Display Layout:




Note: In this display the cooling setup can be modified directly by click on the particular cooling section but won't be updated on the system unless button



is pressed.

So if you modify sections and then enter Modify Mode without pushing the button Send Cooling Setup previously, the Modify screen has the origin settings, which differ to your previous changes.


Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 80
-----------------	--	--	--------------------	---------------------	------------



Dialogs:

Modify Cooling Setup:

Additionally to the cooling sections, cooling start and end timing can be modified (in seconds related to strip in mill F2).




Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 81
-----------------	--	--	--------------------	---------------------	------------



2.3 Material Tracking

2.3.1 Material Tracking Overview



Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 82
-----------------	--	--	--------------------	---------------------	------------

Dialogs:

Enter Coil Weight / Confirm Coil:

This dialog is used by the *Weighing and Banding Operator* to confirm or enter weight, disposition and defect code for a produced coil.

The display pops up with the data for the oldest coil within the weighing and banding queue (max. 5 coils).

Disposition and *Defect Codes* can be entered directly or by a single click on the corresponding line in the shown lists.


When button Confirm is pushed, the production result data are sent to the Level 3 system and the coil is removed from HSM Level 2.

Confirming a coil should be done as soon as weighing data are available.

Dont let the queue run full !

Should 5 coils already be waiting for confirmation and the next coil comes from

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 83
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
Operator Handbook
D4 - Displays and Dialogs



down coiler, the system automatically removes the oldest coil and sends it to Level 3.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 84
-----------------	--	--	--------------------	---------------------	------------


Delete Slab:



Similar to the *Confirm Coil Dialog* a certain slab is reported to Level 3 and removed from the system.

This dialog is used for taking a slab out of actual production (cobble, runback).

Pushing the button *Delete Slab*, the ID of the trouble maker has to be entered.



If the slab ID is invalid or not existing, following box appears



Further dialog is same as shown at *Confirm Coil*.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 85
-----------------	--	--	--------------------	---------------------	------------

Button Area:



Close display Tracking Overview




Open display *Roll Inventory* (see page 5)



Open display *Primary Data* (see page 3)



Open display *Setup Data RM* (see page 56)



Open display *Setup Data FM* (see page 60)




Open display *Setup Data Cooling* (see page 76)

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 86
-----------------	--	--	--------------------	---------------------	------------

2.3.2 Furnace Map

Display Layout:



First slab in list (top) is next to be discharged.

Slab dimensions (length, width and thickness) are the **dimensions at discharging temperature** (hot values).

Target strip dimensions (width and thickness) are the **dimensions at room temperature** (cold values).

The Furnace Map should give an overview about the next coming slabs and the actual temperatures. It displays whatever the Reheat Furnace computer sends (cyclically every 30 seconds). There is no active tracking behind.

Dialogs:

Furnace Map Request:

Requests the actual Furnace Map from the Reheat Furnace Level 2 computer.

Since the Furnace computer sends the map every 30 seconds, this function is practically not needed.

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 87
-----------------	--	--	--------------------	---------------------	------------




2.4 Actual Production Data

2.4.1 Primary Edger Area

This display shows actual Furnace and Primary Edger data.


Display Layout:



Dialogs:

None


Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 88
-----------------	--	--	--------------------	---------------------	------------



2.4.2 Roughing Mill Area

This display shows actual data for the Roughing Mill.

Display Layout:



Dialogs:

None

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 89
-----------------	--	--	--------------------	---------------------	------------

2.4.3 Finishing Mill Area

This display shows actual data for the Finishing Mill and strip cooling line.

Display Layout:



Dialogs:

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 90
-----------------	--	--	--------------------	---------------------	------------




ARMCO Hot Strip Mill
Documentation Level 2 System
Operator Handbook
D4 - Displays and Dialogs



None

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 91
-----------------	--	--	--------------------	---------------------	------------



3. Revision and Document Distribution List

<u>REVISION LIST</u>			
Date	Version	Author	Description
94-Dec-05	V1.0	F.Dvo.	first draft
95-Jan-30	V1.1	F.Dvo.	final version
95-Dec-30	V1.2	F.Dvo.	revision
96-Feb-28	as built	F.Dvo.	as built

<u>DISTRIBUTION LIST</u>	
Version	Receiver
as built	ARMCO

Author TAP 4	Document HSM_D4 Displays and Dialogs.doc		Date 1996-02-28	Version as built	Page 92
-----------------	--	--	--------------------	---------------------	------------