




A1 - Interfaces

Data Link to Level 1

Table of Contents

1. OVERVIEW	3
1.1 MESSAGES LEVEL 1 (ABB) --> LEVEL 2	3
1.2 MESSAGES LEVEL 1 (AGC) --> LEVEL 2	3
1.3 MESSAGES LEVEL 2 --> LEVEL 1 (ABB)	4
2. TRANSACTION DESCRIPTION ABB LINK	5
2.1 MESSAGES LEVEL 1 --> LEVEL 2	5
2.1.1 Tracking Event	5
2.1.2 PE - Start of Rolling	7
2.1.3 PE - End of Rolling	8
2.1.4 PE - Drive Status	9
2.1.5 RM - Start of Pass	10
2.1.6 RM - Measured Pass Data	12
2.1.7 RM - End of Pass	13
2.1.8 General Information RM Area	14
2.1.8.1 FM - Start of Rolling	15
2.1.8.2 FM - End of Rolling	16
2.1.8.3 FM - Measured Entry Data	17
2.1.8.4 FM - Measured Rolling Exit Data	18
2.1.8.5 FM - Measured Finishing Data	19
2.1.8.6 FM - Measured Stand Data	20
2.1.8.7 FM - State Change	21
2.2 MESSAGES LEVEL 2 --> LEVEL 1 (ABB)	22
2.2.1 Level 2 Watchdog	22
2.2.2 Level 2 Alarm Message	23
2.2.3 PE - Setup Data	24
2.2.4 PE - Stand Data	25
2.2.5 RM - Setup Data	26
2.2.5.1 RM Setup - Header Data	26
2.2.5.2 RM Setup - Pass Data	27
2.2.6 RM - Stand Data	28
2.2.7 FM - Setup Data	29
2.2.7.1 FM Setup - Header Data	29
2.2.7.2 FM Setup - Stand Specific Data	30
2.2.8 FM - Stand Data	31
2.2.9 Analysis Data	32
2.2.9.1 Part 1	32
2.2.9.2 Part 2	33

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc	Date 1996-02-28	Version as built	Page 1
-----------------	--	--------------------	---------------------	-----------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1



2.2.10 Cooling Setup Data	34
3. TRANSACTION DESCRIPTION INTEL LINK	35
3.1 GENERAL.....	35
3.2 MESSAGE FORMAT.....	35
3.2.1 Data Format.....	35
3.3 MESSAGE DEFINITIONS	38
3.3.1 Measured Rolling Data FM.....	38
3.3.2 FM Stretch Curve	40
3.3.3 FM Stand Calibration.....	41
4. APPENDIX.....	42
4.1 RECEIVE DEFINITION FILE	42
4.2 SEND DEFINITION FILE	48
5. REVISION AND DOCUMENT DISTRIBUTION LIST	50

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 2
-----------------	--	--	--------------------	---------------------	-----------

1. Overview


1.1 Messages Level 1 (ABB) --> Level 2

message	dsp no.
TRACKING EVENT	200
PE - START OF ROLLING	202
PE - END OF ROLLING	203
PE - DRIVE STATUS	204
RM - CALIBRATION	206
RM - START OF PASS	220
RM - MEASURED PASS DATA	221
RM - END OF PASS	222
GENERAL INFORMATION RM AREA	224
FM - START OF ROLLING	237
FM - END OF ROLLING	238
FM - MEASURED ENTRY DATA	239
FM - MEASURED EXIT DATA	240
FM - MEASURED FINISHING DATA	241
FM - MEASURED STAND DTA	191 - 196
FM - STATE CHANGE	246

1.2 Messages Level 1 (AGC) --> Level 2

message	dsp no.
FM MEASURED ROLLING DATA	-
FM STRETCH CURVE	-
FM STAND CALIBRATION	-

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 3
-----------------	--	--	--------------------	---------------------	-----------



1.3 Messages Level 2 --> Level 1 (ABB)

message	dsp no.
LEVEL 2 WATCHDOG	255
LEVEL 2 ALARM MESSAGE	254
PE - SETUP DATA	201
PE - STAND DATA	205
RM - SETUP DATA HEADER	210
RM - SETUP DATA PASS SPECIFIC	211 - 219
RM - STAND DATA	223
FM - SETUP DATA HEADER	230
FM - SETUP DATA STAND SPECIFIC	231 - 236
FM - STAND DATA	243
ANALYSIS DATA - PART 1	244
ANALYSIS DATA - PART 2	245
COOLING SETUP DATA	250

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 4
-----------------	--	--	--------------------	---------------------	-----------



2. Transaction Description ABB LINK

2.1 Messages Level 1 --> Level 2


2.1.1 Tracking Event

DSP no.: 200
Sender: HSM_MP4
Receiver: HSM_L2
Transmission Event: event concerning tracking occurred
Remarks: none

```
typedef struct                /* message structure */
{
    long    slabIdPE;          /* slab ID PE area (HMD 1 - HMD 7) */
    long    slabIdRM;          /* slab ID RM area (HMD 8 - HMD 17) */
    long    slabIdFM;          /* slab ID FM area */
    long    bitmap;            /* tracking bitmap */
                                /* 2**0 not used */
                                /* 2**1 HMD 1 */
                                /* 2**2 HMD 2 */
                                /* 2**3 HMD 3 */
                                /* 2**4 HMD 4 */
                                /* 2**5 HMD 5 */
                                /* 2**6 HMD 6 */
                                /* 2**7 HMD 7 */
                                /* 2**8 HMD 8 */
                                /* 2**9 HMD 9 */
                                /* 2**10 HMD 10 */
                                /* 2**11 HMD 11 */
                                /* 2**12 HMD 12 */
                                /* 2**13 HMD 13 */
                                /* 2**14 HMD 14 */
                                /* 2**15 HMD 15 */
                                /* 2**16 HMD 16 */
                                /* 2**17 HMD 17 */
}
```

... continued on next page

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 5
-----------------	--	--	--------------------	---------------------	-----------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1



```
/*      2**18 Stand F1      */
/*      2**19 Stand F2      */
/*      2**20 Stand F3      */
/*      2**21 Stand F4      */
/*      2**22 Stand F5      */
/*      2**23 Stand F6      */
/*      2**24 Pyrometer behind F6      */
/*      2**25 Pyrometer in front of DC */
long      eventCode;      /* tracking event code */
/*      2**0 PE (set at start of      */
/*      edging - reset at end)      */
/*      2**1 RM (set at start of pass */
/*      reset at end of pass)      */
/*      2**2 FM (set at start of      */
/*      rolling - reset at end      */

} LV1_MsgTraEve, *LV1_MsgTraEvePtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 6
-----------------	--	--	--------------------	---------------------	-----------




2.1.2 PE - Start of Rolling

DSP no.: 202
Sender: HSM_MP1
Receiver: HSM_L2
Transmission Event: Slab head enters PE
Remarks: none

```
typedef struct          /* message structure          */
{
    long      slabId;      /* slab identification          */
    long      edgAdjust;    /* edger adjust [in. x 10**2]  */
    long      speed;       /* speed PE      [fpm]         */
} LV1_MsgPEstartRol, *LV1_MsgPEstartRolPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 7
-----------------	--	--	--------------------	---------------------	-----------



2.1.3 PE - End of Rolling

DSP no.: 203
Sender: HSM_MP1
Receiver: HSM_L2
Transmission Event: Slab tail leaves PE
Remarks: none

```
typedef struct                /* message structure          */  
{  
    long        slabId;        /* slab identification    */  
} LV1_MsgPEendRol,    *LV1_MsgPEendRolPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 8
-----------------	--	--	--------------------	---------------------	-----------



2.1.4 PE - Drive Status

DSP no.: 204
Sender: HSM_MP1
Receiver: HSM_L2
Transmission Event: Cyclically every minute
Remarks: none

```
typedef struct          /* message structure          */  
{  
    long                status;          /* 0 = PE-Drive OFF, 1 = PE-Drive ON*/  
                                /* sent cyclically every minute      */  
} LV1_MsgPEdriveStatus, *LV1_MsgPEdriveStatusPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 9
-----------------	--	--	--------------------	---------------------	-----------



2.1.5 RM - Calibration

DSP no.: 206
Sender: HSM_MP2
Receiver: HSM_L2
Transmission Event: Calibration of RM finished
Remarks: none

```
typedef struct          /* message structure          */
{
    long      force;      /* calibration force center [ton] */
    float     screwDownOS; /* calib. screw down OS [in] */
    float     screwDownDS; /* calib. screw down DS [in] */
} LV1_MsgRmcalibration, *LV1_MsgRmcalibrationPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 10
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



2.1.6 RM - Start of Pass

DSP no.: 220
Sender: HSM_MP2
Receiver: HSM_L2
Transmission Event: Start of pass in RM
Remarks: none

```
typedef struct          /* message structure          */
{
    long    slabId;      /* slab identification          */
    long    pasNo;       /* actual pass number          */
    long    blindActive; /* blind - active indicator    */
                        /* 0 ... blind pass          */
                        /* 1 ... active pass          */
    long    indiLastPas; /* indication last pass started: */
                        /* 0 ... not yet last pass    */
                        /* 1 ... last pass started    */

    long    edgAdjust;   /* actual edger adjust [in. x 10**2] */
                        /* -1 = not used (even pass)    */
    long    speedRMDT;   /* actual speed RMDT [fpm]      */
    long    rollCooling; /* roll cooling (0 = OFF / 1 = ON) */
} LV1_MsgRMstartPas, *LV1_MsgRMstartPasPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 11
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



2.1.7 RM - Measured Pass Data

DSP no.: 221
Sender: HSM_MP2
Receiver: HSM_L2
Transmission Event: cyclically (200 - 300ms), starting at signal strip in RM
Remarks: none

```
typedef struct          /* message structure          */
{
    long    slabId;      /* slab identification          */
    long    pasNo;       /* actual pass number          */
    long    blindActive; /* blind - active indicator    */
                        /* 0 ... blind pass           */
                        /* 1 ... active pass           */
    long    seqNo;       /* measurement sequence number */
    float    location;   /* material location [fpm]     */
                        /* location 0 for head on odd pass */
                        /* location 0 for tail on even pas */
    float    timeStartPas; /* time from start of pass [s] */
    long    tempEntry;   /* material temp. entry side [oF] */
    long    tempDel;     /* material temp. delivery side [oF] */
    long    RMforceOS;   /* RM roll force operator side [ton] */
    long    RMforceDS;   /* RM roll force drive side [ton] */
    long    RMtorque;    /* RM roll torque [ft.lb.] */
    long    RMspeed;     /* RM rolling speed [fpm] */
    long    RMScrewDownDS; /* RM screw down Drive Side */
                        /* (no load gap) [in x 10**3] */
    long    RMScrewDownOS; /* RM screw down Operator Side */
                        /* (no load gap) [in x 10**3] */
    long    edgAdjust;   /* actual edger adjust [in. x 10**2] */
                        /* -1 = not used (even pass) */
    float    current;    /* motor current [amp] */
    float    volt;       /* motor volts [volt] */
    float    descPressure; /* descaling pressure [psi] */
    long    operMode;    /* RM operation mode: */
                        /* 0 ... manual mode */
                        /* 1 ... level 1 mode */
                        /* 2 ... level 2 mode */
} LV1_MsgRMmeaPasDat, *LV1_MsgRMmeaPasDatPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 12
-----------------	--	--	--------------------	---------------------	------------




2.1.8 RM - End of Pass

DSP no.: 222
Sender: HSM_MP2
Receiver: HSM_L2
Transmission Event: End of pass in RM
Remarks: none

```
typedef struct                /* message structure          */
{
    long        slabId;        /* slab identification    */
    long        pasNo;         /* actual pass number     */
} LV1_MsgRMendPas,    *LV1_MsgRMendPasPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 13
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



2.1.9 General Information RM Area

DSP no.: 224
Sender: HSM_MP2
Receiver: HSM_L2
Transmission Event: Table cover position or descaler state changed
Remarks: none

```
typedef struct                /* message structure */
{
    long      posTableCover; /* position table cover 1 - 4: */
    /*          +----- CLOSED */
    /*          | +----- INTERMEDIATE POS. */
    /*          | | +-- OPEN */
    /*          | | | */
    /* +--+ +--+ +--+ */
    /* 0000 0000 0000 */
    /* |||| |||| |||| Bit */
    /* |||| |||| |||+ 2**0 Tab.Cov. 1 */
    /* |||| |||| ||+- 2**1 Tab.Cov. 2 */
    /* |||| |||| |+-- 2**2 Tab.Cov. 3 */
    /* |||| |||| +--- 2**3 Tab.Cov. 4 */
    /* |||| |||| */
    /* |||| |||+----- 2**4 Tab.Cov. 1 */
    /* |||| ||+----- 2**5 Tab.Cov. 2 */
    /* |||| |+----- 2**6 Tab.Cov. 3 */
    /* |||| +----- 2**7 Tab.Cov. 4 */
    /* |||| */
    /* |||+----- 2**8 Tab.Cov. 1 */
    /* ||+----- 2**9 Tab.Cov. 2 */
    /* |+----- 2**10 Tab.Cov. 3 */
    /* +----- 2**11 Tab.Cov. 4 */
    /* */
    /* all other bits not used */
    /* */
    long      descalerState; /* descaler state: */
    /* bit 2**0 primary descaler south */
    /* bit 2**1 primary descaler north */
    /* bit 2**2 RM descaler entry top */
    /* bit 2**3 RM descaler entry bot */
    /* bit 2**4 RM descaler deliv top */
    /* bit 2**5 RM descaler deliv bot */
} LV1_MsgRMgenInfo, *LV1_MsgRMgenInfoPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 14
-----------------	--	--	--------------------	---------------------	------------



2.1.9.1 FM - Start of Rolling

DSP no.: 237
Sender: HSM_MP4
Receiver: HSM_L2
Transmission Event: Signal "Strip in Mill" at stand F1
Remarks: none

```
typedef struct          /* message structure          */
{
    long      slabId;     /* slab identification          */
    long      descBitmap; /* descaling bitmap PR scale breaker*/
                                /* bit 2**0 Descale South      */
                                /* bit 2**1 Descale North      */
    long      operMode;   /* FM operation mode:          */
                                /* 0 ... manual mode           */
                                /* 1 ... level 1 mode           */
                                /* 2 ... level 2 mode           */
} LV1_MsgFMstartRol, *LV1_MsgFMstartRolPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 15
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



2.1.9.2 FM - End of Rolling

DSP no.: 238
Sender: HSM_MP4
Receiver: HSM_L2
Transmission Event: Strip tail end leaves F6
Remarks: none

```
typedef struct          /* message structure */
{
    long    slabId;      /* slab identification */
    float   totStripLen; /* total strip length [ft] */
    long    coolPattern; /* actual selected cooling pattern */
    /* bit 2**0 spare */
    /* Top cooling sprays: */
    /* bit 2**1 section 1 */
    /* bit 2**2 section 2 Main */
    /* bit 2**3 section 3 Cooling */
    /* bit 2**4 section 4 Section */
    /* bit 2**5 section 5 */
    /* bit 2**6 section 6 */
    /* bit 2**7 section 7 Trim */
    /* bit 2**8 section 8 Cooling */
    /* bit 2**9 section 9 Section */
    /* bit 2**10 section 10 */
    /* Bottom cooling sprays: */
    /* bit 2**11 section 1 */
    /* bit 2**12 section 2 */
    /* bit 2**13 section 3 */
    /* bit 2**14 section 4 */
    long    curLimitReached; /* bitmap for current limit reached */
    /* bit 2**0 spare */
    /* bit 2**1 stand F1 */
    /* bit 2**2 stand F2 */
    /* bit 2**3 stand F3 */
    /* bit 2**4 stand F4 */
    /* bit 2**5 stand F5 */
    /* bit 2**6 stand F6 */
    long    manualSpeedCorr; /* manual speed correction */
    /* -1 ... speed decrease */
    /* 0 ... no correction */
    /* 1 ... speed increase */
} LV1_MsgFMendRol, *LV1_MsgFMendRolPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc	Date 1996-02-28	Version as built	Page 16
-----------------	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



2.1.9.3 FM - Measured Entry Data

DSP no.: 239
Sender: HSM_MP4
Receiver: HSM_L2
Transmission Event: cyclically (200 - 300ms), starting at first temperature reading from FM entry pyrometer
Remarks: none

```
typedef struct          /* message structure          */
{
    long    slabId;      /* slab identification          */
    long    seqNo;       /* measurement sequence number */
    long    speedRT;     /* Speed roller table (RMDT) [fpm] */
    float   timePyr;     /* time since TB head entered   */
                                /* pyrometer [s]                */
    long    temp;        /* actual temp. of segment [oF] */

    float   lubeFlowRateF1; /* actual flow rate F1 [Gpm] */
    float   lubeFlowRateF2; /* actual flow rate F2 [Gpm] */
    float   lubeFlowRateF3; /* actual flow rate F3 [Gpm] */
    float   lubeFlowRateF4; /* actual flow rate F4 [Gpm] */

} LV1_MsgFMmeaEntryDat, *LV1_MsgFMmeaEntryDatPtr;
```

Remarks: **lubeFlowRateFx**
while no strip in mill, value has to be zero (0.0)

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 17
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



2.1.9.4 FM - Measured Rolling Exit Data

DSP no.: 240
Sender: HSM_MP4
Receiver: HSM_L2
Transmission Event: cyclically (200 - 300ms), starting at first measurement from gauge meter behind F6
Remarks: none

```
typedef struct          /* message structure          */
{
    long    slabId;      /* slab identification          */
    long    seqNo;       /* measurement sequence number */
    float    location;   /* strip location (0. for head) [ft] */
    long    thick;       /* X-Ray thickness cold [in x 10**3] */
    long    width;       /* width gauge [in x 10**2] */
    long    temp;        /* temperature [oF] */
    long    profile;     /* average profile [in x 10**5] */
    long    wedge;       /* wedge [in x 10**5] */
    long    edgeDropOS;  /* edge drop [in x 10**5] */
    long    edgeDropDS;  /* edge drop [in x 10**5] */
    long    devCentLine; /* centerline deviation [in x 10**5] */
    float    shapeFactor; /* shape factor [%] */
    float    delTime;    /* delta time since head passed [s] */
    long    coolPattern; /* actual cooling pattern */
    /* bit 2**0 spare */
    /* Top cooling sprays: */
    /* bit 2**1 section 1 */
    /* bit 2**2 section 2 Main */
    /* bit 2**3 section 3 Cooling */
    /* bit 2**4 section 4 Section */
    /* bit 2**5 section 5 */
    /* bit 2**6 section 6 */
    /* bit 2**7 section 7 Trim */
    /* bit 2**8 section 8 Cooling */
    /* bit 2**9 section 9 Section */
    /* bit 2**10 section 10 */
    /* Bottom cooling sprays: */
    /* bit 2**11 section 1 */
    /* bit 2**12 section 2 */
    /* bit 2**13 section 3 */
    /* bit 2**14 section 4 */
    long    actProfile;  /* act. profile reading [in x 10**5] */
    /* -1 = start/end of cycle */
    long    actProfilePos; /* position of act. profile reading */
    /* (width) [in x 10**2] */

} LV1_MsgFMmeaExitDat, *LV1_MsgFMmeaExitDatPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc	Date 1996-02-28	Version as built	Page 18
-----------------	--	--------------------	---------------------	------------




2.1.9.5 FM - Measured Finishing Data

DSP no.: 241
Sender: HSM_MP4
Receiver: HSM_L2
Transmission Event: cyclically (200 - 300ms), starting at first temperature reading from down coiler entry side pyrometer
Remarks: none

```
typedef struct                /* message structure          */
{
    long    slabId;            /* slab identification      */
    long    seqNo;             /* measurement sequence number */
    float    location;         /* strip location (0. for head) [ft] */
    long    temp;              /* temperature [oF]         */
    float    delTime;          /* delta time since head passed [s] */
} LV1_MsgFMmeaFinDat, *LV1_MsgFMmeaFinDatPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 19
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1



2.1.9.6 FM - Measured Stand Data

DSP no.: 191 - Stand F1
 192 - Stand F2
 193 - Stand F3
 194 - Stand F4
 195 - Stand F5
 196 - Stand F6

Sender: HSM_MP4

Receiver: HSM_L2

Transmission Event: cyclically (200 - 300ms), starting at signal
 "Strip in Mill"

Remarks: none

```
typedef struct                               /* message structure               */
{
    long           slabId;                   /* slab identification               */
    long           seqNo;                   /* measurement sequence number       */
    float          delTime;                 /* delt.time since strip in mill [s] */
    float          current;                 /* motor current [amp]               */
    float          volt;                    /* motor volts [volt]                */
    float          looperAngle;            /* actual looper angle [deg]         */
    float          speed;                  /* rolling speed [fpm]               */
} LV1_MsgFMmeaStandDat, *LV1_MsgFMmeaStandDatPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 20
-----------------	--	--	--------------------	---------------------	------------




2.1.9.7 FM - State Change

DSP no.: 246
Sender: HSM_MP4
Receiver: HSM_L2
Transmission Event: - State of a stand has changed (operator input L1 MMI)
Remarks: none

```
typedef struct                /* message structure          */
{
    long          stateMap;    /* actual state bitmap:      */
                                /* bit set    ... stand active */
                                /* bit clear ... dummy stand  */
                                /*                               */
                                /* bit 2**0  spare           */
                                /* bit 2**1  stand F1         */
                                /* bit 2**2  stand F2         */
                                /* bit 2**3  stand F3         */
                                /* bit 2**4  stand F4         */
                                /* bit 2**5  stand F5         */
                                /* bit 2**6  stand F6         */
                                /*                               */
} LV1_MsgFMstateChange, *LV1_MsgFMstateChangePtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 21
-----------------	--	--	--------------------	---------------------	------------



2.2 Messages Level 2 --> Level 1 (ABB)

2.2.1 Level 2 Watchdog

DSP no.: 255
Sender: HSM_L2
Receiver: HSM_MP2
Transmission Event: cyclically every 6 sec.
Remarks: none

```
typedef struct          /* message structure          */
{
    long      hours;      /* L2 system time - hours          */
    long      minutes;    /* L2 system time - minutes        */
    long      seconds;    /* L2 system time - seconds        */
    long      flag;       /* watchdog flag (always 1)        */
} LV1_MsgL2Watchdog, *LV1_MsgL2WatchdogPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 22
-----------------	--	--	--------------------	---------------------	------------



2.2.2 Level 2 Alarm Message

DSP no.: 254
Sender: HSM_L2
Receiver: HSM_MP2
Transmission Event: one of following listed alarms goes ON or OFF
Remarks: none

```
typedef struct          /* message structure          */
{
    long                bitmap01; /* alarm bitmap:          */
                                /* bit set   = Alarm is ON      */
                                /* bit clear = Alarm is OFF    */
                                /*          */
                                /* 2**0 - AGC link to level 2 down */
                                /* 2**1 through          */
                                /* 2**31 not used          */
                                /*          */
} LV1_MsgL2Alarm, *LV1_MsgL2AlarmPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 23
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1




2.2.3 PE - Setup Data

DSP no.: 201
Sender: HSM_L2
Receiver: HSM_MP1
Transmission Event: - Charging of 1. slab into furnace
- Furnace discharging
- Last pass finished (for next slab in furnace)
Remarks: none

```
typedef struct          /* message structure          */
{
    long    slabId;      /* slab identification          */
    float   slabLen;     /* slab length [ft.]          */
    long    slabWidth;   /* slab width [in. x 10**2]    */
    long    slabThick;   /* slab thickness [in. x 10**3] */
    long    edgAdjust;   /* edger adjust [in. x 10**2]   */
} LV1_MsgPEsetup, *LV1_MsgPEsetupPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 24
-----------------	--	--	--------------------	---------------------	------------



2.2.4 PE - Stand Data

DSP no.: 205
Sender: HSM_L2
Receiver: HSM_MP1
Transmission Event: Operator on level 2 has entered PE roll diameters
Remarks: none

```
typedef struct          /* message structure          */  
{  
    long                rollDia;          /* roll diameter  [in. x 10**2]  */  
} LV1_MsgPEstandData, *LV1_MsgPEstandDataPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 25
-----------------	--	--	--------------------	---------------------	------------



2.2.5 RM - Setup Data

This message consists of several DSP's:

210 Setup header data
211 Setup data for pass 1
212 Setup data for pass 2
:
219 Setup data for pass 9

2.2.5.1 RM Setup - Header Data

DSP no.: 210
Sender: HSM_L2
Receiver: HSM_MP2
Transmission Event: - Charging of 1. slab into furnace
- Furnace discharging
- Last pass finished (for next slab in furnace)
Remarks: all dimensions are related to hot material

```
typedef struct                /* message structure          */
{
    long    slabId;            /* slab identification        */
    long    pasSchNo;          /* adjusted pass schedule number */
    float    slabLen;          /* slab length [ft.]         */
    long    slabWidth;         /* slab width [in. x 10**2]   */
    long    slabThick;         /* slab thickness [in. x 10**3] */
    long    tgtWidthTB;        /* target transfer bar width  */
                                /* [in. x 10**2]              */
    long    tgtThickTB;        /* target transfer bar thickness */
                                /* [in. x 10**3]              */
    long    slabDischTemp;     /* average slab discharg. temp [oF] */
    long    descSpeed;         /* descaling speed [fpm]      */
    long    totPasNo;          /* total number of passes     */

} LV1_MsgRMsetupHdr, *LV1_MsgRMsetupHdrPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 26
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1




2.2.5.2 RM Setup - Pass Data

DSP no.: 211 - 219
Sender: HSM_L2
Receiver: HSM_MP2
Transmission Event: In continuation of Setup Header Data RM
Remarks: all dimensions are related to hot material

```
typedef struct          /* message structure          */
{
    long                blindActive; /* blind - active indicator          */
                                /* 0 ... blind pass                  */
                                /* 1 ... active pass                  */
    long                posSGRMET; /* position side guide RM entry tabl*/
                                /* [in. x 10**2]                      */
    long                posSGRMDT; /* position side guide RM deliv.tabl*/
                                /* [in. x 10**2]                      */
    long                edgAdjust; /* edger adjust                      */
                                /* -1 = not used (even pass)          */
                                /* [in. x 10**2]                      */
    long                screwDown; /* rougher screw down [in. x 10**3] */
    long                millEntrySpeed; /* mill entry speed [fpm]          */
    long                millRunSpeed; /* mill run speed [fpm]            */
    long                edgEntrySpeed; /* edger entry speed [fpm]          */
    long                edgRunSpeed; /* edger run speed [fpm]            */
    long                descBitmap; /* descaling bitmap                  */
                                /* bit 2**0 primary descaler south*/
                                /* bit 2**1 primary descaler north*/
                                /* bit 2**2 RM descaler entry top */
                                /* bit 2**3 RM descaler entry bot */
                                /* bit 2**4 RM descaler deliv top */
                                /* bit 2**5 RM descaler deliv bot */
} LV1_MsgRMsetupPas, *LV1_MsgRMsetupPasPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 27
-----------------	--	--	--------------------	---------------------	------------



2.2.6 RM - Stand Data

DSP no.: 223
Sender: HSM_L2
Receiver: HSM_MP2
Transmission Event: - Operator on L2 has completed roll change for RM
- Operator has entered new RM-Edger roll diameter
Remarks: none

```
typedef struct          /* message structure          */
{
    long                indicator; /* indicator for roll kind          */
                                /* 1 ... is RM-Edger roll diam      */
                                /* 2 ... is RM work roll diam       */
    long                rollDia;   /* roll diameter [in x 10**2]       */
} LV1_MsgRMstandData, *LV1_MsgRMstandDataPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 28
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



2.2.7 FM - Setup Data

This message consists of several DSP's:


230 Setup header data
231 Setup data for stand F1
232 Setup data for stand F2
:
236 Setup data for stand F6

2.2.7.1 FM Setup - Header Data

DSP no.: 230
Sender: HSM_L2
Receiver: HSM_MP4
Transmission Event: - Furnace discharging
- Last pass RM
Remarks: none

```
typedef struct /* message structure */
{
    long slabId; /* slab identification */
    long pasSchNo; /* adjusted pass schedule number */
    /* 0 ... pass schedule from model */
    /* >0 ... pass schedule from table */
    long widthTB; /* transfer bar width [in x 10**2] */
    long thickTB; /* transf.bar thickness [in x 10**3] */
    long finalWidthHot; /* tgt strip width hot[in x 10**2] */
    long tgtTempF6; /* target temperature after F6 [oF] */
    long posSGPR; /* position PR scale breaker side */
    /* guide [in x 10**2] */
    long speedPR; /* speed PR scale breaker [fpm] */
    long descBitmapPR; /* descaling bitmap PR scale breaker */
    /* bit 2**0 Descale South */
    /* bit 2**1 Descale North */
    long timOnSouth; /* time to be ON - descale SOUTH [s] */
    long timOnNorth; /* time to be ON - descale NORTH [s] */
    long interStandCoolMap; /* Interstand cooling map: */
    /* bit 2**1 header between F1-F2 */
    /* bit 2**2 header between F2-F3 */
    /* 0 = header OFF */
    /* 1 = header ON */
    long timeF1F2ON; /* Duration of cooling between F1-F2 */
    long timeF2F3ON; /* Duration of cooling between F2-F3 */
    long finalWidthCold; /* target strip width cold */
    /* [in x 10**2] */
    long tgtStripThickHot; /* tgt strip thick.hot [in x 10**3] */
    long tgtStripThickCold; /* tgt strip thick.cold [in x 10**3] */
} LV1_MsgFMsetupHdr, *LV1_MsgFMsetupHdrPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 29
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



2.2.7.2 FM Setup - Stand Specific Data

DSP no.: 231-236
Sender: HSM_L2
Receiver: HSM_MP4
Transmission Event: In continuation of Setup Header Data FM
Remarks: none

```
typedef struct          /* message structure          */
{
    long    posEntrySG;  /* position stand entry side guide  */
                        /* [in x 10**2]                      */
    long    speed;       /* speed main drive [fpm]           */
    long    force;       /* roll force [ton]                 */
    long    exitThick;   /* stand exit thickness [in x 10**3]*/

    long    fwSlip;      /* forward slip [% x 10**2]         */
    long    bwSlip;      /* backward slip [% x 10**2]        */
    long    stretch;    /* stretch [in x 10**3]            */
    long    rollWear;    /* roll wear [in x 10**3]           */
    long    thermCrown;  /* thermal crown [in x 10**3]       */
    long    asymFinValue; /* asymptotic final value           */
                        /* [in x 10**3]                     */
    long    timeConstCrown; /* time constant thermal crown [s] */

    long    looperAngle; /* looper angle (for F6 empty) [deg]*/
    long    looperTension; /* spec tension (F6 empty) [deg] */

} LV1_MsgFMsetupStand, *LV1_MsgFMsetupStandPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 30
-----------------	--	--	--------------------	---------------------	------------



2.2.8 FM - Stand Data

DSP no.: 243
Sender: HSM_L2
Receiver: HSM_MP4
Transmission Event: Operator on level 2 has completed roll change
Remarks: none

```
typedef struct                /* message structure          */
{
    struct
    {
        long        rollDiaBRtop; /* roll diameter backup roll top    */
                                /* [in x 10**2]                      */
        long        rollDia;      /* roll diameter work roll          */
                                /* [in x 10**3]                      */
        long        rollDiaBRbot; /* roll diameter backup roll bottom */
                                /* [in x 10**2]                      */
    } stand[6];
} LV1_MsgFMstandData, *LV1_MsgFMstandDataPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 31
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



2.2.9 Analysis Data

2.2.9.1 Part 1

DSP no.: 244
Sender: HSM_L2
Receiver: HSM_MP4
Transmission Event: Furnace discharging
Remarks: none

```
typedef struct /* message structure */
{
    long    slabId; /* slab identification */
    long    nomThick; /* nominal thickn. cold [in x 10**3] */
    union
    {
        long    l[2]; /* steel grade in longword format */
        short    w[2]; /* steel grade in word format */
        char    c[8]; /* steel grade in ASCII format */
    } grade;
    long    estStripTemp; /* estimated strip temperature [oF] */
    float    eleFe; /* Fe [%] */
    float    eleC; /* C [%] */
    float    eleMn; /* Mn [%] */
    float    eleP; /* P [%] */
    float    eleS; /* S [%] */
    float    eleSi; /* Si [%] */
    float    eleCu; /* Cu [%] */
    float    eleNi; /* Ni [%] */
    float    eleCr; /* Cr [%] */
    float    eleMo; /* Mo [%] */
    float    eleSn; /* Sn [%] */
    float    eleV; /* V [%] */
    float    eleAl; /* Al [%] */
    float    elePb; /* Pb [%] */
    long    numSteelGrade; /* numeric steel grade */
} LV1_MsgAnaDataPl, *LV1_MsgAnaDataPlPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 32
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1



2.2.9.2 Part 2

DSP no.: 245
Sender: HSM_L2
Receiver: HSM_MP4
Transmission Event: In continuation to Analysis Data Part 1
Remarks: none

```
typedef struct                /* message structure          */
{
    float    eleCo;           /* Co [%]                */
    float    eleZr;           /* Zr [%]                */
    float    eleNb;           /* Nb [%]                */
    float    eleCe;           /* Ce [%]                */
    float    eleW;            /* W [%]                */
    float    eleTi;           /* Ti [%]                */
    float    eleN2;           /* N2 [%]                */
} LV1_MsgAnaDataP2, *LV1_MsgAnaDataP2Ptr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 33
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1



2.2.10 Cooling Setup Data

DSP no.: 250
Sender: HSM_L2
Receiver: HSM_MP4
Transmission Event: - Furnace discharging
- Operator pushed button "Send" at L2 MMI
Remarks: none

```
typedef struct          /* message structure          */
{
    long    slabId;      /* slab identification          */
    long    tgtCoilTemp; /* target coiling temperature [oF] */
    long    coolPattern; /* cooling pattern:              */
                        /* bit 2**0 spare              */
                        /* Top cooling sprays:          */
                        /* bit 2**1 section 1          */
                        /* bit 2**2 section 2    Main  */
                        /* bit 2**3 section 3    Cooling */
                        /* bit 2**4 section 4    Section */
                        /* bit 2**5 section 5          */
                        /* bit 2**6 section 6          */
                        /* bit 2**7 section 7    Trim   */
                        /* bit 2**8 section 8    Cooling */
                        /* bit 2**9 section 9    Section */
                        /* bit 2**10 section 10         */
                        /* Bottom cooling sprays:      */
                        /* bit 2**11 section 1         */
                        /* bit 2**12 section 2         */
                        /* bit 2**13 section 3         */
                        /* bit 2**14 section 4         */

    long    durCoolStartF2; /* duration cool.start after F2 [s] */
    long    durCoolEndF2;  /* duration cool.end after F2 [s] */
} LV1_MsgCoolSetup, *LV1_MsgCoolSetupPtr;
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 34
-----------------	--	--	--------------------	---------------------	------------



3. Transaction Description INTEL Link

3.1 General

This chapter specifies the messages which are exchanged between HSM Level 1 AGC (Automatic Gauge Control), realized on INTEL systems, and HSM Level 2 system.

The logical link and message transfer is based on TCP/IP.

3.2 Message Format

Messages have variable length and consist of a *Header Part* and a *Data Part*. The general message format is defined in figure 6 on next page.

3.2.1 Data Format

AnASCII representation of an integer with the length **n**


An.dASCII representation of a float with total length **n** (decimal point included) and **d** digits behind decimal point:

Example: A8.2 = "00123.12"

Data values contain leading zeros.

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 35
-----------------	--	--	--------------------	---------------------	------------


Figure 6 - Message format INTEL link



Header Part:

<i>message ID</i>	format: A4 message identification
<i>message type</i>	format: A4 message type; specifies how the message contents has to be interpreted: "0001" ... binary message "0002" ... ASCII message "0003" ... test message
<i>index</i>	format: A4 continuous message index "0001" - "9999"

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc	Date 1996-02-28	Version as built	Page 36
-----------------	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1



message size

format: A4
length of *Data Part* in byte

reserved

format: A4
reserved

Data Part:

value 1 - n

data values 1 to n
contents and data format is described in chapter
Message Definitions

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 37
-----------------	--	--	--------------------	---------------------	------------



3.3 Message Definitions

3.3.1 Measured Rolling Data FM

Message ID / Size: 0001 / 1272 Byte
Sender: AGC
Receiver: HSM_L2
Transmission Event: cyclically (200 ms), starting at signal *Strip in Mill*
Remarks: none

no.		min	max	format	explanation
1	-	1	6	A8	Stand number
2	-	100000	999999	A8	Slab ID
3	-	1	12	A8	<i>nBlocks</i> - Number of data blocks Following data will be repeated up to <i>nBlocks</i> :
4	-	1	99999	A8	Measurement sequence number
5	ft.	0.00	9999.99	A8.2	Strip location (0. for head)
6	ms	0	999999	A8	Delta time since strip in stand
7	in.	0.000	9.9999	A8.4	Load gap
8	in.	0.000	9.9999	A8.4	Screw down operator side
9	in.	0.000	9.9999	A8.4	Screw down drive side
10	fpm	0	9999	A8	Speed main drive
11	tons	0	6000	A8	Roll force operator side
12	tons	0	6000	A8	Roll force drive side
13		0	9999	A8	Roll torque
14	in.	0.000	9.9999	A8.4	X-Ray thickness (F6 only)
15	in.	0.000	9.9999	A8.4	Monitor feedback

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 38
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1



16	-	0	11000000	A8	AGC info block (0/1): 00000000 + AGC overload reached +- DMC gauge used +-- WESTON gauge used +--- manual Gap change +----- Monitor On/Off
----	---	---	----------	----	---

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 39
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1



3.3.2 FM Stretch Curve

Message ID / Size: 0002 / 1336 Byte
Sender: AGC
Receiver: HSM_L2
Transmission Event: - Measurement ready
- Stretch curve accepted by operator (at L1 MMI)
Remarks: none

no.		min	max	format	explanation
1	-	1	6	A8	Stand number
<i>Following 5 items are repeated 28 times:</i>					
2	-	1	255	A8	Setpoint number (value 255 terminates the list)
3	tons	0	6000	A8	Setpoint force center
4	in.	0.000	9.9999	A8.4	Setpoint position (average)
5	in.	0.000	9.9999	A8.4	Setpoint position operator side
6	in.	0.000	9.9999	A8.4	Setpoint position drive side
142	-	0	11000000	A8	AGC information: 00000000 +--- Bad calibration = 1 +----- Coeff. changed = 1
143	mil.	0.0	1.0	A16	Mill stretch coefficient 1
144	mil.	0.0	1.0	A16	Mill stretch coefficient 2
145	mil.	0.0	1.0	A16	Mill stretch coefficient 3
146	mil.	0.0	1.0	A16	Mill stretch coefficient 4
147	mil.	0.0	1.0	A16	Mill stretch coefficient 5
148	mil.	0.0	1.0	A16	Mill stretch coefficient 6
149	mil.	0.0	1.0	A16	Mill stretch coefficient 7
150	mil.	0.0	1.0	A16	Mill stretch coefficient 8
151	in.	0.0	9.9	A8.4	Zero point offset
152	in.	0.0	9.9	A8.4	Zero point offset OS
153	in.	0.0	9.9	A8.4	Zero point offset DS
154	mil/ton	0.0	99.9	A8.4	Slope
155	mil/ton	0.0	99.9	A8.4	Slope OS
156	mil/ton	0.0	99.9	A8.4	Slope DS
157	tons	0	999	A8.4	Force standard deviation
158	tons	0	999	A8.4	Force standard deviation OS

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 40
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill
Documentation Level 2 System
A1 - Interfaces / Data Link to Level 1



159	tons	0	999	A8.4	Force standard deviation DS
-----	------	---	-----	------	-----------------------------

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 41
-----------------	--	--	--------------------	---------------------	------------



3.3.3 FM Stand Calibration

Message ID / Size: 0003 / 176 Byte
Sender: AGC
Receiver: HSM_L2
Transmission Event: Automatic calibration cycle completed
Remarks: none

no.		min	max	format	explanation
1	-	1	6	A8	Stand number
3	tons	0	6000	A8	Setpoint force center
4	in.	0.000	9.9999	A8.4	Setpoint position (average)
5	in.	0.000	9.9999	A8.4	Setpoint position operator side
6	in.	0.000	9.9999	A8.4	Setpoint position drive side
7	-	0	1100000	A8	AGC information: 00000000 +--- Bad calibration = 1 +----- Coeff. changed = 1
8	mil.	0.0	1.0	A16	Mill stretch coefficient 1
9	mil.	0.0	1.0	A16	Mill stretch coefficient 2
10	mil.	0.0	1.0	A16	Mill stretch coefficient 3
11	mil.	0.0	1.0	A16	Mill stretch coefficient 4
12	mil.	0.0	1.0	A16	Mill stretch coefficient 5
13	mil.	0.0	1.0	A16	Mill stretch coefficient 6
14	mil.	0.0	1.0	A16	Mill stretch coefficient 7
15	mil.	0.0	1.0	A16	Mill stretch coefficient 8

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 42
-----------------	--	--	--------------------	---------------------	------------



ARMCO Hot Strip Mill

Documentation Level 2 System

A1 - Interfaces / Data Link to Level 1



4. Appendix

4.1 Receive Definition File

Following table defines all at Level 2 received DSP's.
The table is stored on node **MSOHSM** in the file
LV1\$EXE:REC_DEFINE.HSM.

```
!
!=====
!
! File: REC_DEFINE.HSM          Date: 14-Jul-94 / Dop      Version: 1.7          Revised: 28-Jul-95 / Dvo          Page: 1 / 5
!
! Data Set Packet and Subscription Definition File for receiving data from ABB Level-1 Basic Automation System rolling Mill (HSM)
!
! For the interpretation of data, please refer to "ABB Link User's Manual"
!
!=====
!
! Definition of Hardware Environment:
! =====
!
! VAX_netw  VAX_node  ABB_netw
! -----
! $ 69      60      61
!
!      +-- Node 1 - HSM_MP1 - PLC Primary Edger
!      +-- Node 2 - HSM_MP4 - PLC Finishing Mill
!      +-- Node 3 - HSM_MP2 - PLC Roughing Mill 1
!      +-- Node 4 - HSM_MP3 - PLC Roughing Mill 2
!      +-- Node 7 - HSM_MP4A - PLC Communication (GCOM card)
!
!
! Definition of Data Set Packets receiving from ABB L1-System:
! =====
!
! 1 2 3 4 5 6 7 8 9 10 11 12 13
! 234567890123456789012345678901234567890123456789012345678901234567890123456789012345678901234567890
!
!-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
!NO|Description of Data|Nd|Name/IdentNo|DD|T12|LEVEL-2 VARIABLE|TR|Cvt.Val|CG|GR|BID1|BID2|BUFINS|V|
!##|#####|##|$$$$$$$$$$$$$$$$|##|$$$|12345678901234567890| $|#####|$$|##|####|####|$$$$$$$$$$$$$$$| $|
!-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
!
! Tracking Event
! =====
! DSP 200 / HSM_MP4
! -----
!
! 001| Slab Id PE | 2| 200 | 0|DLL|traSlabIdPE| C| 0|P| 1|1200| 0| |X|
! 002| Slab Id RM | 2| 200 | 1|DLL|traSlabIdRM| C| 0| 0| 0| 0| 0| |X|
! 003| Slab Id FM | 2| 200 | 2|DLL|traSlabIdFM| C| 0| 0| 0| 0| 0| |X|
! 004| Tracking Bitmap | 2| 200 | 3|DLL|traBitmap| C| 0| 0| 0| 0| 0| |X|
! 005| Tracking Event Code | 2| 200 | 4|DLL|traEventCode| C| 0| 0| 0| 0| 0| |X|
!-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
!
```

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc	Date 1996-02-28	Version as built	Page 43
-----------------	--	--------------------	---------------------	------------

[illegible]

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 44
-----------------	--	--	--------------------	---------------------	------------

[illegible]

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 48
-----------------	--	--	--------------------	---------------------	------------

[illegible]

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 50
-----------------	--	--	--------------------	---------------------	------------



5. Revision and Document Distribution List

<u>REVISION LIST</u>			
Date	Version	Author	Description
95-Aug-28	V1.0	F.Dvo.	first draft
95-Sep-04	V1.1	F.Dvo.	revision
96-Feb-28	as built	F.Dvo.	as built

<u>DISTRIBUTION LIST</u>	
Version	Receiver
V1.0	VAI / H. Beer
V1.1	VAI / H. Beer
as built	ARMCO

Author TAP 4	Document HSM_A11 Interfaces Level 1.doc		Date 1996-02-28	Version as built	Page 51
-----------------	--	--	--------------------	---------------------	------------