

# USBX™ Host Stack

User Guide

Renesas Synergy™ Platform  
Synergy Software  
Synergy Software (SSP) Component

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.  
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.  
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.  
Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

# Renesas Synergy Specific Information

If you are using USBX Host Stack for the Renesas Synergy platform, please use the following information.

## Customer Support

For Renesas Synergy platform support, please contact Renesas directly:

Support: <https://synergycastle.renesas.com/support>

America: <https://www.renesas.com/en-us/support/contact.html>

Europe: <https://www.renesas.com/en-eu/support/contact.html>

Japan: <https://www.renesas.com/ja-jp/support/contact.html>

## Isochronous Transfer Type Not Supported

**Page 7:** Isochronous transfer is only supported for USB Host. This transfer type is not supported for USB Device.

## Installation and Use of USBX Host

**Page 10:** If you are using Renesas Synergy SSP and the e<sup>2</sup> studio ISDE, USBX Host will already be installed. You can ignore the Installation section.

## Unsupported Classes/Features

**Page 66 and following:** The following classes or features are not supported in SSP v1.5.0:

- USBX host class pima
- USBX host class asix
- USBX host class audio
- USBX host class gser
- USBX host class printer
- USBX host class dpump
- USBX Pictbridge implementation
- USBX OTG
- USB composite devices



the high performance USB stack

# User Guide for USBX Host Stack

Express Logic, Inc.  
858.613.6640  
Toll Free 888.THREADX  
FAX 858.521.4259

<http://www.expresslogic.com>

**©1999-2017 by Express Logic, Inc.**

All rights reserved. This document and the associated USBX software are the sole property of Express Logic, Inc. Each contains proprietary information of Express Logic, Inc. Reproduction or duplication by any means of any portion of this document without the prior written consent of Express Logic, Inc. is expressly forbidden.

Express Logic, Inc. reserves the right to make changes to the specifications described herein at any time and without notice in order to improve design or reliability of USBX. The information in this document has been carefully checked for accuracy; however, Express Logic, Inc. makes no warranty pertaining to the correctness of this document.

## **Trademarks**

FileX, and ThreadX are registered trademarks of Express Logic, Inc., and USBX, NetX, *picokernel*, *preemption-threshold*, and *event-chaining* are trademarks of Express Logic, Inc. All other product and company names are trademarks or registered trademarks of their respective holders.

## **Warranty Limitations**

Express Logic, Inc. makes no warranty of any kind that the USBX products will meet the USER's requirements, or will operate in the manner specified by the USER, or that the operation of the USBX products will operate uninterrupted or error-free, or that any defects that may exist in the USBX products will be corrected after the warranty period. Express Logic, Inc. makes no warranties of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, with respect to the USBX products. No oral or written information or advice given by Express Logic, Inc., its dealers, distributors, agents, or employees shall create any other warranty or in any way increase the scope of this warranty and licensee may not rely on any such information or advice.

Part Number: 000-1010

Revision 5.8SP2

# Contents

<b>Contents .....</b>	<b>3</b>
<b>About This Guide .....</b>	<b>7</b>
<b>Chapter 1: Introduction to USBX .....</b>	<b>8</b>
USBX features .....	8
Product Highlights .....	9
Powerful Services of USBX .....	9
Multiple Host Controller Support .....	9
USB Software Scheduler .....	9
Complete USB Device Framework Support .....	9
Easy-To-Use APIs .....	9
<b>Chapter 2: USBX Installation .....</b>	<b>11</b>
Host Considerations .....	11
Computer Type .....	11
Download Interfaces .....	11
Debugging Tools .....	11
Required Hard Disk Space .....	11
Target Considerations .....	11
Configuration Options .....	14
Source Code Tree .....	17
Initialization of USBX resources .....	18
Uninitialization of USBX resources .....	19
Definition of USB Host Controllers .....	19
Definition of Host Classes .....	20
Troubleshooting .....	22
USBX Version ID .....	22
<b>Chapter 3: Functional Components of USBX Host Stack .....</b>	<b>23</b>
Execution Overview: .....	23
Initialization .....	24
Application Interface Calls .....	24
USB Host Stack APIs .....	24
USB Host Class APIs .....	24
Root Hub .....	25
Hub Class .....	25

USB Host Stack.....	25
Topology Manager.....	25
USB Class Binding .....	25
USBX APIs .....	26
Host Controller.....	26
Root Hub .....	27
Power Management .....	27
Endpoints .....	27
Transfers .....	27
USB Device Framework .....	28
Device Descriptors .....	30
Configuration Descriptors .....	33
Interface Descriptors .....	35
Endpoint Descriptors .....	38
String descriptors .....	41
Functional Descriptors.....	43
USBX Device Descriptor Framework in Memory.....	43
<b>Chapter 4: Description of USBX Host Services .....</b>	<b>45</b>
ux_host_stack_initialize.....	46
ux_host_stack_endpoint_transfer_abort .....	47
ux_host_stack_class_get .....	48
ux_host_stack_class_register .....	49
ux_host_stack_class_instance_create .....	50
ux_host_stack_class_instance_destroy .....	51
ux_host_stack_class_instance_get.....	52
ux_host_stack_device_configuration_get.....	53
ux_host_stack_device_configuration_select .....	54
ux_host_stack_device_get.....	56
ux_host_stack_interface_endpoint_get.....	57
ux_host_stack_hcd_register.....	59
ux_host_stack_configuration_interface_get .....	61
ux_host_stack_interface_setting_select.....	62
ux_host_stack_transfer_request_abort .....	63
ux_host_stack_transfer_request .....	64
<b>Chapter 5: USBX Host Classes API .....</b>	<b>66</b>
ux_host_class_printer_read .....	67
ux_host_class_printer_write .....	68
ux_host_class_printer_soft_reset.....	69
ux_host_class_printer_status_get.....	70
ux_host_class_audio_read.....	71
ux_host_class_audio_write .....	72
ux_host_class_audio_control_get.....	73

ux_host_class_audio_control_value_set.....	74
ux_host_class_audio_streaming_sampling_set.....	75
ux_host_class_audio_streaming_sampling_get.....	76
ux_host_class_hid_client_register .....	78
ux_host_class_hid_report_callback_register.....	79
ux_host_class_hid_periodic_report_start.....	80
ux_host_class_hid_periodic_report_stop .....	81
ux_host_class_hid_report_get .....	83
ux_host_class_hid_report_set.....	84
ux_host_class_hid_mouse_button_get .....	85
ux_host_class_hid_mouse_position_get.....	86
ux_host_class_hid_keyboard_key_get.....	87
ux_host_class_hid_remote_control_usage_get .....	89
ux_host_class_asix_read .....	91
ux_host_class_asix_write.....	92
ux_host_class_cdc_acm_read .....	93
ux_host_class_cdc_acm_write.....	94
ux_host_class_cdc_acm_ioctl.....	95
ux_host_class_cdc_ecm_read.....	97
ux_host_class_cdc_ecm_write.....	98
ux_host_class_pima_session_open.....	99
ux_host_class_pima_session_close .....	100
ux_host_class_pima_storage_ids_get .....	101
ux_host_class_pima_storage_info_get .....	102
ux_host_class_pima_num_objects_get.....	103
ux_host_class_pima_object_handles_get.....	106
ux_host_class_pima_object_info_get.....	108
ux_host_class_pima_object_info_send.....	110
ux_host_class_pima_object_open .....	112
ux_host_class_pima_object_get .....	114
ux_host_class_pima_object_send .....	116
ux_host_class_pima_thumb_get.....	119
ux_host_class_pima_object_delete.....	121
ux_host_class_pima_object_close .....	123
ux_host_class_gser_read .....	125
ux_host_class_gser_write .....	126
ux_host_class_gser_ioctl .....	127
ux_host_class_gser_reception_start.....	129
ux_host_class_gser_reception_stop .....	130
<b>Chapter 6: USBX DPUMP Class Considerations .....</b>	<b>131</b>
USBX DPUMP Host Class .....	132
USBX DPUMP Device Class.....	134
<b>Chapter 7: USBX Pictbridge implementation.....</b>	<b>135</b>



Pictbridge client implementation .....	136
ux_pictbridge_jobinfo_object_data_read .....	140
Pictbridge host implementation.....	141
ux_pictbridge_application_object_data_write .....	143
<b>Chapter 8: USBX OTG .....</b>	<b>144</b>
<b>Index .....</b>	<b>147</b>

# ***About This Guide***

This guide provides comprehensive information about USBX, the high performance USB foundation software from Express Logic, Inc.

It is intended for the embedded real-time software developer. The developer should be familiar with standard real-time operating system functions, the USB specification, and the C programming language.

For technical information related to USB, see the USB specification and USB Class specifications that can be downloaded at <http://www.USB.org/developers>

## **Organization**

**Chapter 1** contains an introduction to USBX

**Chapter 2** gives the basic steps to install and use USBX with your ThreadX application

**Chapter 3** provides a functional overview of USBX and basic information about USB

**Chapter 4** details the application's interface to USBX in host mode

**Chapter 5** is titled USBX DPUMP Class Considerations

**Chapter 6** is titled USBX Pictbridge Implementation

**Chapter 7** is titled USBX OTG

# Chapter 1: Introduction to USBX

USBX is a full-featured USB stack for deeply embedded applications. This chapter introduces USBX, describing its applications and benefits.


## USBX features

USBX support the three existing USB specifications: 1.1, 2.0 and OTG. It is designed to be scalable and will accommodate simple USB topologies with only one connected device as well as complex topologies with multiple devices and cascading hubs. USBX supports all the data transfer types of the USB protocols: control, bulk, interrupt, and isochronous.

USBX supports both the host side and the device side. Each side is comprised of three layers:

- Controller layer
- Stack layer
- Class layer

The relationship between the USB layers is as follows:



## **Product Highlights**

- Complete ThreadX processor support
- No royalties
- Complete ANSI C source code
- Real-time performance
- Responsive technical support
- Multiple host controller support
- Multiple class support
- Multiple class instances
- Integration of classes with ThreadX, FileX and NetX
- Support for USB devices with multiple configuration
- Support for USB composite devices
- Support for cascading hubs
- Support for USB power management
- Support for USB OTG
- Export trace events for TraceX

## **Powerful Services of USBX**

### **Multiple Host Controller Support**

USBX can support multiple USB host controllers running concurrently. This feature allows USBX to support the USB 2.0 standard using the backward compatibility scheme associated with most USB 2.0 host controllers on the market today.

### **USB Software Scheduler**

USBX contains a USB software scheduler necessary to support USB controllers that do not have hardware list processing. The USBX software scheduler will organize USB transfers with the correct frequency of service and priority, and will instruct the USB controller to execute each transfer.

### **Complete USB Device Framework Support**

USBX can support the most demanding USB devices, including multiple configurations, multiple interfaces, and multiple alternate settings.

### **Easy-To-Use APIs**

USBX provides the very best deeply embedded USB stack in a manner that is easy to understand and use. The USBX API makes the services intuitive and consistent. By using the provided USBX class APIs, the user application does not need to understand the complexity of the USB protocols.



# ***Chapter 2: USBX Installation***

## **Host Considerations**

### **Computer Type**

Embedded development is usually performed on Windows PC or Unix host computers. After the application is compiled, linked, and located on the host, it is downloaded to the target hardware for execution.

### **Download Interfaces**

Usually, the target download is done over an RS-232 serial interface, although parallel interfaces, USB, and Ethernet are becoming more popular. See the development tool documentation for available options.

### **Debugging Tools**

Debugging is done typically over the same link as the program image download. A variety of debuggers exist, ranging from small monitor programs running on the target through Background Debug Monitor (BDM) and In-Circuit Emulator (ICE) tools. Of course, the ICE tool provides the most robust debugging of actual target hardware.

### **Required Hard Disk Space**

The source code for USBX is delivered in ASCII format and requires approximately 500 KBytes of space on the host computer's hard disk. Please review the supplied *readme\_usbx.txt* file for additional host system considerations and options.

## **Target Considerations**

USBX requires between 24 KBytes and 64 KBytes of Read Only Memory (ROM) on the target in host mode. The amount of memory required is dependent on the type of controller used and the USB classes linked to USBX. Another 32 KBytes of the target's Random Access Memory (RAM) are required for USBX global data structures and memory pool. This memory pool can also be adjusted depending on the expected number of devices on the USB and the type of USB controller. The USBX device side requires roughly 10-12K of ROM depending on the type of device controller. The RAM memory usage depends on the type of class emulated by the device.

USBX also relies on ThreadX semaphores, mutexes, and threads for multiple thread protection, and I/O suspension and periodic processing for monitoring the USB bus topology.

## Product Distribution

Two USBX packages are available—standard and premium. The standard package includes minimal source code, while the premium package contains the complete USBX source code. Either package is shipped on a single CD.

The content of the distribution CD depends on the target processor, development tools, and the USBX package. Following is a list of the important files common to most product distributions:

<b><i>readme_usb.txt</i></b>	This file contains specific information about the USBX port, including information about the target processor and the development tools.
<b><i>ux_api.h</i></b>	This C header file contains all system equates, data structures, and service prototypes.
<b><i>ux_port.h</i></b>	This C header file contains all development-tool-specific data definitions and structures.
<b><i>ux.lib</i></b>	This is the binary version of the USBX C library. It is distributed with the standard package.
<b><i>demo_usb.c</i></b>	The C file containing a simple USBX demo

All filenames are in lower-case. This naming convention makes it easier to convert the commands to Unix development platforms.

Installation of USBX is straightforward. The following general instructions apply to virtually any installation. However, the ***readme\_usb\_generic.txt*** file should be examined for changes specific to the actual development tool environment.

- Step 1: Backup the USBX distribution disk and store it in a safe location.
- Step 2: Use the same directory in which you previously installed ThreadX on the host hard drive. All USBX names are unique and will not interfere with the previous USBX installation.
- Step 3: Add a call to ***ux\_system\_initialize*** at or near the beginning of ***tx\_application\_define***. This is where the USBX resources are initialized.
- Step 4: Add a call to ***ux\_host\_stack\_initialize***.
- Step 5: Add one or more calls to initialize the required USBX
- Step 6: Add one or more calls to initialize the host controllers available in the system.
- Step 7: It may be required to modify the *tx\_low\_level\_initialize.c* file to add low level hardware initialization and interrupt vector routing. This is specific to the hardware platform and will not be discussed here.

Step 8: Compile application source code and link with the USBX and ThreadX run time libraries (FileX and/or Netx may also be required if the USB storage class and/or USB network classes are to be compiled in), ux.a (or ux.lib) and tx.a (or tx.lib). The resulting can be downloaded to the target and executed!



# Configuration Options

There are several configuration options for building the USBX library. All options are located in the ***ux\_port.h***.

The list below details each configuration option. Additional development tool options are described in the ***readme\_usbx.txt*** file supplied on the distribution disk:

## UX\_PERIODIC\_RATE

This value represents how many ticks per seconds for a specific hardware platform. The default is 1000 indicating 1 tick per millisecond.

## UX\_MAX\_CLASS\_DRIVER

This value is the maximum number of classes that can be loaded by USBX. This value represents the class container and not the number of instances of a class. For instance, if a particular implementation of USBX needs the hub class, the printer class, and the storage class, then the UX\_MAX\_CLASS\_DRIVER value can be set to 3 regardless of the number of devices that belong to these classes.

## UX\_MAX\_HCD

This value represents the number of different host controllers that are available in the system. For USB 1.1 support, this value will mostly be 1. For USB 2.0 support this value can be more than 1. This value represents the number of concurrent host controllers running at the same time. If for instance, there are two instances of OHCI running or one EHCI and one OHCI controllers running, the UX\_MAX\_HCD should be set to 2.

## UX\_MAX\_DEVICES

This value represents the maximum number of devices that can be attached to the USB. Normally, the theoretical maximum number on a single USB is 127 devices. This value can be scaled down to conserve memory. It should be noted that this value represents the total number of devices regardless of the number of USB buses in the system.

## UX\_MAX\_ED

This value represents the maximum number of EDs in the controller pool. This number is assigned to one controller only. If multiple instances of controllers are present, this value is used by each individual controller.

## UX\_MAX\_TD and UX\_MAX\_ISO\_TD

This value represents the maximum number of regular and isochronous TDs in the controller pool. This number is assigned to one controller only. If multiple instances of controllers are present, this value is used by each individual controller

## UX\_THREAD\_STACK\_SIZE

This value is the size of the stack in bytes for the USBX threads. It can be typically 1024 or 2048 bytes depending on the processor used and the host controller.

## UX\_HOST\_ENUM\_THREAD\_STACK\_SIZE

This value is the stack size of the USB host enumeration thread. If this symbol is not set, the USBX host enumeration thread stack size is set to UX\_THREAD\_STACK\_SIZE.

## UX\_HOST\_HCD\_THREAD\_STACK\_SIZE

This value is the stack size of the USB host HCD thread. If this symbol is not set, the USBX host HCD thread stack size is set to UX\_THREAD\_STACK\_SIZE.

## UX\_HOST\_HNP\_POLLING\_THREAD\_STACK\_SIZE

This value is the stack size of the USB host HNP polling thread. If this symbol is not set, the USBX host HNP polling thread stack size is set to UX\_THREAD\_STACK\_SIZE. Note that the HNP Polling thread is only used in USB OTG.

## UX\_THREAD\_PRIORITY\_ENUM

This is the ThreadX priority value for the USBX enumeration threads that monitors the bus topology.

## UX\_THREAD\_PRIORITY\_CLASS

This is the ThreadX priority value for the standard USBX threads.

## UX\_THREAD\_PRIORITY\_KEYBOARD

This is the ThreadX priority value for the USBX HID keyboard class.

UX\_THREAD\_PRIORITY\_HCD

This is the ThreadX priority value for the host controller thread.

UX\_NO\_TIME\_SLICE


If defined to 1, the ThreadX target port does not use time slice.

UX\_MAX\_HOST\_LUN

This value represents the maximum number of SCSI logical units represented in the host storage class driver

# Source Code Tree

The USBX files are provided in several directories.



In order to make the files recognizable by their names, the following convention has been adopted:

File Suffix Name	File description
ux_host_stack	usbh host stack core files
ux_host_class	usbh host stack classes files
ux_hcd	usbh host stack controller driver files
ux_device_stack	usbh device stack core files
ux_device_class	usbh device stack classes files
ux_dcd	usbh device stack controller driver files
ux_otg	usbh otg controller driver related files
ux_pictbridge	usbh pictbridge files
ux_utility	usbh utility functions
demo_usbh	demonstration files for USBH

## Initialization of USBH resources

USBH has its own memory manager. The memory needs to be allocated to USBH before the host or device side of USBH is initialized. USBH memory manager can accommodate systems where memory can be cached.

The following function initializes USBH memory resources with 128K of regular memory and no separate pool for cache safe memory:

```
/* Initialize USBH Memory */
ux_system_initialize(memory_pointer, (128*1024), UX_NULL, 0);
```

The prototype for the ux\_system\_initialize is as follows:

```
UINT ux_system_initialize(VOID *regular_memory_pool_start,
                          ULONG regular_memory_size,
                          VOID *cache_safe_memory_pool_start,
                          ULONG cache_safe_memory_size)
```

Input parameters:

VOID *regular_memory_pool_start	Beginning of the regular memory pool
ULONG regular_memory_size	Size of the regular memory pool
VOID *cache_safe_memory_pool_start	Beginning of the cache safe memory pool
ULONG cache_safe_memory_size	Size of the cache safe memory pool

Not all systems require the definition of cache safe memory. In such a system, the values passed during the initialization for the memory pointer will be set to UX\_NULL and the size of the pool to 0. USBH will then use the regular memory pool in lieu of the cache safe pool.

In a system where the regular memory is not cache safe and a controller requires to perform DMA memory (like OHCI, EHCI controllers amongst others) it is necessary to define a memory pool in a cache safe zone.

## Uninitialization of USBX resources

USBX can be terminated by releasing its resources. Prior to terminating usb, all classes and controller resources need to be terminated properly. The following function uninitializes USBX memory resources :

```
/* Unitialize USBX Resources */  
ux_system_uninitialize();
```

The prototype for the `ux_system_initialize` is as follows:

```
UINT ux_system_uninitialize(VOID);
```

## Definition of USB Host Controllers

It is required to define at least one USB host controller for USBX to operate in host mode. The application initialization file should contain this definition. The following line performs the definition of a generic host controller:

```
ux_host_stack_hcd_register("ux_hcd_controller",  
    ux_hcd_controller_initialize, 0xd0000, 0x0a);
```

The `ux_host_stack_hcd_register` has the following prototype:

```
UINT ux_host_stack_hcd_register(CHAR_PTR hcd_name,  
    UINT (*hcd_initialize_function)(struct UX_HCD_STRUCT *),  
    ULONG hcd_param1,  
    ULONG hcd_param2);
```

The `ux_host_stack_hcd_register` function has the following parameters:

<code>hcd_name:</code>	string of the controller name
<code>hcd_initialize_function:</code>	initialization function of the controller
<code>hcd_param1:</code>	usually the IO value or Memory used by the controller
<code>hcd_param2:</code>	usually the IRQ used by the controller

In our previous example:

"ux\_hcd\_controller" is the name of the controller,  
ux\_hcd\_controller\_initialize is the initialization routine for the host controller,

0xd0000 is the address at which the host controller registers are visible in memory, and 0x0a is the IRQ used by the host controller.

Following is an example of the initialization of USBX in host mode with one host controller and several classes.

```
UINT  status;

/* Initialize USBX. */
ux_system_initialize(memory_ptr, (128*1024),0,0);

/* The code below is required for installing the USBX host stack. */
status = ux_host_stack_initialize(UX_NULL);

/* If status equals UX_SUCCESS, host stack has been initialized. */

/* Register all the host classes for this USBX implementation. */
status = ux_host_class_register("ux_host_class_hub",
                                ux_host_class_hub_entry);

/* If status equals UX_SUCCESS, host class has been registered. */

status = ux_host_class_register("ux_host_class_storage",
                                ux_host_class_storage_entry);

/* If status equals UX_SUCCESS, host class has been registered. */

status = ux_host_class_register("ux_host_class_printer",
                                ux_host_class_printer_entry);

/* If status equals UX_SUCCESS, host class has been registered. */

status = ux_host_class_register("ux_host_class_audio",
                                ux_host_class_audio_entry);

/* If status equals UX_SUCCESS, host class has been registered. */

/* Register all the USB host controllers available in this system. */
status = ux_host_stack_hcd_register("ux_hcd_controller",
                                    ux_hcd_controller_initialize,
                                    0x300000, 0x0a);

/* If status equals UX_SUCCESS, USB host controllers have been
registered. */
```

## Definition of Host Classes

It is required to define one or more host classes with USBX. A USB class is required to drive a USB device after the USB stack has configured the USB device. A USB class is very specific to the device. One or more classes may be required to drive a USB device depending on the number of interfaces contained in the USB device descriptors.

This is an example of the registration of the HUB class:

```
status = ux_host_stack_class_register("ux_host_class_hub",  
                                     ux_host_class_hub_entry);
```

The function `ux_host_class_register` has the following prototype:

```
UINT ux_host_stack_class_register(CHAR_PTR class_name,  
                                  UINT (*class_entry_address)  
                                  (struct UX_HOST_CLASS_COMMAND_STRUCT *))
```

`class_name` is the name of the class

`class_entry_address` is the entry point of the class

In the example of the HUB class initialization:

"ux\_host\_class\_hub" is the name of the hub class

`ux_host_class_hub_entry` is the entry point of the HUB class.



## Troubleshooting

USBX is delivered with a demonstration file and a simulation environment. It is always a good idea to get the demonstration platform running first—either on the target hardware or a specific demonstration platform.

If the demonstration system does not work, try the following things to narrow the problem:

## USBX Version ID

The current version of USBX is available both to the user and the application software during run-time.

The programmer can obtain the USBX version from examination of the ***usbx\_generic.txt*** file. In addition, this file also contains a version history of the corresponding port. Application software can obtain the USBX version by examining the global string ***\_ux\_version\_id***, which is defined in ***ux\_port.h***.

# Chapter 3: Functional Components of USBX Host Stack


This chapter contains a description of the high performance USBX embedded USB host stack from a functional perspective.

## Execution Overview:

USBX is composed of several components:

- Initialization
- Application interface calls
- Root Hub
- Hub Class
- Host Classes
- USB Host Stack
- Host controller

The following diagram illustrates the USBX host stack:



## Initialization

In order to activate USBX, the function ***ux\_system\_initialize*** must be called. This function initializes the memory resources of USBX.

In order to activate USBX host facilities, the function ***ux\_host\_stack\_initialize*** must be called. This function will in turn initialize all the resources used by the USBX host stack such as ThreadX threads, mutexes, and semaphores.

It is up to the application initialization to activate at least one USB host controller and one or more USB classes. When the classes have been registered to the stack and the host controller(s) initialization function has been called the bus is active and device discovery can start. If the root hub of the host controller detects an attached device, the USB enumeration thread, in charge of the USB topology, will be wake up and proceed to enumerate the device(s).

It is possible, due to the nature of the root hub and downstream hubs, that all attached USB devices may not have been configured completely when the host controller initialization function returns. It can take several seconds to enumerate all USB devices, especially if there are one or more hubs between the root hub and USB devices.

## Application Interface Calls

There are two levels of APIs in USBX:

- USB Host Stack APIs
- USB Host Class APIs

Normally, a USBX application should not have to call any of the USB host stack APIs. Most applications will only access the USB Class APIs.

### USB Host Stack APIs

The host stack APIs are responsible for the registration of USBX components (host classes and host controllers), configuration of devices, and the transfer requests for available device endpoints.

### USB Host Class APIs

The Class APIs are very specific to each USB class. Most of the common APIs for USB classes provide services such as opening/closing a device and reading from and writing to a device.

## Root Hub

Each host controller instance has one or more USB root hubs. The number of root hubs is either determined by the nature of the controller or can be retrieved by reading specific registers from the controller.

## Hub Class

The hub class is in charge of driving USB hubs. A USB hub can either be a stand-alone hub or as part of a compound device such as a keyboard or a monitor. A hub can be self-powered or bus-powered. Bus-powered hubs have a maximum of four downstream ports and can only allow for the connection of devices that are either self-powered or bus-powered devices that use less than 100mA of power. Hubs can be cascaded. Up to five hubs can be connected to one another.

## USB Host Stack

The USB host stack is the centerpiece of USBX. It has three main functions:

- Manage the topology of the USB.
- Bind a USB device to one or more classes.
- Provide an API to classes to perform device descriptor interrogation and USB transfers.

## Topology Manager

The USB stack topology thread is awakened when a new device is connected or when a device has been disconnected. Either the root hub or a regular hub can accept device connections. Once a device has been connected to the USB, the topology manager will retrieve the device descriptor. This descriptor will contain the number of possible configurations available for this device. Most devices have one configuration only. Some devices can operate differently according to the available power available on the port where it is connected. If this is the case, the device will have multiple configurations that can be selected depending on the available power. When the device is configured by the topology manager, it is then allowed to draw the amount of power specified in its configuration descriptor.

## USB Class Binding

When the device is configured, the topology manager will let the class manager continue the device discovery by looking at the device interface descriptors. A device can have one or more interface descriptors.

An interface represents a function in a device. For instance, a USB speaker has three interfaces, one for audio streaming, one for audio control, and one to manage the various speaker buttons.

The class manager has two mechanisms to join the device interface(s) to one or more classes. It can either use the combination of a PID/VID (product ID and vendor ID) found in the interface descriptor or the combination of Class/Subclass/Protocol.

The PID/VID combination is valid for interfaces that cannot be driven by a generic class. The Class/Subclass/Protocol combination is used by interfaces that belong to a USB-IF certified class such as a printer, hub, storage, audio, or HID.

The class manager contains a list of registered classes from the initialization of USBX. The class manager will call each class one at a time until one class accepts to manage the interface for that device. A class can only manage one interface. For the example of the USB audio speaker, the class manager will call all the classes for each of the interfaces.

Once a class accepts an interface, a new instance of that class is created. The class manager will then search for the default alternate setting for the interface. A device may have one or more alternate settings for each interface. The alternate setting 0 will be the one used by default until a class decides to change it.

For the default alternate setting, the class manager will mount all the endpoints contained in the alternate setting. If the mounting of each endpoint is successful, the class manager will complete its job by returning to the class that will finish the initialization of the interface.

## **USBX APIs**

The USB stack exports a certain number of APIs for the USB classes to perform interrogation on the device and USB transfers on specific endpoints. These APIs are described in detail in this reference manual.

## **Host Controller**

The host controller driver is responsible for driving a specific type of USB controller. A USB host controller can have multiple controllers inside. For instance, certain Intel PC chipset contain two UHCI controllers. Some USB 2.0 controllers contain multiple instances of an OHCI controller in addition to one instance of the EHCI controller.

The Host controller will manage multiple instance of the same controller only. In order to drive most USB 2.0 host controllers, it will be required to initialize both the OHCI controller and the EHCI controller during the initialization of USBX.

The host controller is responsible for managing the following:

- Root Hub
- Power Management
- Endpoints
- Transfers

## **Root Hub**

The root hub management is responsible for the powering up of each controller port and determining if there is a device inserted or not. This functionality is used by the USBX generic root hub to interrogate the controller downstream ports.

## **Power Management**

The power management processing provides for the handling of suspend/resume signals either in gang mode, therefore affecting all controller downstream ports at the same time, or individually if the controller offers this functionality.

## **Endpoints**

The endpoint management provides for the creation or destruction of physical endpoints to the controller. The physical endpoints are memory entities that are parsed by the controller if the controller supports master DMA or that are written in the controller. The physical endpoints contain transactions information to be performed by the controller.

## **Transfers**


Transfer management provides for a class to perform a transaction on each of the endpoints that have been created. Each logical endpoint contains a component called TRANSFER REQUEST for USB transfer requests. The TRANSFER REQUEST is used by the stack to describe the transaction. This TRANSFER REQUEST is then passed to the stack and to the controller, which may divide it into several sub transactions depending on the capabilities of the controller.

# USB Device Framework

A USB device is represented by a tree of descriptors. There are six main types of descriptors:


- Device descriptors
- Configuration descriptors
- Interface descriptors
- Endpoint descriptors
- String descriptors
- Functional descriptors

A USB device may have a very simple description and looks like this:



In the above illustration, the device has only one configuration. A single interface is attached to this configuration, indicating that the device has only one function, and it has one endpoint only. Attached to the device descriptor is a string descriptor providing a visible identification of the device.

However, a device may be more complex and may appear as follows:



In the above illustration, the device has two configuration descriptors attached to the device descriptor. This device may indicate that it has two power modes or can be driven by either standard classes or proprietary classes.

Attached to the first configuration are two interfaces indicating that the device has two logical functions. The first function has 3 endpoint descriptors and a functional descriptor. The functional descriptor may be used by the class responsible to drive the interface to obtain further information about this interface normally not found by a generic descriptor.



## Device Descriptors

Each USB device has one single device descriptor. This descriptor contains the device identification, the number of configurations supported, and the characteristics of the default control endpoint used for configuring the device.

Offset	Field	Size	Value	Description
0	BLength	1	Number	Size of this descriptor in bytes
1	bDescriptorType	1	Constant	DEVICE Descriptor Type
2	bcdUSB	2	BCD	<p>USB Specification Release Number in Binary-Coded Decimal</p> <p>Example: 2.10 is equivalent to 0x210. This field identifies the release of the USB Specification that the device and its descriptors are compliant with.</p>
4	bDeviceClass	1	Class	<p>Class code (assigned by USB-IF).</p> <p>If this field is reset to 0, each interface within a configuration specifies its own class information and the various interfaces operate independently.</p> <p>If this field is set to a value between 1 and 0xFE, the device supports different class specifications on different interfaces and the interfaces may not operate independently. This value identifies the class definition used for the aggregate interfaces.</p> <p>If this field is set to 0xFF, the device class is vendor specific.</p>
5	bDeviceSubClass	1	SubClass	<p>Subclass code (assigned by USB-IF).</p> <p>These codes are qualified by the value of the bDeviceClass field. If the bDeviceClass field is reset to 0, this field must also be reset to 0. If the bDeviceClass field is not set to 0xFF, all values are reserved for assignment by USB.</p>
6	bDeviceProtocol	1	Protocol	<p>Protocol code (assigned by USB-IF).</p> <p>These codes are qualified by the value of the bDeviceClass and the bDeviceSubClass fields. If a device supports class-specific protocols on a device basis as opposed to an interface basis, this code identifies the protocols that the device uses as defined by the specification of the device class. If this field is reset to 0, the device does not use class specific protocols on a device basis. However, it may use class specific protocols on an interface basis.</p> <p>If this field is set to 0xFF, the device uses a vendor specific protocol on a device basis.</p>
7	bMaxPacketSize0	1	Number	Maximum packet size for endpoint zero (only byte sizes of 8, 16, 32, or 64 are valid)
8	idVendor	2	ID	Vendor ID (assigned by USB-IF)

10	idProduct	2	ID	Product ID (assigned by the Manufacturer)
12	bcdDevice	2	BCD	Device release number in binary-coded decimal
14	iManufacturer	1	Index	Index of string descriptor describing manufacturer
15	iProduct	1	Index	Index of string descriptor describing product
16	iSerialNumber	1	Index	Index of string descriptor describing the device's serial number
17	bNumConfigurations	1	Number	Number of possible configurations

USBX defines a USB device descriptor as follows:

```
typedef struct UX_DEVICE_DESCRIPTOR_STRUCT
{
    UINT        bLength;
    UINT        bDescriptorType;
    USHORT      bcdUSB;
    UINT        bDeviceClass;
    UINT        bDeviceSubClass;
    UINT        bDeviceProtocol;
    UINT        bMaxPacketSize0;
    USHORT      idVendor;
    USHORT      idProduct;
    USHORT      bcdDevice;
    UINT        iManufacturer;
    UINT        iProduct;
    UINT        iSerialNumber;
    UINT        bNumConfigurations;
} UX_DEVICE_DESCRIPTOR;
```

The USB device descriptor is part of a device container described as:

```
typedef struct UX_DEVICE_STRUCT
{
    ULONG        ux_device_handle;
    ULONG        ux_device_type;
    ULONG        ux_device_state;
    ULONG        ux_device_address;
    ULONG        ux_device_speed;
    ULONG        ux_device_port_location;
    ULONG        ux_device_max_power;
    ULONG        ux_device_power_source;
    UINT         ux_device_current_configuration;
    TX_SEMAPHORE ux_device_protection_semaphore;
    struct UX_DEVICE_STRUCT *ux_device_parent;
    struct UX_HOST_CLASS_STRUCT
        *ux_device_class;
    VOID         *ux_device_class_instance;
    struct UX_HCD_STRUCT
        *ux_device_hcd;
    struct UX_CONFIGURATION_STRUCT
        *ux_device_first_configuration;
    struct UX_DEVICE_STRUCT
        *ux_device_next_device;
    struct UX_DEVICE_DESCRIPTOR_STRUCT
        ux_device_descriptor;
```

```

struct UX_ENDPOINT_STRUCT
    ux_device_control_endpoint;
struct UX_HUB_TT_STRUCT
    ux_device_hub_tt[UX_MAX_TT];
} UX_DEVICE;

```

Variable Name	Variable Description																								
ux_device_handle	Handle of the device. This is typically the address of the instance of this structure for the device.																								
ux_device_type	Obsolete value. Unused.																								
ux_device_state	<p>Device State, which can have one of the following values:</p> <table> <tr><td>UX_DEVICE_RESET</td><td>0</td></tr> <tr><td>UX_DEVICE_ATTACHED</td><td>1</td></tr> <tr><td>UX_DEVICE_ADDRESSED</td><td>2</td></tr> <tr><td>UX_DEVICE_CONFIGURED</td><td>3</td></tr> <tr><td>UX_DEVICE_SUSPENDED</td><td>4</td></tr> <tr><td>UX_DEVICE_RESUMED</td><td>5</td></tr> <tr><td>UX_DEVICE_SELF_POWERED_STATE</td><td>6</td></tr> <tr><td>UX_DEVICE_SELF_POWERED_STATE</td><td>7</td></tr> <tr><td>UX_DEVICE_REMOTE_WAKEUP</td><td>8</td></tr> <tr><td>UX_DEVICE_BUS_RESET_COMPLETED</td><td>9</td></tr> <tr><td>UX_DEVICE_REMOVED</td><td>10</td></tr> <tr><td>UX_DEVICE_FORCE_DISCONNECT</td><td>11</td></tr> </table>	UX_DEVICE_RESET	0	UX_DEVICE_ATTACHED	1	UX_DEVICE_ADDRESSED	2	UX_DEVICE_CONFIGURED	3	UX_DEVICE_SUSPENDED	4	UX_DEVICE_RESUMED	5	UX_DEVICE_SELF_POWERED_STATE	6	UX_DEVICE_SELF_POWERED_STATE	7	UX_DEVICE_REMOTE_WAKEUP	8	UX_DEVICE_BUS_RESET_COMPLETED	9	UX_DEVICE_REMOVED	10	UX_DEVICE_FORCE_DISCONNECT	11
UX_DEVICE_RESET	0																								
UX_DEVICE_ATTACHED	1																								
UX_DEVICE_ADDRESSED	2																								
UX_DEVICE_CONFIGURED	3																								
UX_DEVICE_SUSPENDED	4																								
UX_DEVICE_RESUMED	5																								
UX_DEVICE_SELF_POWERED_STATE	6																								
UX_DEVICE_SELF_POWERED_STATE	7																								
UX_DEVICE_REMOTE_WAKEUP	8																								
UX_DEVICE_BUS_RESET_COMPLETED	9																								
UX_DEVICE_REMOVED	10																								
UX_DEVICE_FORCE_DISCONNECT	11																								
ux_device_address	Address of the device after the SET_ADDRESS command has been accepted (from 1 to 127).																								
ux_device_speed	<p>Speed of the device:</p> <table> <tr><td>UX_LOW_SPEED_DEVICE</td><td>0</td></tr> <tr><td>UX_FULL_SPEED_DEVICE</td><td>1</td></tr> <tr><td>UX_HIGH_SPEED_DEVICE</td><td>2</td></tr> </table>	UX_LOW_SPEED_DEVICE	0	UX_FULL_SPEED_DEVICE	1	UX_HIGH_SPEED_DEVICE	2																		
UX_LOW_SPEED_DEVICE	0																								
UX_FULL_SPEED_DEVICE	1																								
UX_HIGH_SPEED_DEVICE	2																								
ux_device_port_location	Index of the port of the parent device (root hub or hub).																								
ux_device_max_power	Maximum power in mA that the device may take in the selected configuration.																								
ux_device_power_source	<p>Can be one of the two following values:</p> <table> <tr><td>UX_DEVICE_BUS_POWERED</td><td>1</td></tr> <tr><td>UX_DEVICE_SELF_POWERED</td><td>2</td></tr> </table>	UX_DEVICE_BUS_POWERED	1	UX_DEVICE_SELF_POWERED	2																				
UX_DEVICE_BUS_POWERED	1																								
UX_DEVICE_SELF_POWERED	2																								
ux_device_current_configuration	Index of the current configuration being used by this device.																								

ux_device_parent	Device container pointer of the parent of this device. If the pointer is null, the parent is the root hub of the controller.
ux_device_class	Pointer to the class type that owns this device.
ux_device_class_instance	Pointer to the instance of the class that owns this device.
ux_device_hcd	USB Host Controller Instance where this device is attached.
ux_device_first_configuration	Pointer to the first configuration container for this device.
ux_device_next_device	Pointer to the next device in the list of device on any of the buses detected by USBX.
ux_device_descriptor	USB device descriptor.
ux_device_control_endpoint	Descriptor of the default control endpoint used by this device.
ux_device_hub_tt	Array of Hub TTs for the device

## Configuration Descriptors

The configuration descriptor describes information about a specific device configuration. A USB device may contain one or more configuration descriptors. The *bNumConfigurations* field in the device descriptor indicates the number of configuration descriptors. The descriptor contains a *bConfigurationValue* field with a value that, when used as a parameter to the Set Configuration request, causes the device to assume the described configuration.

The descriptor describes the number of interfaces provided by the configuration. Each interface represents a logical function within the device and may operate independently. For instance a USB audio speaker may have three interfaces, one for audio streaming, one for audio control, and one HID interface to manage the speaker's buttons.

When the host issues a GET\_DESCRIPTOR request for the configuration descriptor, all related interface and endpoint descriptors are returned.

Offset	Field	Size	Value	Description
0	bLength	1	Number	Size of this descriptor in bytes.
1	bDescriptorType	1	Constant	CONFIGURATION
2	wTotalLength	2	Number	Total length of data returned for this configuration. Includes the combined length of all descriptors (configuration, interface, endpoint, and class or vendor specific) returned for this configuration.
4	bNumInterfaces	1	Number	Number of interfaces supported by this configuration.
5	bConfigurationValue	1	Number	Value to use as an argument to Set Configuration to select this configuration.
6	iConfiguration	1	Index	Index of string descriptor describing this configuration.
7	bMAttributes	1	Bitmap	Configuration characteristics D7 Bus Powered D6 Self Powered D5 Remote Wakeup D4..0 Reserved (reset to 0) A device configuration that uses power from the bus and a local source sets both D7 and D6. The actual power source at runtime may be determined using the Get Status device request. If a device configuration supports remote wakeup, D5 is set to 1.
8	MaxPower	1	mA	Maximum power consumption of USB device from the bus in this specific configuration when the device is fully operational.  Expressed in 2 mA units (e.g., 50 = 100 mA).  Note: A device configuration reports whether the configuration is bus-powered or self-powered. Device status reports whether the device is currently self-powered. If a device is disconnected from its external power source, it updates device status to indicate that it is no longer self-powered.

USBX defines a USB configuration descriptor as follows:

```
typedef struct UX_CONFIGURATION_DESCRIPTOR_STRUCT
{
    UINT            bLength;
    UINT            bDescriptorType;
    USHORT          wTotalLength;
    UINT            bNumInterfaces;
    UINT            bConfigurationValue;
    UINT            iConfiguration;
    UINT            bmAttributes;
    UINT            MaxPower;
} UX_CONFIGURATION_DESCRIPTOR;
```

The USB configuration descriptor is part of a configuration container described as:

```
typedef struct UX_CONFIGURATION_STRUCT
{
    ULONG            ux_configuration_handle;
    ULONG            ux_configuration_state;
    struct UX_CONFIGURATION_DESCRIPTOR_STRUCT
                    ux_configuration_descriptor;
    struct UX_INTERFACE_STRUCT *ux_configuration_first_interface;
    struct UX_CONFIGURATION_STRUCT
                    *ux_configuration_next_configuration;
    struct UX_DEVICE_STRUCT
                    *ux_configuration_device;
} UX_CONFIGURATION;
```

Variable Name	Variable Description
ux_configuration_handle	Handle of the configuration. This is typically the address of the instance of this structure for the configuration.
ux_configuration_state	State of the configuration.
ux_configuration_descriptor	USB device descriptor.
ux_configuration_first_interface	Pointer to the first interface for this configuration.
ux_configuration_next_configuration	Pointer to the next configuration for the same device.
ux_configuration_device	Pointer to the device owner of this configuration.

## Interface Descriptors

The interface descriptor describes a specific interface within a configuration. An interface is a logical function within a USB device. A configuration provides one or more interfaces, each with zero or more endpoint descriptors describing a unique set of endpoints within the configuration. When a configuration supports more than one interface, the endpoint descriptors for a particular interface follow the interface

descriptor in the data returned by the GET\_DESCRIPTOR request for the specified configuration.

An interface descriptor is always returned as part of a configuration descriptor. An interface descriptor cannot be directly access by a GET\_DESCRIPTOR request.

An interface may include alternate settings that allow the endpoints and/or their characteristics to be varied after the device has been configured. The default setting for an interface is always alternate setting zero. A class can select to change the current alternate setting to change the interface behavior and the characteristics of the associated endpoints. The SET\_INTERFACE request is used to select an alternate setting or to return to the default setting.

Alternate settings allow a portion of the device configuration to be varied while other interfaces remain in operation. If a configuration has alternate settings for one or more of its interfaces, a separate interface descriptor and its associated endpoints are included for each setting.

If a device configuration contains a single interface with two alternate settings, the GET\_DESCRIPTOR request for the configuration would return the configuration descriptor, then the interface descriptor with the *bInterfaceNumber* and *bAlternateSetting* fields set to zero and then the endpoint descriptors for that setting, followed by another interface descriptor and its associated endpoint descriptors. The second interface descriptor's *bInterfaceNumber* field would also be set to zero, but the *bAlternateSetting* field of the second interface descriptor would be set to 1 indicating that this alternate setting belongs to the first interface.

An interface may not have any endpoints associated with it, in which case only the default control endpoint is valid for that interface.

Alternate settings are used mainly to change the requested bandwidth for periodic endpoints associated with the interface. For example, a USB speaker streaming interface should have the first alternate setting with a 0 bandwidth demand on its isochronous endpoint. Other alternate settings may select different bandwidth requirements depending on the audio streaming frequency.

The USB descriptor for the interface is as follows:

Offset	Field	Size	Value	Descriptor
0	bLength	1	Number	Size of this descriptor in bytes.
1	bDescriptorType	1	Constant	INTERFACE Descriptor Type
2	bInterfaceNumber	1	Number	Number of interface. Zero-based value identifying the index in the array of concurrent interfaces supported by this configuration.
3	bAltenateSetting	1	Number	Value used to select alternate setting for the interface identified in the prior field.

4	bNumEndpoints	1	Number	Number of endpoints used by this interface (excluding endpoint zero). If this value is 0, this interface only uses endpoint zero.
5	bInterfaceClass	1	Class	Class code (assigned by USB) If this field is reset to 0, the interface does not belong to any USB specified device class. If this field is set to 0xFF, the interface class is vendor specific. All other values are reserved for assignment by USB.
6	bInterfaceSubClass	1	SubClass	Subclass code (assigned by USB). These codes are qualified by the value of the bInterfaceClass field. If the bInterfaceClass field is reset to 0, this field must also be reset to 0. If the bInterfaceClass field is not set to 0xFF, all values are reserved for assignment by USB.
7	bInterfaceProtocol	1	Protocol	Protocol code (assigned by USB). These codes are qualified by the value of the bInterfaceClass and the bInterfaceSubClass fields. If an interface supports class-specific requests, this code identifies the protocols that the device uses as defined by the specification of the device class. If this field is reset to 0, the device does not use a class specific protocol on this interface. If this field is set to 0xFF, the device uses a vendor specific protocol for this interface.
8	iInterface	1	Index	Index of string descriptor describing this interface.

USBX defines a USB interface descriptor as follows:

```
typedef struct UX_INTERFACE_DESCRIPTOR_STRUCT
{
    UINT    bLength;
    UINT    bDescriptorType;
    UINT    bInterfaceNumber;
    UINT    bAlternateSetting;
    UINT    bNumEndpoints;
    UINT    bInterfaceClass;
    UINT    bInterfaceSubClass;
    UINT    bInterfaceProtocol;
    UINT    iInterface;
} UX_INTERFACE_DESCRIPTOR;
```



The USB interface descriptor is part of an interface container described as:

```
typedef struct UX_INTERFACE_STRUCT
{
    ULONG                ux_interface_handle;
    ULONG                ux_interface_state;
    ULONG                ux_interface_current_alternate_setting;
    struct UX_INTERFACE_DESCRIPTOR_STRUCT ux_interface_descriptor;
    struct UX_HOST_CLASS_STRUCT *ux_interface_class;
    VOID                *ux_interface_class_instance;
    struct UX_ENDPOINT_STRUCT *ux_interface_first_endpoint;
    struct UX_INTERFACE_STRUCT *ux_interface_next_interface;
    struct UX_CONFIGURATION_STRUCT *ux_interface_configuration;
} UX_INTERFACE;
```

Variable Name	Variable Description
ux_interface_handle	Handle of the interface. This is typically the address of the instance of this structure for the interface.
ux_interface_state	State of the interface.
ux_interface_descriptor	USB interface descriptor.
ux_interface_class	Pointer to the class type that owns this interface.
ux_interface_class_instance	Pointer to the instance of the class that owns this interface.
ux_interface_first_endpoint	Pointer to the first endpoint registered with this interface.
ux_interface_next_interface	Pointer to the next interface associated with the configuration.
ux_interface_configuration	Pointer to the configuration owner of this interface.

## Endpoint Descriptors

Each endpoint associated with an interface has its own endpoint descriptor. This descriptor contains the information required by the host stack to determine the bandwidth requirements of each endpoint, the maximum payload associated with the endpoint, its periodicity, and its direction. An endpoint descriptor is always returned by a GET\_DESCRIPTOR command for the configuration.

The default control endpoint associated with the device descriptor is not counted as part of the endpoint(s) associated with the interface and therefore not returned in this descriptor.

When the host software requests a change of the alternate setting for an interface, all the associated endpoints and their USB resources are modified according to the new alternate setting.

Except for the default control endpoints, endpoints cannot be shared between interfaces.

Offset	Field	Size	Value	Description
0	bLength	1	Number	Size of this descriptor in bytes.
1	bDescriptorType	1	Constant	ENDPOINT Descriptor Type.
2	bEndpointAddress	1	Endpoint	<p>The address of the endpoint on the USB device described by this descriptor. The address is encoded as follows:</p> <p>Bit 3...0: The endpoint number          Bit 6...4: Reserved, reset to zero          Bit 7: Direction, ignored for control endpoints          0 = OUT endpoint          1 = IN endpoint</p>
3	bmAttributes	1	Bitmap	<p>This field describes the endpoint's attributes when it is configured using the bConfigurationValue.</p> <p>Bits 1..0: Transfer Type          00 = Control          01 = Isochronous          10 = Bulk          11 = Interrupt</p> <p>If not an isochronous endpoint, bits 5..2 are reserved and must be set to zero. If isochronous, they are defined as follows:</p> <p>Bits 3..2: Synchronization Type          00 = No Synchronization          01 = Asynchronous          10 = Adaptive          11 = Synchronous</p> <p>Bits 5..4: Usage Type          00 = Data endpoint          01 = Feedback endpoint          10 = Implicit feedback data endpoint          11 = Reserved</p>
4	wMaxPacketSize	2	Number	<p>Maximum packet size this endpoint is capable of sending or receiving when this configuration is selected.</p> <p>For isochronous endpoints, this value is used to reserve the bus time in the schedule, required for the per-(micro)frame data payloads. The pipe may, on an ongoing basis, actually use less bandwidth than that reserved. The device reports, if necessary, the actual bandwidth used via its normal, non-USB defined mechanisms.</p> <p>For all endpoints, bits 10..0 specify the maximum packet size (in bytes).</p>

				<p>For high-speed isochronous and interrupt endpoints:  Bits 12..11 specify the number of additional transaction opportunities per microframe:  00 = None (1 transaction per microframe)  01 = 1 additional (2 per microframe)  10 = 2 additional (3 per microframe)  11 = Reserved  Bits 15..13 are reserved and must be set to zero.</p>
6	bInterval	1	Number	<p>Number interval for polling endpoint for data transfers.  Expressed in frames or microframes depending on the device operating speed (i.e., either 1 millisecond or 125 <math>\mu</math>s units).  For full-/high-speed isochronous endpoints, this value must be in the range from 1 to 16. The <i>bInterval</i> value is used as the exponent for a <math>2^{bInterval-1}</math> value; e.g., a <i>bInterval</i> of 4 means a period of 8 (<math>2^{4-1}</math>).  For full-/low-speed interrupt endpoints, the value of this field may be from 1 to 255.  For high-speed interrupt endpoints, the <i>bInterval</i> value is used as the exponent for a <math>2^{bInterval-1}</math> value; e.g., a <i>bInterval</i> of 4 means a period of 8 (<math>2^{4-1}</math>). This value must be from 1 to 16.  For high-speed bulk/control OUT endpoints, the <i>bInterval</i> must specify the maximum NAK rate of the endpoint. A value of 0 indicates the endpoint never NAKs. Other values indicate at most one NAK each <i>bInterval</i> number of microframes.  This value must be in the range from 0 to 255.</p>

USBX defines a USB endpoint descriptor as follows:

```
typedef struct UX_ENDPOINT_DESCRIPTOR_STRUCT
{
    UINT        bLength;
    UINT        bDescriptorType;
    UINT        bEndpointAddress;
    UINT        bmAttributes;
    USHORT      wMaxPacketSize;
    UINT        bInterval;
} UX_ENDPOINT_DESCRIPTOR;
```

The USB endpoint descriptor is part of an endpoint container, which is described as follows:

```
typedef struct UX_ENDPOINT_STRUCT
{
    ULONG                ux_endpoint_handle;
    ULONG                ux_endpoint_state;
    VOID                *ux_endpoint_ed;
    struct UX_ENDPOINT_DESCRIPTOR_STRUCT ux_endpoint_descriptor;
    struct UX_ENDPOINT_STRUCT *ux_endpoint_next_endpoint;
    struct UX_INTERFACE_STRUCT *ux_endpoint_interface;
    struct UX_DEVICE_STRUCT *ux_endpoint_device;
    struct UX_TRANSFER_REQUEST_STRUCT ux_endpoint_transfer_request;
} UX_ENDPOINT;
```

Variable Name	Variable Description
ux_endpoint_handle	Handle of the endpoint. This is typically the address of the instance of this structure for the endpoint.
ux_endpoint_state	State of the endpoint.
ux_endpoint_ed	Pointer to the physical endpoint at the host controller layer.
ux_endpoint_descriptor	USB endpoint descriptor.
ux_endpoint_next_endpoint	Pointer to the next endpoint that belongs to the same interface.
ux_endpoint_interface	Pointer to the interface that owns this endpoint interface.
ux_endpoint_device	Pointer to the parent device container.
ux_endpoint_transfer request	USB transfer request used to send/receive data from to/from the device.

## String descriptors

String descriptors are optional. If a device does not support string descriptors, all references to string descriptors within device, configuration, and interface descriptors must be reset to zero.

String descriptors use UNICODE encoding, thus allowing the support for several character sets. The strings in a USB device may support multiple languages. When requesting a string descriptor, the requester specifies the desired language using a language ID defined by the USB-IF. The list of currently defined USB LANGIDs can be found in the USBX appendix ???. String index zero for all languages returns a string descriptor that contains an array of two-byte LANGID codes supported by the device. It should be noted that the UNICODE string is not 0 terminated. Instead, the size of the string array is computed by subtracting two from the size of the array contained in the

first byte of the descriptor.

The USB string descriptor 0 is encoded as follows:

Offset	Field	Size	Value	Description
0	bLength	1	N+2	Size of this descriptor in bytes
1	bDescriptorType	1	Constant	STRING Descriptor Type
2	wLANGID[0]	2	Number	LANGID code 0
..	...]	..	...	...
N	wLANGID[n]	2	Number	LANGID code n

Other USB string descriptors are encoded as follows:

Offset	Field	Size	Value	Description
0	bLength	1	Number	Size of this descriptor in bytes
1	bDescriptorType	1	Constant	STRING Descriptor Type
2	bString	n	Number	UNICODE encoded string

USBX defines a non-zero length USB string descriptor as follows:


```
typedef struct UX_STRING_DESCRIPTOR_STRUCT
{
    UINT      bLength;
    UINT      bDescriptorType;
    USHORT    bString[1];
} UX_STRING_DESCRIPTOR;
```

## Functional Descriptors

Functional descriptors are also known as class-specific descriptors. They normally use the same basic structures as generic descriptors and allow for additional information to be available to the class. For example, in the case of the USB audio speaker, class specific descriptors allow the audio class to retrieve for each alternate setting the type of audio frequency supported.

## USBX Device Descriptor Framework in Memory

USBX maintains most device descriptors in memory, that is, all descriptors except the string and functional descriptors. The following diagram shows how these descriptors are stored and related.



## ***Chapter 4: Description of USBX Host Services***



## ux\_host\_stack\_initialize

---

Initialize USBX for host operation

### Prototype

```
UINT  ux_host_stack_initialize(UINT  (*system_change_function)
                                (ULONG, UX_HOST_CLASS *))
```

### Description

This function will initialize the USB host stack. The supplied memory area will be setup for USBX internal use. If UX\_SUCCESS is returned, USBX is ready for host controller and class registration.

### Input Parameter

<b>system_change_function</b>	Pointer to optional callback routine for notifying application of device changes.
-------------------------------	---

### Return Value

<b>UX_SUCCESS</b>	(0x00)	Successful initialization.
-------------------	--------	----------------------------

### Example

```
UINT  status;

/* Initialize USBX for host operation, without notification. */
status = ux_host_stack_initialize(UX_NULL);

/* If status equals UX_SUCCESS, USBX has been successfully
   initialized for host operation. */
```

## **ux\_host\_stack\_endpoint\_transfer\_abort**

---

Abort all transactions attached to a transfer request for an endpoint

### **Prototype**

```
UINT  ux_host_stack_endpoint_transfer_abort(UX_ENDPOINT *endpoint)
```

### **Description**

This function will cancel all transactions active or pending for a specific transfer request attached to an endpoint. If the transfer request has a callback function attached, the callback function will be called with the `UX_TRANSACTION_ABORTED` status.

### **Input Parameter**

<b>endpoint</b>	Pointer to an endpoint.
-----------------	-------------------------

### **Return Values**

<b>UX_SUCCESS</b>	(0x00)	No errors.
<b>UX_ENDPOINT_HANDLE_UNKNOWN</b>	(0x53)	Endpoint handle is not valid.

### **Example**

```
UX_HOST_CLASS_PRINTER  *printer;
UINT  status;

/* Get the instance for this class. */
printer =
    (UX_HOST_CLASS_PRINTER *) command -> ux_host_class_command_instance;

/* The printer is being shut down. */
printer -> printer_state = UX_HOST_CLASS_INSTANCE_SHUTDOWN;

/* We need to abort transactions on the bulk out pipe. */
status = ux_host_stack_endpoint_transfer_abort
        (printer -> printer_bulk_out_endpoint);

/* If status equals UX_SUCCESS, the operation was successful */
```

## ux\_host\_stack\_class\_get

---

Get the pointer to a class container

### Prototype

```
UINT ux_host_stack_class_get(UCHAR *class_name, UX_HOST_CLASS **class)
```

### Description

This function returns a pointer to the class container. A class needs to obtain its container from the USB stack to search for instances when a class or an application wants to open a device.

### Parameters

<b>class_name</b>	Pointer to the class name.
<b>class</b>	A pointer updated by the function call that contains the class container for the name of the class.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	No errors, on return the class field is filled with the pointer to the class container.
<b>UX_HOST_CLASS_UNKNOWN</b>	(0x59)	Class is unknown by the stack.

### Example

```
UX_HOST_CLASS  *printer_container;
UINT           status;

/* Get the container for this class. */
status = ux_host_stack_class_get("ux_host_class_printer",
                                &printer_container);

/* If status equals UX_SUCCESS, the operation was successful */
```

## ux\_host\_stack\_class\_register

---

Register a USB class to the USB stack

### Prototype

```
UINT  ux_host_stack_class_register (CHAR_PTR class_name,
                                     UINT  (*class_entry_address)
                                     (struct UX_HOST_CLASS_COMMAND_STRUCT *))
```

### Description

This function registers a USB class to the USB stack. The class must specify an entry point for the USB stack to send commands such as:

```
UX_HOST_CLASS_COMMAND_QUERY
UX_HOST_CLASS_COMMAND_ACTIVATE
UX_HOST_CLASS_COMMAND_DESTROY
```

### Parameters

<b>class_name</b>	Pointer to the name of the class, valid entries are found in the file <code>ux_system_initialize.c</code> under the USB Classes of USBX.
<b>class_entry_address</b>	Address of the entry function of the class.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	Class installed successfully.
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	No more memory to store this class.
<b>UX_HOST_CLASS_ALREADY_INSTALLED</b>	(0x58)	Host class already installed.

### Example:

```
UINT  status;

/* Register all the classes for this implementation. */
status = ux_host_stack_class_register ("ux_host_class_hub",
                                       ux_host_class_hub_entry);

/* If status equals UX_SUCCESS, class was successfully installed. */
```

## ux\_host\_stack\_class\_instance\_create

---

Create a new class instance for a class container

### Prototype

```
UINT  ux_host_stack_class_instance_create(UX_HOST_CLASS *class,  
                                          VOID *class_instance)
```

### Description

This function creates a new class instance for a class container. The instance of a class is not contained in the class code to reduce the class complexity. Rather, each class instance is attached to the class container located in the main stack.

### Parameters

<b>class</b>	Pointer to the class container.
<b>class_instance</b>	Pointer to the class instance to be created.

### Return Value

<b>UX_SUCCESS</b>	(0x00)	The class instance was attached to the class container.
-------------------	--------	---

### Example

```
UINT          status;  
UX_HOST_CLASS_PRINTER *printer;  
  
/* Obtain memory for this class instance. */  
printer = ux_memory_allocate(UX_NO_ALIGN,  
                             sizeof(UX_HOST_CLASS_PRINTER));  
  
if (printer == UX_NULL)  
    return(UX_MEMORY_INSUFFICIENT);  
  
/* Store the class container into this instance. */  
printer -> printer_class = command -> ux_host_class;  
  
/* Create this class instance. */  
status = ux_host_stack_class_instance_create(printer -> printer_class,  
                                              (VOID *)printer);  
  
/* If status equals UX_SUCCESS, the class instance was successfully  
   created and attached to the class container. */
```

## ux\_host\_stack\_class\_instance\_destroy

---

Destroy a class instance for a class container

### Prototype

```
UINT  ux_host_stack_class_instance_destroy(UX_HOST_CLASS *class,  
                                           VOID *class_instance);
```

### Description

This function destroys a class instance for a class container.

### Parameters

<b>class</b>	Pointer to the class container.
<b>class_instance</b>	Pointer to the instance to destroy.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The class instance was destroyed.
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	The class instance is not attached to the class container.

### Example

```
UINT          status;  
UX_HOST_CLASS_PRINTER *printer;  
  
/* Get the instance for this class. */  
printer =  
    (UX_HOST_CLASS_PRINTER *) command -> ux_host_class_command_instance;  
  
/* The printer is being shut down. */  
printer -> printer_state = UX_HOST_CLASS_INSTANCE_SHUTDOWN;  
  
/* Destroy the instance. */  
status = ux_host_stack_class_instance_destroy(printer -> printer_class,  
                                              (VOID *) printer);  
  
/* If status equals UX_SUCCESS, the class instance was successfully  
   destroyed. */
```

## ux\_host\_stack\_class\_instance\_get

---

Get a class instance pointer for a specific class

### Prototype

```
UINT  ux_host_stack_class_instance_get(UX_HOST_CLASS *class,
                                       UINT  class_index,
                                       VOID **class_instance)
```

### Description

This function returns a class instance pointer for a specific class. The instance of a class is not contained in the class code to reduce the class complexity. Rather, each class instance is attached to the class container. This function is used to search for class instances within a class container.

### Parameters

<b>class</b>	Pointer to the class container.
<b>class_index</b>	An index to be used by the function call within the list of attached classes to the container.
<b>class_instance</b>	Pointer to the instance to be returned by the function call.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The class instance was found.
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	There are no more class instances attached to the class container.

### Example

```
UINT          status;
UX_HOST_CLASS_PRINTER *printer;

/* Obtain memory for this class instance. */
printer = ux_memory_allocate(UX_NO_ALIGN,
                             sizeof(UX_HOST_CLASS_PRINTER));

if (printer == UX_NULL)
    return(UX_MEMORY_INSUFFICIENT);

/* Search for instance index 2. */
status = ux_host_stack_class_instance_get(class, 2, (VOID *) printer);

/* If status equals UX_SUCCESS, the class instance was found. */
```

## ux\_host\_stack\_device\_configuration\_get

---

Get a pointer to a configuration container

### Prototype

```
UINT ux_host_stack_device_configuration_get(UX_DEVICE *device,  
                                            UINT configuration_index,  
                                            UX_CONFIGURATION **configuration)
```

### Description

This function returns a configuration container based on a device handle and a configuration index.

### Parameters

<b>device</b>	Pointer to the device container that owns the configuration requested.
<b>configuration_index</b>	Index of the configuration to be searched.
<b>configuration</b>	Address of the pointer to the configuration container to be returned.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The configuration was found.
<b>UX_DEVICE_HANDLE_UNKNOWN</b>	(0x50)	The device container does not exist.
<b>UX_CONFIGURATION_HANDLE_UNKNOWN</b>	(0x51)	The configuration handle for the index does not exist.

### Example

```
UINT status;  
UX_HOST_CLASS_PRINTER *printer;  
  
/* If the device has been configured already, we don't need to do it  
again. */  
if (printer -> printer_device -> ux_device_state ==  
    UX_DEVICE_CONFIGURED)  
    return(UX_SUCCESS);  
  
/* A printer normally has one configuration, retrieve 1st configuration  
only. */  
status = ux_host_stack_device_configuration_get(printer ->  
    printer_device, 0, configuration);  
  
/* If status equals UX_SUCCESS, the configuration was found. */
```



## ux\_host\_stack\_device\_configuration\_select

---

Select a specific configuration for a device

### Prototype

```
UINT ux_host_stack_device_configuration_select
                                         (UX_CONFIGURATION *configuration)
```

### Description

This function selects a specific configuration for a device. When this configuration is set to the device, by default, each device interface and its associated alternate setting 0 is activated on the device. If the device/interface class wishes to change the setting of a particular interface, it needs to issue a **ux\_host\_stack\_interface\_setting\_select** service call.

### Parameters

<b>configuration</b>	Pointer to the configuration container that is to be enabled for this device.
----------------------	---

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The configuration selection was successful.
<b>UX_CONFIGURATION_HANDLE_UNKNOWN</b>	(0x51)	The configuration handle does not exist.
<b>UX_OVER_CURRENT_CONDITION</b>	(0x43)	An over current condition exists on the bus for this configuration.

### Example

```
UINT status;
UX_HOST_CLASS_PRINTER *printer;

/* If the device has been configured already, we don't need to do it
   again. */
if (printer -> printer_device -> ux_device_state ==
    UX_DEVICE_CONFIGURED)
    return(UX_SUCCESS);

/* A printer normally has one configuration - retrieve 1st
   configuration only. */
status = ux_host_stack_device_configuration_get(printer ->
    printer_device, 0, configuration);

/* If status equals UX_SUCCESS, the configuration selection was
   successful. */
```

```
/* If valid configuration, ask USBX to set this configuration. */  
status = ux_host_stack_device_configuration_select(configuration);  
  
/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_stack\_device\_get

---

Get a pointer to a device container

### Prototype

```
UINT  ux_host_stack_device_get(ULONG device_index, UX_DEVICE **device)
```

### Description

This function returns a device container based on its index. The device index starts with 0. Note that the index is a ULONG because we could have several controllers and a byte index might not be enough. The device index should not be confused with the device address that is bus specific.

### Parameters

<b>device_index</b>	Index of the device.
<b>device</b>	Address of the pointer for the device container to return.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The device container exists and is returned
<b>UX_DEVICE_HANDLE_UNKNOWN</b>	(0x50)	Device unknown

### Example

```
UINT  status;

/* Locate the first device in USBX. */
status = ux_host_stack_device_get(0, device);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_stack\_interface\_endpoint\_get

---

Get an endpoint container

### Prototype

```
UINT  ux_host_stack_interface_endpoint_get(UX_INTERFACE *interface,
                                           UINT endpoint_index,
                                           UX_ENDPOINT **endpoint)
```

### Description

This function returns an endpoint container based on the interface handle and an endpoint index. It is assumed that the alternate setting for the interface has been selected or the default setting is being used prior to the endpoint(s) being searched.

### Parameters

<b>interface</b>	Pointer to the interface container that contains the endpoint requested.
<b>endpoint_index</b>	Index of the endpoint in this interface.
<b>endpoint</b>	Address of the endpoint container to be returned.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The endpoint container exists and is returned.
<b>UX_INTERFACE_HANDLE_UNKNOWN</b>	(0x52)	Interface specified does not exist.
<b>UX_ENDPOINT_HANDLE_UNKNOWN</b>	(0x53)	Endpoint index does not exist.

### Example

```
UINT          status;
UX_HOST_CLASS_PRINTER *printer;

for(endpoint_index = 0;
   endpoint_index < printer -> printer_interface ->
   ux_interface_descriptor.bNumEndpoints;
   endpoint_index++)
{
    status = ux_host_stack_interface_endpoint_get
        (printer ->printer_interface, endpoint_index, &endpoint);

    if (status == UX_SUCCESS)
    {
```

```

        /* Check if endpoint is bulk and OUT. */
        if (((endpoint -> ux_endpoint_descriptor.bEndpointAddress &
            UX_ENDPOINT_DIRECTION) == UX_ENDPOINT_OUT) &&
            ((endpoint -> ux_endpoint_descriptor.bmAttributes &
            UX_MASK_ENDPOINT_TYPE) == UX_BULK_ENDPOINT))
            return(UX_SUCCESS)
    }
}

```

## ux\_host\_stack\_hcd\_register

---

Register a USB controller to the USB stack

### Prototype

```
UINT  ux_host_stack_hcd_register (CHAR_PTR hcd_name,
                                   UINT  (*hcd_function) (struct UX_HCD_STRUCT *),
                                   ULONG hcd_param1, ULONG hcd_param2)
```

### Description

This function registers a USB controller to the USB stack. It mainly allocates the memory used by this controller and passes the initialization command to the controller.

### Parameters

<b>hcd_name</b>	Name of the host controller
<b>hcd_function</b>	The function in the host controller responsible for the initialization.
<b>hcd_param1</b> <b>hcd_param2</b>	The IO or memory resource used by the hcd. The IRQ used by the host controller.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The controller was initialized properly.
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory for this controller.
<b>UX_PORT_RESET_FAILED</b>	(0x31)	The reset of the controller failed.
<b>UX_CONTROLLER_INIT_FAILED</b>	(0x32)	The controller failed to initialize properly.

## Example

```
UINT    status;

/* Initialize a host controller mapped at address 0xd0000 and using
   IRQ 10. */
status = ux_host_stack_hcd_register("ux_hcd_controller",
                                     ux_hcd_controller_initialize,
                                     0xd0000, 0x0a);

/* If status equals UX_SUCCESS, the controller was initialized
   properly. */

/* Note that the application must also setup a call to the interrupt
   handler for the controller. The function for the controller is
   called
   _ux_hch_controller_interrupt_handler. */
```

## ux\_host\_stack\_configuration\_interface\_get

---

Get an interface container pointer

### Prototype

```
UINT ux_host_stack_configuration_interface_get
    (UX_CONFIGURATION *configuration,
     UINT interface_index,
     UINT alternate_setting_index,
     UX_INTERFACE **interface)
```

### Description

This function returns an interface container based on a configuration handle, an interface index, and an alternate setting index.

### Parameters

<b>configuration</b>	Pointer to the configuration container that owns the interface.
<b>interface_index</b>	Interface index to be searched.
<b>alternate_setting_index</b>	Alternate setting within the interface to search.
<b>interface</b>	Address of the interface container pointer to be returned.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The interface container for the interface index and the alternate setting was found and returned.
<b>UX_CONFIGURATION_HANDLE_UNKNOWN</b>	(0x51)	The configuration does not exist.
<b>UX_INTERFACE_HANDLE_UNKNOWN</b>	(0x52)	The interface does not exist.

### Example

```
UINT status;

/* Search for the default alternate setting on the first interface for
the printer. */
status = ux_host_stack_configuration_interface_get(configuration, 0, 0,
                                                    &printer -> printer_interface);

/* If status equals UX_SUCCESS, the operation was successful. */
```



## ux\_host\_stack\_interface\_setting\_select

---

Select an alternate setting for an interface

### Prototype

```
UINT  ux_host_stack_interface_setting_select(UX_INTERFACE *interface)
```

### Description

This function selects a specific alternate setting for a given interface belonging to the selected configuration. This function is used to change from the default alternate setting to a new setting or to go back to the default alternate setting. When a new alternate setting is selected, the previous endpoint characteristics are invalid and should be reloaded.

### Input Parameter

<b>interface</b>	Pointer to the interface container whose alternate setting is to be selected.
------------------	---

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The alternate setting for this interface has been successfully selected.
<b>UX_INTERFACE_HANDLE_UNKNOWN</b>	(0x52)	The interface does not exist.

### Example

```
UINT  status;

/* Select a new alternate setting for this interface. */
status = ux_host_stack_interface_setting_select(interface);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_stack\_transfer\_request\_abort

---

Abort a pending transfer request

### Prototype

```
UINT  ux_host_stack_transfer_request_abort(UX_TRANSFER_REQUEST
                                           *transfer_request)
```

### Description

This function aborts a pending transfer request that has been previously submitted. This function only cancels a specific transfer request. The call back to the function will have the UX\_TRANSFER\_REQUEST\_STATUS\_ABORT status.

### Parameters

<b>transfer request</b>	Pointer to the transfer request to be aborted.
-------------------------	--

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The USB transfer for this transfer request was canceled.
-------------------	--------	--

### Example

```
UINT  status;

/* The following example illustrates this service. */
status = ux_host_stack_transfer_request_abort(transfer_request);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_stack\_transfer\_request

---

Request a USB transfer

### Prototype

```
UINT ux_host_stack_transfer_request(UX_TRANSFER_REQUEST *transfer_request)
```

### Description

This function performs a USB transaction. On entry the transfer request gives the endpoint pipe selected for this transaction and the parameters associated with the transfer (data payload, length of transaction). For Control pipe, the transaction is blocking and will only return when the three phases of the control transfer have been completed or if there is a previous error. For other pipes, the USB stack will schedule the transaction on the USB but will not wait for its completion. Each transfer request for non-blocking pipes has to specify a completion routine handler.

When the function call returns, the status of the transfer request should be examined as it contains the result of the transaction.

### Input Parameter

<b>transfer_request</b>	Pointer to the transfer request. The transfer request contains all the necessary information required for the transfer.
-------------------------	---

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The USB transfer for this transfer request was scheduled properly. The status code of the transfer request should be examined when the transfer request completes.
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to allocate the necessary controller resources.

### Example:

```
UINT status;

/* Create a transfer request for the SET_CONFIGURATION request.
   No data for this request. */
transfer_request -> ux_transfer_endpoint_handle = control_endpoint;
transfer_request -> ux_transfer_requested_length = 0;
transfer_request -> ux_transfer_request_function =
                                     UX_SET_CONFIGURATION;
transfer_request -> ux_transfer_request_type =
                                     UX_REQUEST_OUT |
```

```

                                UX_REQUEST_TYPE_STANDARD |
                                UX_REQUEST_TARGET_DEVICE;
transfer_request -> ux_transfer_request_value =
    (USHORT) configuration ->
        ux_configuration_descriptor.bConfigurationValue;
transfer_request -> ux_transfer_request_index = 0;

/* Send request to HCD layer. */
status = ux_host_stack_transfer_request(transfer_request);

/* If status equals UX_SUCCESS, the operation was successful. */

```

# ***Chapter 5: USBX Host Classes API***

This chapter covers all the exposed APIs of the USBX host classes. The following APIs for each class are described in detail:

- Printer class
- HID class
- Audio class
- Asix class
- CDC-ACM class
- CDC-ECM class
- Pima/PTP class
- Prolific class
- Storage class
- Generic Serial class

## ux\_host\_class\_printer\_read

---

Read from the printer interface

### Prototype

```
UINT  ux_host_class_printer_read(UX_HOST_CLASS_PRINTER *printer,
                                  UCHAR *data_pointer,
                                  ULONG requested_length,
                                  ULONG *actual_length)
```

### Description

This function reads from the printer interface. The call is blocking and only returns when there is either an error or when the transfer is complete. A read is allowed only on bi-directional printers.

### Parameters

<b>printer</b>	Pointer to the printer class instance.
<b>data_pointer</b>	Pointer to the buffer address of the data payload.
<b>requested_length</b>	Length to be received.
<b>actual_length</b>	Length actually received.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported because the printer is not bi-directional.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, reading incomplete.

### Example

```
UINT  status;

/* The following example illustrates this service. */
status = ux_host_class_printer_read(printer, data_pointer,
                                     requested_length, &actual_length);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_printer\_write

---

Write to the printer interface

### Prototype

```
UINT  ux_host_class_printer_write(UX_HOST_CLASS_PRINTER *printer,
                                   UCHAR *data_pointer, ULONG requested_length,
                                   ULONG *actual_length)
```

### Description

This function writes to the printer interface. The call is blocking and only returns when there is either an error or when the transfer is complete.

### Parameters

<b>printer</b>	Pointer to the printer class instance.
<b>data_pointer</b>	Pointer to the buffer address of the data payload.
<b>requested_length</b>	Length to be sent.
<b>actual_length</b>	Length actually sent.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, writing incomplete.

### Example

```
UINT  status;

/* The following example illustrates this service. */
status = ux_host_class_printer_write(printer, data_pointer,
                                      requested_length, &actual_length);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_printer\_soft\_reset

---

Perform a soft reset to the printer

### Prototype

```
UINT  ux_host_class_printer_soft_reset(UX_HOST_CLASS_PRINTER *printer)
```

### Description

This function performs a soft reset to the printer.

### Input Parameter

<b>printer</b>	Pointer to the printer class instance.
----------------	--

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The reset was completed.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, reset not completed.

### Example

```
UINT  status;  
  
/* The following example illustrates this service. */  
status = ux_host_class_printer_soft_reset(printer);  
  
/* If status equals UX_SUCCESS, the operation was successful. */
```



## ux\_host\_class\_printer\_status\_get

---

Get the printer status

### Prototype

```
UINT  ux_host_class_printer_status_get(UX_HOST_CLASS_PRINTER *printer,  
                                       ULONG *printer_status)
```

### Description

This function obtains the printer status. The printer status is similar to the LPT status (1284 standard).

### Parameters

<b>printer</b>	Pointer to the printer class instance.
<b>printer_status</b>	Address of the status to be returned.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The reset was completed.
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to perform the operation.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, reset not completed

### Example

```
UINT  status;  
  
/* The following example illustrates this service. */  
status = ux_host_class_printer_status_get(printer, printer_status);  
  
/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_audio\_read

---

Read from the audio interface

### Prototype

```
UINT  ux_host_class_audio_read(UX_HOST_CLASS_AUDIO *audio,
                               UX_HOST_CLASS_AUDIO_TRANSFER_REQUEST
                               *audio_transfer_request)
```

### Description

This function reads from the audio interface. The call is non-blocking. The application must ensure that the appropriate alternate setting has been selected for the audio streaming interface.

### Parameters

audio	Pointer to the audio class instance.
audio_transfer_request	Pointer to the audio transfer structure.

### Return values

<b>UX_SUCCESS</b>	(0x00) The data transfer was completed
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54) Function not supported

### Example

```
/* The following example reads from the audio interface. */

audio_transfer_request.ux_host_class_audio_transfer_request_completion_function =
    tx_audio_transfer_completion_function;
audio_transfer_request.ux_host_class_audio_transfer_request_class_instance = audio;
audio_transfer_request.ux_host_class_audio_transfer_request_next_audio_transfer_request =
    UX_NULL;
audio_transfer_request.ux_host_class_audio_transfer_request_data_pointer =
    audio_buffer;
audio_transfer_request.ux_host_class_audio_transfer_request_requested_length =
    requested_length;
audio_transfer_request.ux_host_class_audio_transfer_request_packet_length =
    AUDIO_FRAME_LENGTH;

status = ux_host_class_audio_read(audio, audio_transfer_request);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_audio\_write

---

Write to the audio interface

### Prototype

```
UINT ux_host_class_audio_write(UX_HOST_CLASS_AUDIO *audio,  
                               UX_HOST_CLASS_AUDIO_TRANSFER_REQUEST *audio_transfer_request)
```

### Description

This function writes to the audio interface. The call is non-blocking. The application must ensure that the appropriate alternate setting has been selected for the audio streaming interface.

### Parameters

<b>audio</b>	Pointer to the audio class instance
<b>audio_transfer_request</b>	Pointer to the audio transfer structure

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported.
<b>UX_HOST_CLASS_AUDIO_WRONG_INTERFACE</b>	(0x81)	Interface incorrect.

### Example

```
UINT status;  
  
/* The following example writes to the audio interface */  
  
audio_transfer_request.ux_host_class_audio_transfer_request_completion_function =  
    tx_audio_transfer_completion_function;  
audio_transfer_request.ux_host_class_audio_transfer_request_class_instance = audio;  
audio_transfer_request.ux_host_class_audio_transfer_request_next_audio_transfer_request =  
    UX_NULL;  
audio_transfer_request.ux_host_class_audio_transfer_request_data_pointer =  
    audio_buffer;  
audio_transfer_request.ux_host_class_audio_transfer_request_requested_length =  
    requested_length;  
audio_transfer_request.ux_host_class_audio_transfer_request_packet_length =  
    AUDIO_FRAME_LENGTH;  
  
status = ux_host_class_audio_write(audio, audio_transfer_request);  
  
/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_audio\_control\_get

---

Get a specific control from the audio control interface

### Prototype

```
UINT  ux_host_class_audio_control_get(UX_HOST_CLASS_AUDIO *audio,
                                       UX_HOST_CLASS_AUDIO_CONTROL
                                       *audio_control)
```

### Description

This function reads a specific control from the audio control interface.

### Parameters

<b>audio</b>	Pointer to the audio class instance
<b>audio_control</b>	Pointer to the audio control structure

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported
<b>UX_HOST_CLASS_AUDIO_WRONG_INTERFACE</b>	(0x81)	Interface incorrect

### Example

```
UINT  status;

/* The following example reads the volume control from a stereo USB speaker. */

UX_HOST_CLASS_AUDIO_CONTROL  audio_control;

audio_control. ux_host_class_audio_control_channel = 1;
audio_control. ux_host_class_audio_control = UX_HOST_CLASS_AUDIO_VOLUME_CONTROL;

status = ux_host_class_audio_control_get(audio, &audio_control);

/* If status equals UX_SUCCESS, the operation was successful. */

audio_control. ux_host_class_audio_control_channel = 2;
audio_control. ux_host_class_audio_control = UX_HOST_CLASS_AUDIO_VOLUME_CONTROL;

status = ux_host_class_audio_control_get(audio, &audio_control);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_audio\_control\_value\_set

---

Set a specific control to the audio control interface

### Prototype

```
UINT ux_host_class_audio_control_value_set(UX_HOST_CLASS_AUDIO *audio,  
                                           UX_HOST_CLASS_AUDIO_CONTROL *audio_control)
```

### Description

This function sets a specific control to the audio control interface.

### Parameters

<b>audio</b>	Pointer to the audio class instance
<b>audio_control</b>	Pointer to the audio control structure

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported
<b>UX_HOST_CLASS_AUDIO_WRONG_INTERFACE</b>	(0x81)	Interface incorrect

### Example

```
/* The following example sets the volume control of a stereo USB speaker. */  
  
UX_HOST_CLASS_AUDIO_CONTROL audio_control;  
UINT status;  
  
audio_control.ux_host_class_audio_control_channel = 1;  
audio_control.ux_host_class_audio_control =  
    UX_HOST_CLASS_AUDIO_VOLUME_CONTROL;  
audio_control.ux_host_class_audio_control_cur = 0xf000;  
  
status = ux_host_class_audio_control_value_set(audio, &audio_control);  
  
/* If status equals UX_SUCCESS, the operation was successful. */  
current_volume = audio_control.audio_control_cur;  
  
audio_control.ux_host_class_audio_control_channel = 2;  
audio_control.ux_host_class_audio_control =  
    UX_HOST_CLASS_AUDIO_VOLUME_CONTROL;  
audio_control.ux_host_class_audio_control_cur = 0xf000;  
  
status = ux_host_class_audio_control_value_set(audio, &audio_control);  
  
/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_audio\_streaming\_sampling\_set

---

Set an alternate setting interface of the audio streaming interface

### Prototype

```
UINT  ux_host_class_audio_streaming_sampling_set(UX_HOST_CLASS_AUDIO *audio,
                                                UX_HOST_CLASS_AUDIO_SAMPLING *audio_sampling)
```

### Description

This function sets the appropriate alternate setting interface of the audio streaming interface according to a specific sampling structure.

### Parameters

<b>audio</b>	Pointer to the audio class instance.
<b>audio_sampling</b>	Pointer to the audio sampling structure.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported
<b>UX_HOST_CLASS_AUDIO_WRONG_INTERFACE</b>	(0x81)	Interface incorrect
<b>UX_NO_ALTERNATE_SETTING</b>	(0x5e)	No alternate setting for the sampling values

### Example

```
/* The following example sets the alternate setting interface of a
   stereo USB speaker. */

UX_HOST_CLASS_AUDIO_SAMPLING  audio_sampling;
UINT  status;

sampling.ux_host_class_audio_sampling_channels = 2;
sampling.ux_host_class_audio_sampling_frequency = AUDIO_FREQUENCY;
sampling.ux_host_class_audio_sampling_resolution = 16;

status = ux_host_class_audio_streaming_sampling_set(audio, &sampling);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_audio\_streaming\_sampling\_get

---

Get possible sampling settings of audio streaming interface

### Prototype

```
UINT  ux_host_class_audio_streaming_sampling_get(UX_HOST_CLASS_AUDIO *audio,  
                                                UX_HOST_CLASS_AUDIO_SAMPLING_CHARACTERISTICS *audio_sampling)
```

### Description

This function gets, one by one, all the possible sampling settings available in each of the alternate settings of the audio streaming interface. The first time the function is used, all the fields in the calling structure pointer must be reset. The function will return a specific set of streaming values upon return unless the end of the alternate settings has been reached. When this function is reused, the previous sampling values will be used to find the next sampling values.

### Parameters

<b>audio</b>	Pointer to the audio class instance
<b>audio_sampling</b>	Pointer to the audio sampling structure

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported
<b>UX_HOST_CLASS_AUDIO_WRONG_INTERFACE</b>	(0x81)	Interface incorrect
<b>UX_NO_ALTERNATE_SETTING</b>	(0x5e)	No alternate setting for the sampling values

### Example

```
/* The following example gets the sampling values for the first alternate  
   setting interface of a stereo USB speaker. */  
  
UX_HOST_CLASS_AUDIO_SAMPLING_CHARACTERISTICS  audio_sampling;  
UINT  status;  
  
sampling.ux_host_class_audio_sampling_channels=0;  
sampling.ux_host_class_audio_sampling_frequency_low=0;  
sampling.ux_host_class_audio_sampling_frequency_high=0;
```

```

sampling.ux_host_class_audio_sampling_resolution=0;

status = ux_host_class_audio_streaming_sampling_get(audio, &sampling);

/* If status equals UX_SUCCESS, the operation was successful and information
   could be displayed as follows:

   printf("Number of channels %d, Resolution %d bits, frequency range %d-
   %d\n",
          sampling.audio_channels, sampling.audio_resolution,
          sampling.audio_frequency_low, sampling.audio_frequency_high);
*/

```



## ux\_host\_class\_hid\_client\_register

---

Register a HID client to the HID class

### Prototype

```
UINT  ux_host_class_hid_client_register(UCHAR_PTR hid_client_name,
                                         UINT  (*hid_client_handler)
                                         (struct UX_HOST_CLASS_HID_CLIENT_COMMAND_STRUCT *))
```

### Description

This function is used to register a HID client to the HID class. The HID class needs to find a match between a HID device and HID client before requesting data from this device.

### Parameters

<b>hid_client_name</b>	Pointer to the HID client name.
<b>hid_client_handler</b>	Pointer to the HID client handler.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported
<b>UX_HOST_CLASS_ALREADY_INSTALLED</b>	(0x58)	This class already exists

### Example

```
UINT  status;

/* The following example illustrates how to register a HID client, in
   this case a USB mouse, to the HID class. */

status =
ux_host_class_hid_client_register("ux_host_class_hid_client_mouse",
                                  ux_host_class_hid_mouse_entry);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_hid\_report\_callback\_register

---

Register a callback from the HID class

### Prototype

```
UINT  ux_host_class_hid_report_callback_register(UX_HOST_CLASS_HID *hid,
                                                UX_HOST_CLASS_HID_REPORT_CALLBACK *call_back)
```

### Description

This function is used to register a callback from the HID class to the HID client when a report is received.

### Parameters

<b>hid</b>	Pointer to the HID class instance
<b>call_back</b>	Pointer to the call_back structure

### Return values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported
<b>UX_HOST_CLASS_HID_REPORT_ERROR</b>	(0x79)	Error in the report callback registration.

### Example

```
UINT  status;

/* This example illustrates how to register a HID client, in this case
   a USB mouse, to the HID class. In this case, the HID client is
   asking the HID class to call the client for each usage received in
   the HID report. */

call_back.ux_host_class_hid_report_callback_id = 0;
call_back.ux_host_class_hid_report_callback_function =
    ux_host_class_hid_mouse_callback;
call_back.ux_host_class_hid_report_callback_buffer = UX_NULL;
call_back.ux_host_class_hid_report_callback_flags =
    UX_HOST_CLASS_HID_REPORT_INDIVIDUAL_USAGE;
call_back.ux_host_class_hid_report_callback_length = 0;

status = ux_host_class_hid_report_callback_register(hid, &call_back);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_hid\_periodic\_report\_start

---

Start the periodic endpoint for a HID class instance

### Prototype

```
UINT  ux_host_class_hid_periodic_report_start(UX_HOST_CLASS_HID *hid)
```

### Description

This function is used to start the periodic (interrupt) endpoint for the instance of the HID class that is bound to this HID client. The HID class cannot start the periodic endpoint until the HID client is activated and therefore it is left to the HID client to start this endpoint to receive reports.

### Input Parameter

<b>hid</b>	Pointer to the HID class instance.
------------	------------------------------------

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported.
<b>UX_HOST_CLASS_HID_PERIODIC_REPORT_ERROR</b>	(0x7A)	Error in the periodic report.
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	HID class instance does not exist.

### Example

```
UINT  status;

/* The following example illustrates how to start the periodic
   endpoint. */

status = ux_host_class_hid_periodic_report_start(hid);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_hid\_periodic\_report\_stop

---

Stop the periodic endpoint for a HID class instance

### Prototype

```
UINT ux_host_class_hid_periodic_report_stop(UX_HOST_CLASS_HID *hid)
```

### Description

This function is used to stop the periodic (interrupt) endpoint for the instance of the HID class that is bound to this HID client. The HID class cannot stop the periodic endpoint until the HID client is deactivated, all its resources freed and therefore it is left to the HID client to stop this endpoint.

### Input Parameter

<b>hid</b>	Pointer to the HID class instance.
------------	------------------------------------

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported.
<b>UX_HOST_CLASS_HID_PERIODIC_REPORT_ERROR</b>	(0x7A)	Error in the periodic report.
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	HID class instance does not exist.

### Example

```
UINT status;

/* The following example illustrates how to stop the periodic
   endpoint. */

status = ux_host_class_hid_periodic_report_stop(hid);

/* If status equals UX_SUCCESS, the operation was successful. */
```



## ux\_host\_class\_hid\_report\_get

---

Get a report from a HID class instance

### Prototype

```
UINT  ux_host_class_hid_report_get(UX_HOST_CLASS_HID *hid,
                                   UX_HOST_CLASS_HID_CLIENT_REPORT *client_report)
```

### Description

This function is used to receive a report directly from the device without relying on the periodic endpoint. This report is coming from the control endpoint but its treatment is the same as though it were coming on the periodic endpoint.

### Parameters

<b>hid</b>	Pointer to the HID class instance.
<b>client_report</b>	Pointer to the HID client report.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported.
<b>UX_HOST_CLASS_HID_REPORT_ERROR</b>	(0x70)	Error in the periodic report.
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	HID class instance does not exist.
<b>UX_BUFFER_OVERFLOW</b>	(0x5d)	The buffer supplied is not big enough to accommodate the uncompressed report

### Example

```
UX_HOST_CLASS_HID_CLIENT_REPORT  input_report;
UINT  status;

/* The following example illustrates how to get a report. */

input_report.ux_host_class_hid_client_report = hid_report;
input_report.ux_host_class_hid_client_report_buffer = buffer;
input_report.ux_host_class_hid_client_report_length = length;
input_report.ux_host_class_hid_client_flags =
    UX_HOST_CLASS_HID_REPORT_INDIVIDUAL_USAGE;

status = ux_host_class_hid_report_get(hid, &input_report);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_hid\_report\_set

---

Send a report

### Prototype

```
UINT  ux_host_class_hid_report_set(UX_HOST_CLASS_HID *hid,
                                   UX_HOST_CLASS_HID_CLIENT_REPORT *client_report)
```

### Description

This function is used to send a report directly to the device.

### Parameters

<b>hid</b>	Pointer to the HID class instance.
<b>client_report</b>	Pointer to the HID client report.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Function not supported.
<b>UX_HOST_CLASS_HID_REPORT_ERROR</b>	(0x70)	Error in the periodic report.
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	HID class instance does not exist.
<b>UX_BUFFER_OVERFLOW</b>	(0x5d)	The buffer supplied is not big enough to accommodate the uncompressed report.

### Example

```
/* The following example illustrates how to send a report. */

UX_HOST_CLASS_HID_CLIENT_REPORT    input_report;

input_report.ux_host_class_hid_client_report = hid_report;
input_report.ux_host_class_hid_client_report_buffer = buffer;
input_report.ux_host_class_hid_client_report_length = length;
input_report.ux_host_class_hid_client_report_flags =
    UX_HOST_CLASS_HID_REPORT_INDIVIDUAL_USAGE;

status = ux_host_class_hid_report_set(hid, &input_report);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_hid\_mouse\_button\_get

---

Get mouse buttons

### Prototype

```
UINT  ux_host_class_hid_mouse_button_get(UX_HOST_CLASS_HID_MOUSE
                                           *mouse_instance, ULONG *mouse_buttons)
```

### Description

This function is used to get the mouse buttons

### Parameters

<b>mouse_instance</b>	Pointer to the HID mouse instance.
<b>mouse_buttons</b>	Pointer to the return buttons.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	HID class instance does not exist.

### Example

```
/* The following example illustrates how to obtain mouse buttons. */

UX_HOST_CLASS_HID_MOUSE *mouse_instance;
ULONG mouse_buttons;

status = ux_host_class_hid_mouse_button_get(mouse_instance,
&mouse_buttons);

/* If status equals UX_SUCCESS, the operation was successful. */
```



## ux\_host\_class\_hid\_mouse\_position\_get

---

Get mouse position

### Prototype

```
UINT ux_host_class_hid_mouse_position_get(UX_HOST_CLASS_HID_MOUSE
    *mouse_instance, SLONG *mouse_x_position, SLONG *mouse_y_position)
```

### Description

This function is used to get the mouse position in x & y coordinates

### Parameters

<b>mouse_instance</b>	Pointer to the HID mouse instance.
<b>mouse_x_position</b>	Pointer to the x coordinate.
<b>mouse_y_position</b>	Pointer to the y coordinate.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	HID class instance does not exist.

### Example

```
/* The following example illustrates how to obtain mouse coordinates.
*/

UX_HOST_CLASS_HID_MOUSE *mouse_instance;
SLONG mouse_x_position;
SLONG mouse_y_position;

status = ux_host_class_hid_mouse_position_get(mouse_instance,
    &mouse_x_position, &mouse_y_position);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_hid\_keyboard\_key\_get

---

Get keyboard key and state

### Prototype

```
UINT ux_host_class_hid_keyboard_key_get(UX_HOST_CLASS_HID_KEYBOARD
    *keyboard_instance, ULONG *keyboard_key, ULONG *keyboard_state)
```

### Description

This function is used to get the keyboard key and state

### Parameters

<b>keyboard_instance</b>	Pointer to the HID keyboard instance.
<b>keyboard_key</b>	Pointer to keyboard key container.
<b>keyboard_state</b>	Pointer to the keyboard state container.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_ERROR</b>	(0xff)	Nothing to report
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	HID class instance does not exist.

The keyboard state can have the following values :

UX_HID_KEYBOARD_STATE_NUM_LOCK	0x0001
UX_HID_KEYBOARD_STATE_CAPS_LOCK	0x0002
UX_HID_KEYBOARD_STATE_SCROLL_LOCK	0x0004
UX_HID_KEYBOARD_STATE_MASK_LOCK	0x0007
UX_HID_KEYBOARD_STATE_LEFT_SHIFT	0x0100
UX_HID_KEYBOARD_STATE_RIGHT_SHIFT	0x0200
UX_HID_KEYBOARD_STATE_SHIFT	0x0300
UX_HID_KEYBOARD_STATE_LEFT_ALT	0x0400
UX_HID_KEYBOARD_STATE_RIGHT_ALT	0x0800
UX_HID_KEYBOARD_STATE_ALT	0x0a00
UX_HID_KEYBOARD_STATE_LEFT_CTRL	0x1000
UX_HID_KEYBOARD_STATE_RIGHT_CTRL	0x2000
UX_HID_KEYBOARD_STATE_CTRL	0x3000
UX_HID_KEYBOARD_STATE_LEFT_GUI	0x4000
UX_HID_KEYBOARD_STATE_RIGHT_GUI	0x8000
UX_HID_KEYBOARD_STATE_GUI	0xa000

### Example

```

while (1)
{
    /* Get a key/state from the keyboard. */
    status = ux_host_class_hid_keyboard_key_get(keyboard,
&keyboard_char, &keyboard_state);

    /* Check if there is something. */
    if (status == UX_SUCCESS)
    {
        /* We have a character in the queue. */
        keyboard_queue[keyboard_queue_index] = (UCHAR)
keyboard_char;

        /* Can we accept more ? */
        if(keyboard_queue_index < 1024)
            keyboard_queue_index++;

    }

    tx_thread_sleep(10);
}

```

## ux\_host\_class\_hid\_remote\_control\_usage\_get

---

Get remote control usage

### Prototype

```
UINT ux_host_class_hid_remote_control_usage_get
    (UX_HOST_CLASS_HID_REMOTE_CONTROL *remote_control_instance,
     ULONG *usage, ULONG *value)
```

### Description

This function is used to get the remote control usages.

### Parameters

<b>remote_control_instance</b>	Pointer to the HID remote control instance.
<b>usage</b>	Pointer to the usage.
<b>value</b>	Pointer to the value for the usage.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_INSTANCE_UNKNOWN</b>	(0x5b)	HID class instance does not exist.

The list of all possible usages is too long to fit in this user guide. For a full description, the `ux_host_class_hid.h` has the entire set of possible values.

### Example

```
/* Read usages and values as the user changes the vol/bass/treble
   buttons on the speaker */
while (remote_control != UX_NULL)
{
    status =
    ux_host_class_hid_remote_control_usage_get(remote_control, &usage,
    &value);
    if (status == UX_SUCCESS)
    {
        /* We have something coming from the HID remote control, we
           filter the usage here and only allow the volume usage which can be
           VOLUME, VOLUME_INCREMENT or VOLUME_DECREMENT */
        switch(usage)
        {
            case UX_HOST_CLASS_HID_CONSUMER_VOLUME :
            case UX_HOST_CLASS_HID_CONSUMER_VOLUME_INCREMENT :
            case UX_HOST_CLASS_HID_CONSUMER_VOLUME_DECREMENT :
```

```

        if (value<0x80)
        {
            if (current_volume +
audio_control.ux_host_class_audio_control_res < 0xffff)
                current_volume = current_volume +
audio_control.ux_host_class_audio_control_res;
            }
            else
            {
                if (current_volume >
audio_control.ux_host_class_audio_control_res)
                    current_volume = current_volume-
audio_control.ux_host_class_audio_control_res;
            }

            audio_control.ux_host_class_audio_control_channel = 1;
            audio_control.ux_host_class_audio_control =
UX_HOST_CLASS_AUDIO_VOLUME_CONTROL;
            audio_control.ux_host_class_audio_control_cur =
current_volume;
            status = ux_host_class_audio_control_value_set(audio,
&audio_control);

            audio_control.ux_host_class_audio_control_channel = 2;
            audio_control.ux_host_class_audio_control =
UX_HOST_CLASS_AUDIO_VOLUME_CONTROL;
            audio_control.ux_host_class_audio_control_cur =
current_volume;
            status = ux_host_class_audio_control_value_set(audio,
&audio_control);

            break;
        }
    }
    tx_thread_sleep(10);
}

```

## ux\_host\_class\_asix\_read

---

Read from the asix interface

### Prototype

```
UINT  ux_host_class_asix_read(UX_HOST_CLASS_ASIX *asix, UCHAR *data_pointer,  
                              ULONG requested_length, ULONG *actual_length)
```

### Description

This function reads from the asix interface. The call is blocking and only returns when there is either an error or when the transfer is complete.

### Parameters

<b>asix</b>	Pointer to the asix class instance.
<b>data_pointer</b>	Pointer to the buffer address of the data payload.
<b>requested_length</b>	Length to be received.
<b>actual_length</b>	Length actually received.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, reading incomplete.

### Example

```
UINT  status;  
  
/* The following example illustrates this service. */  
  
status = ux_host_class_asix_read(asix, data_pointer,  
                                requested_length, &actual_length);  
  
/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_asix\_write

---

Write to the asix interface

### Prototype

```
UINT ux_host_class_asix_write(VOID *asix_class, NX_PACKET *packet)
```

### Description

This function writes to the asix interface. The call is non blocking.

### Parameters

<b>asix</b>	Pointer to the asix class instance.
<b>packet</b>	Netx data packet

### Return Values

<b>UX_SUCCESS</b>	(0x00) The data transfer was completed.
<b>UX_ERROR</b>	(0xFF) Transfer could not be requested.

### Example

```
UINT status;

/* The following example illustrates this service. */

status = ux_host_class_asix_write(asix, packet);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_cdc\_acm\_read

---

Read from the cdc\_acm interface

### Prototype

```
UINT  ux_host_class_cdc_acm_read(UX_HOST_CLASS_CDC_ACM *cdc_acm,
                                  UCHAR *data_pointer,
                                  ULONG requested_length,
                                  ULONG *actual_length)
```

### Description

This function reads from the cdc\_acm interface. The call is blocking and only returns when there is either an error or when the transfer is complete.

### Parameters

<b>cdc_acm</b>	Pointer to the cdc_acm class instance.
<b>data_pointer</b>	Pointer to the buffer address of the data payload.
<b>requested_length</b>	Length to be received.
<b>actual_length</b>	Length actually received.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, reading incomplete.

### Example

```
UINT  status;

/* The following example illustrates this service. */

status = ux_host_class_cdc_acm_read(cdc_acm, data_pointer,
                                     requested_length, &actual_length);

/* If status equals UX_SUCCESS, the operation was successful. */
```



## ux\_host\_class\_cdc\_acm\_write

---

Write to the cdc\_acm interface

### Prototype

```
UINT  ux_host_class_cdc_acm_write(UX_HOST_CLASS_CDC_ACM *cdc_acm,
                                   UCHAR *data_pointer,
                                   ULONG requested_length,
                                   ULONG *actual_length)
```

### Description

This function writes to the cdc\_acm interface. The call is blocking and only returns when there is either an error or when the transfer is complete.

### Parameters

<b>cdc_acm</b>	Pointer to the cdc_acm class instance.
<b>data_pointer</b>	Pointer to the buffer address of the data payload.
<b>requested_length</b>	Length to be sent.
<b>actual_length</b>	Length actually sent.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, writing incomplete.

### Example

```
UINT  status;

/* The following example illustrates this service. */

status = ux_host_class_cdc_acm_write(cdc_acm, data_pointer,
                                     requested_length, &actual_length);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_cdc\_acm\_ioctl

---

Perform an IOCTL function to the cdc\_acm interface

### Prototype

```
UINT  ux_host_class_cdc_acm_ioctl(UX_HOST_CLASS_CDC_ACM *cdc_acm,  
                                  ULONG ioctl_function, VOID *parameter)
```

### Description

This function performs a specific ioctl function to the cdc\_acm interface. The call is blocking and only returns when there is either an error or when the command is completed.

### Parameters

<b>cdc_acm</b>	Pointer to the cdc_acm class instance.
<b>ioctl_function</b>	ioctl function to be performed. See table below for one of the allowed ioctl functions.
<b>parameter</b>	Pointerto a parameter specific to the ioctl

### Return Value

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory.
<b>UX_HOST_CLASS_UNKNOWN</b>	(0x59)	Wrong class instance
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Unknown IOCTL function

### IOCTL functions:

```
UX_HOST_CLASS_CDC_ACM_IOCTL_SET_LINE_CODING  
UX_HOST_CLASS_CDC_ACM_IOCTL_GET_LINE_CODING  
UX_HOST_CLASS_CDC_ACM_IOCTL_SET_LINE_STATE  
UX_HOST_CLASS_CDC_ACM_IOCTL_SEND_BREAK  
UX_HOST_CLASS_CDC_ACM_IOCTL_ABORT_IN_PIPE  
UX_HOST_CLASS_CDC_ACM_IOCTL_ABORT_OUT_PIPE  
UX_HOST_CLASS_CDC_ACM_IOCTL_NOTIFICATION_CALLBACK  
UX_HOST_CLASS_CDC_ACM_IOCTL_GET_DEVICE_STATUS
```

## Example

```
UINT    status;

/* The following example illustrates this service. */

status = ux_host_class_cdc_acm_write(cdc_acm, data_pointer,
                                     requested_length, &actual_length);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_cdc\_ecm\_read

---

Read from the cdc\_ecm interface

### Prototype

```
UINT  ux_host_class_cdc_ecm_read(UX_HOST_CLASS_CDC_ECM *cdc_ecm,
                                  UCHAR *data_pointer,
                                  ULONG requested_length,
                                  ULONG *actual_length)
```

### Description

This function reads from the cdc\_ecm interface. The call is blocking and only returns when there is either an error or when the transfer is complete.

### Parameters

<b>cdc_ecm</b>	Pointer to the cdc_ecm class instance.
<b>data_pointer</b>	Pointer to the buffer address of the data payload.
<b>requested_length</b>	Length to be received.
<b>actual_length</b>	Length actually received.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, reading incomplete.

### Example

```
UINT  status;

/* The following example illustrates this service. */

status = ux_host_class_cdc_ecm_read(cdc_cm, data_pointer,
                                     requested_length, &actual_length);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_cdc\_ecm\_write

---

Write to the cdc\_ecm interface

### Prototype

```
UINT  ux_host_class_cdc_ecm_write(VOID *cdc_ecm_class, NX_PACKET *packet)
```

### Description

This function writes to the cdc\_ecm interface. The call is non blocking.

### Parameters

<b>cdc_ecm</b>	Pointer to the cdc_ecm class instance.
<b>packet</b>	Netx data packet

### Return Values

<b>UX_SUCCESS</b>	(0x00) The data transfer was completed.
<b>UX_ERROR</b>	(0xFF) Transfer could not be requested

### Example

```
UINT  status;

/* The following example illustrates this service. */

status = ux_host_class_cdc_ecm_write(cdc_ecm, packet);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_pima\_session\_open

---

Open a session between Initiator and Responder

### Prototype

```
UINT  ux_host_class_pima_session_open(UX_HOST_CLASS_PIMA *pima,  
                                       UX_HOST_CLASS_PIMA_SESSION *pima_session)
```

### Description

This function opens a session between a PIMA Initiator and a PIMA Responder. Once a session is successfully opened, most PIMA commands can be executed.

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session

### Return Values

<b>UX_SUCCESS</b>	(0x00)	Session successfully opened
<b>UX_HOST_CLASS_PIMA_RC_SESSION_ALREADY_OPENED</b>	(0x201E)	Session already opened

### Example

```
/* Open a pima session. */  
status = ux_host_class_pima_session_open(pima, pima_session);  
  
if (status != UX_SUCCESS)  
    return(UX_PICTBRIDGE_ERROR_SESSION_NOT_OPEN);
```

## ux\_host\_class\_pima\_session\_close

---

Close a session between Initiator and Responder

### Prototype

```
UINT  ux_host_class_pima_session_close(UX_HOST_CLASS_PIMA *pima,  
                                         UX_HOST_CLASS_PIMA_SESSION *pima_session)
```

### Description

This function closes a session that was previously opened between a PIMA Initiator and a PIMA Responder. Once a session is closed, most PIMA commands can no longer be executed.

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The session was closed
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened

### Example

```
/* Close the pima session. */  
status = ux_host_class_pima_session_close(pima, pima_session);
```

## ux\_host\_class\_pima\_storage\_ids\_get

---

Obtain the storage ID array from Responder

### Prototype

```
UINT  ux_host_class_pima_storage_ids_get(UX_HOST_CLASS_PIMA *pima,
                                          UX_HOST_CLASS_PIMA_SESSION *pima_session,
                                          ULONG *storage_ids_array,
                                          ULONG storage_id_length)
```

### Description

This function obtains the storage ID array from the responder.

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>storage_ids_array</b>	Array where storage IDs will be returned
<b>storage_id_length</b>	Length of the storage array

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The storage ID array has been populated
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command.

### Example

```
/* Get the number of storage IDs. */
status = ux_host_class_pima_storage_ids_get(pima, pima_session,
                                             pictbridge -> ux_pictbridge_storage_ids, 64);

if (status != UX_SUCCESS)
{
    /* Close the pima session. */
    status = ux_host_class_pima_session_close(pima, pima_session);

    return(UX_PICTBRIDGE_ERROR_STORE_NOT_AVAILABLE);
}
```



## ux\_host\_class\_pima\_storage\_info\_get

---

Obtain the storage information from Responder

### Prototype

```
UINT  ux_host_class_pima_storage_info_get(UX_HOST_CLASS_PIMA *pima,
                                           UX_HOST_CLASS_PIMA_SESSION *pima_session,
                                           ULONG storage_id,
                                           UX_HOST_CLASS_PIMA_STORAGE *storage)
```

### Description

This function obtains the storage information for a storage container of value storage\_id

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>storage_id</b>	ID of the storage container
<b>storage</b>	Pointer to storage information container

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The storage information was retrieved
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command.

### Example

```
/* Get the first storage ID info container.    */
status = ux_host_class_pima_storage_info_get(pima, pima_session,
                                             pictbridge -> ux_pictbridge_storage_ids[0],
                                             (UX_HOST_CLASS_PIMA_STORAGE *)pictbridge ->
                                             ux_pictbridge_storage);

if (status != UX_SUCCESS)
{
    /* Close the pima session.    */
    status = ux_host_class_pima_session_close(pictbridge ->
                                              ux_pictbridge_pima, pima_session);

    return(UX_PICTBRIDGE_ERROR_STORE_NOT_AVAILABLE);
}
```

## ux\_host\_class\_pima\_num\_objects\_get

Obtain the number of objects on a storage container from Responder

### Prototype

```
UINT ux_host_class_pima_num_objects_get(UX_HOST_CLASS_PIMA *pima,  
                                         UX_HOST_CLASS_PIMA_SESSION *pima_session,  
                                         ULONG storage_id,  
                                         ULONG object_format_code)
```

### Description

This function obtains the number of objects stored on a specific storage container of value `storage_id` matching a specific format code. The number of objects is returned in the field: `ux_host_class_pima_session_nb_objects` of the `pima_session` structure.

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>storage_id</b>	ID of the storage container
<b>object_format_code</b>	Objects format code filter.

The Object Format Codes can have one of the following values:

Object Format Code	Description	USBX code
0x3000	Undefined Undefined non-image object	UX_HOST_CLASS_PIMA_OFC_UNDEFINED
0x3001	Association Association (e.g. folder)	UX_HOST_CLASS_PIMA_OFC_ASSOCIATION
0x3002	Script Device-model-specific script	UX_HOST_CLASS_PIMA_OFC_SCRIPT
0x3003	Executable Device-model-specific binary executable	UX_HOST_CLASS_PIMA_OFC_EXECUTABLE
0x3004	Text Text file	UX_HOST_CLASS_PIMA_OFC_TEXT
0x3005	HTML HyperText Markup Language file (text)	UX_HOST_CLASS_PIMA_OFC_HTML
0x3006	DPOF Digital Print Order Format file (text)	UX_HOST_CLASS_PIMA_OFC_DPOF
0x3007	AIFF Audio clip	UX_HOST_CLASS_PIMA_OFC_AIFF
0x3008	WAV Audio clip	UX_HOST_CLASS_PIMA_OFC_WAV

0x3009	MP3 Audio clip	UX_HOST_CLASS_PIMA_OFC_MP3
0x300A	AVI Video clip	UX_HOST_CLASS_PIMA_OFC_AVI
0x300B	MPEG Video clip	UX_HOST_CLASS_PIMA_OFC_MPEG
0x300C	ASF Microsoft Advanced Streaming Format (video)	UX_HOST_CLASS_PIMA_OFC_ASF
0x3800	Undefined Unknown image object	UX_HOST_CLASS_PIMA_OFC_QT
0x3801	EXIF/JPEG Exchangeable File Format, JEIDA standard	UX_HOST_CLASS_PIMA_OFC_EXIF_JPEG
0x3802	TIFF/EP Tag Image File Format for Electronic Photography	UX_HOST_CLASS_PIMA_OFC_TIFF_EP
0x3803	FlashPix Structured Storage Image Format	UX_HOST_CLASS_PIMA_OFC_FLASHPIX
0x3804	BMP Microsoft Windows Bitmap file	UX_HOST_CLASS_PIMA_OFC_BMP
0x3805	CIFF Canon Camera Image File Format	UX_HOST_CLASS_PIMA_OFC_CIFF
0x3806	Undefined Reserved	
0x3807	GIF Graphics Interchange Format	UX_HOST_CLASS_PIMA_OFC_GIF
0x3808	JFIF JPEG File Interchange Format	UX_HOST_CLASS_PIMA_OFC_JFIF
0x3809	PCD PhotoCD Image Pac	UX_HOST_CLASS_PIMA_OFC_PCD
0x380A	PICT Quickdraw Image Format	UX_HOST_CLASS_PIMA_OFC_PICT
0x380B	PNG Portable Network Graphics	UX_HOST_CLASS_PIMA_OFC_PNG
0x380C	Undefined Reserved	
0x380D	TIFF Tag Image File Format	UX_HOST_CLASS_PIMA_OFC_TIFF
0x380E	TIFF/IT Tag Image File Format for Information Technology (graphic arts)	UX_HOST_CLASS_PIMA_OFC_TIFF_IT
0x380F	JP2 JPEG2000 Baseline File Format	UX_HOST_CLASS_PIMA_OFC_JP2
0x3810	JPX JPEG2000 Extended File Format	UX_HOST_CLASS_PIMA_OFC_JPX

All other codes with MSN of 0011	Any Undefined Reserved for future use	
All other codes with MSN of 1011	Any Vendor-Defined Vendor-Defined type: Image	

## Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command.

## Example

```

/* Get the number of objects on all containers matching a SCRIPT
   object. */
status = ux_host_class_pima_num_objects_get(pima, pima_session,
      UX_PICTBRIDGE_ALL_CONTAINERS, UX_PICTBRIDGE_OBJECT_SCRIPT);
if (status != UX_SUCCESS)
{
    /* Close the pima session. */
    status = ux_host_class_pima_session_close(pima, pima_session);

    return(UX_PICTBRIDGE_ERROR_STORE_NOT_AVAILABLE);
}
else
    /* The number of objects is returned in the field: pima_session -
       > ux_host_class_pima_session_nb_objects */

```

## ux\_host\_class\_pima\_object\_handles\_get

Obtain object handles from Responder

### Prototype

```
UINT ux_host_class_pima_object_handles_get(UX_HOST_CLASS_PIMA *pima,  
                                            UX_HOST_CLASS_PIMA_SESSION *pima_session,  
                                            ULONG *object_handles_array,  
                                            ULONG object_handles_length,  
                                            ULONG storage_id,  
                                            ULONG object_format_code,  
                                            ULONG object_handle_association)
```

### Description

Returns an array of Object Handles present in the storage container indicated by the storage\_id parameter. If an aggregated list across all stores is desired, this value shall be set to 0xFFFFFFFF.

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>object_handles_array</b>	Array where handles are returned
<b>object_handles_length</b>	Length of the array
<b>storage_id</b>	ID of the storage container
<b>object_format_code</b>	Format code for object (see table for function ux_host_class_pima_num_objects_get)
<b>object_handle_association</b>	Optional object association value

The object handle association can be one of the value from the table below:

AssociationCode	AssociationType	AssociationDesc Interpretation
0x0000	Undefined	Undefined
0x0001	GenericFolder	Unused
0x0002	Album	Reserved
0x0003	TimeSequence	DefaultPlaybackDelta
0x0004	HorizontalPanoramic	Unused
0x0005	VerticalPanoramic	Unused
0x0006	2DPanoramic	ImagesPerRow
0x0007	AncillaryData	Undefined
All other values with bit 15 set to 0	Reserved	Undefined
All values with bit 15 set to 1	Vendor-Defined	Vendor-Defined

## Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command.

## Example

```
/* Get the array of objects handles on the container. */
status = ux_host_class_pima_object_handles_get(pima, pima_session,
    pictbridge -> ux_pictbridge_object_handles_array,
    4 * pima_session -> ux_host_class_pima_session_nb_objects,
    UX_PICTBRIDGE_ALL_CONTAINERS,
    UX_PICTBRIDGE_OBJECT_SCRIPT, 0);

if (status != UX_SUCCESS)
{
    /* Close the pima session. */
    status = ux_host_class_pima_session_close(pima, pima_session);

    return(UX_PICTBRIDGE_ERROR_STORE_NOT_AVAILABLE);
}
```

## ux\_host\_class\_pima\_object\_info\_get

---

Obtain the object information from Responder

### Prototype

```
UINT  ux_host_class_pima_object_info_get(UX_HOST_CLASS_PIMA *pima,  
                                          UX_HOST_CLASS_PIMA_SESSION *pima_session,  
                                          ULONG object_handle,  
                                          UX_HOST_CLASS_PIMA_OBJECT *object)
```

### Description

This function obtains the object information for an object handle.

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>object_handle</b>	Handle of the object
<b>object</b>	Pointer to object information container

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command.

## Example

```
/* We search for an object that is a picture or a script. */
object_index = 0;
while (object_index < pima_session ->
        ux_host_class_pima_session_nb_objects)
{
    /* Get the object info structure. */
    status = ux_host_class_pima_object_info_get(pima, pima_session,
        pictbridge ->
            ux_pictbridge_object_handles_array[object_index],
            pima_object);
    if (status != UX_SUCCESS)
    {
        /* Close the pima session. */
        status = ux_host_class_pima_session_close(pima, pima_session);

        return(UX_PICTBRIDGE_ERROR_INVALID_OBJECT_HANDLE );
    }
}
```



## ux\_host\_class\_pima\_object\_info\_send

---

Send the object information to Responder

### Prototype

```
UINT ux_host_class_pima_object_info_send(UX_HOST_CLASS_PIMA *pima,
                                          UX_HOST_CLASS_PIMA_SESSION *pima_session,
                                          ULONG storage_id,
                                          ULONG parent_object_id,
                                          UX_HOST_CLASS_PIMA_OBJECT *object)
```

### Description

This function sends the storage information for a storage container of value storage\_id. The Initiator should use this command before sending an object to the responder.

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>storage_id</b>	Destination storage ID
<b>parent_object_id</b>	Parent ObjectHandle on Responder where object should be placed
<b>object</b>	Pointer to object information container

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command.

## Example

```
/* Send a script info. */
status = ux_host_class_pima_object_info_send(pima, pima_session,
                                              0, 0, pima_object);

if (status != UX_SUCCESS)
{
    /* Close the pima session. */
    status = ux_host_class_pima_session_close(pima, pima_session);

    return(UX_ERROR );
}
```

## ux\_host\_class\_pima\_object\_open

---

Open an object stored in the Responder

### Prototype

```
UINT ux_host_class_pima_object_open(UX_HOST_CLASS_PIMA *pima,  
                                     UX_HOST_CLASS_PIMA_SESSION *pima_session,  
                                     ULONG object_handle,  
                                     UX_HOST_CLASS_PIMA_OBJECT *object)
```

### Description

This function opens an object on the responder before reading or writing.

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>object_handle</b>	handle of the object
<b>object</b>	Pointer to object information container

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened.
<b>UX_HOST_CLASS_PIMA_RC_OBJECT_ALREADY_OPENED</b>	(0x2021)	Object already opened.
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command.

### Example

```
/* Open the object. */  
status = ux_host_class_pima_object_open(pima, pima_session,  
                                         object_handle, pima_object);
```

```
/* Check status. */  
if (status != UX_SUCCESS)  
    return(status);
```

## ux\_host\_class\_pima\_object\_get

---

Get an object stored in the Responder

### Prototype

```
UINT ux_host_class_pima_object_get(UX_HOST_CLASS_PIMA *pima,
                                   UX_HOST_CLASS_PIMA_SESSION *pima_session,
                                   ULONG object_handle,
                                   UX_HOST_CLASS_PIMA_OBJECT *object,
                                   UCHAR *object_buffer,
                                   ULONG object_buffer_length,
                                   ULONG *object_actual_length)
```

### Description

This function gets an object on the responder.

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>object_handle</b>	handle of the object
<b>object</b>	Pointer to object information container
<b>object_buffer</b>	Address of object data
<b>object_buffer_length</b>	Requested length of object
<b>object_actual_length</b>	Length of object returned

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The object was transferred
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_HOST_CLASS_PIMA_RC_OBJECT_NOT_OPENED</b>	(0x2023)	Object not opened.
<b>UX_HOST_CLASS_PIMA_RC_ACCESS_DENIED</b>	(0x200f)	Access to object denied
<b>UX_HOST_CLASS_PIMA_RC_INCOMPLETE_TRANSFER</b>	(0x2007)	Transfer is incomplete
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command.
<b>UX_TRANSFER_ERROR</b>	(0x23)	Transfer error while reading object

## Example

```
/* Open the object. */
status = ux_host_class_pima_object_open(pima, pima_session,
                                         object_handle, pima_object);

/* Check status. */
if (status != UX_SUCCESS)
    return(status);

/* Set the object buffer pointer. */
object_buffer = pima_object -> ux_host_class_pima_object_buffer;

/* Obtain all the object data. */
while(object_length != 0)
{
    /* Calculate what length to request. */
    if (object_length > UX_PICTBRIDGE_MAX_PIMA_OBJECT_BUFFER)

        /* Request maximum length. */
        requested_length = UX_PICTBRIDGE_MAX_PIMA_OBJECT_BUFFER;
    else

        /* Request remaining length. */
        requested_length = object_length;

    /* Get the object data. */
    status = ux_host_class_pima_object_get(pima, pima_session,
                                           object_handle, pima_object, object_buffer,
                                           requested_length, &actual_length);

    if (status != UX_SUCCESS)
    {
        /* We had a problem, abort the transfer. */
        ux_host_class_pima_object_transfer_abort(pima, pima_session,
                                                object_handle, pima_object);

        /* And close the object. */
        ux_host_class_pima_object_close(pima, pima_session,
                                       object_handle, pima_object,
                                       object);

        return(status);
    }

    /* We have received some data, update the length remaining. */
    object_length -= actual_length;

    /* Update the buffer address. */
    object_buffer += actual_length;
}

/* Close the object. */
status = ux_host_class_pima_object_close(pima, pima_session,
                                         object_handle,
                                         pima_object, object);
```

## ux\_host\_class\_pima\_object\_send

---

Send an object stored in the Responder

### Prototype

```
UINT  ux_host_class_pima_object_send(UX_HOST_CLASS_PIMA *pima,
                                      UX_HOST_CLASS_PIMA_SESSION *pima_session,
                                      UX_HOST_CLASS_PIMA_OBJECT *object,
                                      UCHAR *object_buffer, ULONG object_buffer_length)
```

### Description

This function sends an object to the responder

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>object_handle</b>	handle of the object
<b>object</b>	Pointer to object information container
<b>object_buffer</b>	Address of object data
<b>object_buffer_length</b>	Requested length of object

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_HOST_CLASS_PIMA_RC_OBJECT_NOT_OPENED</b>	(0x2023)	Object not opened.
<b>UX_HOST_CLASS_PIMA_RC_ACCESS_DENIED</b>	(0x200f)	Access to object denied
<b>UX_HOST_CLASS_PIMA_RC_INCOMPLETE_TRANSFER</b>	(0x2007)	Transfer is incomplete
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create

## UX\_TRANSFER\_ERROR

(0x23)

PIMA  
command.  
Transfer  
error while  
writing  
object

### Example

```
/* Open the object. */
status = ux_host_class_pima_object_open(pima, pima_session,
                                         object_handle,
                                         pima_object);

/* Get the object length. */
object_length = pima_object -> ux_host_class_pima_object_compressed_size;

/* Recall the object buffer address. */
pima_object_buffer = pima_object -> ux_host_class_pima_object_buffer;

/* Send all the object data. */
while(object_length != 0)
{
    /* Calculate what length to request. */
    if (object_length > UX_PICTBRIDGE_MAX_PIMA_OBJECT_BUFFER)

        /* Request maximum length. */
        requested_length = UX_PICTBRIDGE_MAX_PIMA_OBJECT_BUFFER;

    else

        /* Request remaining length. */
        requested_length = object_length;

    /* Send the object data. */
    status = ux_host_class_pima_object_send(pima, pima_session, pima_object,
                                             pima_object_buffer, requested_length);
    if (status != UX_SUCCESS)
    {
        /* Abort the transfer. */
        ux_host_class_pima_object_transfer_abort(pima, pima_session,
                                                  object_handle, pima_object);

        /* Return status. */
        return(status);
    }

    /* We have sent some data, update the length remaining. */
    object_length -= requested_length;
}

/* Close the object. */
status = ux_host_class_pima_object_close(pima, pima_session, object_handle,
```



```
pima_object, object);
```

## ux\_host\_class\_pima\_thumb\_get

---

Get a thumb object stored in the Responder

### Prototype

```
UINT ux_host_class_pima_thumb_get(UX_HOST_CLASS_PIMA *pima,  
    UX_HOST_CLASS_PIMA_SESSION *pima_session,  
    ULONG object_handle, UX_HOST_CLASS_PIMA_OBJECT *object,  
    UCHAR *thumb_buffer, ULONG thumb_buffer_length,  
    ULONG *thumb_actual_length)
```

### Description

This function gets a thumb object on the responder

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>object_handle</b>	handle of the object
<b>object</b>	Pointer to object information container
<b>thumb_buffer</b>	Address of thumb object data
<b>thumb_buffer_length</b>	Requested length of thumb object
<b>thumb_actual_length</b>	Length of thumb object returned

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_HOST_CLASS_PIMA_RC_OBJECT_NOT_OPENED</b>	(0x2023)	Object not opened.
<b>UX_HOST_CLASS_PIMA_RC_ACCESS_DENIED</b>	(0x200f)	Access to object denied
<b>UX_HOST_CLASS_PIMA_RC_INCOMPLETE_TRANSFER</b>	(0x2007)	Transfer is incomplete
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create

**UX\_TRANSFER\_ERROR**

(0x23)

PIMA  
command.  
Transfer  
error while  
reading  
object

### Example

```
/* Get the thumb object data. */
status = ux_host_class_pima_thumb_get(pima, pima_session,
                                         object_handle, pima_object, object_buffer,
                                         requested_length, &actual_length);

if (status != UX_SUCCESS)
{
    /* And close the object. */
    ux_host_class_pima_object_close(pima, pima_session,
                                     object_handle, pima_object, object);

    return(status);
}
```

## ux\_host\_class\_pima\_object\_delete

---

Delete an object stored in the Responder

### Prototype

```
UINT  ux_host_class_pima_object_delete(UX_HOST_CLASS_PIMA *pima,
                                       UX_HOST_CLASS_PIMA_SESSION *pima_session,
                                       ULONG object_handle)
```

### Description

This function deletes an object on the responder

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>object_handle</b>	handle of the object

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The object was deleted.
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_HOST_CLASS_PIMA_RC_ACCESS_DENIED</b>	(0x200f)	Cannot delete object
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command .

### Example

```
/* Delete the object. */
status = ux_host_class_pima_object_delete(pima, pima_session,
                                          object_handle, pima_object);

/* Check status. */
if (status != UX_SUCCESS)
    return(status);
```



## ux\_host\_class\_pima\_object\_close

---

Close an object stored in the Responder

### Prototype

```
UINT ux_host_class_pima_object_close(UX_HOST_CLASS_PIMA *pima,  
                                     UX_HOST_CLASS_PIMA_SESSION *pima_session,  
                                     ULONG object_handle,  
                                     UX_HOST_CLASS_PIMA_OBJECT *object)
```

### Description

This function closes an object on the responder

### Parameters

<b>pima</b>	Pointer to the pima class instance.
<b>pima_session</b>	Pointer to PIMA session
<b>object_handle</b>	Pandle of the object
<b>object</b>	Pointer to object

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The object was closed
<b>UX_HOST_CLASS_PIMA_RC_SESSION_NOT_OPEN</b>	(0x2003)	Session not opened
<b>UX_HOST_CLASS_PIMA_RC_OBJECT_NOT_OPENED</b>	(0x2023)	Object not opened.
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory to create PIMA command .

### Example

```
/* Close the object. */  
status = ux_host_class_pima_object_close(pima, pima_session,  
                                         object_handle, object);
```



## ux\_host\_class\_gser\_read

---

Read from the generic serial interface

### Prototype

```
UINT  ux_host_class_gser_read(UX_HOST_CLASS_GSER *gser,  
                              ULONG interface_index, UCHAR *data_pointer,  
                              ULONG requested_length,  
                              ULONG *actual_length)
```

### Description

This function reads from the generic serial interface. The call is blocking and only returns when there is either an error or when the transfer is complete.

### Parameters

<b>gser</b>	Pointer to the gser class instance.
<b>interface_index</b>	Interface index to read from
<b>data_pointer</b>	Pointer to the buffer address of the data payload
<b>requested_length</b>	Length to be received.
<b>actual_length</b>	Length actually received.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, reading incomplete.

### Example

```
UINT  status;  
  
/* The following example illustrates this service. */  
status = ux_host_class_gser_read(cdc_acm, interface_index, data_pointer,  
                                requested_length, &actual_length);  
  
/* If status equals UX_SUCCESS, the operation was successful. */
```



## ux\_host\_class\_gser\_write

---

Write to the generic serial interface

### Prototype

```
UINT  ux_host_class_gser_write(UX_HOST_CLASS_CDC_ACM *cdc_acm,
                               ULONG interface_index, UCHAR *data_pointer,
                               ULONG requested_length, ULONG *actual_length)
```

### Description

This function writes to the generic serial interface. The call is blocking and only returns when there is either an error or when the transfer is complete.

### Parameters

<b>gser</b>	Pointer to the gser class instance.
<b>interface_index</b>	Interface to which to write
<b>data_pointer</b>	Pointer to the buffer address of the data payload.
<b>requested_length</b>	Length to be sent.
<b>actual_length</b>	Length actually sent.

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_TRANSFER_TIMEOUT</b>	(0x5c)	Transfer timeout, writing incomplete.

### Example

```
UINT  status;

/* The following example illustrates this service. */
status = ux_host_class_cdc_acm_write(cdc_acm, data_pointer,
                                     requested_length, &actual_length);

/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_gser\_ioctl

---

Perform an IOCTL function to the generic serial interface

### Prototype

```
UINT ux_host_class_cdc_acm_ioctl(UX_HOST_CLASS_CDC_ACM *cdc_acm,  
                                ULONG ioctl_function,  
                                VOID *parameter)
```

### Description

This function performs a specific ioctl function to the gser interface. The call is blocking and only returns when there is either an error or when the command is completed.

### Parameters

<b>gser</b>	Pointer to the gser class instance.
<b>ioctl_function</b>	ioctl function to be performed. See table below for one of the allowed ioctl functions.
<b>parameter</b>	Pointerto a parameter specific to the ioctl

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_MEMORY_INSUFFICIENT</b>	(0x12)	Not enough memory.
<b>UX_HOST_CLASS_UNKNOWN</b>	(0x59)	Wrong class instance
<b>UX_FUNCTION_NOT_SUPPORTED</b>	(0x54)	Unknown IOCTL function

### IOCTL functions:

```
UX_HOST_CLASS_GSER_IOCTL_SET_LINE_CODING  
UX_HOST_CLASS_GSER_IOCTL_GET_LINE_CODING  
UX_HOST_CLASS_GSER_IOCTL_SET_LINE_STATE  
UX_HOST_CLASS_GSER_IOCTL_SEND_BREAK  
UX_HOST_CLASS_GSER_IOCTL_ABORT_IN_PIPE  
UX_HOST_CLASS_GSER_IOCTL_ABORT_OUT_PIPE  
UX_HOST_CLASS_GSER_IOCTL_NOTIFICATION_CALLBACK  
UX_HOST_CLASS_GSER_IOCTL_GET_DEVICE_STATUS
```

## Example

```
UINT    status;

/* The following example illustrates this service. */
status = ux_host_class_gser_write(gser, data_pointer, interface_index,
                                   requested_length, &actual_length);
/* If status equals UX_SUCCESS, the operation was successful. */
```

## ux\_host\_class\_gser\_reception\_start

---

Start reception on the generic serial interface

### Prototype

```
UINT  ux_host_class_gser_reception_start(UX_HOST_CLASS_GSER *gser,  
                                         UX_HOST_CLASS_GSER_RECEPTION *gser_reception)
```

### Description

This function starts the reception on the generic serial class interface. This function allows for non blocking reception. When a buffer is received, a callback is invoked into the application.

### Parameters

<b>gser</b>	Pointer to the gser class instance.
<b>gser_reception</b>	Structure containing the reception parameters

### Return Values

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_UNKNOWN</b>	(0x59)	Wrong class instance
<b>UX_ERROR</b>	(0x01)	Error

### Example

```
/* Start the reception for gser. AT commands are on interface 2. */  
gser_reception.ux_host_class_gser_reception_interface_index =  
    UX_DEMO_GSER_AT_INTERFACE;  
gser_reception.ux_host_class_gser_reception_block_size =  
    UX_DEMO_RECEPTION_BLOCK_SIZE;  
gser_reception.ux_host_class_gser_reception_data_buffer =  
    gser_reception_buffer;  
gser_reception.ux_host_class_gser_reception_data_buffer_size =  
    UX_DEMO_RECEPTION_BUFFER_SIZE;  
gser_reception.ux_host_class_gser_reception_callback =  
    tx_demo_thread_callback;  
ux_host_class_gser_reception_start(gser, &gser_reception);
```

## **ux\_host\_class\_gser\_reception\_stop**

---

Stop reception on the generic serial interface

### **Prototype**

```
UINT  ux_host_class_gser_reception_stop(UX_HOST_CLASS_GSER *gser,  
                                         UX_HOST_CLASS_GSER_RECEPTION *gser_reception)
```

### **Description**

This function stops the reception on the generic serial class interface.

### **Parameters**

<b>gser</b>	Pointer to the gser class instance.
<b>gser_reception</b>	Structure containing the reception parameters

### **Return Values**

<b>UX_SUCCESS</b>	(0x00)	The data transfer was completed.
<b>UX_HOST_CLASS_UNKNOWN</b>	(0x59)	Wrong class instance
<b>UX_ERROR</b>	(0x01)	Error


### **Example**

```
/* Stops the reception for gser. */  
ux_host_class_gser_reception_stop(gser, &gser_reception);
```

# Chapter 6: USBX DPUMP Class Considerations

USBX contains a DPUMP class for the host and device side. This class is not a standard class per se, but rather an example that illustrates how to create a simple device by using 2 bulk pipes and sending data back and forth on these 2 pipes. The DPUMP class could be used to start a custom class or for legacy RS232 devices.

USB DPUMP flow chart:



## USBX DPUMP Host Class

The host side of the DPUMP Class has 2 functions, one for sending data and one for receiving data:

```
ux_host_class_dpump_write
ux_host_class_dpump_read
```

Both functions are blocking to make the DPUMP application easier. If it is necessary to have both pipes (IN and OUT) running at the same time, the application will be required to create a transmit thread and a receive thread.

The prototype for the writing function is as follows:

```
UINT  ux_host_class_dpump_write(UX_HOST_CLASS_DPUMP *dpump,
                                UCHAR * data_pointer,
                                ULONG requested_length,
                                ULONG *actual_length)
```

Where:

- dpump is the instance of the class
- data\_pointer is the pointer to the buffer to be sent
- requested\_length is the length to send
- actual\_length is the length sent after completion of the transfer, either successfully or partially.

The prototype for the receiving function is the same:

```
UINT  ux_host_class_dpump_read(UX_HOST_CLASS_DPUMP *dpump,
                                UCHAR *data_pointer,
                                ULONG requested_length,
                                ULONG *actual_length)
```

Here is an example of the host DPUMP class where an application writes a packet to the device side and receives the same packet on the reception:

```
/* We start with a 'A' in buffer. */
current_char = 'A';

while(1)
{
    /* Initialize the write buffer. */
    ux_utility_memory_set(out_buffer, current_char,
                          UX_HOST_CLASS_DPUMP_PACKET_SIZE);

    /* Increment the character in buffer. */
    current_char++;

    /* Check for upper alphabet limit. */
    if (current_char > 'Z')
        current_char = 'A';
```

```

/* Write to the Data Pump Bulk out endpoint. */
status = ux_host_class_dpump_write (dpump, out_buffer,
                                     UX_HOST_CLASS_DPUMP_PACKET_SIZE,
                                     &actual_length);

/* Verify that the status and the amount of data is correct. */
if ((status == UX_SUCCESS) && actual_length ==
    UX_HOST_CLASS_DPUMP_PACKET_SIZE)

{
    /* Read to the Data Pump Bulk out endpoint. */
    status = ux_host_class_dpump_read (dpump, in_buffer,
                                       UX_HOST_CLASS_DPUMP_PACKET_SIZE, &actual_length);
}

```



## USBX DPUMP Device Class

The device DPUMP class uses a thread which is started upon connection to the USB host. The thread waits for a packet coming on the Bulk Out endpoint. When a packet is received, it copies the content to the Bulk In endpoint buffer and posts a transaction on this endpoint, waiting for the host to issue a request to read from this endpoint. This provides a loopback mechanism between the Bulk Out and Bulk In endpoints.

## ***Chapter 7: USBX Pictbridge implementation***


UBSX supports the full Pictbridge implementation both on the host and the device. Pictbridge sits on top of USBX PIMA class on both sides.

The PictBridge standards allows the connection of a digital still camera or a smart phone directly to a printer without a PC, enabling direct printing to certain Pictbridge aware printers.

When a camera or phone is connected to a printer, the printer is the USB host and the camera is the USB device. However, with Pictbridge, the camera will appear as being the host and commands are driven from the camera. The camera is the storage server, the printer the storage client. The camera is the print client and the printer is, of course, the print server.

Pictbridge uses USB as a transport layer but relies on PTP (Picture Transfer Protocol) for the communication protocol.

The following is a diagram of the commands/responses between the DPS client and the DPS server when a print job occurs:



## Pictbridge client implementation

The Pictbridge on the client requires the USBX device stack and the PIMA class to be running first.

A device framework describes the PIMA class in the following way:

```

UCHAR device_framework_full_speed[] =
{
    /* Device descriptor */
    0x12, 0x01, 0x10, 0x01, 0x00, 0x00, 0x00, 0x20,
    0xA9, 0x04, 0xB6, 0x30, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x01,

    /* Configuration descriptor */
    0x09, 0x02, 0x27, 0x00, 0x01, 0x01, 0x00, 0xc0, 0x32,

    /* Interface descriptor */
    0x09, 0x04, 0x00, 0x00, 0x03, 0x06, 0x01, 0x01, 0x00,

    /* Endpoint descriptor (Bulk Out) */
    0x07, 0x05, 0x01, 0x02, 0x40, 0x00, 0x00,

    /* Endpoint descriptor (Bulk In) */
    0x07, 0x05, 0x82, 0x02, 0x40, 0x00, 0x00,

```

```

        /* Endpoint descriptor (Interrupt) */
        0x07, 0x05, 0x83, 0x03, 0x08, 0x00, 0x60

};

```

The Pima class is using the ID field 0x06 and has its subclass is 0x01 for Still Image and the protocol is 0x01 for PIMA 15740.

3 endpoints are defined in this class, 2 bulks for sending/receiving data and one interrupt for events.

Unlike other USBX device implementations, the Pictbridge application does not need to define a class itself. Rather it invokes the function `ux_pictbridge_dpsclient_start`. An example is below:

```

/* Initialize the Pictbridge string components. */
ux_utility_memory_copy
    (pictbridge.ux_pictbridge_dpslocal.ux_pictbridge_devinfo_vendor_name,
     "ExpressLogic",13);
ux_utility_memory_copy
    (pictbridge.ux_pictbridge_dpslocal.ux_pictbridge_devinfo_product_name,
     "EL_Pictbridge_Camera",21);
ux_utility_memory_copy
    (pictbridge.ux_pictbridge_dpslocal.ux_pictbridge_devinfo_serial_no,
     "ABC_123",7);
ux_utility_memory_copy
    (pictbridge.ux_pictbridge_dpslocal.ux_pictbridge_devinfo_dpsversions,
     "1.0 1.1",7);
pictbridge.ux_pictbridge_dpslocal.
    ux_pictbridge_devinfo_vendor_specific_version = 0x0100;
/* Start the Pictbridge client. */
status = ux_pictbridge_dpsclient_start(&pictbridge);

if(status != UX_SUCCESS)
    return;

```

The parameters passed to the pictbridge client are as follows:

```

pictbridge.ux_pictbridge_dpslocal.ux_pictbridge_devinfo_vendor_name
    : String of Vendor name
pictbridge.ux_pictbridge_dpslocal.ux_pictbridge_devinfo_product_name
    : String of product name
pictbridge.ux_pictbridge_dpslocal.ux_pictbridge_devinfo_serial_no,
    : String of serial number
pictbridge.ux_pictbridge_dpslocal.ux_pictbridge_devinfo_dpsversions
    : String of version
pictbridge.ux_pictbridge_dpslocal.
    ux_pictbridge_devinfo_vendor_specific_version
    : Value set to 0x0100;

```

The next step is for the device and the host to synchronize and be ready to exchange information.

This is done by waiting on an event flag as follows:

```
/* We should wait for the host and the client to discover one another. */
status = ux_utility_event_flags_get
    (&pictbridge.ux_pictbridge_event_flags_group,
     UX_PICTBRIDGE_EVENT_FLAG_DISCOVERY, TX_AND_CLEAR, &actual_flags,
     UX_PICTBRIDGE_EVENT_TIMEOUT);
```

If the state machine is in the DISCOVERY\_COMPLETE state, the camera side (the DPS client) will gather information regarding the printer and its capabilities.

If the DPS client is ready to accept a print job, its status will be set to UX\_PICTBRIDGE\_NEW\_JOB\_TRUE. It can be checked below:

```
/* Check if the printer is ready for a print job. */
if (pictbridge.ux_pictbridge_dpsclient.ux_pictbridge_devinfo_newjobok ==
    UX_PICTBRIDGE_NEW_JOB_TRUE)
    /* We can print something ... */
```

Next some print job descriptors need to be filled as follows:

```
/* We can start a new job. Fill in the JobConfig and PrintInfo structures. */
jobinfo = &pictbridge.ux_pictbridge_jobinfo;

/* Attach a printinfo structure to the job. */
jobinfo -> ux_pictbridge_jobinfo_printinfo_start = &printinfo;

/* Set the default values for print job. */
jobinfo -> ux_pictbridge_jobinfo_quality =
    UX_PICTBRIDGE_QUALITIES_DEFAULT;
jobinfo -> ux_pictbridge_jobinfo_papersize =
    UX_PICTBRIDGE_PAPER_SIZES_DEFAULT;
jobinfo -> ux_pictbridge_jobinfo_papertype =
    UX_PICTBRIDGE_PAPER_TYPES_DEFAULT;
jobinfo -> ux_pictbridge_jobinfo_filetype =
    UX_PICTBRIDGE_FILE_TYPES_DEFAULT;
jobinfo -> ux_pictbridge_jobinfo_dateprint =
    UX_PICTBRIDGE_DATE_PRINTS_DEFAULT;
jobinfo -> ux_pictbridge_jobinfo_filenameprint =
    UX_PICTBRIDGE_FILE_NAME_PRINTS_DEFAULT;
jobinfo -> ux_pictbridge_jobinfo_imageoptimize =
    UX_PICTBRIDGE_IMAGE_OPTIMIZES_OFF;
jobinfo -> ux_pictbridge_jobinfo_layout =
    UX_PICTBRIDGE_LAYOUTS_DEFAULT;
jobinfo -> ux_pictbridge_jobinfo_fixedsize =
    UX_PICTBRIDGE_FIXED_SIZE_DEFAULT;
jobinfo -> ux_pictbridge_jobinfo_cropping =
    UX_PICTBRIDGE_CROPPINGS_DEFAULT;

/* Program the callback function for reading the object data. */
jobinfo -> ux_pictbridge_jobinfo_object_data_read =
    ux_demo_object_data_copy;
```

```

/* This is a demo, the fileID is hardwired (1 and 2 for scripts, 3 for photo
   to be printed. */
printinfo.ux_pictbridge_printinfo_fileid =
    UX_PICTBRIDGE_OBJECT_HANDLE_PRINT;
ux_utility_memory_copy(printinfo.ux_pictbridge_printinfo_filename,
    "Pictbridge demo file", 20);
ux_utility_memory_copy(printinfo.ux_pictbridge_printinfo_date, "01/01/2008",
    10);

/* Fill in the object info to be printed. First get the pointer to the
   object container in the job info structure. */
object = (UX_SLAVE_CLASS_PIMA_OBJECT *) jobinfo ->
    ux_pictbridge_jobinfo_object;

/* Store the object format: JPEG picture. */
object -> ux_device_class_pima_object_format =
    UX_DEVICE_CLASS_PIMA_OFC_EXIF_JPEG;
object -> ux_device_class_pima_object_compressed_size = IMAGE_LEN;
object -> ux_device_class_pima_object_offset = 0;
object -> ux_device_class_pima_object_handle_id =
    UX_PICTBRIDGE_OBJECT_HANDLE_PRINT;
object -> ux_device_class_pima_object_length = IMAGE_LEN;

/* File name is in Unicode. */
ux_utility_string_to_unicode("JPEG Image", object ->
    ux_device_class_pima_object_filename);

/* And start the job. */
status =ux_pictbridge_dpsclient_api_start_job(&pictbridge);

```

The Pictbridge client now has a print job to do and will fetch the image blocks at a time from the application through the callback defined in the field

```

jobinfo -> ux_pictbridge_jobinfo_object_data_read

```

The prototype of that function is defined as:

## ux\_pictbridge\_jobinfo\_object\_data\_read

---

Copying a block of data from user space for printing

### Prototype

```
UINT ux_pictbridge_jobinfo_object_data_read(UX_PICTBRIDGE *pictbridge,
      UCHAR *object_buffer, ULONG object_offset, ULONG object_length,
      ULONG *actual_length)
```

### Description

This function is called when the DPS client needs to retrieve a data block to print to the target Pictbridge printer.

### Parameters

<b>pictbridge</b>	Pointer to the pictbridge class instance.
<b>object_buffer</b>	Pointer to object buffer
<b>object_offset</b>	Where we are starting to read the data block
<b>object_length</b>	Length to be returned
<b>actual_length</b>	Actual length returned

### Return Value

<b>UX_SUCCESS</b>	(0x00)	This operation was successful.
<b>UX_ERROR</b>	(0x01)	The application could not retrieve data.

### Example

```
/* Copy the object data. */
UINT ux_demo_object_data_copy(UX_PICTBRIDGE *pictbridge, UCHAR *object_buffer,
      ULONG object_offset, ULONG object_length, ULONG *actual_length)
{
    /* Copy the demanded object data portion. */
    ux_utility_memory_copy(object_buffer, image + object_offset,
        object_length);

    /* Update the actual length. */
    *actual_length = object_length;

    /* We have copied the requested data. Return OK. */
    return(UX_SUCCESS);
}
```

# Pictbridge host implementation

The host implementation of Pictbridge is different from the client.

The first thing to do in a Pictbridge host environment is to register the Pima class as the example below shows:

```
status = ux_host_stack_class_register(ux_system_host_class_pima_name,  
                                     ux_host_class_pima_entry);  
if(status != UX_SUCCESS)  
    return;
```

This class is the generic PTP layer sitting between the USB host stack and the Pictbridge layer.

The next step is to initialize the Pictbridge default values for print services as follows:

Pictbridge field	Value
DpsVersion[0]	0x00010000
DpsVersion[1]	0x00010001
DpsVersion[2]	0x00000000
VendorSpecificVersion	0x00010000
PrintServiceAvailable	0x30010000
Qualities[0]	UX_PICTBRIDGE_QUALITIES_DEFAULT
Qualities[1]	UX_PICTBRIDGE_QUALITIES_NORMAL
Qualities[2]	UX_PICTBRIDGE_QUALITIES_DRAFT
Qualities[3]	UX_PICTBRIDGE_QUALITIES_FINE
PaperSizes[0]	UX_PICTBRIDGE_PAPER_SIZES_DEFAULT
PaperSizes[1]	UX_PICTBRIDGE_PAPER_SIZES_4IX6I
PaperSizes[2]	UX_PICTBRIDGE_PAPER_SIZES_L
PaperSizes[3]	UX_PICTBRIDGE_PAPER_SIZES_2L
PaperSizes[4]	UX_PICTBRIDGE_PAPER_SIZES_LETTER
PaperTypes[0]	UX_PICTBRIDGE_PAPER_TYPES_DEFAULT
PaperTypes[1]	UX_PICTBRIDGE_PAPER_TYPES_PLAIN
PaperTypes[2]	UX_PICTBRIDGE_PAPER_TYPES_PHOTO
FileTypes[0]	UX_PICTBRIDGE_FILE_TYPES_DEFAULT
FileTypes[1]	UX_PICTBRIDGE_FILE_TYPES_EXIF_JPEG
FileTypes[2]	UX_PICTBRIDGE_FILE_TYPES_JFIF
FileTypes[3]	UX_PICTBRIDGE_FILE_TYPES_DPOF
DatePrints[0]	UX_PICTBRIDGE_DATE_PRINTS_DEFAULT
DatePrints[1]	UX_PICTBRIDGE_DATE_PRINTS_OFF
DatePrints[2]	UX_PICTBRIDGE_DATE_PRINTS_ON
FileNamePrints[0]	UX_PICTBRIDGE_FILE_NAME_PRINTS_DEFAULT
FileNamePrints[1]	UX_PICTBRIDGE_FILE_NAME_PRINTS_OFF
FileNamePrints[2]	UX_PICTBRIDGE_FILE_NAME_PRINTS_ON
ImageOptimizes[0]	UX_PICTBRIDGE_IMAGE_OPTIMIZES_DEFAULT



ImageOptimizes[1]	UX_PICTBRIDGE_IMAGE_OPTIMIZES_OFF
ImageOptimizes[2]	UX_PICTBRIDGE_IMAGE_OPTIMIZES_ON
Layouts[0]	UX_PICTBRIDGE_LAYOUTS_DEFAULT
Layouts[1]	UX_PICTBRIDGE_LAYOUTS_1_UP_BORDER
Layouts[2]	UX_PICTBRIDGE_LAYOUTS_INDEX_PRINT
Layouts[3]	UX_PICTBRIDGE_LAYOUTS_1_UP_BORDERLESS
FixedSizes[0]	UX_PICTBRIDGE_FIXED_SIZE_DEFAULT
FixedSizes[1]	UX_PICTBRIDGE_FIXED_SIZE_35IX5I
FixedSizes[2]	UX_PICTBRIDGE_FIXED_SIZE_4IX6I
FixedSizes[3]	UX_PICTBRIDGE_FIXED_SIZE_5IX7I
FixedSizes[4]	UX_PICTBRIDGE_FIXED_SIZE_7CMX10CM
FixedSizes[5]	UX_PICTBRIDGE_FIXED_SIZE_LETTER
FixedSizes[6]	UX_PICTBRIDGE_FIXED_SIZE_A4
Croppings[0]	UX_PICTBRIDGE_CROPPINGS_DEFAULT
Croppings[1]	UX_PICTBRIDGE_CROPPINGS_OFF
Croppings[2]	UX_PICTBRIDGE_CROPPINGS_ON

The state machine of the DPS host will be set to Idle and ready to accept a new print job.

The host portion of Pictbridge can now be started as the example below shows:

```
/* Activate the pictbridge dpshost. */
status = ux_pictbridge_dpshost_start(&pictbridge, pima);

if (status != UX_SUCCESS)
    return;
```

The Pictbridge host function requires a callback when data is ready to be printed. This is accomplished by passing a function pointer in the pictbridge host structure as follows:

```
/* Set a callback when an object is being received. */
pictbridge.ux_pictbridge_application_object_data_write =
    tx_demo_object_data_write;
```

This function has the following properties:

## ux\_pictbridge\_application\_object\_data\_write

---

Writing a block of data for printing

### Prototype

```
UINT ux_pictbridge_application_object_data_write(UX_PICTBRIDGE
        *pictbridge, UCHAR *object_buffer, ULONG offset,
        ULONG total_length, ULONG length);
```

### Description

This function is called when the DPS server needs to retrieve a data block from the DPS client to print to the local printer.

### Parameters

<b>pictbridge</b>	Pointer to the pictbridge class instance.
<b>object_buffer</b>	Pointer to object buffer
<b>object_offset</b>	Where we are starting to read the data block
<b>total_length</b>	Entire length of object
<b>length</b>	Length of this buffer

### Return Value

<b>UX_SUCCESS</b>	(0x00)	This operation was successful.
<b>UX_ERROR</b>	(0x01)	The application could not print data.

### Example

```
/* Copy the object data. */
UINT tx_demo_object_data_write(UX_PICTBRIDGE *pictbridge,
        UCHAR *object_buffer, ULONG offset, ULONG total_length, ULONG length);
{
    UINT status;

    /* Send the data to the local printer. */
    status = local_printer_data_send(object_buffer, length);

    /* We have printed the requested data. Return status. */
    return(status);
}
```

## ***Chapter 8: USBX OTG***

USBX supports the OTG functionalities of USB when an OTG compliant USB controller is available in the hardware design.

USBX supports OTG in the core USB stack. But for OTG to function, it requires a specific USB controller. USBX OTG controller functions can be found in the `usbx_otg` directory. The current USBX version only supports the NXP LPC3131 with full OTG capabilities.

The regular controller driver functions (host or device) can still be found in the standard USBX `usbx_device_controllers` and `usbx_host_controllers` but the `usbx_otg` directory contains the specific OTG functions associated with the USB controller.

There are 4 categories of functions for an OTG controller in addition to the usual host/device functions:

- VBUS specific functions
- Start and Stop of the controller
- USB role manager
- Interrupt handlers

## VBUS functions

Each controller needs to have a VBUS manager to change the state of VBUS based on power management requirements. Usually this function only performs turning on or off VBUS

## Start and Stop the controller

Unlike a regular USB implementation, OTG requires the host and/or the device stack to be activated and deactivated when the role changes.

## USB role Manager

The USB role manager receives commands to change the state of the USB. There are several states that need transitions to and from:

State	Value	Description
UX_OTG_IDLE	0	The device is Idle. Usually not connected to anything
UX_OTG_IDLE_TO_HOST	1	Device is connected with type A connector
UX_OTG_IDLE_TO_SLAVE	2	Device is connected with type B connector
UX_OTG_HOST_TO_IDLE	3	Host device got disconnected
UX_OTG_HOST_TO_SLAVE	4	Role swap from Host to Slave
UX_OTG_SLAVE_TO_IDLE	5	Slave device is disconnected
UX_OTG_SLAVE_TO_HOST	6	Role swap from Slave to Host

## Interrupt handlers

Both host and device controller drivers for OTG needs different interrupt handlers to monitor signals beyond traditional USB interrupts, in particular signals due to SRP and VBUS.

How to initialize a USB OTG controller. We use the NXP LPC3131 as an example here:

```
/* Initialize the LPC3131 OTG controller. */
status = ux_otg_lpc3131_initialize(0x19000000, lpc3131_vbus_function,
                                   tx_demo_change_mode_callback);
```

In this example, we initialize the LPC3131 in OTG mode by passing a VBUS function and a callback for mode change (from host to slave or vice versa).

The callback function should simply record the new mode and wake up a pending thread to act up the new state:

```
void tx_demo_change_mode_callback(ULONG mode)
{
    /* Simply save the otg mode. */
    otg_mode = mode;
```

```

    /* Wake up the thread that is waiting. */
    ux_utility_semaphore_put(&mode_change_semaphore);
}

```

The mode value that is passed can have the following values:

- UX\_OTG\_MODE\_IDLE
- UX\_OTG\_MODE\_SLAVE
- UX\_OTG\_MODE\_HOST

The application can always check what the device is by looking at the variable:

```
ux_system_otg -> ux_system_otg_device_type
```

Its values can be:

- UX\_OTG\_DEVICE\_A
- UX\_OTG\_DEVICE\_B
- UX\_OTG\_DEVICE\_IDLE

A USB OTG host device can always ask for a role swap by issuing the command:

```

/* Ask the stack to perform a HNP swap with the device. We relinquish the
   host role to A device. */
ux_host_stack_role_swap(storage -> ux_host_class_storage_device);

```

For a slave device, there is no command to issue but the slave device can set a state to change the role which will be picked up by the host when it issues a GET\_STATUS and the swap will then be initiated.

```

/* We are a B device, ask for role swap. The next GET_STATUS from the host
   will get the status change and do the HNP. */
ux_system_otg -> ux_system_otg_slave_role_swap_flag =
    UX_OTG_HOST_REQUEST_FLAG;

```

# ***Index***

Asix class, 66  
audio class, 66  
bulk in, 134, 136  
bulk out, 134, 136  
callback, 46, 47, 79, 129, 138, 139, 142, 145  
CDC-ACM class, 66  
class container, 14, 48, 50, 51, 52  
class instance, 9, 50, 51, 52, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 91, 92, 93, 94, 95, 97, 98, 99, 100, 101, 102, 103, 106, 108, 110, 112, 114, 116, 119, 121, 123, 125, 126, 127, 129, 130, 140, 143  
Class layer, 8  
configuration, 9, 14, 24, 25, 28, 29, 30, 31, 32, 33, 34, 35, 36, 38, 39, 41, 53, 54, 55, 61, 62, 65  
configuration descriptor, 28, 33, 136  
Controller layer, 8  
device descriptor, 28, 30, 43, 136  
device index, 56  
device side, 8, 11, 18, 131, 132  
DPUMP, 7, 131, 132, 133, 134  
EHCI controller, 19, 26  
endpoint descriptor, 28, 38, 136, 137  
FileX, 2, 9, 13  
functional descriptor, 28, 43  
generic serial class, 66  
handle, 31, 32, 35, 38, 41, 47, 53, 54, 57, 61, 64, 106, 108, 112, 114, 115, 116, 117, 119, 120, 121, 123, 139  
HID class, 66, 78, 79, 80, 81, 83, 84, 85, 86, 87, 89  
host controller, 9, 12, 14, 15, 16, 19, 20, 24, 25, 26, 41, 46, 59  
host side, 8, 132  
host stack, 18, 20, 23, 24, 38  
initialization, 12, 18, 19, 20, 21, 24, 26, 46, 59  
interface descriptor, 28, 35, 136  
LUN, 16  
master, 27  
memory allocate, 50, 52  
memory insufficient, 49, 50, 52, 59, 64, 70, 95, 101, 102, 105, 107, 108, 110, 112, 114, 116, 119, 121, 123, 127  
NetX, 2, 9  
OHCI controller, 14, 19, 20, 26, 60  
OTG, 7, 8, 9, 144, 145, 146  
Picture Transfer Protocol, 135  
PIMA class, 135, 136, 137, 141  
pipe, 39, 47, 64  
power management, 9, 26, 27, 145  
printer class, 66  
prolific class, 66  
receive thread, 132  
root hub, 23, 24, 25, 26, 27, 32, 33  
SCSI logical unit, 16  
semaphore, 31, 146  
slave, 145, 146  
stack layer, 8  
storage class, 66  
string descriptor, 28, 41  
target, 11, 12, 13, 16, 22, 140  
ThreadX, 2, 7, 9, 11, 12, 13, 15, 16, 24  
timer tick, 14  
TraceX, 9  
transfers, 9, 25, 26, 27, 40  
transmit thread, 132  
UNICODE, 41, 43  
USB device, 9, 28  
USB host stack, 23, 24, 25, 46, 141  
USB IF, 26, 30, 41  
USB protocol, 8, 9  
USBX components, 24  
USBX pictbridge, 7, 135  
USBX thread, 15  
VBUS, 144, 145  
version\_id, 22

---

USBX™ Host Stack User Guide

Publication Date: Rev.5.83 Nov 8, 2018

Published by: Renesas Electronics Corporation

---



## SALES OFFICES

## Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

### **Renesas Electronics Corporation**

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

### **Renesas Electronics America Inc.**

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.

Tel: +1-408-432-8888, Fax: +1-408-434-5351

### **Renesas Electronics Canada Limited**

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3

Tel: +1-905-237-2004

### **Renesas Electronics Europe Limited**

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K

Tel: +44-1628-651-700

### **Renesas Electronics Europe GmbH**

Arcadiastrasse 10, 40472 Düsseldorf, Germany

Tel: +49-211-6503-0, Fax: +49-211-6503-1327

### **Renesas Electronics (China) Co., Ltd.**

Room 1709 Quantum Plaza, No.27 ZhichunLu, Haidian District, Beijing, 100191 P. R. China

Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

### **Renesas Electronics (Shanghai) Co., Ltd.**

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, 200333 P. R. China

Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

### **Renesas Electronics Hong Kong Limited**

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

Tel: +852-2265-6688, Fax: +852 2886-9022

### **Renesas Electronics Taiwan Co., Ltd.**

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan

Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

### **Renesas Electronics Singapore Pte. Ltd.**

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949

Tel: +65-6213-0200, Fax: +65-6213-0300

### **Renesas Electronics Malaysia Sdn.Bhd.**

Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia

Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

### **Renesas Electronics India Pvt. Ltd.**

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India

Tel: +91-80-67208700, Fax: +91-80-67208777

### **Renesas Electronics Korea Co., Ltd.**

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea

Tel: +82-2-558-3737, Fax: +82-2-558-5338



# USBX™ Host Stack User Guide