


90Exx Metering Demo Board GUI



Preface

90Exx Metering Demo Board GUI is designed to meter Atmel AFE chips of ATM90E2x, ATM90E32AS and ATM90E36.

Table of Contents

1.	INTRODUCTION	3
1.1	FEATURES.....	3
1.2	KIT OVERVIEW	3
2.	GETTING STARTED	4
2.1	START GUI.....	4
2.2	CONNECTION	4
2.3	DESIGN DOCUMENTATION AND RELATED LINKS	4
3.	INTRODUCTION OF GUI	5
3.1	MAIN INTERFACE	5
3.2	REGISTER	6
3.3	METER CONFIGURATION	7
3.4	FUNCTION CONFIGURATION.....	8
3.5	MEASUREMENT	9
3.6	INTERRUPT & STATUS.....	10
3.7	CALIBRATION	11
3.8	TEMPERATURE COMPENSATION.....	13
3.9	SEGMENT COMPENSATION (ONLY FOR 90E32A)	14
3.10	FOURIER ANALYSIS.....	15
3.11	REAL TIME CLOCK.....	16
4.	REVISION HISTORY	16

1. Introduction

1.1 Features

- Optimized graphic user interface
- Expandable registers
- Data import and export supported

1.2 Kit Overview

90Exx metering demo board GUI (hereinafter referred to as GUI) is designed for evaluating ATM90E2x, ATM90E32AS and ATM90E36A metering chips. The GUI adopts user-defined DL/T645-1997 communication protocol. Metering parameters are calibrated through the RS485 interface.

2. Getting Started

2.1 Start GUI

Please download the GUI, unzip it and then launch it by clicking on 'ATM90EXX GUI.exe'.

2.2 Connection

Follow below steps to connect to the serial port through GUI.

1. Select the COM port from the drop-down list.
2. Select Baud Rate from the following selection: 1200, 2400, 4800, 9600, 19200 bps. Default is 2400 bps.
3. Click on the Connect button. GUI will perform the following:
 - a) Read meter number
 - b) Read chip part number
 - c) Display part number
 - d) Auto select the GUI functions corresponding to the part number
 - e) Read voltage and current scale from the meter

2.3 Design Documentation and Related links

The following list contains links to the most relevant documents.

1. AFE Control Board SAM4C User Guide – PDF version.
2. ATM90E25 datasheet – PDF version.
3. ATM90E32AS datasheet – PDF version.
4. ATM90E36A datasheet – PDF version.

3. Introduction of GUI

3.1 Main Interface




Figure 3-1 Main Interface

- 【1】 Serial Port Settings: configure the serial port. When complete, click on 'Connect'.
- 【2】 Function Tab: different tabs contain different functions.
- 【3】 Status Window: display operation results and status.
- 【4】 SendData Window: display the DL/T645-1997 data frame to be sent.
- 【5】 ReceiveData Window: display the DL/T645-1997 data frame received.

3.2 Register




Figure 3-2 Register

【1】 Read Reg: read register values.

- Addr: address of the register
- Count: the number of registers to read
- Read: read the specified register
- Clear: clear data in the display window
- Export: export the register reading log and save it as a .txt file
- Open: Open a .txt file and load it into GUI

【2】 Write Reg: write values to registers.

- Addr: address of the register
- Data: Data to be written
- Write: write data to the specified register
- AutoCS: if checked, check-sum will be automatically calculated
- Import: import a file and write to the registers according to the address and data in the imported file

【3】 Register list: display the complete register list

3.3 Meter Configuration




Figure 3-3 Meter configuration

- 【1】 Parameters Display Setting:** define or read the parameter items displayed on the meter panel
 - Default: display the default parameters on the meter panel
 - All On: display all the parameters on the meter panel
 - Read: read the parameters being displayed on the meter panel. The parameters that are being displayed on the meter panel will be ticked on GUI.
 - Set: display the parameters that are ticked on GUI on the meter panel
- 【2】 Meter ID**
 - Get ID: get the meter ID
 - Set ID: set the meter ID
- 【3】 Voltage & Current Scale**
 - Voltage Scale: voltage scale value read from or to be written to the meter.
 - Current Scale: current scale value read from or to be written to the meter.
 - Get UIScale: read the voltage and current scale parameters.
 - Set UIScale: set the voltage and current scale values.
- 【4】 Meter Constant**
 - Set: click to set the meter constant
- 【5】 Power Mode**
 - Power Mode Switch: select a power mode from the drop down box
 - Set: set the power mode
- 【6】 Detect Mode Control**
 - Tick to set current channel positive power-down or negative power down in Detect Mode.

3.4 Function Configuration




Figure 3-4 Function Configuration

- 【1】 Startup Power:
 - Un
 - Active Startup Power
 - Reactive Startup Power
 - Apparent Startup Power
 - Set: click to configure the above values
- 【2】 Startup Power for Phase Participating:
 - Active Startup Power
 - Reactive Startup Power
 - Apparent Startup Power
 - Set: click to configure the above values
- 【3】 Voltage Sag & Phase Loss:
 - Voltage Sag Threshold
 - Phase Loss Threshold
 - Set: click to configure the above values
- 【4】 Zero Crossing:
 - Disable All ZX: click to disable all ZX
 - Set: click to configure ZX0/1/2 sources and polarity
- 【5】 Neutral Current Detection:
 - Calculated N Line Current Threshold
 - Sampled N Line Current Threshold
 - Set: click to configure the above values

3.5 Measurement




Figure 3-5 Measurement

【1】 Parameter Measurement:

- Urms (V): voltage RMS
- Irms (A): current RMS
- Pmean (kW): mean active power
- Qmean (kW): mean reactive power
- Smean (kW): mean apparent power
- PF: Power Factor
- PmeanF (kW): mean fundamental active power
- PmeanH (kW): mean harmonic active power
- Phase Angle
- Freq (Hz)

Refresh: click to read the above parameters

3.6 Interrupt & Status




Figure 3-6 Interrupt & Status

【1】 Pin Status

- IRQ1: IRQ1 pin status
 - IRQ0: IRQ0 pin status
 - Warnout: Warnout pin status
- Read: click to read the above parameters

【2】 Interrupt & EMM Status

- SysStatus0 [0x01]
 - SysStatus0 [0x02]
 - EnSysStatus0 [0x95]
 - EnStatus1 [0x96]
- Read: click to read the above registers
View Register Bits: click to read the bit values of the selected register.

【3】 Interrupt Configuration

- FuncEn0 [0x03]: input the value to be written to 0x03
Set: click to set the value to 0x03
FuncEn1 [0x04]: input the value to be written to 0x04
Set: click to set the value to 0x04

3.7 Calibration




Figure 3-7 Calibration

【1】 Normal Mode Calibration:

Configuration

- Wire Type
- Grid Frequency
- Current Sampling Type
- Meter Constant
- Current PGA Gain
- Voltage PGA Gain
- Voltage Scale
- Current Scale

Calibration

- Current Offset Calibration
- Power Offset Calibration
- Measurement Calibration

Start: click to start calibration which sequentially includes the following:

- Voltage and Current. Refer to Figure 3-8.
- Energy (Phase A). Refer to Figure 3-9.
- Phase Angle (Phase A). Refer to Figure 3-10.
- Energy (Phase B)
- Phase Angle (Phase B)
- Energy (Phase C)
- Phase Angle (Phase C)




Figure 3-8 Voltage and Current Calibration




Figure 3-9 Energy Calibration (Phase A)




Figure 3-10 Phase Angel Calibration (Phase A)

3.8 Temperature Compensation




Figure 3-8 Temperature Compensation

【1】 Temperature Sensor

- Temperature Calibration
 - o Temperature Coefficient
 - o Temperature OffsetSet: click to configure temperature sensor
- Chip Temperature
 - o TemperatureRead: click to read chip temperature

【2】 ADC Temperature Compensation

- Normal Temperature
 - Temperature Compensation Gain
- Set: click to set the specified temperature and gain
-
- Disable Compensation: click to disable the current compensation

【3】 Reference Voltage Based Temperature Compensation

- Specify compensation at different temperatures
Default: click to read the default values
Set: click to configure the specified values

3.9 Segment Compensation (only for 90E32A)




Figure 3-9 Compensation

【1】 GainIrms Compensation: current RMS gain compensation

- PhaseA: phase A
- PhaseB: phase B
- PhaseC: phase C
- Error (I0): error at current I0
- Error (I1): error at current I1
- IrmsMax: current RMS at Imax
- Error (Max): error at Imax
- IrmsMin: current RMS at Imin
- Error (Min): error at Imin
- Set: click to configure the above values

【2】 Philrms Compensation: phase current RMS compensation

- PhaseA: phase A
- PhaseB: phase B
- PhaseC: phase C
- Error (I0): error at current I0
- Error (I1): error at current I1
- IrmsMax: current RMS at Imax
- Error (Max): error at Imax
- IrmsMin: current RMS at Imin
- Error (Min): error at Imin
- Set: click to configure the above values

【3】 PhiFreq Compensation: phase frequency compensation

- Freq0: frequency 0
- Error (F0): error at frequency 0
- Freq1: frequency 1
- Error (F1): error at frequency 1
- Set: click to configure the above values

3.10 Fourier Analysis




Figure 3-10 Fourier Analysis

【1】 THD+N

- THDNUA: phase A voltage THD
- THDNIA: phase A current THD
- THDNUB: phase B voltage THD
- THDNIB: phase B current THD
- THDNUC: phase C voltage THD
- THDNIC: phase C current THD

Read: click to get values of the above parameters

【2】 THD Test

Start Harmonic Order: the harmonic order to start with

Test: click to start test

3.11 Real Time Clock




Figure 3-10 Real Time Clock

- 【1】 Real Time Clock
- System Clock
Set to Meter: click to set the meter clock with the system clock
 - Meter Clock
Read: click to read the meter clock
Set: click to set the meter clock with the configured values

4. Revision History

Doc. Rev.	Date	Comments
1.0	09/09/2013	Initial release.



Enabling Unlimited Possibilities®

Atmel Corporation

1600 Technology Drive
San Jose, CA 95110
USA

Tel: (+1)(408) 441-0311

Fax: (+1)(408) 487-2600

www.atmel.com

Atmel Asia Limited

Unit 01-5 & 16, 19F
BEA Tower, Millennium City 5
418 Kwun Tong Road
Kwun Tong, Kowloon

HONG KONG

Tel: (+852) 2245-6100

Fax: (+852) 2722-1369

Atmel Munich GmbH

Business Campus
Parkring 4
D-85748 Garching b. Munich
GERMANY

Tel: (+49) 89-31970-0

Fax: (+49) 89-3194621

Atmel Japan G.K.

16F Shin-Osaki Kangyo Bldg.
1-6-4 Osaki, Shinagawa-ku
Tokyo 141-0032

JAPAN

Tel: (+81)(3) 6417-0300

Fax: (+81)(3) 6417-0370

© 2013 Atmel Corporation. All rights reserved. / Rev.: 1.0

Atmel®, Atmel logo and combinations thereof, SAM4C®, SAM4C Studio®, BitCloud®, Enabling Unlimited Possibilities®, STK®, XMEGA®, ZigBit®, and others are registered trademarks or trademarks of Atmel Corporation or its subsidiaries. Other terms and product names may be trademarks of others.

Disclaimer: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN THE ATMEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATMEL WEBSITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.