

**CONFIDENTIAL**

RH850/D1x Device Family

RGL-D1x\_User-Manual

User's Manual: Software

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

# CONFIDENTIAL

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
  2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
  3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
  4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
  5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.  
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.  
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.  
Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
  6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
  7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
  8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
  9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
  10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
  11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
  12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

# CONFIDENTIAL

## Trademark

- Green Hills, the Green Hills logo, INTEGRITY, MULTI, DoubleCheck, EventAnalyzer, Integrate, SuperTrace, ResourceAnalyzer, CodeFactor, INTEGRITY MULTIVISOR, GMART, GSTART, G-Cover, PathAnalyzer, GHNet, TimeMachine,  $\mu$ -velOSity, Padded Cell, TotalDeveloper, and Optimizing Compiler are trademarks or registered trademarks of Green Hills Software in the US and/or internationally.
- This software contains the technology owned by TES Electronic Solutions GmbH. All rights reserved for TES Electronic Solutions GmbH
- Trademarks and trademark symbols (® or ™) are omitted in the text of this manual.

# CONFIDENTIAL

## How to Use This Manual

### 1. Purpose and Target Readers

This manual is designed to provide the user with an understanding of the functions of the RGL (Renesas Graphics Library). This manual is written for engineers who use RGL.

The Renesas Graphic Library (RGL) is an API for the functions of the 2D/3D-Drawing engine, for the serial flash as well as for the Video Output and Video Input Interface of the RH850/D1L/D1M microcontrollers driver. Industry standard APIs (EGL, OpenVG) are not described in this manual.

The revision history summarizes the locations of revisions and additions. It does not list all revisions. Refer to the text of the manual for details.

Please refer to documents of drivers and hardware for a target system implementing RGL as necessary.

The following documents are related documents. Make sure to refer to the latest versions of these documents.

Document Type	Description	Document Title	Document No.
User's manual for Hardware	Hardware specifications (pin assignments, memory maps, peripheral function specifications, electrical characteristics, timing charts) and operation description	RH850/D1L/D1M Group User's Manual: Hardware	R01UH0451EJ0220
User's manual for Software	Description of RGL overview	Renesas Graphics Library User's Manual: Software	R01US0181ED0400 (This manual)
	Description of WM	Renesas Graphics Library Window Manager (WM) Driver User's Manual: Software	LLWEB-10035990
	Description of SPEA	Renesas Graphics Library Sprite Engine A (SPEA) Driver User's Manual: Software	LLWEB-10035991
	Description of VDCE	Renesas Graphics Library Video Data Controller E (VDCE) Driver User's Manual: Software	LLWEB-10035992
	Description of VOWE	Renesas Graphics Library Video Output Warping Engine (VOWE) Driver User's Manual: Software	LLWEB-10035993
	Description of JCUA	Renesas Graphics Library JPEG Codec Unit A (JCUA) Driver User's Manual: Software	LLWEB-10035994
	Description of SFMA	Renesas Graphics Library Serial Flash Memory Interface A (SFMA) Driver User's Manual: Software	LLWEB-10064753
	Description of HYPB	Renesas Graphics Library HyperBus Controller (HYPB) Driver User's Manual: Software	LLWEB-10064754
	Description of OCTA	Renesas Graphics Library OctaBus Controller (OCTA) Driver User's Manual: Software	LLWEB-10064755
	Description of VOCA	Renesas Graphics Library Video Output Checker (VOCA) Driver User's Manual: Software	LLWEB-10063801

## CONFIDENTIAL

	Description of DISCOM	Renesas Graphics Library Display Output Comparator (DISCOM) Driver User's Manual: Software	LLWEB-10063802
	Description of DRW2D	Renesas Graphics Library 2D Graphics (DRW2D) Driver User's Manual: Software	LLWEB-10059472
Porting Layer Guide	Description of porting layer of RGL	Renesas Graphics Library Porting Layer Guide	LLWEB-10035995

## 2. Notation of Numbers and Symbols

This manual uses the following notation.

Binary 0bXXXXXXXX (X=0 or 1)  
Decimal XXX (X=0-9)  
Hex 0xXXXXXXXX (X=0-9,A-F)

## CONFIDENTIAL

### 3. List of Abbreviations and Acronyms

Abbreviation	Full Form
Context	An internal state machine of the single framework
CPU	Central Processing Unit. The microprocessor core of the LSI.
DHD	Dave HD. This is H/W which controls 2D graphics rendering.
DISCOM	Display Output Comparator. This is H/W, which calculates CRC.
Drw2D	Draw 2D. This is a driver stack, which enables an abstract access to DHD driver.
Framebuffer	A region in the memory attached to a window that can be shown on the screen; A region in the memory holding the bitmap as the result of GPU rendering activities
GPU	Graphics Processing Unit. This is H/W which controls 2D graphics rendering.
H/W	Hardware
HYPB	HyperBus Controller. This is H/W which enables direct connection of the HyperRAM or HyperFlash memory.
Layer	A HW concept of the stackable visual area on the display
MCU	Minimum Coded Unit
OCTA	OctaBus Controller. This is H/W which enables direct connection of the OctaRAM or OctaFlash memory.
Pitch	(a.k.a. stride) Distance in pixels between two adjacent pixel rows of the framebuffer in the memory
RLE	TARGA run-length encoded image standard, for easy image compression, supported by Drw2D.
Screen	A physical display surface; a SW abstraction of the attached physical display
SFMA	Serial Flash Memory Interface A. This is H/W which enables direct connection of the serial flash memory.
Sprite	A graphical entity which can be moved on the screen independently.
Surface	A concrete (i.e. physical) implementation of the window's area
S/W	Software
TARGA	Truevision Graphics Adapter
Texture	A binary image registered with the GPU driver that can be transformed and drawn to the framebuffer in a HW accelerated way
VOCA	Video Output Checker A. This is H/W, which monitors video output signal.
VOUT	Video output HW
Window	A SW abstraction of the rectangular visual area that can be shown on the display
WM	Window Manager. This is a driver stack, which enables an abstract access to VDCE driver and SPEA driver.

All trademarks and registered trademarks are the property of their respective owners.

## Table of Contents

1.	RGL package.....	2
1.1	Overview.....	2
1.2	Definition of sample / example .....	2
1.3	Package contents .....	2
1.3.1	Applications content.....	3
1.4	Folder structure .....	3
1.5	Integration of the library into a user project.....	4
2.	Appendix .....	6
2.1	RH850/D1x optimization hints .....	6
2.2	RH850/D1x graphics programming alignment table .....	6

# 1. RGL package

## 1.1 Overview


The RGL (Renesas Graphics Library) package bundles several drivers as well as sample applications. It is bound to a specific hardware (RH850/D1Lx, RH850/D1Mx) and compiler (GHS Multi).

## 1.2 Definition of sample / example

Sample code or example code is mentioned in this document as well as all files containing copyright headers in the RGL package. Sample/Example code is not qualified for usage in mass-production. When qualified at customer site it can be used partly or completely in the user application if not stated differently in the signed contract.

## 1.3 Package contents

The RGL consists of the following modules/API's:



The different drawing API's are shown. Drw2D is a simple and slim abstraction layer to render primitives and textures. Its underlying graphics stack is the hardware-accelerated DaveHD GPU or CPU drawing.

Another way to render is to use OpenVG directly. This implementation is Khronos conformant.

The Windows Manager can be used to control the Video-Out, Video-In, Video checker and the sprite engine.

The JCUA driver is the interface to the hardware JPEG decoding unit.



The VOWE driver is the interface to the hardware warping engine. It can be used for head-up displays or other warping use-cases.

The SFMA, HYPB and OCTA driver provides access to the high-speed flash with read/write/delete functionality.

### 1.3.1 Applications content

There are several applications, delivered in source code, which can be built for RH850/D1x targets. One of it is:

#### Simple Draw

Demonstrates drawing the simple graphic primitives (triangles and rectangles), with a solid color or textured, and using the sprite engine as well as the warping engine.

For other sample applications please check the README.txt of your RGL package.

## 1.4 Folder structure

When installing the library package, the files are copied into a folder *rgl\_xx\_yy* where *xx* stands for the compiler and *yy* for the library version. In this folder you will find the *vlib* folder containing the library files, and a *doc* folder where the HTML API documentation and this user manual are located.

The *vlib* folder is divided into:

- *app*  
The source code for the application
- *compiler*  
The rules for different compilers
- *bsp*  
The device independent source code for the board set up
- *device*  
The device dependent source code for the board set up and graphic libraries
- *cdi*  
The source code for the common driver interface library, e.g. memory manager
- *macro*  
The files specific to different HW macros found on the target device
- *grape*  
The implementation of the Graphics Application Programming Environment, a higher-level programming framework
- *os*  
The source code of the Renesas OS
- *middleware*  
The source code of middleware for application

## 1.5 Integration of the library into a user project

If the RH850/D1x device has to be ported to a non-Renesas board the following table gives basic information which directories and files to port, i.e. which are optional, which are necessary to port and which have to be adapted.

Directory	Description	Integration comments
app	Application examples. Integration optional	
bsp	Board support package: Example BSP for RH850/D1x Mango board. Integration <b>necessary</b>	Start here for H/W bringup (clocks, memories, PLL, etc.)
cdi	Example Memory manager. Integration optional	If a different memory manager should be used: 1) Adapt r_wm_sys.c 2) Adapt davehd_os_libc.c 3) CDI can be removed
compiler	Example Build system for GHS with Makefiles: Integration optional	
device/d1mx/src/	Example Integration layer for RH850/D1M specific macros. Integration <b>necessary</b>	Has to be taken as-is or implemented for RGL
device/d1x_common/src	Example Integration layer for RH850/D1x generic macros. Integration <b>necessary</b>	Has to be taken as-is or implemented for RGL
device/d1mx/lib/libd1mx_rh850_ghs.a	<b>This</b> is the RGL	Take as-is
device/d1mx/macro_cfg	Example configuration for RH850/D1M specific macros. Integration optional	
device/d1x_common/macro_cfg	Example Integration layer for RH850/D1x generic macros. Integration optional	
grape	Example higher-Level API for RGL. Integration optional	
macro/*/lib	RGL macro header files. Integration not necessary	Take as-is
macro/*/src	Example macro source. Integration optional	In case of RGL_SRC product, the full source of the RGL is here, too

## CONFIDENTIAL

### Renesas Graphics Library User's Manual

---

middleware	Example middleware for application examples. Integration optional	
os	Example operating system. Integration optional	<p>If O/S is not necessary, the project "simple_draw" provides an example without ROS.</p> <p>If O/S is necessary, the other bundled sample applications provide an example how to use ROS</p>

## 2. Appendix

### 2.1 RH850/D1x optimization hints

- Avoid blitting rotated textures specified in serial flash by Drw2D, copy it first to the RAM
- When rotating, use texture flag R\_DRW2D\_TEX\_VT or R\_DRW2D\_TEX\_SWIZZLE; For swizzling you first need to prepare your textures ('swizzle' them) by an appropriate tool (like swizzle tool from RGBench)
- In case of non-rotated textures, take care when using R\_DRW2D\_TEX\_VT or R\_DRW2D\_TEX\_SWIZZLE texture flags, because they can improve as well as worsen the performance, depending on the use-case
- Using R\_DRW2D\_TEX\_BILINEAR introduces some performance penalty, so use judiciously, i.e. make sure to turn it off if the output quality suffices without it
- Align the texture address to 128 byte boundary (due to bus cache-line)
- For blitting one texture several times: if not already there, make sure to copy it to the RAM first
- Use clipping rectangle feature to restrain the area needed to be updated by the GPU
- Using transformation (rotate, wrap, scale, etc.) or filtering (bilinear filter) on compressed textures (like RLE) will cause a performance penalty

### 2.2 RH850/D1x graphics programming alignment table

Action	Alignment	Constraint of	Directly affected APIs	Comment
Window framebuffer start address (i.e. HW layer start address)	128 bytes	VDCE	R_WM_WindowCreate	
Window framebuffer stride (a.k.a. pitch)	128 bytes (+ 128 bytes RLE)	VDCE SPEA	R_WM_WindowCreate	
Sprite buffer address	64 bit	SPEA	R_WM_SpriteCreate, R_WM_SpriteBufSet	
Sprite X start position	64 bit	SPEA	R_WM_SpriteCreate	
Sprite width (i.e. X direction dimension)	64 bit	SPEA	R_WM_SpriteCreate	
CLUT start address	32bit	VDCE	R_WM_WindowClutSet R_WM_ScreenColorCurveSet	
Drw2D framebuffer address	128 bytes	DaveHD	R_DRW2D_FramebufferSet	
Drw2D framebuffer pitch	None	DaveHD	R_DRW2D_FramebufferSet	Recommended: 128 bytes
Drw2D texture address	any	DaveHD	R_DRW2D_CtxTextureSet	Recommended: 128 bytes
Drw2D RLE texture address	8 bytes	DaveHD	R_DRW2D_CtxTextureSet	Recommended: 128 bytes

Revision History	Renesas Graphics Library User's Manual: Software
------------------	---

Rev.	Date	Description	
		Page	Summary
0.1	2013-10-04	-	Initial Release
0.2	2013-10-09	-	Added notes to indicate D1Mx vs D1Hx features Replaced VDC5 by VDCE
0.3	2014-01-30	-	Updated Drw2D, WM (Scanline support), JCUA VOWE and SFMA APIs
0.4	2014-05-13	-	Updated Drw2D
0.5	2014-05-15	-	Update WM API
0.6	2014-06-14	-	Completely revised – user/reference manual separation
0.7	2014-06-17	-	2 <sup>nd</sup> draft – expanded + added VOWE, JCUA and SFMA
0.8	2014-09-24	-	Version for RGL V1.0.0 release
0.9	2014-10-29	-	Version for RGL V1.1.0 release
1.0	2014-12-12	-	Version for RGL V1.1.2 release
1.1	2015-03-06	-	Several updates for D1L and D1M releases
1.2	2015-07-27	-	Drw2D Effects update
1.3	2015-09-29	-	Version for RGL V1.4.0 (D1Mx) and V1.1.0 (D1Lx) releases
1.4	2016-03-16	-	Version for RGL V1.5.0 (D1Mx) and V1.2.0 (D1Lx) releases
1.5	2016-04-15	-	Drw2D Transformation Matrices update
1.6	2016-06-28	-	SFMA update
1.7	2016-07-13	-	Delete D1Hx, small adaptations in generic chapters
1.8	2016-12-19	-	Minor typo corrections only
1.9	2017-06-01	-	Add required WM CLUT alignment, add DaveHD chapter regarding DHD working memory, adapt WM chapter regarding D1M1A/D1M1v2, add Drw2D rendering step diagram, various small changes
2.0	2017-06-06	-	Add HYPB and OCTA driver chapter, adapt SFMA chapter regarding D1M1A/D1M1v2. Delete win32.
2.1	2018-01-15	-	Version for RGL V1.9.0 (D1Mx)
2.2	2018-10-31	9, 36	Removed the driver related information (WM, VOWE, JCUA) to support separate User's Manual for each driver.
3.0	2019-06-12	22	Fixed the sample of (d) Add signed effect
4.0	2020-05-13	3	Added DISCOM and VOCA driver. Removed the driver related information (DRW2D, SFMA, OCTA, HYPB) to support separate User's Manual for each driver. Removed the memory manager information to support Porting Layer Guide.

---

RH850/D1x device family

RGL-D1x\_User-Manual

User's Manual: Software

Publication Date:	Rev.0.10	Jan 20, 2017
	Rev.4.0	May 13, 2020

Published by:      Renesas Electronics Corporation

---



## SALES OFFICES

## Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

### **Renesas Electronics Corporation**

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

### **Renesas Electronics America Inc. Milpitas Campus**

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.

Tel: +1-408-432-8888, Fax: +1-408-434-5351

### **Renesas Electronics America Inc. San Jose Campus**

6024 Silver Creek Valley Road, San Jose, CA 95138, USA

Tel: +1-408-284-8200, Fax: +1-408-284-2775

### **Renesas Electronics Canada Limited**

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3

Tel: +1-905-237-2004

### **Renesas Electronics Europe GmbH**

Arcadiastrasse 10, 40472 Düsseldorf, Germany

Tel: +49-211-6503-0, Fax: +49-211-6503-1327

### **Renesas Electronics (China) Co., Ltd.**

Room 101-T01, Floor 1, Building 7, Yard No. 7, 8th Street, Shangdi, Haidian District, Beijing 100085, China

Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

### **Renesas Electronics (Shanghai) Co., Ltd.**

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai 200333, China

Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

### **Renesas Electronics Hong Kong Limited**

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

Tel: +852-2265-6688, Fax: +852 2886-9022

### **Renesas Electronics Taiwan Co., Ltd.**

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan

Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

### **Renesas Electronics Singapore Pte. Ltd.**

80 Bendemeer Road, #06-02 Singapore 339949

Tel: +65-6213-0200, Fax: +65-6213-0300

### **Renesas Electronics Malaysia Sdn.Bhd.**

Unit No 3A-1 Level 3A Tower 8 UOA Business Park, No 1 Jalan Pengaturcara U1/51A, Seksyen U1, 40150 Shah Alam, Selangor, Malaysia

Tel: +60-3-5022-1288, Fax: +60-3-5022-1290

### **Renesas Electronics India Pvt. Ltd.**

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India

Tel: +91-80-67208700

### **Renesas Electronics Korea Co., Ltd.**

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea

Tel: +82-2-558-3737, Fax: +82-2-558-5338



ルネサスエレクトロニクス株式会社

■営業お問合せ窓口

<http://www.renesas.com>

※営業お問合せ窓口の住所は変更になることがあります。最新情報につきましては、弊社ホームページをご覧ください。

ルネサス エレクトロニクス株式会社 〒135-0061 東京都江東区豊洲3-2-24（豊洲フォレシア）

■技術的なお問合せおよび資料のご請求は下記へどうぞ。  
総合お問合せ窓口：<https://www.renesas.com/contact/>



## Renesas Graphics Library