


STANDARD DEPARTURE CHART -INSTRUMENT

RJNT / TOYAMA

RNAV SID and TRANSITION



STANDARD DEPARTURE CHART -INSTRUMENT

RJNT / TOYAMA

RNAV SID and TRANSITION

UOZU ONE DEPARTURE

RWY02

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course [°M(°T)]	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	021 (013.5)	-7.8	—	—	+600	—	—	Basic RNP1
002	DF	NT001	—	—	-7.8	—	—	—	—	—	Basic RNP1
003	TF	IKUJI	—	049 (041.2)	-7.8	21.5	—	—	—	—	Basic RNP1

RWY20

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course [°M(°T)]	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	201 (193.5)	-7.8	—	—	+700	—	—	Basic RNP1
002	DF	NT001	—	—	-7.8	—	R	—	—	—	Basic RNP1
003	TF	IKUJI	—	049 (041.2)	-7.8	21.5	—	—	—	—	Basic RNP1

MIRAGE TRANSITION

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course [°M(°T)]	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	IKUJI	—	—	-7.8	—	—	—	—	—	Basic RNP1
002	TF	HISUI	—	040 (032.1)	-7.8	39.4	—	—	—	—	Basic RNP1