

## RJAZ / KOZUSHIMA

## AD CHART



**INTENTIONALLY LEFT BLANK**

STANDARD DEPARTURE CHART-INSTRUMENT



## STANDARD DEPARTURE CHART-INSTRUMENT

RJAZ / KOZUSHIMA

RNAV SID

KOZU ONE DEPARTURE

## RWY11

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance(NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	112 (105.2)	-7.1	—	—	+1800	—	—	Basic RNP1
002	DF	XAC	—	—	-7.1	—	L	—	—	—	Basic RNP1

## RWY29


Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance(NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	292 (285.2)	-7.1	—	—	+1700	—	—	Basic RNP1
002	DF	XAC	—	—	-7.1	—	R	—	—	—	Basic RNP1

CHANGE : New PROC

INSTRUMENT APPROACH CHART

RJAZ / KOZUSHIMA

RNAV (GNSS) RWY11




CHANGE : Sensor for RNAV.

## INSTRUMENT APPROACH CHART

RJAZ / KOZUSHIMA

RNAV (GNSS) RWY29



RJAZ / KOZUSHIMA

Visual REP



CHANGE : Note(Call IZU RADIO on 124.3MHz) deleted.

※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).

Call sign	BRG / DIST from ARP	Remarks
10NM N	360°T / 10.0NM	海上 Over the sea
赤崎 Akasaki	003°T / 3.1NM	岬 Cape
祇苗島 Tadanaejima	069°T / 3.0NM	島 Island
10NM SE	135°T / 10.0NM	海上 Over the sea

RJAZ / KOZUSHIMA

Minimum Vectoring Altitude CHART



CENTER : 341122N/1390801E (ARP)