

Page 1: Introduction & Overview

The Maruti Suzuki Baleno is a premium hatchback designed for performance, comfort, and efficiency.

Engine Options: 1.2L Dual Jet Petrol / 1.2L CNG

Transmission: 5-speed Manual or 5-speed AMT

Mileage: ~2230 km/l (depending on variant)

Fuel Tank Capacity: 37 litres

Seating Capacity: 5 persons

This manual provides essential information for safe and efficient use of your Baleno.

Page 2: Safety Information

Important Safety Guidelines:

- Always wear seatbelts (driver and passengers).
- Do not use mobile phones while driving.
- Maintain tire pressure (33 PSI front, 30 PSI rear approx).
- Avoid sudden braking on wet or loose surfaces.
- Follow traffic rules and speed limits.

Airbags: Dual front airbags are standard; some variants offer up to 6 airbags.

Child Safety: Use ISOFIX anchors for child seats.

Page 3: Instrument Cluster & Controls

Dashboard Indicators:

Engine Check - visit service if illuminated continuously.

Fuel Indicator - blinking means low fuel.

Battery - check alternator connections.

Seatbelt Reminder - fasten before starting.

Steering Controls:

Left: Audio & call controls

Right: Cruise control (in higher variants)

Driver Display (MID):

Displays fuel economy, trip info, average speed, and gear position.

Page 4: Infotainment & Connectivity

SmartPlay Pro+ System:

- 9-inch touchscreen (depending on variant)
- Apple CarPlay & Android Auto (wireless)
- Bluetooth hands-free calling
- Voice assist & navigation

Tips:

- Keep volume low during calls.
- Update system software regularly via Maruti Connect.
- USB port supports fast charging.

Page 5: Driving Guide

Starting the Engine:

1. Ensure gear lever is in neutral.
2. Press clutch and turn ignition (or press start button).
3. Wait for all dashboard lights to turn off.

Fuel Efficiency Tips:

- Maintain steady speeds.
- Shift gears at recommended RPM.
- Avoid unnecessary idling.

Transmission:

Manual or AMT (Automatic Manual Transmission). Use N when parked; D for drive.

Page 6: Maintenance Schedule

Recommended Service Intervals:

1,000 km / 1 month - General check, oil top-up

5,000 km / 6 months - Engine oil, filter change

10,000 km - Tyre rotation, battery check

20,000 km - Air filter, spark plugs

40,000 km - Full inspection, coolant, brakes

Engine Oil: 0W-16 (Synthetic recommended)

Battery: 12V maintenance-free

Page 7: Tires & Battery Care

Tyre Pressure:

Front: 33 PSI

Rear: 30 PSI

Spare: 35 PSI

Tire Rotation: Every 10,000 km.

Battery Maintenance:

- Check terminals for corrosion.
- Avoid leaving lights ON when parked.

Page 8: Common Troubleshooting

Issue | Possible Cause | Solution

Car wont start | Weak battery | Jump start or replace battery

Engine overheating | Low coolant | Check coolant level

Unusual vibration | Tire imbalance | Get wheel alignment

Poor mileage | Dirty air filter | Replace air filter

Warning light on | Sensor fault | Visit service centre

Page 9: Emergency Information

In Case of Breakdown:

1. Move to roadside safely.
2. Switch on hazard lights.
3. Call Maruti Suzuki On-Road Assistance: 1800 102 1800
4. Use reflective triangle if available.

Spare Tire Location: Under luggage area.

Tools: Jack, spanner, and screwdriver included.

Page 10: Warranty & Contact Info

Standard Warranty: 2 years / 40,000 km (whichever earlier)

Extended Warranty: Up to 5 years / 1 lakh km available.

Maruti Service Network: Over 3,000 authorised centres across India.

Customer Care: 1800 102 1800

Website: www.marutisuzuki.com

Note: Always use genuine Maruti Suzuki parts for replacement and servicing.