







NEBRA ANYBEAM

ON-SCREEN DISPLAY (OSD) OPERATION INSTRUCTIONS

Rev.A01 18B

JOG LEVER CONTROLS

Mode	Operation
Adjusting the Volume	Slide the jog lever to  or  directly to adjust the volume.  Volume up  Volume down
OSD Menu [Main Menu, Sub-menu]	Hold down the jog lever for 3 seconds while at the ENTER position to display the menu of the projector.
	<ol style="list-style-type: none">Slide the jog lever to  or  to move to the next or previous item.Press the jog lever while at the ENTER position with the desired item highlighted to enter the sub-menuHold down the jog lever for 3 seconds while at the ENTER position to return to the display mode.

Note:







- The effect of the volume adjustment varies from the connected device.
- Hold down the jog lever for 3 seconds while at the **ENTER** position to make switching between OSD and general display mode.

MAIN MENU OPTIONS

KEYSTONE
FLIP
BRIGHTNESS
SHARPNESS
GREEN ALIGNMENT
BLUE ALIGNMENT
LANGUAGE
FACTORY RESET

DISPLAY ADJUSTMENT

Sub-menu of Keystone, Flip, Brightness and Sharpness

Image	Description
 	Slide the jog lever to  or  to select the sub menu, then click the jog lever while at the ENTER position to adjust.
	Press the jog lever while at the ENTER position to save.
	Press the jog lever while at the ENTER position to go back to the MAIN MENU.













Note: Sharpness

- When adjusting, please check the image sharpness.
- After adjustment is completed, please save the settings.



COLOUR ALIGNMENT



Sub-menu of Green and Blue

Image	Description
   	Slide the jog lever to  or  to select the direction of arrow, then click the jog lever while at the ENTER position to adjust.
	Slide the jog lever to  or  to select and then press the jog lever while at the ENTER position to SAVE.
	Slide the jog lever to  or  to select and then press the jog lever while at the ENTER position to go back to the MAIN MENU.

Note:




- When adjusting, please mind the colour change of the checkerboard image's edge. When there is no obvious colour difference. please save the settings.

LANGUAGE SETTINGS

Slide the jog lever to  or  to select and press the jog lever while at the position to confirm the language. Then slide the jog lever to the option "RETURN" and then press the jog lever while at the **ENTER** position to back to the MAIN MENU.

ENGLISH
CHINESE SIMPLIFIED
JAPANESE
FRENCH
GERMAN
SPANISH
ITALIAN
ARABIC

SUB-MENU OF FACTORY RESET

Image	Description
	Slide the jog lever to  or  to select and then press the jog lever while at the ENTER position to confirm.
