



LSM100A

F/W Download Guide

Rev 1.0

SEONG JI

Dec. 23, 2021

Contents

| | |
|---|----------|
| 1. F/W DOWNLOAD | 3 |
| 1.1 CONNECT..... | 3 |
| 1.2 F/W DOWNLOAD USING STM32 CUBE PROGRAMMER..... | 4 |

History


| Date | Contents | Version | |
|------------|----------|---------|--|
| 2021-12-15 | Create | V1.0 | |
| | | | |
| | | | |

1. F/W Download

1.1 Connect


1) Connect STlink and module

- Connect the circuit as shown in the image below
- PC and STlink connection
 - Red: VCC
 - Blue: SWDIO
 - Green: SWCLK
 - Purple: GND



2) Connect PC and module


- PC and module connection using micro 5pin cable



1.2 F/W download using STM32 Cube Programmer


Note: STM32 Cube Programmer can be downloaded from the STMicroelectronics website below
<https://www.st.com/en/development-tools/stm32cubeprog.html>

1) Open the STM32 Cube Programmer




2) Connect the programmer and module

- While holding push the reset button, click connect of programmer and release the reset button




3) Check the connection

- The connect button changes to disconnect
- Device memory is print



4) Hexfile import

- open file click
- Load the hex file you want to download




※ Warning: Never erase the entire memory

Users are responsible for any problems caused by the erase

※ Warning: Users are responsible for any problems resulting from the use of any hexfile other than the provided hexfile

5) Download

- Click Download in the loaded hex file tab
- After that, check the "File download complete" message



6) Check the booting log

- Check the booting log using serial monitoring program

