


UNIVERSAL LASER INSTRUCTIONS



UNIVERSAL LASER

Model PLS6.75

70 Watt Co2 Laser



Laser cutter preparation:

1. Power on: Universal Laser Cutter
2. Power on: Air pump (located in lower front of cabinet)
3. Booster fan on (located behind the large vacu-former)
4. Air exhaust gates open (1 in line on the floor, 1 at the large vertical trunk)
5. Z height set to match stock thickness (reminder of this later)

Computer work station preparation:

1. Power On
2. Log in
3. Select "Desktop"
4. Power up Corel Draw Application



Corel Draw

Used to layout and manipulate geometry and describe which features to cut or etch

1. Create a new document

- a. File > new
 - i. 32 x 18 page layout
 - ii. RGB Color

2. Import artwork


- a. File > import
 - i. Navigate to the file you want to import (DXF file format preferred)
 - ii. Place file on the page

3. Adjust line properties based to match the desired operation

- a. Line weight = hairline
- b. Line color
 - i. Vector Cut = **RED** (RGB Values = 255,0,0,)
 - ii. Vector Etch = **BLUE** (RGB Values = 0,0,255)
 - iii. Raster Etch = **BLACK** (RGB Values = 0,0,0)

4. Send the job to the laser

- a. File > print






Universal Driver

Used to adjust power and speed settings for cutting and etching


LOAD PRE-CONFIGURED SETTINGS

1. **Settings** Button (Universal driver home page)
2. **Load** Button (directs you to a list of material and thickness possibilities)
3. Highlight preferred material / thickness configuration file
4. **Open** Button
5. **Apply** Button
6. **OK** Button



Universal driver home page

① Settings



Universal driver settings page

⑤ Apply

② Load


⑥ OK



Universal Driver

Used to adjust power and speed settings for cutting and etching

③ Highlight Preferred Material



④ Open

Menu of pre-set speed / feed options


IMPORTANT:

PLEASE SEE STAFF IF YOU WOULD LIKE TO USE MATERIAL OTHER THAN THAT LISTED IN OUR DEFAULT DIRECTORY

Final Inspection

Final Inspection:


1. Review thickness of stock
2. Adjust bed height to match stock thickness



Bed Height Adjustment

Final Step:

Press green arrow to start laser



Universal driver home page

Clean-up Instructions

Laser cutter shut down procedure:

1. Power off: Universal Laser Cutter
2. Power off: Air pump (located in lower front of cabinet)
3. Booster fan off (located behind the large vacu-former)
4. Remove all stock from work area

Computer work station shut down procedure:

1. Save Corel File (2009 Student Files / (folder with your name))
2. Log Out
3. Power Off Computer
4. Pull down door of computer workstation

Thank You !

