

Description to **rob6server** – Version 1.0.9

Sven-Thomas Antoni

german version until 1.01 by Floris Ernst

March 16, 2017

Contents

1	Introduction	1
1.1	Units	1
2	Starting the server	1
3	Connection	2
3.1	Connect to the server as a client	2
3.1.1	Connect to the robot server	2
3.1.2	Initiate communication between server and client	2
4	Commands	2
4.1	Commands for managing the server	2
4.2	Commands to alter movement	4
4.3	Commands for movement	6
4.3.1	Payload	6
4.3.2	Precision of movement	6
4.3.3	Speed and acceleration	7
4.3.4	Joint limits	10
4.3.5	Movement	11
4.3.6	Queries	13
4.4	Gripper commands	14
4.5	Additional commands	14
5	Outdated commands	15
6	Not documented commands	15

1 Introduction

This documents gives a list of commands that can be used for communication with the **rob6server** and gives a short introduction on how to use it.

1.1 Units

To control the server, the following units are used:

- **mm** for displacements
- **degree** for angles
- **kg** for weights

2 Starting the server

- Usage:
`rob6server [params] <robot-type>`

- robot-types:

ur5	Universal Robots UR5
ur3	Universal Robots UR3
abb	ABB IRB120
kr3	Kuka KR3
kr16	Kuka KR16
ad850	Adept Viper s850
kaw_fs	Kawasaki FS003N

- params: (optional)

-p	PORTNO	listen on port PORTNO (default: 5005)
-s	SERIAL	connect to Kuka on SERIAL (default: /dev/ttyS0)
-a	IP	connect to robot on IP (default UR5: 134.28.45.57)
-A	PORTNO	connect to robot on PORTNO (default: 30000)
-b	IP	robot connects to this IP on the server (only UR3 and UR5; default: 134.28.45.36)
-B	PORTNO	robot's joint thread connects to this PORTNO on the server (only UR3 and UR5; default: 30005)
-d		dummy mode (default: disabled)
-h		print this help message
-i		more information

3 Connection

In order to connect to the robot server (**rob6server**) the server needs to be running. This includes initialization of the robot as well as the robot server. Once this is successfully accomplished the **rob6server** waits for a client. Only one client is able to properly connect to the robot server at once.

3.1 Connect to the server as a client

3.1.1 Connect to the robot server

The connection is accomplished via TCP-sockets. The default port for connection is 5005, the server can **not** handle multiple clients.

Example:

```
start    telnet 127.0.0.1 5005
receive  Trying 127.0.0.1...
receive  Connected to 127.0.0.1.
receive  Escape character is '^]'
receive  Welcome to rob6server 0.1.01 !
```

3.1.2 Initiate communication between server and client

In order to initiate the communication with the server the command **Hello Robot** needs to be passed to the server.

Example:

```
send    Hello Robot
receive accepted
```

Now the client can use all functions as stated in the next section.

4 Commands

4.1 Commands for managing the server

- Help

Only for UR3, UR5 and ABB

Returns a list of possible commands for the connected robot.

Example:

```
send    Help
receive list of commands
```

- **GetRobot**

Returns the currently connected robot, possible return values are: `ad850`, `kaw_fs`, `kr3rt`, `kr16rt`, `ur3`, `ur5`, `abb` and (outdated) `kr3`, `kr16`

Example:

```
send    GetRobot
receive ad850
```

- **Is[Adept|Kuka|Kawa|KR3|KR16|UR|UR3|UR5|ABB]**

Returns `true` if the connected robot is of given type.

Example:

```
send    GetRobot
receive ad850
send    IsAdept
receive true
send    IsKawa
receive false
```

- **GetVersion**

Returns the version number of the server.

Example:

```
send    GetVersion
receive 0.1.08
```

- **Quit**

Closes the connection.

Example:

```
send    Quit
receive bye!
```

- **Shutdown**

Closes the connection and shuts down the server.

Example:

```
send    Quit
receive bye!
        shutting down ...
```

- **GetTimestamp**

Gets the current timestamp from the server

Example:

```
send    GetTimestamp
receive 1285831711.121
```

- **PingRobot num wait**

Only Adept-Robot

Gets the communication latency between server and robot. Here `num` is the number of pings to do and `wait` the time between two pings in milliseconds.

Example:

```
send    PingRobot 100 50
receive 0.003414 3659.8930000000 1285828592.9111907482 -0.00016902738 1.4625943e-05
```

The first number is the mean time for the robot to answer (in seconds), the second number is the neutral point of the robot time, the third number is the neutral point of the server time and the forth and fifth values are the coefficients of degree 2 to calibrate both times.

- **CM_PING**

Pings the server.

Example:

```
send    CM_PING
receive PONG
```

- **IsAlive**

Only UR-Robots

Verifies that the robot is still connected and the robot driver running.

Example:

```
send    IsAlive
receive true
```

- **SetVerbosity num**

Sets the verbosity of the robot server. The following values for **num** are possible:

- 0 — nothing
- 1 — only errors
- 2 — errors & warnings
- 3 — errors, warnings and communication data
- 4 — everything

Example:

```
send    SetVerbosity 4
receive true
```

4.2 Commands to alter movement

- **EnableAlter**

Activates the realtime mode. Depending on the connected robot and the server software on the robot this mode is more or less hard. Proper realtime control is working for **kr3rt** and **kr16rt**.

Example:

```
send    EnableAlter
receive true
```

- **EnableAdeptAlter**

Only Adept-Robot

Activates the hard realtime mode for the **ad850** if **serveralter** is running.

Example:

```
send    EnableAdeptAlter
receive true
```

- **EnableURAlter**

Only UR-Robots

Activates the hard realtime mode for the **ur3** and **ur5**.

Example:

```
send    EnableURAlter
receive true
```

- **EnableFreedrive**

Only UR-Robots

Activates the freedrive mode. This allows manual manipulation of the robot. To avoid damage to the robot the Payload needs to be set correctly. No movement commands can be executed while in this mode. Not available in realtime mode.

Example:

```
send    EnableFreedrive
receive true
```

- **EnableBlocking**

Only for UR3, UR5 and ABB

Disables the waypoint queue. The server's command line will block until the robot has reached the designated position. Not available in realtime mode.

Example:

```
send    EnableBlocking
receive true
```

- **EnableLin**

Activates the linear movement mode.

Example:

```
send    EnableLin
receive true
```

- **EnableKeepAlive**

Only UR-Robots

If enabled, the server will detect connection losses and automatically recover. For this mode, movements using the panel are not advised. (Default on)

Example:

```
send    EnableKeepAlive
receive true
```

- **DisableAlter**

Not UR3, UR5 and ABB

Deactivates the realtime mode. Movement is done in a point-to-point sense. This means the server waits after every movement command until the robot has reached its destination.

Example:

```
send    DisableAlter
receive true
```

- **DisableAlter**

Only for UR3, UR5 and ABB

Deactivates the realtime mode. Movement is done in a point-to-point sense. All sent movement commands are saved in a queue on the robot and are executed in order.

Example:

```
send    DisableAlter
receive true
```

- **DisableFreedrive**

Only UR-Robots

Deactivates the freedrive mode. Allowing control of the robot only through the server or the panel.

Example:

```
send    DisableFreedrive
receive true
```

- **DisableBlocking**

Only for UR3, UR5 and ABB

Enables the waypoint queue. All sent movement commands are saved in a queue on the robot and are executed in order.

Example:

```
send    DisableBlocking
receive true
```

- **DisableLin**

Deactivates the linear movement mode.

Example:

```
send    DisableLin
receive true
```

- **DisableKeepAlive**

Only UR-Robots

Disables the automatic recovery from disconnects between server and robot. This allows for using the panel while the server is running but manual recovery of the resulting disconnect is necessary.

Example:

```
send    DisableKeepAlive
receive true
```

- **SetRTSpeedControl 0|1**

Only KUKA-Robots

Sets the behavior in realtime mode. If this is active the robot will drive ramps in realtime mode, else it will move its joint in a way that they arrive simultaneously.

Example:

```
send    SetRTSpeedControl 1
receive true
```

4.3 Commands for movement

4.3.1 Payload

- **SetPayload w**

Only for UR3, UR5 and ABB

Sets the TCP payload to w .

Example:

```
send    SetPayload 0.1
receive true
```

- **SetPayloadCOG w cog_x cog_y cog_z**

Only for UR3, UR5 and ABB

Sets the TCP payload to w and the center of gravity (COG) to $[cog_x, cog_y, cog_z]$ in TCP coordinates.

Example:

```
send    SetPayloadCOG 0.1 10 0 5
receive true
```

4.3.2 Precision of movement

- **SetAdeptFine v**

Only Adept-Robot

Activates fine positioning with a precision of v percent of the joints default precision.

Example:

```
send    SetAdeptFine 50
receive true
```

- **SetAdeptCoarse v**

Only Adept-Robot

Activates coarse positioning with a precision of v percent of the joints default precision.

Example:

```
send    SetAdeptCoarse 50
receive true
```

- **SetBlend num**

Only for UR3, UR5 and ABB

Sets the blend radius in mm. Has no effect in realtime mode.

Example:

```
send    SetBlend 5
receive true
```

- **SetFine num**

Only for UR3, UR5 and ABB

Sets the blend radius to 0mm.

Example:

```
send    SetFine
receive true
```

4.3.3 Speed and acceleration

- **SetSpeed v**

Only for UR3, UR5 and ABB

Sets the speed given in percent of the maximum value. Values up to $v = 120$ are possible.

Example:

```
send    SetSpeed 10
receive true
```

- **SetSpeedJoints v**

Only for UR3, UR5 and ABB

Sets the maximum speed for joint motion, given in degree per second.

Example:

```
send    SetSpeedJoints 10
receive true
```

- **SetSpeedLIN v**

Only for UR3, UR5 and ABB

Sets the maximum speed for linear PTP motion, given in millimeters per second.

Example:

```
send    SetSpeedLIN 10
receive true
```

- **SetAccel a**

Only for UR3, UR5 and ABB

Sets the acceleration in percent of the maximum value. Values up to $a = 150$ are possible.

Example:

```
send    SetAccel 10
receive true
```

- **SetAccelJoints a**

Only UR-Robots

Sets the maximum acceleration for joint motion, given in degree per seconds square.

Example:

```
send    SetAccelJoints 10
receive true
```

- **SetAccelLIN a**

Only UR-Robots

Sets the maximum acceleration for linear PTP motion, given in millimeters per seconds square.

Example:

```
send    SetAccelLIN 10
receive true
```

- **SetURAccel a**

Only UR-Robots

Sets the acceleration in percent of the maximum value. Values up to $a = 150$ are possible.

Example:

```
send    SetUR5Accel 100
receive true
```

- **SetABBAccel a r**

Only ABB-Robots

Sets the acceleration (a) and acceleration ramp (r) in percent of the maximum value. Values up to $a, r = 150$ are possible.

Example:

```
send      SetABBAccel 100 50
receive   true
```

- **SetAdeptSpeed** v

Only Adept-Robot

Sets the speed given in percent of the maximum value. Values up to $v = 120$ are possible.

Example:

```
send      SetAdeptSpeed 100
receive   true
```

- **SetAdeptAccel** $a_1 a_2$

Only Adept-Robot

Sets the acceleration and deceleration given in percent of the maximum value. Values up to $a_1, a_2 = 120$ are possible.

Example:

```
send      SetAdeptAccel 100 50
receive   true
```

- **SetKukaRTSpeed** $v_1 v_2 v_3 v_4 v_5 v_6$

Only KUKA-Robot with RT-Interface

Sets the speed for the six different joints.

Example:

```
send      SetKukaRTSpeed 0.3 0.1 0.1 0.1 0.1 0.1
receive   true
```

- **SetJointsMaxSpeed** $v_1 v_2 v_3 v_4 v_5 v_6$

Only KUKA-Robots

Sets the speed for the six different joints.

Example:

```
send      SetJointsMaxSpeed 0.3 0.1 0.1 0.1 0.1 0.1
receive   true
```

- **SetSingleJointMaxSpeed** $j a$

Only KUKA-Robots

Sets the speed for a single joint.

Example:

```
send      SetSingleJointMaxSpeed 3 0.3
receive   true
```

- **SetJointsMaxAcceleration** $a_1 a_2 a_3 a_4 a_5 a_6$

Only KUKA-Robots

Sets the acceleration for the six different joints.

Example:

```
send      SetJointsMaxAcceleration 0.005 0.001 0.01 0.01 0.01 0.05
receive   true
```

- **SetSingleJointMaxAcceleration** $j a$

Only KUKA-Robots

Sets the acceleration for a single joint.

Example:

```
send      SetSingleJointMaxAcceleration 3 0.1
receive   true
```

- **GetJointsMaxSpeed**

Only KUKA-Robots

Returns the set speed of all six joints.

Example:

```
send    GetJointsMaxSpeed
receive 0.187200 0.187200 0.187200 0.396000 0.396000 0.738000
```

- **GetJointsMaxAcceleration**

Only KUKA-Robots

Returns the set acceleration of all six joints.

Example:

```
send    GetJointsMaxAcceleration
receive 0.005000 0.005000 0.005000 0.005000 0.005000 0.005000
```

- **ResetJointsMaxSpeed**

Only KUKA-Robots

Resets speed to default.

Example:

```
send    ResetJointsMaxAcceleration
receive true
```

- **ResetJointsMaxAcceleration**

Only KUKA-Robots

Resets acceleration to default.

Example:

```
send    ResetJointsMaxAcceleration
receive true
```

4.3.4 Joint limits

- **GetJointsMaxChange**

Returns the maximal rotation angle of the joints for a single movement.

Example:

```
send    GetJointsMaxChange
receive 370.000000 175.000000 284.000000 700.000000 250.000000 700.000000
```

- **SetJointsMaxChange $\alpha_1 \alpha_2 \alpha_3 \alpha_4 \alpha_5 \alpha_6$**

Sets the maximal rotation angle of the joints for single movements. Six angles (degree) are expected.

Example:

```
send    SetJointsMaxChange 10 10 10 10 10 10
receive true
```

- **SetSingleJointMaxChange $j \alpha$**

Sets the maximal rotation angle per movement of the joint j to α .

Example:

```
send    SetSingleJointMaxChange 3 20
receive true
```

- **GetJointsMaxTurnMax**

Returns the maximal rotation angle of the joints.

Example:

```
send    GetJointsMaxTurnMax
receive 185.000000 20.000000 154.000000 350.000000 125.000000 350.000000
```

- **SetJointsMaxTurnMax $\alpha_1 \alpha_2 \alpha_3 \alpha_4 \alpha_5 \alpha_6$**

Sets the maximal rotation angle of the joints.

Example:

```
send    SetJointsMaxTurnMax 10 10 10 10 10 10
receive true
```

- **SetSingleJointMaxTurnMax $j \alpha$**

Sets the maximal rotation angle of the joint j to α .

Example:

```
send    SetSingleJointMaxTurnMax 3 40
receive true
```

- **GetJointsMaxTurnMin**

Return the minimal rotation angle of the joints.

Example:

```
send    GetJointsMaxTurnMin
receive -185.000000 -155.000000 -130.000000 -350.000000 -125.000000 -350.000000
```

- **SetJointsMaxTurnMin $\alpha_1 \alpha_2 \alpha_3 \alpha_4 \alpha_5 \alpha_6$**

Sets the minimal rotation angle of the joints. Six angles (degree) are expected.

Example:

```
send    SetJointsMaxTurnMin -10 -10 -10 -10 -10 -10
receive true
```

- **SetSingleJointMaxTurnMin $j \alpha$**

Sets the minimal rotation angle of the joint j to α .

Example:

```
send    SetSingleJointMaxTurnMin 3 -40
receive  true
```

- **ResetJointsMaxChange $j \alpha$**

Resets the maximal and minimal rotation angle of the joints per movement to default.

Example:

```
send    ResetJointsMaxChange
receive  true
```

- **ResetJointsMaxTurn $j \alpha$**

Resets the maximal and minimal rotation angle of the joints to default.

Example:

```
send    ResetJointsMaxTurn
receive  true
```

4.3.5 Movement

- **MoveMinChangeRowWiseStatus $m_{1,1} m_{1,2} m_{1,3} m_{1,4} m_{2,1} m_{2,2} m_{2,3} m_{2,4} m_{3,1} m_{3,2} m_{3,3} m_{3,4} \leftrightarrow$**
flip|noflip|toggleHand|noToggleHand \leftrightarrow
up|down|toggleElbow|noToggleElbow \leftrightarrow
lefty|righty|toggleArm|noToggleArm

This command is used to execute a point-to-point (PTP) movement. The target matrix (homogeneous coordinates, line wise, only the first three lines) and the robot configuration is submitted. If the target pose can be reached with different allowed configurations the configuration is chosen where the change in joint angles is minimal.

Example:

```
send    MoveMinChangeRowWiseStatus 0 0 -1 1768 0 -1 0 0 -1 0 0 640 flip toggleElbow toggleArm
receive  true
```

- **MovePTPJoints $j_1 j_2 j_3 j_4 j_5 j_6$**

Moves the robot in PTP-mode to a new joint position.

Example:

```
send    MovePTPJoints 10 0 0 0 0 0
receive  true
```

- **MoveRTHomRowWise $m_{1,1} m_{1,2} m_{1,3} m_{1,4} m_{2,1} m_{2,2} m_{2,3} m_{2,4} m_{3,1} m_{3,2} m_{3,3} m_{3,4}$**

Only KUKA (RT), Adept, UR3, UR5 and ABB in soft-RT-mode

This command is used to execute a realtime (RT) movement. The target matrix (homogeneous coordinates, line wise, only the first three lines) is submitted. The current configuration is kept.

Example:

```
send    MoveRTHomRowWise 0 0 -1 1768 0 -1 0 0 -1 0 0 640
receive  true
```

- **MoveRTHomRowWise $m_{1,1} m_{1,2} m_{1,3} m_{1,4} m_{2,1} m_{2,2} m_{2,3} m_{2,4} m_{3,1} m_{3,2} m_{3,3} m_{3,4}$**

Only UR3 and UR5 in hard-RT-mode

This command is used to execute a realtime (RT) movement. The target matrix (homogeneous coordinates, line wise, only the first three lines) is submitted. The pose is directly send to the robot and neither configuration nor possibility or accordance to set joint turn limits are checked.

Example:

```
send    MoveRTHomRowWise 0 0 -1 1768 0 -1 0 0 -1 0 0 640
receive  true
```

- **MoveRTHomRowWiseStatus** $m_{1,1} m_{1,2} m_{1,3} m_{1,4} m_{2,1} m_{2,2} m_{2,3} m_{2,4} m_{3,1} m_{3,2} m_{3,3} m_{3,4} \leftarrow$
 $\text{flip|noflip|toggleHand|noToggleHand} \leftarrow$
 $\text{up|down|toggleElbow|noToggleElbow} \leftarrow$
 $\text{lefty|righty|toggleArm|noToggleArm}$

This command is used to execute a RT movement. The target matrix (homogeneous coordinates, line wise, only the first three lines) and the robot configuration is submitted. If the target pose can be reached with different allowed configurations the configuration is chosen where the change in joint angles is minimal.

Example:

```
send    MoveRTHomRowWiseStatus 0 0 -1 1768 0 -1 0 0 -1 0 0 640 flip toggleElbow toggleArm
receive true
```

- **MoveRTJoints** $j_1 j_2 j_3 j_4 j_5 j_6$ **Only KUKA (RT), Adept, UR3, UR5 and ABB in soft-RT-mode**

Moves the robot in RT-mode to a new joint position.

Example:

```
send    MoveRTJoints 10 20 10 10 10 10
receive true
```

- **MoveRTJoints** $j_1 j_2 j_3 j_4 j_5 j_6$ **Only UR3 and UR5 in hard-RT-mode**

Moves the robot in RT-mode to a new joint position. The joint positions are directly send to the robot and neither configuration nor possibility or accordance to set joint turn limits are checked.

Example:

```
send    MoveRTJoints 10 20 10 10 10 10
receive true
```

- **MoveLINJoints** $j_1 j_2 j_3 j_4 j_5 j_6$

Moves the robot in linear-mode to a new joint position.

Example:

```
send    MoveLINJoints 10 0 0 0 0 0
receive true
```

- **MoveLINHomRowWise** $m_{1,1} m_{1,2} m_{1,3} m_{1,4} m_{2,1} m_{2,2} m_{2,3} m_{2,4} m_{3,1} m_{3,2} m_{3,3} m_{3,4}$

Not UR3, UR5 and ABB

This command is used to execute a linear movement. The target matrix (homogeneous coordinates, line wise, only the first three lines) is submitted. The current configuration is kept.

Example:

```
send    MoveLINHomRowWise 0 0 -1 768 0 -1 0 0 -1 0 0 640
receive true
```

- **MoveLINHomRowWise** $m_{1,1} m_{1,2} m_{1,3} m_{1,4} m_{2,1} m_{2,2} m_{2,3} m_{2,4} m_{3,1} m_{3,2} m_{3,3} m_{3,4}$

Only for UR3, UR5 and ABB

This command is used to execute a linear movement. The target matrix (homogeneous coordinates, line wise, only the first three lines) is submitted. As the trajectory is calculated on the robot, no guarantees can be given regarding the configuration for the target, configuration while moving and violations of joint turn limits.

Example:

```
send    MoveLINHomRowWise 0 0 -1 768 0 -1 0 0 -1 0 0 640
receive true
```

- **MoveLINHomRowWiseDirect** $m_{1,1}$ $m_{1,2}$ $m_{1,3}$ $m_{1,4}$ $m_{2,1}$ $m_{2,2}$ $m_{2,3}$ $m_{2,4}$ $m_{3,1}$ $m_{3,2}$ $m_{3,3}$ $m_{3,4}$

Only for UR3, UR5 and ABB

This command is used to execute a linear movement. The target matrix (homogeneous coordinates, line wise, only the first three lines) is submitted. The pose is directly send to the robot and neither configuration nor possibility or accordance to set joint turn limits are checked.

Example:

```
send    MoveLINHomRowWiseDirect 0 0 -1 768 0 -1 0 0 -1 0 0 640
receive true
```

- **MoveStop**

Only UR-Robots

Stops the robot movement. In RT-mode the robot's motion is stopped immediately. Else, the robot finishes the current motion and then stops. Same as **BRAKE**.

Example:

```
send    MoveStop
receive true
```

4.3.6 Queries

- **GetPositionHomRowWise**

Returns the current position in a homogeneous matrix (linewise, only the first three lines).

Example:

```
send    GetPositionHomRowWise
receive 0.000000 -0.173648 -0.984808 1741.140107 ↵
        0.000000 -0.984808 0.173648 -307.009978 ↵
        -1.000000 -0.000000 -0.000000 640.000000
```

- **GetPositionJoints**

Returns the current joint angles.

Example:

```
send    GetPositionJoints
receive 10.000000 0.000000 0.000000 0.000000 0.000000 0.000000
```

- **GetStatus**

Returns the current configuration. Return arguments are **flip|noflip up|down lefty|righty**

Example:

```
send    GetStatus
receive noflip down lefty
```

- **GetQueueLength**

Only for UR3, UR5 and ABB

Returns the elements in the robots PTP queue.

Example:

```
send    GetQueueLength
receive 8
```

- **GetSpeed**

Only for UR3, UR5 and ABB

Returns the currently set speed, depending on the movement mode (linear or joint-space) in degree or millimeter per seconds.

Example:

```
send    GetSpeed
receive 20 °/s
```

- **GetAccel**

Only UR-Robots

Returns the currently set acceleration, depending on the movement mode (linear or joint-space) in degree or millimeter per seconds square.

Example:

```
send    GetAccel
receive 20 °/s^2
```

- **GetAccel**

Only ABB-Robots

Returns the currently set acceleration in percent

Example:

```
send    GetAccel
receive 20
```

4.4 Gripper commands

- **HasGripper**

Only Adept-Robot

Checks whether the serial gripper is connected and running.

Example:

```
send    HasGripper
receive true
```

- **GripperGoHome**

Only Adept-Robot

Moves the gripper to the reference position (approximately 4cm open):

Example:

```
send    GripperGoHome
receive State: 01000000000000001000000000000000
        true
```

- **GripperMove amp**

Only Adept-Robot

Moves the gripper with **amp** ampere. Negative values close the gripper, positives open it.

Example:

```
send    GripperMove -1
receive Start moving with amperage -1.000
        true
```

- **GripperMoveToPosition pos**

Only Adept-Robot

Moves the gripper to the given position **pos** (opening in m).

Example:

```
send    GripperMoveToPosition 0.025
receive State: 01000010010000010000000000000000
        true
```

4.5 Additional commands

- **ForwardCalc $j_1 j_2 j_3 j_4 j_5 j_6$**

Calculates the homogeneous matrix of a given joint position.

Example:

```
send    ForwardCalc 10 0 0 0 0 0
receive 0.000000 -0.173648 -0.984808 1741.140107 ↵
        0.000000 -0.984808 0.173648 -307.009978 ↵
        -1.000000 -0.000000 -0.000000 640.000000
        noflip up lefty
```

- **BackwardCalc** $m_{1,1} \ m_{1,2} \ m_{1,3} \ m_{1,4} \ m_{2,1} \ m_{2,2} \ m_{2,3} \ m_{2,4} \ m_{3,1} \ m_{3,2} \ m_{3,3} \ m_{3,4} \ \leftarrow$
flip|noflip up|down

Given a given homogeneous matrix and a corresponding configuration the joint positions are calculated.
Example:

```
send      BackwardCalc ←
          0.000000 -0.173648 -0.984808 1741.140107 ←
          0.000000 -0.984808 0.173648 -307.009978 ←
          -1.000000 -0.000000 -0.000000 640.000000 ←
          noflip up lefty
receive   10.000001 -0.000055 0.000110 0.000000 -0.000055 0.000000
```

- **DirectAdeptCmd** MSG

Sends MSG to the Adept and executes the command.
Example:

```
send      DirectAdeptCmd jmove 0,0,0,0,0,0
receive   true
```

Only Adept-Robot

5 Outdated commands

Obsolete command	Replacement
GetJointsRowWise	BackwardCalc
MovePTPHomRowWise	MoveMinChangeRowWiseStatus
MovePTPHomRowWiseStatusTurn	MoveMinChangeRowWiseStatus

6 Not documented commands

DisableRoutetest, DoAlterCart, DoAlterJoint, EnableRoutetest, GetAllowedStatus, GetMinChangeWeights, IsPossible, GetJointsRowWise, MovePTPJointsStatus, ResetAllowedStatus, ResetMinChangeWeights, RoutetestJoints, RoutetestRowWiseStatus, SetAllowedStatus, SetMinChangeWeights, GetRTSpeedControl, BRAKE

History

- 1.08.1 further improvements to UR RT-mode; fixes for ABB; introduction of **KeepAlive**-Functions controlling the automatic recovery of UR robots; Introduced functions to set speed and acceleration in real world units.
- 1.08 improved RT-mode for UR3 and UR5; improved performance
- 1.07 added freedrive and blocking mode; added commands for setting payload of UR3 and UR5; rob6server can now reconnect to UR robots after connection loss
- 1.06 added UR3; expanded MoveLINHomRowWiseDirect to UR3 and UR5; added hard-RT mode for UR robots and changed behavior of MoveRTHomRowWise and MoveRTJoints in hard-RT mode; various bug fixes; new combined functions for UR3 and UR5 to reduce redundancy
- 1.05 introduced MoveLINHomRowWiseDirect for ABB
- 1.04 english translation, ABB with various commands added
- 1.03 fixes and additional commands for UR5
- 1.02 UR5 added
- 1.0b = old commands
- 1.0a error correction (**SetVerbosity** was not documented)
- 1.0 initial version