

## 4.3 CC-Link IE TSN Instructions

### Own station number/IP address setting

Instruction symbol	Description	Reference
G.UINI	Sets the station number and IP address for FX5-CCLGN-MS (own station).	Page 1073
GP.UINI		

### Sending an SLMP Frame

Instruction symbol	Description	Reference
G.SLMPSND	Sends an SLMP message to the SLMP-compatible device on the same network.	Page 1076
GP.SLMPSND		

4

## 4.4 CC-Link IE Field Network Instruction

### Setting parameters

Instruction symbol	Description	Reference
G.CCPASET	Sets parameters in the FX5-CCLIEF (own station).	Page 1085
GP.CCPASET	Use the G(P).CCPASET instruction to set parameters in the following cases. <ul style="list-style-type: none"><li>• If you want to change parameters without resetting the CPU module</li><li>• If you want to mount more intelligent device station modules than the number of modules set by the engineering tool</li></ul>	

### Setting the station number to own station

Instruction symbol	Description	Reference
G.UINI	Sets the station number in the FX5-CCLIEF (own station).	Page 1088
GP.UINI		