


Jump to END

GOEND

- FX5S
- FX5UJ
- FX5U
- FX5UC

This instruction moves the program execution to the FEND or END instruction in the same program file.

| Ladder diagram | Structured text |
|---|-----------------|
|  | Not supported |
| FBD/LD | |
| Not supported. | |

Processing details

- This instruction moves the program execution to the FEND or END instruction in the same program file.

Precautions

- When a GOEND instruction is executed by invalid jump during interrupt program execution, it becomes the same operation as the IRET instruction.

Operation error

| Error code (SD0/SD8067) | Description |
|----------------------------|---|
| 3340H | After the FOR instruction is executed, the GOEND instruction is executed before the NEXT instruction is executed. |
| 3381H | After the CALL(P) or XCALL instruction is executed, the GOEND instruction is executed before the RET instruction is executed. |