

Lab Report

Your Performance

Your Score: 4 of 4 (100%)

Elapsed Time: 3 minutes 7 seconds

Pass Status: Pass

Required Score: 100%

Task Summary

Actions you were required to perform:

- ✓ Select the Photosmart Plus inkjet printer
- ✓ Connect the printer to the workstation
- ✓ Plug in the printer to surge protector
- ✓ Configure the printer as the default

Explanation

In this lab, your task is to complete the following:

- Select the appropriate printer. Choose the printer with the best quality and the fastest print capabilities.
- Connect the printer to the computer using the appropriate cable for a local printer.
- Plug the printer into the surge protector.
- Switch to the operating system and verify the printer's installation.
- Set the new printer as the default printer.

Complete this lab as follows:

1. Choose a printer as follows:
 - a. Above the computer, select **Back** to switch to the back view of the computer.
 - b. On the Shelf, expand **Printers**.
 - c. Read the **description** for each of the available printer types.
 - d. Identify the **printer** that best meets the scenario requirements.
 - e. Drag the **HP Photosmart Plus** printer to the Workspace.
2. Connect the printer as follows:
 - a. Above the printer, select **Back** to switch to the back view of the printer and examine the connection port.
 - b. On the Shelf, expand **Cables**.
 - c. Read the **description** for each cable.
 - d. Select the **USB cable (A/B)**.
 - e. Under Selected Component, drag the **USB Type B Connector** to the port on the back of the printer.
 - f. Under Selected Component, drag the **USB Type A Connector** to the port on the back of the computer.
 - g. On the Shelf, select the **Power Adapter for HP**.
 - h. Under Selected Component, drag the **Power Adapter, DC** to the connector on the printer.
 - i. Under Selected Component, drag the **Power Adapter, AC** to an AC power port on the surge protector.
3. Verify the installation and set the printer as the default printer:
 - a. On the monitor, select **Click to view Windows 10**.
 - b. Select **Start**.
 - c. Select **Settings**.
 - d. Select **Devices**.
 - e. From the left menu, select **Printers & scanners**. You should see the newly installed printer.
 - f. Select **HP Photosmart Plus**.
 - g. Select **Set as default**.