

下面的代码描述如何改变看门狗定时器的超时值。

汇编代码

```
WDT_TOV_Change:
    ; Turn off global interrupt
    CLI
    ; Reset watchdog timer
    WDR
    ; Start timed sequence
    LDS r16, WDTCR
    ORI r16, (1 << WDCE) | (1 << WDE)
    STS WDTCR, r16
    ; -- Got for cycles to set the new value from here --
    ; Set new time-out value = 64k cycles
    LDI r16, (1 << WDE) | (1 << WDP2) | (1 << WDP0)
    STS WDTCR, r16
    ; -- Finished setting new value, used 2 cycles -
    ; Turn on global interrupt
    SEI
    RET
```

C 语言代码

```
void WDT_TOV_Change(void)
{
    __disable_interrupt();
    __watchdog_reset();
    /* Start timed sequence */
    WDTCR |= (1 << WDCE) | (1 << WDE);
    /* Set new time-out value = 64K cycles */
    WDTCR |= (1 << WDE) | (1 << WDP2) | (1 << WDP0);
    __enable_interrupt();
}
```

【使用说明】

在改变 WDP 配置位之前，建议复位看门狗定时器。因为更改 WDP 位到比较小的超时周期很可能会导致看门狗超时复位。