

		data					Slave mode; slave address response; TWGCE = 1 When the response to the broadcast; transmitting the bus is free START
0xA0 Receives from the work machine To STOP or REPEATED START		No action	0	0	1	0 Will switch to unaddressed	Slave mode; slave will not respond to a broadcast address and
		No action	0	0	1	1 Will switch to unaddressed	Slave mode; slave address response; TWGCE = 1 The response time of broadcast
		No action	1	0	1	0 Will switch to unaddressed	Slave mode; slave will not respond to a broadcast address; transmitting the bus is free START
		No action	1	0	1	1 Will switch to unaddressed	Slave mode; slave address response; TWGCE = 1 When the response to the broadcast; transmitting the bus is free START

And a state machine format from FIG reception mode is as follows: