


							<p>The response slave address;</p> <p><b>TWGCE = 1</b> When the response to the broadcast; transmitting the bus is free</p> <p><b>START</b></p>
--	--	--	--	--	--	--	---

Format from the transmission mode and the state machine as shown below:



From the format and transmission mode state machine of FIG.

### Other states

No two status codes corresponding TWI State is defined in the following table:

Other state code table

status code	Bus and hardware-like state	Response application software				Hardware next move	
		Read / Write  TWDR	Correct TWCR Operations				
			STA	STO	TWINT		TWEA
0xF8	No status information;  TWINT = 0	No action	Does not operate TWCR				Or wait for the current operation
0x00	Unlawful START  or STOP Bus errors  caused	No action 0		1	1	x Only affect the internal hardware;  Will not send STOP To the bus;  the bus is released and cleared TWSTO  Place	

status code 0xF8 Indicates that no relevant information, because TWINT Flag "0". This state may occur TWI The interface is not participating in the current transmission or serial transmission is not yet complete.