

	send	load SLA + W	0	0	1	x Will send SLA + W ; The reception ACK or NACK; Will switch to MT mode
0x38	SLA + R Arbitration or data failure	No action	0	0	1	x Will release the bus; The addressed slave mode does not enter
		No action	1	0	1	x Will be sent when idle START
0x40	SLA + R It has been sent; received ACK	No action	0	0	1	0 The received data; Will send NACK
		No action	0	0	1	1 The received data; Will send ACK
0x48	SLA + R It has been sent; received NACK	No action	1	0	1	x Will send REPEATED START
		No action	0	1	1	x Will send STOP ; Reset TWSTO Mark
		No action	1	1	1	x Will send STOP ; Reset TWSTO Signs; sending START
0x50	It received data byte; ACK Has been sent	Read data	0	0	1	0 The received data; Will send NACK
		Read data	0	0	1	1 The received data; Will send ACK
0x58	It received data byte; NACK Has been sent	Read data	1	0	1	x Will send REPEATED START
		Read data	0	1	1	x Will send STOP ; Reset TWSTO Mark
		Read data	1	1	1	x Will send STOP ; Reset TWSTO Signs; sending START

Format and status of the host receiving mode as shown below: