

	give away	load SLA + R	0	0	1	x Will send SLA + R ; The reception ACK or NACK; Will switch to MR mode
0x18	SLA + W It has been sent; received ACK	Download Data	0	0	1	x Transmitting data; The reception ACK or NACK
		No action	1	0	1	x Will send REPEATED START
		No action	0	1	1	x Will send STOP ; Reset TWSTO Mark
		No action	1	1	1	x Will send STOP ; Reset TWSTO Signs; sending START
0x20	SLA + W It has been sent; received NACK	Download Data	0	0	1	x Transmitting data; The reception ACK or NACK
		No action	1	0	1	x Will send REPEATED START
		No action	0	1	1	x Will send STOP ; Reset TWSTO Mark
		No action	1	1	1	x Will send STOP ; Reset TWSTO Signs; sending START
0x28 Data bytes	It has been sent; received ACK	Download Data	0	0	1	x Transmitting data; The reception ACK or NACK
		No action	1	0	1	x Will send REPEATED START
		No action	0	1	1	x Will send STOP ; Reset TWSTO Mark
		No action	1	1	1	x Will send STOP ; Reset TWSTO Signs; sending START
0x30 Data bytes	It has been sent; received NACK	Download Data	0	0	1	x Transmitting data; The reception ACK or NACK
		No action	1	0	1	x Will send REPEATED START
		No action	0	1	1	x Will send STOP ; Reset TWSTO Mark
		No action	1	1	1	x Will send STOP ; Reset TWSTO Signs; sending START
0x38	SLA + W Arbitration or data failure	No action	0	0	1	x Will release the bus; The addressed slave mode does not enter
		No action	1	0	1	x Will be sent when idle START