



### Slave transmit mode

In slave mode transmission may be sent a certain number of data bytes to the host receiver. The status code section referred to assume control bit prescaler "0" .

To initiate the Slave receive mode, to set TWAR with TWCR register.

TWAR Must be set as follows:

TWA6	TWA5	TWA4	TWA3	TWA2	TWA1	TWA0	TWGCE
Device slave address							

TWAR height of 7 Bit is addressed by a master TWI Interface slave address will respond. If the LSB Position, TWI It responds to call address ( 0x00 ),

Otherwise ignore the call address.

TWCR Must be set as follows:

TWINT	TWEA	TWSTA	TWSTO	TWWC	TWEN	-	TWIE
0	1	0	0	0	1	0	x