

## Set hostname Raspberry Pi

Connect the RPI to a wired network. The RPI will show its IP address and hostname on the SenseHAT led matrix.

Start a remote terminal (ssh) and update the hostname text RPIxx00 to the new hostname using the nano editor:

```
sudo nano /etc/hostname  
sudo nano /etc/hosts  
sudo shutdown -r now
```

The RPI will show its IP address and new hostname on the SenseHAT led matrix. A remote shell will also show the new hostname in the prompt.