

uFR Online – Quick Start Guide

Version 1.6

Table of contents

Installing uFR Online Reader	4
Step 1: Power on a device	4
Step 2: Connect to the uFR Online	4
Step 3: Set up your device	4
Step 4: Finish setting up your device	4
uFR Online Reader settings	5
Open WiFi network settings dashboard	5
Open advanced settings dashboard	5
uFR Online Test	6
Access Point settings	7
UDP/TCP ports and protocols settings	7
UART settings	8
Transparent mode settings	8
Login credentials settings	9
Master/Slave mode settings	9
Bluetooth Serial mode settings – available in versions 2.0+	9
Bluetooth HID mode settings – available in versions 2.0+	10
Bluetooth HID mode reverse UID settings – available in versions 2.0+	10
Bluetooth Low Energy mode settings – available in versions 2.0+	10
Host address settings	11
UDP broadcast IP settings	11
Master mode settings	12
Linear read settings	12
HTTP command test	13
UDP broadcast IP settings	13
Install uFR firmware	14
Modem sleep settings	15
Basic information	15
uFR Online LED status table	16
uFR Online default settings table	17
uFR Online REST services	18

uFR Online Reader basic usage	20
UDP/TCP communication	20
UDP/TCP communication – Reader opening example	20
Bluetooth serial mode communication	20
Bluetooth serial mode communication – Reader opening example	20
Bluetooth serial mode communication	21
Transparent mode communication – Reader opening example	21
HTTP mode communication	21
HTTP mode communication – GetCardIdEx example	21
uFR Online Reader protocols structure	22
Master mode POST request	22
Master mode POST response	23
Master mode UDP broadcast	24
UDP discovery server	24
uFR Online only COM protocol commands	25
uFR Online Reader tools	26
uFR Online flasher oneclick – Update tool	26
uFR Online finder – Network discovery tool	26
uFR Online OEM lock/unlock	27
uFR NFC Browser Extension – Useful links	29
Revision history	31

Installing uFR Online Reader

Follow the instructions below to install your uFR Online reader.

Step 1: Power on a device

1. Connect device to a power source.
2. Wait for a few moments to device boot in Access Point mode (see LED status table below).

Step 2: Connect to the uFR Online

1. Scan for networks using your WiFi enable device (computer, smartphone etc.).
2. Connect to device named ONxxxxxx.
3. Wait for the connection to be made successfully.
4. Open your favorite web browser and navigate to <http://192.168.4.1>

Step 3: Set up your device

1. After web page is loaded successfully log in using default credentials (see table 1 below).
2. Wait for a few moments to device scan for an available WiFi networks.
3. Select a WiFi network and click connect button.
4. Enter password for wireless network if needed and wait to connect successfully.

Step 4: Finish setting up your device

1. Click on uFR Online button on top left corner to find out your new IP address.
2. Reboot your uFR Online reader.

uFR Online Reader settings

Follow the instructions below to change uFR Online reader settings.


Open WiFi network settings dashboard

1. Open your favorite web browser and navigate to `http://<device-ip-address>`.
2. Log in using default credentials (see table 1 below).
3. After web page is loaded successfully, WiFi settings dashboard will be shown.
4. **If reader is working in BLE, BT or HID mode, WiFi station mode is not available (Only AP).**




Open advanced settings dashboard

1. Follow the instruction above (WiFi network setting section).
2. Click on Other settings button.
3. Advanced settings dashboard will be shown on screen.



uFR Online Test

1. Open advanced settings dashboard.
2. Navigate to Open μ FR Online test section and click.
3. Use color wheels to change LED colors.
4. Click on Beep button to send sound signal.
5. Approach an NFC card or tag to read UID.



Access Point settings


1. Open advanced settings dashboard.
2. Click on Edit button in section Access point.
3. Change fields SSID and Password.
4. Click on button Save.



The screenshot shows a web interface for 'Access point' settings. It has a title 'Access point' in blue. Below it, there are two input fields: 'SSID:' with the value 'UN101302' and 'Password:'. To the right of the password field is a grey 'Edit' button.

UDP/TCP ports and protocols settings


1. Open advanced settings dashboard.
2. Click on Edit button in section UDP/TCP ports..
3. Change fields Port 1 and Port 2.
4. Click on button Save.
5. Click on UDP/TCP ports header text to toggle between this two protocols.



The screenshot shows a web interface for 'UDP ports' settings. It has a title 'UDP ports - Click to switch to TCP' in blue. Below it, there are two input fields: 'Port 1:' with the value '8881' and 'Port 2:' with the value '8882'. To the right of the port 2 field is a grey 'Edit' button.


UART settings

1. Open advanced settings dashboard.
2. Click on Edit button in section UART Baud rates.
3. Change fields UART 1 and UART 2.
4. Click on button Save.
5. Click on UART2 RS485 disabled/enabled to toggle RS485 support on second serial port.




Transparent mode settings

1. Open advanced settings dashboard.
2. Click on Edit button in section Transparent mode.
3. Change field Reader to toggle between first and second serial ports.
4. Click on button Save.
5. Click on Transparent disabled/enabled text to toggle transparent mode.



Login credentials settings

1. Open advanced settings dashboard.
2. Click on Edit button in section Login.
3. Change fields Username and Password.
4. Click on button Save.



A screenshot of a web interface showing a 'Login' section. It contains two input fields: 'Username' with the value 'ufr' and 'Password' with masked characters '***'. Below the fields is a grey 'Edit' button.

Master/Slave mode settings

1. Open advanced settings dashboard.
2. Click on text Working in Master/Slave mode to toggle between this two modes.



A screenshot of a text-based toggle switch that reads 'Working in slave mode - Click to switch to master mode'.

Bluetooth Serial mode settings – available in versions 2.0+

1. Open advanced settings dashboard.
2. Click on text Bluetooth mode enabled/disabled to toggle Bluetooth serial mode.
3. This settings is only available in slave mode only if Bluetooth Low Energy mode is disabled.



A screenshot of a text-based toggle switch that reads 'Bluetooth mode disabled - Click to enable'.

Bluetooth HID mode settings – available in versions 2.0+

1. Open advanced settings dashboard.
2. Click on text Bluetooth mode enabled/disabled to toggle HID mode.
3. This settings is only available in master mode.

Bluetooth mode disabled - Click to enable

Bluetooth HID mode reverse UID settings – available in versions 2.0+

1. Open advanced settings dashboard.
2. Click on text Bluetooth HID mode UID /not/ reversed to change settings.

Bluetooth HID mode UID reversed

Bluetooth Low Energy mode settings – available in versions 2.0+

1. Open advanced settings dashboard.
2. Click on text Bluetooth Low Energy mode enabled/disabled to toggle BLE mode.
3. This settings is only available in slave mode and only if Bluetooth Serial mode is disabled.

Bluetooth Low Energy mode disabled - Click to enable

Host address settings


1. Open advanced settings dashboard.
2. Click on Edit button in section Host.
3. Change field Host.
4. Click on button Save.
5. This settings is only available in master mode.



The screenshot shows a settings panel titled "Host" in blue. Below the title is a horizontal line. Underneath, the label "Host:" is followed by a text input field. To the right of the input field is a grey button labeled "Edit".

UDP broadcast IP settings


1. Open advanced settings dashboard.
2. Click on Edit button in section UDP broadcast IP.
3. Change field IP.
4. Click on button Save.
5. This settings is only available in master mode.



The screenshot shows a settings panel titled "UDP broadcast IP" in blue. Below the title is a horizontal line. Underneath, the label "IP:" is followed by a text input field containing the value "192.168.1.88". To the right of the input field is a grey button labeled "Edit".

Master mode settings

1. Open advanced settings dashboard.
2. Switch to master mode.
3. Click on option what you want to enable or disable.
4. This settings is only available in master mode.



Master mode settings

UDP broadcast enabled - [Click to disable](#)


HTTP POST request enabled - [Click to disable](#)

Linear read disabled - [Click to enable](#)

RTC POST disabled - [Click to enable](#)

Linear read settings

1. Open advanced settings dashboard.
2. Switch to master mode.
3. Enable Linear read.
4. Click on Edit button and change linear read settings.
5. Click on button Save.
6. This settings is only available in master mode.



Linear read settings

Mode:


Address:

Size:

Auth mode:

HTTP command test

1. Open advanced settings dashboard.
2. Write HEX string in field Command.
3. Click on button Sent to UART1/UART2.




The screenshot shows a web interface titled "HTTP command test". Below the title is a horizontal line. Underneath the line, there is a label "Command:" followed by a text input field containing the hexadecimal string "5526AA000101E0". To the right of the input field are two buttons: "Send to UART1" and "Send to UART2".

For more informations about COM protocol visit:

https://www.d-logic.net/code/nfc-rfid-reader-sdk/ufr-doc/raw/master/uFR_COM_Protocol.pdf

UDP broadcast IP settings


1. Open advanced settings dashboard.
2. Click on Edit button and change UDP broadcast IP address.
3. Click on button Save.
4. This settings is only available in master mode.



The screenshot shows a web interface titled "UDP broadcast IP". Below the title is a horizontal line. Underneath the line, there is a label "IP:" followed by a text input field containing the IP address "192.168.1.255". To the right of the input field is a button labeled "Edit".

Install uFR firmware

1. Open advanced settings dashboard.
2. Navigate to install uFR firmware section.
3. Select port and click Get available firmwares button.
4. Click on firmware version to install and wait for confirmation message.




Install uFR firmware

Port:

Get available firmwares

RTC settings

1. Open advanced settings dashboard.
2. Navigate to RTC settings section.
3. Click on Get UTC date/time button to get current RTC UTC date/time.
4. Click on Set current UTC system date/time button to set RTC UTC date/time from system.



RTC settings

UTC Date/time:

Get UTC date/time

Set current UTC system date/time


Modem sleep settings

1. Open advanced settings dashboard.
2. Navigate to Modem sleep section.
3. Click on text Modem sleep enabled/disabled to toggle.
3. Modem sleep can reduce performance, but also reduces heating significantly.

Modem sleep enabled - Click to disable

Basic information

1. Click on uFR Online button on top left corner.
2. Basic information about device will pop up on screen.



uFR Online LED status table

In table below are described all LED states of uFR Online.

LED status color		Description
Steady white	Steady white	Device is booted. Waiting for connection.
Steady blue	Steady blue	Device is booted in Bluetooth serial mode.
Steady cyan	Steady yellow	Device connected to WiFi in Slave mode.
Steady cyan	Steady cyan	Device connected to LAN in Slave mode.
Steady blue	Steady magenta	Device connected to WiFi in Master mode.
Steady magenta	Steady magenta	Device connected to LAN in Master mode.
Blinking cyan	Blinking yellow	Device is visible as AP in Slave mode.
Blinking blue	Blinking magenta	Device is visible as AP in Master mode.
Steady blue	Steady blue	Device is booted in Bluetooth serial mode.
Steady orange	Steady orange	Device is booted in HID mode.
Steady light blue	Steady light blue	Device booted in Bluetooth Low energy mode.
Steady red	Steady red	Device is booted in uFR Nano flashing mode.
Steady green	Steady green	Device is updating firmware OTA.

uFR Online default settings table

In table below are shown default settings for uFR Online.

Parameter	Value
Access point IP address	192.168.4.1
Server protocol	UDP
Port 1	8881
Port 2	8882
UART1 baud rate	115200
UART2 baud rate	115200
RS485 support	Disabled
Transparent mode	Enabled
Transparent device	1
Master/Slave mode	Slave
AP SSID	uFR Online Serial number (ONxxxxxx)
AP password	None
Login username	ufr
Login password	ufr
Discovery server port	8880
Master mode POST request	Enabled
Master mode UDP broadcast	Enabled
Master mode UDP broadcast address	Local broadcast address (eg. X.X.X.255)
Master mode linear read	Disabled
Default Bluetooth Low Energy mode PIN	123456

uFR Online REST services

In table below are described all REST services available on uFR Online. HTTP method is POST. Basic Authorization is needed except for /uart1 and /uart2. Username and password are same as Login.

URL	Parameters	Description
/info	None	Get configuration info.
/scan	None	Get available WiFi networks.
/togglemode	None	Toggle master/slave mode.
/toggletransparent	None	Toggle transparent mode.
/changetransparent	None	Change transparent device.
/changeap	ssid, password	Change device AP SSID and password.
/changehost	host	Change master mode host.
/changebroadcast	ip	Change master mode UDP broadcast IP.
/changeauth	username, password	Change authorization credentials.
/changesta	ssid, password	Connect to WiFi network.
/setport	port1, port2	Change UDP/TCP ports.
/disconnect	None	Disconnect from WiFi network.
/restart	None	Reboot device.
/toggleserver	None	Toggle UDP/TCP protocol. Only in slave mode.
/toggleble	None	Toggle Bluetooth Low Energy mode.
/setbaud	uart1, uart2	Change UART1 and UART2 baud rates.
/setdefaultbaud	uart	Reset connected uFR device to default baud rate.
/toggle485	None	Toggle UART2 RS485 support.
/setdefault	None	Reset device to factory default settings.



/togglepost	None	Toggle master mode POST request.
/togglebroadcast	None	Toggle master mode UDP broadcast.
/togglelinear	None	Toggle linear read. Only in master mode.
/changelinearmode	mode	Change linear read mode (1-8).
/changelinearsize	begin, size	Change linear read address and size.
/changelinearauth	auth	Change linear read authmode (0x60, 0x61...)
/changelinearkeyindex	index	Change linear read key index (0-31).
/changelinearkey	HEX string	Change linear read key.
/uart1	HEX string	Send HEX string command to UART1.
/uart2	HEX string	Send HEX string command to UART2.
/tooglebt	None	Toggle Bluetooth Serial mode.
/togglesleep	None	Toggle Modem sleep.
/update	requested_fw_version	Request firmware and update.
/getufrlist	uart	Get uFR Nano firmware list.
/ufrupdate	uart, vers	Update uFR Nano. Request /getufrlist first.
/changeblepin	pin	Change Bluetooth Low Energy passkey.
/setrtc	rtc	Set RTC UTC date/time.
/getrtc	None	GET request returns RTC UTC date/time.
/getled	None	GET current LED colors (r1g1b1r2g2b2) in HEX
/setled	HEX colors string	Set LED colors

uFR Online Reader basic usage

In this section will be described how to use uFR Online reader.

UDP/TCP communication

- All bytes sent to UDP/TCP port 1 will be forwarded to UART1 and vice versa.
- All bytes sent to UDP/TCP port 2 will be forwarded to UART2 and vice versa.
- uFR Series libraries has support for UDP/TCP communication.
- UDP/TCP mode works in parallel with Transparent and HTTP mode.

UDP/TCP communication – Reader opening example

```
/*  
Opening reader on IP address 192.168.1.112 and port 8881 for UDP communication.  
*/  
ReaderOpenEx(0, "192.168.1.112:8881", 'U', 0);  
  
/*  
Opening reader on IP address 192.168.1.112 and port 8881 for TCP communication.  
*/  
ReaderOpenEx(0, "192.168.1.112:8881", 'T', 0);
```

Bluetooth serial mode communication

- All bytes sent to Bluetooth serial port will be forwarded to UART1 or UART2 and vice versa.
- Bluetooth mode doesn't work in parallel with UDP/TCP and HTTP mode.

Bluetooth serial mode communication – Reader opening example

```
/*  
Opening reader in Bluetooth serial mode on virtual port COM34. Must disable reset on opening.  
*/  
ReaderOpenEx(2, "COM34", 0, "UNIT_OPEN_RESET_DISABLE");
```

Bluetooth serial mode communication

- All bytes sent to USB serial port will be forwarded to UART1 or UART2 and vice versa.
- Transparent mode works in parallel with UDP/TCP and HTTP mode.

Transparent mode communication – Reader opening example

```
/*  
Opening reader in Transparent mode. Must disable reset on opening.  
*/  
ReaderOpenEx(2, 0, 0, "UNIT_OPEN_RESET_DISABLE");
```

HTTP mode communication

- All HEX string bytes sent in POST body will be forwarded to UART1 or UART2 and vice versa.
- HTTP mode works in parallel with UDP/TCP and Transparent mode.

HTTP mode communication – GetCardIdEx example

```
/*  
Getting Card ID in HTTP mode using HTTP POST request.  
*/  
  
HTTP POST Request body sent to uFR Reader /uart1 or /uart2 > 557caa00aaccec  
  
HTTP POST Response body sent from uFR Reader > de7ced0b08044f52dad995000000000000cb
```

uFR Online Reader protocols structure

In this section will be described how to use uFR Online reader.

Master mode POST request

- In master mode if card is detected, device sends HTTP POST request to host.
- HTTP response must be "OK" or "FAILED" **for firmware version 1.5.4 and below.**
- If response is "OK", device will beep once and turn on green LED.
- If response is "FAILED", device will beep twice and turn on red LED.
- If server doesn't response is, device will beep three times and turn on red LED.
- [For firmware version 1.6.0 and above see Master mode POST response protocol section.](#)

Master mode HTTP POST request structure					
*	Form parameters				
Linear read disabled	SN	UID	CTRLINFO	ONLINE	
Linear read enabled	SN	UID	CTRLINFO	ONLINE	DATA
Description	Reader Serial number	Card UID	Control number from 0 to 255	Number 1 or 2 depends of reader	Linear read data as HEX string

Master mode POST response

- When server received POST request, uFR Online is waiting for HTTP response.
- Response contains HEX String commands from uFR COM protocol.
- Response must contains 3 rows delimited by newline character (\n), one for each UART.
- CMD-EXT must be sent in one string preceded by CMD, without any delimiter.
- Sending multiple commands can be done by splitting multiple strings with whitespace delimiter.

Master mode HTTP POST response structure				
Command sent to UART2	\n	Command sent to UART1	\n	Command sent to Transparent UART
Example - Sending USER_INTERFACE_SIGNAL command to UART1 and UART2				
5526AA000101E0	\n	5526AA000000E0	\n	0
Command sent to UART1	\n	Command sent to UART2	\n	Nothing sent to Transparent UART
Example - Sending USER_DATA_WRITE command to UART1 (CMD_EXT)				
551CAA110000F96A 6A0000360000003000 32003800410054	\n	0	\n	0
Command sent to UART1	\n	Nothing sent to UART2	\n	Nothing sent to Transparent UART

- PHP Server API for handling Master mode request with example is available at:
https://www.d-logic.net/code/nfc-rfid-reader-sdk/ufr_online-examples-php-master_mode

Master mode UDP broadcast

- In master mode if card is detected and UDP broadcast is enabled, device sends UDP broadcast.
- If HTTP POST request is enabled, indication is same as described above.
- If HTTP POST request is disabled, device will beep once and turn on green LED.

Master mode UDP broadcast structure																		
80/ReaderSerialNumber/CardUID/0																		

UDP discovery server

- UDP discovery server is used for finding uFR readers in local network.
- Send any UDP packet to uFR reader port 8880 and wait for response.

UDP discovery server response example																		
*					UART 1 PORT							UART 2 PORT						
*	IP address				Port	CP	Baud rate					Port	CP	Baud rate				
DEC	192	168	1	5	8881	'T'	115200					8882	'U'	250000				
HEX	C0	A8	01	05	B1	22	54	00	C2	01	00	B2	22	55	90	D0	03	00
*CP is network communication protocol. 'T' stands for TCP and 'U' for UDP.																		

uFR Online only COM protocol commands

- This commands are uFR Online only.
- Commands are sent in ASCII mode
- Commands be used in Transparent, Bluetooth Serial and Bluetooth Low Energy mode.


Command	Description
!TURN_MST_MODE_ON!	Toggle device to WiFi master mode.
!TURN_SLV_MODE_ON!	Toggle device to WiFi slave mode.
!TURN_BLE_MODE_ON!	Toggle device to Bluetooth Low Energy mode.
!TURN_SPP_MODE_ON!	Toggle device to Bluetooth Serial mode.
!TURN_HID_MODE_ON!	Toggle device to Bluetooth HID mode.
!TURN_APO_MODE_ON!	Turn off Access Point when Bluetooth is using.
!TURN_AP1_MODE_ON!	Turn on Access Point when Bluetooth is using.
!TURN_LD0_MODE_ON!	Turn off LED indication when Bluetooth is using.
!TURN_LD1_MODE_ON!	Turn on LED indication when Bluetooth is using.

uFR Online Reader tools

In this section will be described available uFR Online reader tools.

uFR Online flasher oneclick – Update tool

- This tool is used for installing firmware and OEM unlocking device.
- Download tool from: www.d-logic.net/code/nfc-rfid-reader-sdk/ufr_online-flasher-oneclick



uFR Online USB tools

COM PORT: COM50 R Connect uFR Online Serial number: MAC address: Hardware version: WiFi+BLE

Firmware install tool

Available versions: 1.5.2W_Custom UDP broadcast address added

Install firmware

Reset to default tool

Reset to factory defaults

OEM unlock tool - Developers only


OEM lock

OEM unlock

STATUS: CONNECTED OEM: LOCKED

uFR Online finder – Network discovery tool

- This tool is used for finding device in local network.
- Download tool from: www.d-logic.net/code/nfc-rfid-reader-sdk/ufr_online_finder



uFR Online tester

Scan for uFR Online readers

Username ufr Password ***

	Serial number	IP address	Port 1	Port 1 protocol	UART1 baudrate	Port 2	Port 2 protocol	UART2 baudrate	UI Signal	Toggle mode	Done	Encryption
▶		192.168.1.143	8881	TCP	115200	8882	TCP	115200	Beep	Toggle	Reset	Check

uFR Online OEM lock/unlock

CAUTION!!!

Devices OEM lock and unlock state can only be changed 3 times (unlock -> lock -> unlock). After that, when you lock it again, OEM will be permanently locked!

In this section will be described how to OEM lock and unlock device. By default device is OEM locked.

- If device is OEM **locked**, you can install only official firmware.
- If device is OEM **unlocked**, you cannot install official firmware. Unlocked device can be used as a development platform for writing your application in ESP-IDF, Arduino, Micropython and other available platforms for ESP32.

For locking and unlocking device, uFR Online flasher oneclick – Update tool is used.

OEM lock

In this section will be described how to OEM lock device.

1. Open uFR Online flasher oneclick – Update tool
2. Select COM port and click button connect.
3. Wait for the connection to be made successfully.
4. Click on button OEM lock.
5. Wait for locking process to finish.
6. After process is done, the latest firmware will be installed.

OEM unlock

In this section will be described how to OEM unlock device.

1. Open uFR Online flasher oneclick – Update tool
2. Select COM port and click button connect.
3. Wait for the connection to be made successfully.
4. Click on button OEM unlock.
5. Wait for locking process to finish.
6. After process is done, 'hello world' app will be installed on device.



Digital Logic

*****Unlocked device restrictions: ESP32 efuse BLK1 and BLK3 are reserved and cannot be used. Also, flash encryption must be disabled.**

uFR NFC Browser Extension

In this section will be described how to use uFR NFC Browser extension with uFR Online reader.

uFR NFC Browser Extension – Useful links

Google Chrome and Opera download link:

<https://chrome.google.com/webstore/detail/nfc-reader-browser-extens/kjfmmpfhdohhcodbkaodgkidbenkgog>

Mozilla Firefox download link:

<https://addons.mozilla.org/en-US/firefox/addon/nfc-reader-browser-extension/?src=search>

Native host installers for Window, Linux and MacOS download link:

https://www.d-logic.net/code/nfc-rfid-reader-sdk/ufr-browser_extensions/tree/master/Store%20installers

uFR NFC Browser Extension demo web app:

<https://www.d-logic.net/browser-extension-demo/>

uFR Reader API reference document:

<https://www.d-logic.net/code/nfc-rfid-reader-sdk/ufr-doc/blob/master/uFR%20Series%20NFC%20reader%20API.pdf>

uFR NFC Browser Extension - UDP reader opening example

ReaderOpenEx__UDP

0

ip_address:port

U

0

SEND

uFR NFC Browser Extension - TCP reader opening example

ReaderOpenEx__TCP

0

ip_address:port

T

0

SEND

uFR NFC Browser Extension - Bluetooth serial reader opening example

ReaderOpenEx__Bluetooth

2

port_name

0

UNIT_OPEN_RESET_DISABLE

SEND

uFR NFC Browser Extension - Transparent serial reader opening example

ReaderOpenEx__Transparent

2

port_name

0

UNIT_OPEN_RESET_DISABLE

SEND

Revision history

Date	Version	Comment
2019-04-11	1.0	Base document
2019-05-09	1.1	Master mode communication protocol changed
2019-06-17	1.2	Added firmware 2.0+ changes
2019-06-20	1.3	RTC and IO pins control added.
2019-06-24	1.4	OEM lock/unlock.
2019-07-19	1.5	uFR Test added.
2019-08-09	1.6	HID reverse UID option added.