

uFR Online – Quick Start Guide

Version 2.7

Table of contents

Installing uFR Online Reader	4
Step 1: Power on a device	4
Step 2: Connect to the uFR Online	4
Step 3: Set up your device	4
Step 4: Finish setting up your device	4
uFR Online Reader settings	5
Open WiFi network settings dashboard	5
Open advanced settings dashboard	5
uFR Online Test	6
Access Point settings	7
UDP/TCP ports and protocols settings	7
UART settings	8
Transparent mode settings	8
Login credentials settings	9
Master/Slave mode settings	9
Bluetooth Serial mode settings – available in versions 2.0+	9
Bluetooth HID mode settings – available in versions 2.0+	10
Bluetooth HID mode reverse UID settings – available in versions 2.0+	10
Bluetooth Low Energy mode settings – available in versions 2.0+	10
Bluetooth Low Energy mode characteristic settings– available in versions 2.0+	11
Host address settings	11
Using Basic HTTP authentication: http://username:password@example.com/	11
Master mode settings	12
Linear read settings	12
DESFire UID settings	13
Additional POST parameters	14
HTTP command test	15
UDP broadcast IP settings	15
UDP broadcast format settings	16
UDP broadcast retry settings	17
Install uFR firmware	17
Modem sleep settings	18

Static IP address settings	19
Basic information	19
uFR Reader Async UID send mode	20
Cloud IoT settings	20
Network timeout on boot settings	21
Log mode settings	22
LED brightness control	23
AP mode NFC Tag polling settings	23
uFR Online LED status table	24
uFR Online default settings table	25
uFR Online REST services	26
uFR Online Reader basic usage	28
UDP/TCP communication	28
UDP/TCP communication – Reader opening example	28
Bluetooth serial mode communication	28
Bluetooth serial mode communication – Reader opening example	28
Bluetooth serial mode communication	29
Transparent mode communication – Reader opening example	29
HTTP mode communication	29
HTTP mode communication – GetCardIdEx example	29
uFR Online Reader protocols structure	30
Master mode POST request	30
Master mode POST response	31
Master mode UDP broadcast	32
UDP discovery server	32
uFR Online only COM protocol commands	33
uFR Online Reader tools	34
uFR Online flasher oneclick – Update tool	34
uFR Online finder – Network discovery tool	34
uFR Online OEM lock/unlock	35
uFR NFC Browser Extension – Useful links	37
Revision history	39

Installing uFR Online Reader

Follow the instructions below to install your uFR Online reader.

Step 1: Power on a device

1. Connect device to a power source.
2. Wait for a few moments to device boot in Access Point mode (see LED status table below).
3. **Device will blink until client is not connected.**

Step 2: Connect to the uFR Online

1. Scan for networks using your WiFi enable device (computer, smartphone etc.).
2. Connect to device named ONxxxxxx.
3. Wait for the connection to be made successfully.
4. Open your favorite web browser and navigate to <http://192.168.4.1>

Step 3: Set up your device

1. After web page is loaded successfully log in using default credentials (see table 1 below).
2. Wait for a few moments to device scan for an available WiFi networks.
3. Select a WiFi network and click connect button.
4. Enter password for wireless network if needed and wait to connect successfully.

Step 4: Finish setting up your device

1. Click on uFR Online button on top left corner to find out your new IP address.
2. Reboot your uFR Online reader.

uFR Online Reader settings

Follow the instructions below to change uFR Online reader settings.


Open WiFi network settings dashboard

1. Open your favorite web browser and navigate to `http://<device-ip-address>`.
2. Log in using default credentials (see table 1 below).
3. After web page is loaded successfully, WiFi settings dashboard will be shown.
4. **If reader is working in BLE, BT or HID mode, WiFi station mode is not available (Only AP).**



Open advanced settings dashboard

1. Follow the instruction above (WiFi network setting section).
2. Click on Other settings button.
3. Advanced settings dashboard will be shown on screen.




uFR Online Test

1. Open advanced settings dashboard.
2. Navigate to Open μ FR Online test section and click.
3. Use color wheels to change LED colors.
4. Click on Beep button to send sound signal.
5. Approach an NFC card or tag to read UID.



Access Point settings


1. Open advanced settings dashboard.
2. Click on Edit button in section Access point.
3. Change fields SSID and Password.
4. Click on button Save.



The screenshot shows a web interface for 'Access point' settings. It has a title 'Access point' in blue. Below it, there are two input fields: 'SSID:' with the value 'UN101302' and 'Password:'. To the right of the password field is a grey 'Edit' button.

UDP/TCP ports and protocols settings


1. Open advanced settings dashboard.
2. Click on Edit button in section UDP/TCP ports..
3. Change fields Port 1 and Port 2.
4. Click on button Save.
5. Click on UDP/TCP ports header text to toggle between this two protocols.



The screenshot shows a web interface for 'UDP ports' settings. It has a title 'UDP ports - Click to switch to TCP' in blue. Below it, there are two input fields: 'Port 1:' with the value '8881' and 'Port 2:' with the value '8882'. To the right of the port 2 field is a grey 'Edit' button.


UART settings

1. Open advanced settings dashboard.
2. Click on Edit button in section UART Baud rates.
3. Change fields UART 1 and UART 2.
4. Click on button Save.
5. Click on UART2 RS485 disabled/enabled to toggle RS485 support on second serial port.




Transparent mode settings

1. Open advanced settings dashboard.
2. Click on Edit button in section Transparent mode.
3. Change field Reader to toggle between first and second serial ports.
4. Click on button Save.
5. Click on Transparent disabled/enabled text to toggle transparent mode.



Login credentials settings

1. Open advanced settings dashboard.
2. Click on Edit button in section Login.
3. Change fields Username and Password.
4. Click on button Save.



A screenshot of a web interface showing a 'Login' section. It contains two input fields: 'Username' with the value 'ufr' and 'Password' with masked characters '***'. Below the fields is a grey 'Edit' button.

Master/Slave mode settings

1. Open advanced settings dashboard.
2. Click on text Working in Master/Slave mode to toggle between this two modes.



A screenshot of a text-based toggle switch that reads 'Working in slave mode - Click to switch to master mode'.

Bluetooth Serial mode settings – available in versions 2.0+

1. Open advanced settings dashboard.
2. Click on text Bluetooth mode enabled/disabled to toggle Bluetooth serial mode.
3. This settings is only available in slave mode only if Bluetooth Low Energy mode is disabled.



A screenshot of a text-based toggle switch that reads 'Bluetooth mode disabled - Click to enable'.

Bluetooth HID mode settings – available in versions 2.0+

1. Open advanced settings dashboard.
2. Click on text Bluetooth mode enabled/disabled to toggle HID mode.
3. This settings is only available in master mode.

Bluetooth mode disabled - Click to enable

Bluetooth HID mode reverse UID settings – available in versions 2.0+

1. Open advanced settings dashboard.
2. Click on text Bluetooth HID mode UID /not/ reversed to change settings.

Bluetooth HID mode UID reversed

Bluetooth Low Energy mode settings – available in versions 2.0+

1. Open advanced settings dashboard.
2. Click on text Bluetooth Low Energy mode enabled/disabled to toggle BLE mode.
3. This settings is only available in slave mode and only if Bluetooth Serial mode is disabled.

Bluetooth Low Energy mode disabled - Click to enable

Bluetooth Low Energy mode characteristic settings– available in versions 2.0+

1. Open advanced settings dashboard.
2. Click on text Bluetooth Low Energy mode using read/notify characteristic to toggle BLE receiving data mode.
3. This settings is only available in slave mode and only if Bluetooth Serial mode is disabled.

Bluetooth Low Energy mode using read characteristic

Host address settings

1. Open advanced settings dashboard.
2. Click on Edit button in section Host.
3. Change field Host.
4. Click on button Save.
5. This settings is only available in master mode.

Host


Host:

Edit

Using Basic HTTP authentication: <http://username:password@example.com/>

Master mode settings

1. Open advanced settings dashboard.
2. Switch to master mode.
3. Click on option what you want to enable or disable.
4. This settings is only available in master mode.



Master mode settings

UDP broadcast enabled - [Click to disable](#)


HTTP POST request enabled - [Click to disable](#)

Linear read disabled - [Click to enable](#)

RTC POST disabled - [Click to enable](#)

Linear read settings

1. Open advanced settings dashboard.
2. Switch to master mode.
3. Enable Linear read.
4. Click on Edit button and change linear read settings.
5. Click on button Save.
6. This settings is only available in master mode.



Linear read settings

Mode:


Address:

Size:

Auth mode:

DESFire UID settings

1. Open advanced settings dashboard.
2. Switch to master mode.
3. Enable DESFire UID.
4. Click on Edit button and change DESFire UID settings.
5. Click on button Save.
6. This settings is only available in master mode.




The screenshot shows a web interface titled "DESFire UID settings". It contains the following fields and controls:

- Mode:** A dropdown menu with the selected value "GetDesfireUid_aes_PK".
- Key:** A text input field containing "00000000000000000000000000000000".
- Aid (3 bytes HEX):** A text input field containing "000000".
- Aid key number:** A text input field containing "0".
- Edit:** A grey button located at the bottom of the form.

Additional POST parameters

1. Open advanced settings dashboard.
2. Click on Edit button in section Additional POST parameters.
3. Change field Parameters.
4. Click on button Save.
5. This settings is only available in master mode.




Additional POST parameters

Parameters (eg. key1=value1&key2=value2):

Edit

HTTP command test

1. Open advanced settings dashboard.
2. Write HEX string in field Command.
3. Click on button Sent to UART1/UART2.




The screenshot shows a web interface titled "HTTP command test". It features a text input field labeled "Command:" containing the hexadecimal string "5526AA000101E0". Below the input field are two buttons: "Send to UART1" and "Send to UART2".

For more informations about COM protocol visit:

https://www.d-logic.net/code/nfc-rfid-reader-sdk/ufr-doc/raw/master/uFR_COM_Protocol.pdf

UDP broadcast IP settings


1. Open advanced settings dashboard.
2. Click on Edit button and change UDP broadcast IP address and port.
3. Click on button Save.
4. This settings is only available in master mode.



The screenshot shows a web interface titled "UDP broadcast IP address". It contains two text input fields: "IP address:" with the value "192.168.1.255" and "Port:" with the value "8881". Below these fields is a button labeled "Edit".

UDP broadcast format settings


1. Open advanced settings dashboard.
2. Navigate to UDP broadcast and edit parameters.
3. Click on button Save.
4. This settings is only available in master mode.



The screenshot shows a web interface titled "UDP broadcast format". It contains several input fields and buttons. The first field has the text "80/". The second field is a dropdown menu labeled "Serial number (UNxxxxxx)". The third field has the text "/". The fourth field is a dropdown menu labeled "UID". The fifth field has the text "/0". Below these fields are two buttons: "Add predefined parameter" and "Add custom parameter". At the bottom, there are four buttons: "Set Date/Time format", "Set UID delimiter", "Save", and "Clear".

UDP broadcast retry settings


1. Open advanced settings dashboard.
2. Click on Edit button and change number of retries (max. 255) and interval (max. 10000).
3. Click on button Save.
4. This settings is only available in master mode.



The screenshot shows a web interface titled "UDP broadcast retry". It contains two input fields: "Number of Retries" with the value "200" and "Retry interval (msec)" with the value "1". Below these fields is a grey button labeled "Edit".

Install uFR firmware


1. Open advanced settings dashboard.
2. Navigate to install uFR firmware section.
3. Select port and click Get available firmwares button.
4. Click on firmware version to install and wait for confirmation message.



The screenshot shows a web interface titled "Install uFR firmware". It contains a "Port:" label followed by an input field with the value "1". To the right of the input field is a grey button labeled "Get available firmwares".

RTC settings

1. Open advanced settings dashboard.
2. Navigate to RTC settings section.
3. Click on Get UTC date/time button to get current RTC UTC date/time.
4. Click on Set current UTC system date/time button to set RTC UTC date/time from system.



Modem sleep settings

1. Open advanced settings dashboard.
2. Navigate to Modem sleep section.
3. Click on text Modem sleep enabled/disabled to toggle.
3. Modem sleep can reduce performance, but also reduces heating significantly.



Static IP address settings


1. Open advanced settings dashboard.
2. Navigate to static IP section.
3. Click on text Static IP enabled/disabled to toggle.
4. Click on Edit button and change ip settings.
5. Click on button Save.
6. Note: If you set wrong parameters, use uFR Online flasher to factory reset.



The screenshot shows a web interface for static IP settings. At the top, it says "Static IP enabled - Click to disable". Below this, there are five input fields for IP configuration: IP address (192.168.1.81), Subnet mask (255.255.255.0), Default gateway (192.168.1.10), and DNS server (empty). At the bottom, there is an "Edit" button.


Basic information

1. Click on uFR Online button on top left corner.
2. Basic information about device will pop up on screen.




uFR Reader Async UID send mode

1. Open advanced settings dashboard.
2. Click on Send async enable command to UART1/2 to enable Async UID mode.
3. Click on Send async disable command to UART1/2 to disable Async UID mode.



Cloud IoT settings


1. Open advanced settings dashboard.
2. Switch to master mode.
3. Enable Cloud IoT support.
4. Select Cloud IoT service from list and enter required data.
5. Click on button Save and overwrite. **All settings are read only.**
6. This settings is only available in master mode.



Network timeout on boot settings

1. Open advanced settings dashboard.
2. Click on edit button and change timeout intervals..
3. Click on save button.

Waiting for network timeout determines how long device will wait for network before turn AP mode on.
AP mode timeout determines how long device will be in AP mode before trying again to connect. (min. 5s)



Network timeout on boot settings

Waiting for network timeout (seconds):

30


AP mode timeout (seconds):

120

Edit

Log mode settings

1. Open advanced settings dashboard.
2. Switch to master mode.
3. Enable Log mode support.
4. Navigate to Log mode setting and click on Edit button.
5. Enter NTP server host, NTP sync interval (in hours), Log server host (URL where to send log), log sending time (when to automatically send log).
5. Click on button Save.
6. This settings is only available in master mode.




The screenshot shows the 'Log mode settings' dashboard. It features several input fields for configuration: NTP server host, NTP sync interval, Log server host, and Log sending time. Below these are seven rows for card types, each with a text input field and a toggle switch. At the bottom, there are three buttons: 'Edit', 'Show log', and 'Send log'.

Using Basic HTTP authentication: <http://username:password@example.com/>

LED brightness control

1. Open advanced settings dashboard.
2. Click on the edit button and change brightness to a value between 0 and 100.
3. Click on the save button.

LED brightness control is global and applies to all modes.




The screenshot shows a settings panel titled "LED brightness control" in blue text. Below the title is a horizontal line. Underneath, the text "Brightness (0-100):" is followed by a text input field containing the value "100". Below the input field is a grey button labeled "Edit".

AP mode NFC Tag polling settings

1. Open advanced settings dashboard.
2. Click on the edit button and change timeout. To disable polling enter **-1**.
3. Click on the save button.



























AP mode NFC Tag polling timeout is time between reading NFC Tag that contains WiFi or Bluetooth connecting parameters and getting commands from transparent mode over USB.



The screenshot shows a settings panel titled "AP mode NFC Tag polling" in blue text. Below the title is a horizontal line. Underneath, the text "Timeout in seconds (set value to -1 to disable polling) :" is followed by a text input field containing the value "10". Below the input field is a grey button labeled "Edit".

uFR Online LED status table

In table below are described all LED states of uFR Online.

LED status color		Description
		Device is booted. Waiting for connection.
		Device is booted in Bluetooth serial mode.
		Device connected to WiFi in Slave mode.
		Device connected to LAN in Slave mode.
		Device connected to WiFi in Master mode.
		Device connected to LAN in Master mode.
		Device is visible as AP in Slave mode.
		Device is visible as AP in Master mode.
		Device is booted in Bluetooth serial mode.
		Device is booted in HID mode.
		Device booted in Bluetooth Low energy mode.
		Device is booted in uFR Nano flashing mode.
		Device is updating firmware OTA.

uFR Online default settings table

In table below are shown default settings for uFR Online.

Parameter	Value
Access point IP address	192.168.4.1
Server protocol	UDP
Port 1	8881
Port 2	8882
UART1 baud rate	115200
UART2 baud rate	115200
RS485 support	Disabled
Transparent mode	Enabled
Transparent device	1
Master/Slave mode	Slave
AP SSID	uFR Online Serial number (ONxxxxxx)
AP password	None
Login username	ufr
Login password	ufr
Discovery server port	8880
Master mode POST request	Enabled
Master mode UDP broadcast	Enabled
Master mode UDP broadcast address	Local broadcast address (eg. X.X.X.255)
Master mode linear read	Disabled
Default Bluetooth Low Energy mode PIN	123456

uFR Online REST services

In table below are described all REST services available on uFR Online. HTTP method is POST. Basic Authorization is needed except for /uart1 and /uart2. Username and password are same as Login.

URL	Parameters	Description
/info	None	Get configuration info.
/scan	None	Get available WiFi networks.
/togglemode	None	Toggle master/slave mode.
/toggletransparent	None	Toggle transparent mode.
/changetransparent	None	Change transparent device.
/changeap	ssid, password	Change device AP SSID and password.
/changehost	host	Change master mode host.
/changebroadcast	ip	Change master mode UDP broadcast IP.
/changeauth	username, password	Change authorization credentials.
/changesta	ssid, password	Connect to WiFi network.
/setport	port1, port2	Change UDP/TCP ports.
/disconnect	None	Disconnect from WiFi network.
/restart	None	Reboot device.
/toggleserver	None	Toggle UDP/TCP protocol. Only in slave mode.
/toggleble	None	Toggle Bluetooth Low Energy mode.
/setbaud	uart1, uart2	Change UART1 and UART2 baud rates.
/setdefaultbaud	uart	Reset connected uFR device to default baud rate.
/toggle485	None	Toggle UART2 RS485 support.
/setdefault	None	Reset device to factory default settings.

/togglepost	None	Toggle master mode POST request.
/togglebroadcast	None	Toggle master mode UDP broadcast.
/togglelinear	None	Toggle linear read. Only in master mode.
/changelinearmode	mode	Change linear read mode (1-8).
/changelinearsize	begin, size	Change linear read address and size.
/changelinearauth	auth	Change linear read authmode (0x60, 0x61...)
/changelinearkeyindex	index	Change linear read key index (0-31).
/changelinearkey	HEX string	Change linear read key.
/uart1	HEX string	Send HEX string command to UART1.
/uart2	HEX string	Send HEX string command to UART2.
/tooglebt	None	Toggle Bluetooth Serial mode.
/togglesleep	None	Toggle Modem sleep.
/update	requested_fw_version	Request firmware and update.
/getufrlist	uart	Get uFR Nano firmware list.
/ufrupdate	uart, vers	Update uFR Nano. Request /getufrlist first.
/changeblepin	pin	Change Bluetooth Low Energy passkey.
/setrtc	rtc	Set RTC UTC date/time.
/getrtc	None	GET request returns RTC UTC date/time.
/getled	None	GET current LED colors (r1g1b1r2g2b2) in HEX
/setled	HEX colors string	Set LED colors
/togglestatic	None	Toggle static/DHCP IP address
/changestatic	ip, mask, gateway, dns	Change static IP address parameters

uFR Online Reader basic usage

In this section will be described how to use uFR Online reader.

UDP/TCP communication

- All bytes sent to UDP/TCP port 1 will be forwarded to UART1 and vice versa.
- All bytes sent to UDP/TCP port 2 will be forwarded to UART2 and vice versa.
- uFR Series libraries has support for UDP/TCP communication.
- UDP/TCP mode works in parallel with Transparent and HTTP mode.

UDP/TCP communication – Reader opening example

```
/*  
Opening reader on IP address 192.168.1.112 and port 8881 for UDP communication.  
*/  
ReaderOpenEx(0, "192.168.1.112:8881", 'U', 0);  
  
/*  
Opening reader on IP address 192.168.1.112 and port 8881 for TCP communication.  
*/  
ReaderOpenEx(0, "192.168.1.112:8881", 'T', 0);
```

Bluetooth serial mode communication

- All bytes sent to Bluetooth serial port will be forwarded to UART1 or UART2 and vice versa.
- Bluetooth mode doesn't work in parallel with UDP/TCP and HTTP mode.

Bluetooth serial mode communication – Reader opening example

```
/*  
Opening reader in Bluetooth serial mode on virtual port COM34. Must disable reset on opening.  
*/  
ReaderOpenEx(2, "COM34", 0, "UNIT_OPEN_RESET_DISABLE");
```

Bluetooth serial mode communication

- All bytes sent to USB serial port will be forwarded to UART1 or UART2 and vice versa.
- Transparent mode works in parallel with UDP/TCP and HTTP mode.

Transparent mode communication – Reader opening example

```
/*  
Opening reader in Transparent mode using ReaderOpen function.  
*/  
ReaderOpen();  
  
/*  
Opening reader in Transparent mode using ReaderOpenEx function. Must disable reset on opening.  
*/  
ReaderOpenEx(1, 0, 0, "UNIT_OPEN_RESET_DISABLE");
```

HTTP mode communication

- All HEX string bytes sent in POST body will be forwarded to UART1 or UART2 and vice versa.
- HTTP mode works in parallel with UDP/TCP and Transparent mode.

HTTP mode communication – GetCardIdEx example

```
/*  
Getting Card ID in HTTP mode using HTTP POST request.  
*/  
  
HTTP POST Request body sent to uFR Reader /uart1 or /uart2 > 557caa00aaccec  
  
HTTP POST Response body sent from uFR Reader > de7ced0b08044f52dad995000000000000cb
```

uFR Online Reader protocols structure

In this section will be described how to use uFR Online reader.

Master mode POST request

- In master mode if card is detected, device sends HTTP POST request to host.
- HTTP response must be "OK" or "FAILED" **for firmware version 1.5.4 and below.**
- If response is "OK", device will beep once and turn on green LED.
- If response is "FAILED", device will beep twice and turn on red LED.
- If server doesn't response is, device will beep three times and turn on red LED.
- [For firmware version 1.6.0 and above see Master mode POST response protocol section.](#)

Master mode HTTP POST request structure					
*	Form parameters				
Linear read disabled	SN	UID	CTRLINFO	ONLINE	
Linear read enabled	SN	UID	CTRLINFO	ONLINE	DATA
Description	Reader Serial number	Card UID	Control number from 0 to 255	Number 1 or 2 depends of reader	Linear read data as HEX string

Master mode POST response

- When server received POST request, uFR Online is waiting for HTTP response.
- Response contains HEX String commands from uFR COM protocol.
- Response must contains 3 rows delimited by newline character (\n), one for each UART.
- CMD-EXT must be sent in one string preceded by CMD, without any delimiter.
- Sending multiple commands can be done by splitting multiple strings with whitespace delimiter.

Master mode HTTP POST response structure				
Command sent to UART2	\n	Command sent to UART1	\n	Command sent to Transparent UART
Example - Sending USER_INTERFACE_SIGNAL command to UART1 and UART2				
5526AA000101E0	\n	5526AA000000E0	\n	0
Command sent to UART1	\n	Command sent to UART2	\n	Nothing sent to Transparent UART
Example - Sending USER_DATA_WRITE command to UART1 (CMD_EXT)				
551CAA110000F96A 6A0000360000003000 32003800410054	\n	0	\n	0
Command sent to UART1	\n	Nothing sent to UART2	\n	Nothing sent to Transparent UART

- PHP Server API for handling Master mode request with example is available at:
https://www.d-logic.net/code/nfc-rfid-reader-sdk/ufr_online-examples-php-master_mode

Master mode UDP broadcast

- In master mode if card is detected and UDP broadcast is enabled, device sends UDP broadcast.
- If HTTP POST request is enabled, indication is same as described above.
- If HTTP POST request is disabled, device will beep once and turn on green LED.

Master mode UDP broadcast structure																		
80/ReaderSerialNumber/CardUID/0																		

UDP discovery server

- UDP discovery server is used for finding uFR readers in local network.
- Send any UDP packet to uFR reader port 8880 and wait for response.

UDP discovery server response example																		
*					UART 1 PORT							UART 2 PORT						
*	IP address				Port	CP	Baud rate					Port	CP	Baud rate				
DEC	192	168	1	5	8881	'T'	115200					8882	'U'	250000				
HEX	C0	A8	01	05	B1	22	54	00	C2	01	00	B2	22	55	90	D0	03	00
*CP is network communication protocol. 'T' stands for TCP and 'U' for UDP.																		

uFR Online only COM protocol commands

- This commands are uFR Online only.
- Commands are sent in ASCII mode
- Commands be used in Transparent, Bluetooth Serial and Bluetooth Low Energy mode.


Command	Description
!TURN_MST_MODE_ON!	Toggle device to WiFi master mode.
!TURN_SLV_MODE_ON!	Toggle device to WiFi slave mode.
!TURN_BLE_MODE_ON!	Toggle device to Bluetooth Low Energy mode.
!TURN_SPP_MODE_ON!	Toggle device to Bluetooth Serial mode.
!TURN_HID_MODE_ON!	Toggle device to Bluetooth HID mode.
!TURN_APO_MODE_ON!	Turn off Access Point when Bluetooth is using.
!TURN_AP1_MODE_ON!	Turn on Access Point when Bluetooth is using.
!TURN_LD0_MODE_ON!	Turn off LED indication when Bluetooth is using.
!TURN_LD1_MODE_ON!	Turn on LED indication when Bluetooth is using.

uFR Online Reader tools

In this section will be described available uFR Online reader tools.

uFR Online flasher oneclick – Update tool

- This tool is used for installing firmware and OEM unlocking device.
- Download tool from: www.d-logic.net/code/nfc-rfid-reader-sdk/ufr_online-flasher-oneclick



uFR Online USB tools

COM PORT: COM50 R Connect uFR Online Serial number: MAC address: Hardware version: WiFi+BLE

Firmware install tool

Available versions: 1.5.2W_Custom UDP broadcast address added

Install firmware

Reset to default tool

Reset to factory defaults

OEM unlock tool - Developers only


OEM lock

OEM unlock

STATUS: CONNECTED OEM: LOCKED

uFR Online finder – Network discovery tool

- This tool is used for finding device in local network.
- Download tool from: www.d-logic.net/code/nfc-rfid-reader-sdk/ufr_online_finder



uFR Online tester

Scan for uFR Online readers

Username: ufr Password: ***

	Serial number	IP address	Port 1	Port 1 protocol	UART1 baudrate	Port 2	Port 2 protocol	UART2 baudrate	UI Signal	Toggle mode	Done	Encryption
▶		192.168.1.143	8881	TCP	115200	8882	TCP	115200	Beep	Toggle	Reset	Check

uFR Online OEM lock/unlock

CAUTION!!!

Devices OEM lock and unlock state can only be changed 6 times (unlock -> lock -> unlock -> lock -> unlock -> permanent lock). After that, when you lock it again, OEM will be permanently locked!

In this section will be described how to OEM lock and unlock device. By default device is OEM locked.

- If device is OEM **locked**, you can install only official firmware.
- If device is OEM **unlocked**, you cannot install official firmware. Unlocked device can be used as a development platform for writing your application in ESP-IDF, Arduino, Micropython and other available platforms for ESP32.

For locking and unlocking device, uFR Online flasher oneclick – Update tool is used.

OEM lock

In this section will be described how to OEM lock device.

1. Open uFR Online flasher oneclick – Update tool
2. Select COM port and click button connect.
3. Wait for the connection to be made successfully.
4. Click on button OEM lock.
5. Wait for locking process to finish.
6. After process is done, the latest firmware will be installed.

OEM unlock

In this section will be described how to OEM unlock device.

1. Open uFR Online flasher oneclick – Update tool
2. Select COM port and click button connect.
3. Wait for the connection to be made successfully.
4. Click on button OEM unlock.
5. Wait for locking process to finish.
6. After process is done, 'hello world' app will be installed on device.



Digital Logic

*****Unlocked device restrictions: ESP32 efuse BLK1 and BLK3 are reserved and cannot be used. Also, flash encryption must be disabled.**

uFR NFC Browser Extension

In this section will be described how to use uFR NFC Browser extension with uFR Online reader.

uFR NFC Browser Extension – Useful links

Google Chrome and Opera download link:

<https://chrome.google.com/webstore/detail/nfc-reader-browser-extens/kjfmmpfhdohhcodbkaodgkidbenkgog>

Mozilla Firefox download link:

<https://addons.mozilla.org/en-US/firefox/addon/nfc-reader-browser-extension/?src=search>

Native host installers for Window, Linux and MacOS download link:

https://www.d-logic.net/code/nfc-rfid-reader-sdk/ufr-browser_extensions/tree/master/Store%20installers

uFR NFC Browser Extension demo web app:

<https://www.d-logic.net/browser-extension-demo/>

uFR Reader API reference document:

<https://www.d-logic.net/code/nfc-rfid-reader-sdk/ufr-doc/blob/master/uFR%20Series%20NFC%20reader%20API.pdf>

uFR NFC Browser Extension - UDP reader opening example

ReaderOpenEx__UDP

0

ip_address:port

U

0

SEND

uFR NFC Browser Extension - TCP reader opening example

ReaderOpenEx__TCP

0

ip_address:port

T

0

SEND

uFR NFC Browser Extension - Bluetooth serial reader opening example

ReaderOpenEx__Bluetooth

2

port_name

0

UNIT_OPEN_RESET_DISABLE

SEND

uFR NFC Browser Extension - Transparent serial reader opening example

ReaderOpenEx__Transparent

2

port_name

0

UNIT_OPEN_RESET_DISABLE

SEND

Revision history

Date	Version	Comment
2019-04-11	1.0	Base document.
2019-05-09	1.1	Master mode communication protocol changed.
2019-06-17	1.2	Added firmware 2.0+ changes.
2019-06-20	1.3	RTC and IO pins control added.
2019-06-24	1.4	OEM lock/unlock.
2019-07-19	1.5	uFR Test added.
2019-08-09	1.6	HID reverse UID option added.
2019-09-20	1.7	Static IP address option added.
2020-02-11	1.8	Added UART async mode and uFR protocol async mode.
2020-02-13	1.9	BLE receiving data mode
2020-03-12	2.0	DESFire UID, additional custom POST parameters
2020-03-25	2.1	Cloud IoT support
2020-04-29	2.2	Log mode support
2020-05-26	2.3	UDP broadcast settings
2020-05-27	2.4	Network timeout settings
2021-01-12	2.6	Transparent mode reader opening updated
2021-01-18	2.7	Added brightness control and AP Tag polling timeout

