

PA  
MUSE

COCKPIT  
DOOR VIDEO  
OFF

ADIRS  
ON BAT

IR1  
FAULT  
OFF  
NAV  
ATT  
OFF

IR3  
FAULT  
OFF  
NAV  
ATT  
OFF

IR2  
FAULT  
OFF  
NAV  
ATT  
OFF

ADR1  
FAULT  
OFF

ADR3  
FAULT  
OFF

ADR2  
FAULT  
OFF

FLT CTL  
ELAC1  
FAULT  
OFF

SEC1  
FAULT  
OFF

FAC1  
FAULT  
OFF

COMMAND  
EVAC  
ON

EVAC  
HORN SHUT OFF

CAPT & PURS  
CAPT

EMER GEN TEST

EMER ELEC PWR  
GEN 1 LINE  
SHAKE  
OFF

RAT &  
EMER GEN  
FAULT  
OFF

MAN ON

GPWS  
TERR  
FAULT  
OFF

SYS  
FAULT  
OFF

Q/S MODE  
OFF

FLAP MODE  
OFF

LDG FLAPS  
ON

GND CTL  
ON

RCDR  
CVR ERASE

CVR TEST

HIGH ALT  
LANDING  
ON

MASK MAN ON

OXYGEN  
PASSENGER  
SYS ON

CREW SUPPLY  
OFF

MECH

ALL

CALLS  
FWD

AFT

EMER  
CALL  
ON

RAIN RPLNT

WIPER  
OFF  
SLOW  
FAST

AGENT1  
SQUB  
DISCH

ENG 1  
FIRE  
PUSH

AGENT2  
SQUB  
DISCH

APU  
FIRE  
PUSH

AGENT1  
SQUB  
DISCH

ENG 2  
FIRE  
PUSH

AGENT2  
SQUB  
DISCH

TEST

GREEN  
ENG 1 PUMP  
FAULT  
OFF

BLUE  
RAT MAN ON

YELLOW  
ENG 2 PUMP  
FAULT  
OFF

ELEC PUMP  
FAULT  
OFF  
AUTO

ENG 1  
L TK PUMPS 1  
FAULT  
OFF

APU  
X FEED  
OPEN  
ON

ENG 2  
R TK PUMPS 1  
FAULT  
OFF

CTR TK L XFR  
FAULT  
OFF

MODE SEL  
FAULT  
MAN  
AUTO

CTR TK R XFR  
FAULT  
OFF

COMMERCIAL  
OFF

BAT1  
FAULT  
OFF

BAT 2  
FAULT  
OFF

BAT 2  
OFF

AC ESS FEED  
FAULT  
ALTN

DC BUS1

AC BUS1  
FAULT  
OFF  
AUTO

GEN1  
FAULT  
OFF

APU GEN  
FAULT  
OFF

BUS TIE  
OFF  
AUTO

EXT PWR  
AVAIL  
ON

DC BUS2

AC BUS2

GEN2  
FAULT  
OFF

IDG2  
FAULT  
OFF

PACK FLOW  
NORM  
LO  
HI

COCKPIT  
COLD  
HOT

FWD CABIN  
COLD  
HOT

AFT CABIN  
COLD  
HOT

HOT AIR  
FAULT  
OFF

PACK1  
FAULT  
OFF

PACK2  
FAULT  
OFF

ENG1 BLEED  
FAULT  
OFF

RAM AIR  
ON

GND HP

APU BLEED  
FAULT  
ON

SHUT

AUTO  
OPEN

ENG2 BLEED  
FAULT  
OFF

WING  
FAULT  
ON

ANTI ICE  
ENG1  
FAULT  
ON

ENG2  
FAULT  
ON

PROBE/WINDOW  
HEAT  
ON  
AUTO

CABIN PRESS  
MAN V/S CTL  
LP  
DN

MODE SEL  
FAULT  
MAN  
AUTO

LDG ELEV  
12  
AUTO  
0

DITCHING  
ON

STROBE  
ON

EXT LT  
BEACON  
ON

WING  
ON

NAV & LOGO  
2  
1  
OFF

APU  
MASTER SW  
FAULT  
ON

START  
AVAIL  
ON

OWD INTEG LT  
OFF

ICE IND & INT  
STBY COMPASS  
OFF

LT DOME  
BRT  
DN  
OFF

ANN LT  
TEST  
BRT  
DN

SEAT BELTS  
ON

NO SMOKING  
OFF

SIGNS  
EMER EXIT LT  
OFF

ON  
ARM  
OFF

TO TAXI  
OFF

NOSE  
ON  
OFF  
RETRACT

LAND  
L  
R  
ON  
OFF

RWY TURN OFF  
ON

VENTILATION  
BLOWER  
FAULT  
OVRD

EXTRACT  
FAULT  
OVRD

CAB FANS  
OFF

WIPER  
OFF  
SLOW  
FAST

RAIN RPLNT

CALL  
CALL  
CALL  
CALL

VHF1  
VHF2  
VHF3  
HF1  
HF2  
INT  
CAB

BT  
RAD

VOR1  
VOR2  
MKR  
ILS

ADF1  
ADF2

-PA-

ACTIVE

STBY/CRS

STBY

NAV

OFF

FLT CTL  
ELAC2  
FAULT  
OFF

SEC2  
FAULT  
OFF

SEC3  
FAULT  
OFF

FAC2  
FAULT  
OFF

CARGO VENT

AFT ISOL VALVE  
FAULT  
OFF

DISCH

CARGO SMOKE  
FWD  
SHOKE  
DISCH

TEST

FWD  
SHOKE  
DISCH

DISCH

VENTILATION  
BLOWER  
FAULT  
OVRD

EXTRACT  
FAULT  
OVRD

CAB FANS  
OFF

WIPER  
OFF  
SLOW  
FAST

RAIN RPLNT