

PA
MUSE

COCKPIT DOOR VIDEO
OFF

ADIRS
ON BAT

IR1
FAULT
OFF

IR3
FAULT
OFF

IR2
FAULT
OFF

ADR1
FAULT
OFF

ADR3
FAULT
OFF

ADR2
FAULT
OFF

FLT CTL
ELAC1
FAULT
OFF

SEC1
FAULT
OFF

FAC1
FAULT
OFF

EVAC
COMMAND
EVAC
ON

HORN SHUT OFF

CAPT & PURS
CAPT

EMER GEN TEST

EMER ELEC PWR
GEN 1 LINE
SMOKE
OFF

RAT & GEN
EMER GEN
FAULT
OFF

MAN ON
AUTO

TERR
FAULT
OFF

GPWS
SYS
FAULT
OFF

G/S MODE
OFF

FLAP MODE
OFF

LDG FLAP3
ON

GND CTL
AUTO

RCDR
CVR ERASE

CVR TEST

HIGH ALT LANDING
ON

MASK MAN ON
AUTO

OXYGEN
PASSENGER
SYS ON

CREW SUPPLY
OFF

MECH

ALL

CALLS
FWD

AFT

EMER
CALL
ON

RAIN RPLNT

WIPER
OFF
SLOW
FAST

AGENT1
SQUB
DISCH

ENG 1
FIRE
PUSH

AGENT2
SQUB
DISCH

APU
FIRE
PUSH

AGENT1
SQUB
DISCH

ENG 2
FIRE
PUSH

AGENT2
SQUB
DISCH

TEST

GREEN

ENG 1 PUMP
FAULT
OFF

RAT MAN ON

BLUE

ELEC PUMP
FAULT
OFF

PTU
FAULT
OFF

YELLOW

ENG 2 PUMP
FAULT
OFF

ELEC PUMP
FAULT
ON

ENG1

APU

X FEED
OPEN
ON

ENG2

L TK PUMPS
1
FAULT
OFF

2
FAULT
OFF

CTR TK L XFR
FAULT
OFF

MODE SEL
MAN

CTR TK R XFR
FAULT
OFF

R TK PUMPS
1
FAULT
OFF

2
FAULT
OFF

COMMERCIAL
DC BUS1
OFF

BAT1

BAT 2
1
FAULT
OFF

2
FAULT
OFF

BAT 2

AC ESS FEED
FAULT
ALTN

DC BUS2

GALY & CAB
FAULT
OFF

AC BUS1

AC ESS BUS

AC BUS2

IDG1
FAULT
OFF

GEN1
FAULT
OFF

APU GEN
FAULT
OFF

BUS TIE
OFF

EXT PWR
AVAIL
ON

GEN2
FAULT
OFF

IDG2
FAULT
OFF

PACK FLOW
LO
HI

COCKPIT
COLD
HOT

FWD CABIN
COLD
HOT

AFT CABIN
COLD
HOT

HOT AIR
FAULT
OFF

PACK1
FAULT
OFF

PACK1

START

RAM AIR
ON

GND HP

APU BLEED
FAULT
ON

X BLEED
SHUT
AUTO
START
OPEN

PACK2
FAULT
OFF

PACK2

ENG1 BLEED
FAULT
OFF

ENG2 BLEED
FAULT
OFF

WING
FAULT
ON

ANTI ICE
ENG1
FAULT
ON

ENG2
FAULT
ON

PROBE/WINDOW HEAT
ON

CABIN PRESS
MAN V/S CTL
UP
DOWN

MODE SEL
MAN

LDG ELEV
12
0
2
4
6
8
10

DITCHING
ON

STROBE
ON
OFF

BEACON
ON
OFF

EXT LT
WING
ON
OFF

NAV & LOGO
2
1
OFF

APU
MASTER SW
FAULT
ON

START
AVAIL
ON

OWHD INTEG LT
OFF
BRT

ICE IND & STBY COMPASS
OFF

LT DOME
BRT
DIM
OFF

ANN LT
TEST
BRT
DIM

SEAT BELTS
ON
OFF

NO SMOKING
ON
OFF

SIGNS
EMER EXIT LT
OFF

EMER EXIT LT
ON
ARM
OFF

CAPT

CALL
VHF1

CALL
VHF2

CALL
VHF3

CALL
HF1

HF2

INT

CAB

INT
VOR1
RAD
VOR2

MKR

ILS

ADF1

ADF2

ACTIVE

STBY/CRS

ELAC2
FAULT
OFF

FLT CTL
SEC2
FAULT
OFF

SEC3
FAULT
OFF

FAC2
FAULT
OFF

CARGO VENT

AFT ISOL VALVE
FAULT
OFF

DISCH

CARGO SMOKE
FWD
SMOKE
DISCH

TEST

FWD
SMOKE
DISCH

DISCH

BLOWER
FAULT
OVRD

EXTRACT
FAULT
OVRD

VENTILATION
CAB FANS
OFF

WIPER
OFF
SLOW
FAST

RAIN RPLNT