

---

# Command Reference: ReadReservoirReturnFromStateMod()

**Read reservoir return flow data from a StateMod reservoir return flow file**

## StateMod Command

Version 3.12.00, 2011-01-02

The `ReadReservoirReturnFromStateMod()` command reads a list of reservoir return flow data from a StateMod reservoir return flow data file. The data can then be manipulated and output with other commands.

The following dialog is used to edit the command and illustrates the syntax of the command.

**Edit ReadReservoirReturnFromStateMod() Command**

This command reads reservoir return data from a StateMod reservoir return file.  
The return data indicates how reservoir seepage is returned to the system.  
It is recommended that the location of the file be specified using a path relative to the working directory.  
The working directory is: C:\Develop\StateDMI\_SourceBuild\StateDMI\test\regression\commands\ReadReservoirReturnFromStateMod

StateMod file:

Command:

ReadReservoirReturnFromStateMod

### ReadReservoirReturnFromStateMod() Command Editor

The command syntax is as follows:

```
ReadReservoirReturnFromStateMod (Parameter=Value,...)
```

#### Command Parameters

Parameter	Description	Default
InputFile	The name of the StateMod reservoir return flow file to read.	None – must be specified.