
Command Reference: ReadBlaneyCriddleFromStateCU()

Read Blaney-Criddle crop coefficients data from a StateCU Blaney-Criddle crop coefficients file

StateCU Command

Version 3.08.02, 2010-01-07

The `ReadBlaneyCriddleFromStateCU()` command reads Blaney-Criddle crop coefficients from a StateCU Blaney-Criddle crop coefficients file and defines crop coefficients in memory. The crop coefficients can then be manipulated and output with other commands. This command can be used to adjust an existing crop coefficients file. The following dialog is used to edit the command and illustrates the syntax of the command.

Edit ReadBlaneyCriddleFromStateCU() Command

This command reads Blaney-Criddle crop coefficients from a StateCU Blaney-Criddle crop coefficients file. Blaney-Criddle crop coefficients estimate crop water requirements for each crop during the year, for standard conditions. It is recommended that the file be specified using a path relative to the working directory. The working directory is:
C:\Develop\StateDMI_SourceBuild\StateDMI\test\regression\UserManualRef\ReadBlaneyCriddleFromStateCU

Input file:

Command:

```
ReadBlaneyCriddleFromStateCU ( InputFile="rg2007.kbc" )
```

ReadBlaneyCriddleFromStateCU

ReadBlaneyCriddleFromStateCU() Command Editor

The command syntax is as follows:

```
ReadBlaneyCriddleFromStateCU(Parameter=Value,...)
```

Command Parameters

Parameter	Description	Default
InputFile	The name of the input file to read, surrounded by double quotes.	None – must be specified.