
Command Reference: ReadCropCharacteristicsFromStateCU()

Read crop characteristics data from a StateCU crop characteristics file

StateCU Command

Version 3.08.02, 2010-01-07

The `ReadCropCharacteristicsFromStateCU()` command reads a list of crops and their characteristics from a StateCU crop characteristics file and defines crop characteristics in memory. The crop characteristics can then be manipulated and output with other commands. This command can be used to adjust an existing crop characteristics file. The following dialog is used to edit the command and illustrates the syntax of the command.

Edit ReadCropCharacteristicsFromStateCU() Command

This command reads crop characteristics from a StateCU crop characteristics file.
Crop characteristics define general parameters for a crop (e.g., growing season, root depth).
It is recommended that the file be specified using a path relative to the working directory.
The working directory is:
C:\Develop\StateDMI_SourceBuild\StateDMI\test\regression\UserManualRef\ReadCropCharacteristicsFromStateCU

Input file:

Command:

ReadCropCharacteristicsFromStateCU

ReadCropCharacteristicsFromStateCU() Command Editor

The command syntax is as follows:

```
ReadCropCharacteristicsFromStateCU(Parameter=Value,...)
```

Command Parameters

Parameter	Description	Default
InputFile	The name of the input file to read, surrounded by double quotes.	None – must be specified.