

Command Reference: SetInstreamFlowStation()

Set instream flow station data

StateMod Command

Version 3.09.01, 2010-02-01

The `SetInstreamFlowStation()` command sets data in existing instream flow stations or adds a new instream flow station. The following dialog is used to edit the command and illustrates the syntax of the command.

Edit SetInstreamFlowStation() Command

This command sets (edits) data in instream flow station(s), using the instream flow station ID to look up the location. The instream flow station ID can contain a * wildcard pattern to match one or more locations. If the instream flow station ID does not contain a * wildcard pattern and does not match an ID, the location will be added if the "If not found" option is set to Add. Use blanks in the any field to indicate no change to the existing value.

Instream flow station ID:	<input type="text" value="954512"/>	Required - instream flow stations to fill (use * for wildcard).
Name:	<input type="text" value="Dillon_Res_Min_Rel"/>	Optional - up to 24 characters for StateMod.
Upstream river node ID:	<input type="text" value="954512"/>	Optional - upstream river node identifier.
Downstream river node ID:	<input type="text" value="954512_Dwn"/>	Optional - downstream river node identifier.
On/Off:	<input type="button" value="1 - On"/>	Optional - is instream flow station on/off in dataset?
Daily ID:	<input type="text" value="0"/>	Optional - daily identifier, "ID" to match ID, or StateMod flag).
Demand type:	<input type="button" value="2 - Average monthly demand"/>	Optional - demand time series type.
If not found:	<input type="button" value="Warn"/>	Optional - indicate action if no match is found (default=Warn).
Command:	<pre>SetInstreamFlowStation(ID="954512",Name="Dillon_Res_Min_Rel",UpstreamRiverNodeID="954512",DownstreamRiverNodeID="954512_Dwn",OnOff=1,DailyID="0",DemandType=2,IfNotFound=Wa rn)</pre>	

SetInstreamFlowStation

SetInstreamFlowStation() Command Editor

The command syntax is as follows:

```
SetInstreamFlowStation(Parameter=Value,...)
```

Command Parameters

Parameter	Description	Default
ID	A single instream flow station identifier to match or a pattern using wildcards (e.g., 20*).	None – must be specified.
Name	The name to be assigned for all matching instream flow stations.	If not specified, the original value will remain.
UpstreamRiverNodeID	The upstream river node identifier to be assigned for all matching instream flow stations.	If not specified, the original value will remain.
DownstreamRiverNodeID	The downstream river node identifier to be assigned for all matching instream flow stations.	If not specified, the original value will remain.
OnOff	The on/off switch value to be assigned for all matching instream flow stations, either 1 for on or 0 for off.	If not specified, the original value will remain.
DailyID	The daily identifier to be assigned for all matching instream flow stations.	If not specified, the original value will remain.
DemandType	The demand type to be assigned for all matching instream flow stations, one of: 1 – Average monthly demand, 2 – Monthly demand.	If not specified, the original value will remain.
IfNotFound	Used for error handling, one of the following: <ul style="list-style-type: none"> • Add – add the instream flow station if the ID is not matched and is not a wildcard • Fail – generate a failure message if the ID is not matched • Ignore – ignore (don't add and don't generate a message) if the ID is not matched • Warn – generate a warning message if the ID is not matched 	Warn