
Command Reference: ReadPlanReturnFromStateMod()

Read plan return flow data from a StateMod plan return flow file

StateMod Command

Version 3.12.00, 2011-01-02

The `ReadPlanReturnFromStateMod()` command reads a list of plan return flow data from a StateMod plan return flow data file. The data can then be manipulated and output with other commands.

The following dialog is used to edit the command and illustrates the syntax of the command.

Edit ReadPlanReturnFromStateMod() Command

This command reads plan return data from a StateMod plan return file.
The return data indicates how canal seepage is returned to the system.
It is recommended that the location of the file be specified using a path relative to the working directory.
The working directory is: C:\Develop\StateDMI_SourceBuild\StateDMI\test\regression\commands\ReadPlanReturnFromStateMod

StateMod file:

Command:

ReadPlanReturnFromStateMod

ReadPlanReturnFromStateMod() Command Editor

The command syntax is as follows:

```
ReadPlanReturnFromStateMod(Parameter=Value,...)
```

Command Parameters

Parameter	Description	Default
InputFile	The name of the StateMod plan return flow file to read.	None – must be specified.