
Command Reference: ReadPlanWellAugmentationFromStateMod()

Read well augmentation plan data from a StateMod well augmentation plan data file

StateMod Command
Version 3.12.00, 2011-01-02

The `ReadPlanWellAugmentationFromStateMod()` command reads well augmentation plan data from a StateMod well augmentation plan data file. The data can then be manipulated and output with other commands.

The following dialog is used to edit the command and illustrates the syntax of the command.

Edit ReadPlanWellAugmentationFromStateMod() Command

This command reads well augmentation plan data from a StateMod well augmentation plan data file.
A plan is an administrative model construct to control the delivery of water, beyond basic allocation and operating rules.
It is recommended that the location of the file be specified using a path relative to the working directory.
The working directory is: C:\Develop\StateDMI_SourceBuild\StateDMI\test\regression\commands\ReadPlanWellAugmentationFromStateMod

StateMod file:

Command:

```
ReadPlanWellAugmentationFromStateMod ( InputFile="Sp2008L.plw" )
```

ReadPlanWellAugmentationFromStateMod() Command Editor

The command syntax is as follows:

```
ReadPlanWellAugmentationFromStateMod(Parameter=Value,...)
```

Command Parameters

Parameter	Description	Default
InputFile	The name of the StateMod well augmentation plan file to read.	None – must be specified.