
Table of Contents

Version 07.00.00, 2007-03-02, Color, Acrobat Distiller

- 1 Acknowledgements
- 2 Introduction
- 3 Getting Started
 - 3.1 Starting StateMod GUI
 - 3.2 Main Interface
 - 3.3 File Menu – Open and Save Data Sets
 - 3.4 Edit Menu – Add and Delete Model Data
 - 3.5 View Menu – Enable/Disable Display Features
 - 3.6 Data Menu – View and Edit Data
 - 3.7 Run Menu – Run StateMod
 - 3.8 Results Menu – View StateMod Results
 - 3.9 Tools Menu
 - 3.10 Help Menu
- 4 The Model Network – Adding and Deleting Data
 - 4.1 Model Network Overview
 - 4.2 Model Network Interface
 - 4.3 Printing a Model Network
 - 4.4 Saving a Model Network as an Image
 - 4.5 Adding an Existing Model Network to an Existing Data Set
 - 4.6 Creating a New Model Network for an Existing Data Set
 - 4.7 Creating a New Model Network With a New Data Set
 - 4.8 Synchronizing a Model Network With a Data Set
 - 4.9 Editing a Model Network – Adding Data
 - 4.10 Editing a Model Network – Deleting Data
- 5 Viewing and Editing Data
 - 5.1 Control Data
 - 5.1.1 Response File
 - 5.1.2 Control File
 - 5.1.3 Output Control File
 - 5.2 Stream Gage Data
 - 5.3 Delay Table Data
 - 5.3.1 Delay Tables (Monthly)
 - 5.4 Diversion Data
 - 5.4.1 Diversion Station Return Flows
 - 5.4.2 Diversion Water Rights
 - 5.4.3 Diversion Time Series
 - 5.5 Precipitation Data
 - 5.6 Evaporation Data
 - 5.7 Reservoir Data
 - 5.7.1 Reservoir Content/Area/Seepage
 - 5.7.2 Reservoir Climate Station Assignment
 - 5.7.3 Reservoir Accounts
 - 5.7.4 Reservoir Water Rights
 - 5.7.5 Reservoir Time Series
 - 5.8 Instream Flow Data
 - 5.8.1 Instream Flow Rights
 - 5.8.2 Instream Flow Time Series

5.9 Well Data	
5.9.1 Well Station Depletions	
5.9.2 Well Station Return Flows	
5.9.3 Well Water Rights	
5.9.4 Well Time Series	
5.10 Stream Estimate Data	
5.10.1 Stream Estimate Time Series	
5.11 River Network Data	
5.12 Operational Rights Data	
6 Running StateMod	
6.1 Running StateMod in Baseflow, Data Check, Simulation, and Information Modes	
6.2 Running StateMod in Report Mode	
7 Viewing StateMod Results	
7.1 Graphing Tool – Create Graphs for StateMod Input and Results	
7.2 Graph Demand/Supply Summary	
7.3 View StateMod Output Files	
8 Using the Map	
9 Tools	
9.1 Run Delta Plot – Summarize Simulation Results and Compare Data Sets	
9.2 Add Summary Map Layer	
9.3 Add Historical/Simulated Streamflow Difference to Map	
9.4 Add Historical/Simulated Streamflow Difference (Percent) to Map	
9.5 Add Animation Map Layer	
9.6 Query Tool – Find Stations that Match Criteria	
9.7 StateMod GUI Options	
9.8 Listing Modified Data	
9.9 Listing Unused Data	
9.10 Network Summary	
9.11 Diagnostic Tools	
10 Troubleshooting	
Appendix – StateMod Installation and Configuration	
Appendix – Configuring Spatial Data for the StateMod GUI	
Appendix – Release Notes	
Appendix – DateValue Input Type (time series file format)	
Appendix – StateMod Input Type (time series file format)	
Appendix – StateMod Binary Input Type (time series file format)	
Appendix – TSView Time Series Viewing Tools	
Appendix – GeoView Mapping Tools	