

N9H30 Linux BSP User Manual

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing this document only for reference purposes of N9H30 microprocessor based system design. Nuvoton assumes no responsibility for errors or omissions.

All data and specifications are subject to change without notice.

For additional information or questions, please contact: Nuvoton Technology Corporation.

www.nuvoton.com

1	N9H30 Linux BSP Introduction.....	3
1.1	Develop Environment.....	3
1.2	Dev Board Setting	4
2	BSP Installation	5
2.1	System Requirement.....	5
2.2	Download and installation VMware virtual machine	5
2.3	Download and installation CentOS Linux	8
2.4	Install missing packages.....	14
2.5	BSP installation procedures.....	14
3	NuWriter Tool	17
4	U-Boot.....	18
5	Linux Kernel.....	19
5.1	The Configuration Interface for the Kernel	19
5.2	Default Configuration	19
5.3	Linux Kernel Configuration.....	19
5.4	Linux Kernel Compilation	49
6	Linux user applications	51
6.1	Sample applications	51
6.2	Cross compilation	55
7	Revision Hisotry.....	56

1 N9H30 Linux BSP Introduction

This BSP supports Nuvoton N9H30 family processors. The NUC970/N9H30 series targeted for general purpose 32-bit microcontroller embeds an outstanding CPU core ARM926EJ-S, a RISC processor designed by Advanced RISC Machines Ltd., runs up to 300 MHz, with 16 KB I-cache, 16 KB D-cache and MMU, 56KB embedded SRAM and 16 KB IBR (Internal Boot ROM) for booting from USB, NAND and SPI FLASH.


The NUC970/N9H30 series processor integrates two 10/100 Mb Ethernet MAC controllers, USB 2.0 HS HOST/Device controller with HS transceiver embedded, TFT type LCD controller, CMOS sensor I/F controller, 2D graphics engine, DES/3DES/AES crypto engine, I2S I/F controller, SD/MMC/NAND FLASH controller, GDMA and 8 channels 12-bit ADC controller with resistance touch screen functionality. It also integrates UART, SPI/MICROWIRE, I2C, CAN, LIN, PWM, Timer, WDT/Windowed-WDT, GPIO, Smart Card I/F, 32.768 KHz XTL and RTC (Real Time Clock)

NUC970 Linux BSP includes following contents:

- Linux 3.10 kernel source code and N9H30 device drivers.
- GCC 4.8.4 cross compiler with EABI support.
- uClibc-0.9.33
- Binutils-2.24
- Demo program for device drivers, busybox, mtd-util, and other open source applications.
- U-Boot source code including N9H30 device drivers.
- Flash programming tool NuWriter, and its Windows driver.
- User manuals.

1.1 Develop Environment

This BSP only provides cross development tool chain in Linux environment. So Linux platform is a must to build Linux kernel, U-Boot, and applications using the cross compiling tool chain in BSP. This platform could be a dedicate Linux server or running on virtual machine. PC can communicate with N9H30 Dev Board via different communication interfaces, such as UART, USB or Ethernet. As well as debug port, JTAG. Above interfaces could be used to load binary file to EV board for execution. JTAG interface could be used for chip level debug. USB interface is the interface used by NuWriter to program NAND, SPI, and eMMC. Following figure is an example of development environment.



1.2 Dev Board Setting

N9H30 family supports different boot modes, it can boot from SPI, NAND, eMMC, or enter USB ISP mode. The booting mode is selected by PA[1:0] jumper. Because most I/O pins support multiplefunctions, the jumpers on DEV board must be set according to the enabled peripherals. Please refer to “N9H30 Development Board User Manual” for the usage of DEV board.

2 BSP Installation


2.1 System Requirement

N9H30 Linux BSP provides cross compilation tools based on Linux operating system. We have tested this BSP in different x86 Linux distributions, including Ubuntu, CentOS, and Debian...etc. Because there are so many distributions out there with different system configuration, sometimes it is necessary to change system setting or manually install some missing component in order to cross compile.

Linux development environment could either be native, or install in a virtual machine execute on top of other operating system. This chapter introduces how to install CentOS Linux to VMware virtual machine, and the steps to install N9H30 Linux BSP.

2.2 Download and installation VMware virtual machine

VMware provides free virtual machine VMware player 5.0.2 for users to download from VMware official website <http://www.vmware.com/>. Select "Products" → "Free Products" → "Player", click "Download" button, select "5.0 (latest)" as "Major Version" and "5.0.2 (latest)" as "Minor Version" and then download "VMware Player for Windows 32-bit and 64-bit". Please refer to the figure below.



Major Version: 5.0 (latest)
Minor Version: 5.0.2 (latest)

Product Downloads
Open Source

VMware Player for Linux 32-bit
(bundle | 210M)
[Show Details](#)

Download ↓

VMware Player for Linux 64-bit
(bundle | 177M)
[Show Details](#)

Download ↓


VMware Player for Windows 32-bit and 64-bit
(exe | 76M)
[Show Details](#)

Download ↓


After download complete, double click the downloaded file.



And then click "Next" to continue installation steps.



At last, double click the installed file to create a virtual machine.



2.3 Download and installation CentOS Linux

Here introduces the procedure to install CentOS 6.4 under VMWare. It is pretty much the same with installing as native operating system. First connect to <http://www.centos.org/>, and enter the download page by selecting "CentOS 6 Releases" → "i386". Select "CentOS-6.4-i386-bin-DVD 1.iso" to download CentOS 6.4.

CentOS 6 Releases

March 12th 2013

The CentOS team is pleased to **announce** the immediate availability of CentOS 6.4 for i386 and x86_64 architectures.

CentOS 6.4 is based on the upstream release EL 6.4 and includes packages from all variants. All upstream repositories have been combined into one, to make it easier for end users to work with.

There are some very important changes to this release compared with the previous versions of CentOS and we highly recommend reading this announcement along with the **Release Notes**. Especially take a look at the "Known Issues" section.

There is also a minimal install CD that will get you a very small base install that you can add to.



And now: Have fun.

Release Notes: [CentOS](#)
Download: [i386](#) [x86_64](#)

<u>Name</u>	<u>Last modified</u>	<u>Size</u>	<u>Description</u>
 Parent Directory		-	
 CentOS-6.4-i386-bin-DVD1.iso	06-Mar-2013 08:42	3.5G	
 CentOS-6.4-i386-bin-DVD2.iso	06-Mar-2013 08:43	1.1G	
 CentOS-6.4-i386-minimal.iso	06-Mar-2013 08:43	301M	
 CentOS-6.4-i386-netinstall.iso	06-Mar-2013 08:43	189M	
 CentOS-6.4-i386-bin-DVD1to2.torrent	09-Mar-2013 05:14	184K	

If VMware virtual machine is already installed, click "Create a New Virtual Machine" to install Linux virtual machine, otherwise follow the steps in previous section to complete VMware installation.

First, click "Installer disc image file (iso):" and "Browse..." and select the downloaded CentOS 6.4 iso as image source file.



Input "Full name:", "User name:", "Password:", and "Confirm:" click Confirm button. Please remember the username and password, they'll be used to login CentOS later.

New Virtual Machine Wizard

Easy Install Information
This is used to install CentOS.

Personalize Linux

Full name: test1 test2

User name: test

Password: ••••

Confirm: ••••

This password is for both user and root accounts.

Help < Back Next > Cancel

Next, input “Virtual machine name:” and “Location:” if necessary, otherwise keep the default value.

New Virtual Machine Wizard


Name the Virtual Machine
What name would you like to use for this virtual machine?

Virtual machine name: CentOS


Location: C:\Users\scfchian1.NUVOTON\Documents\Virtual Machines\Cent Browse...

< Back Next > Cancel

In the next step, input “Maximum disk size (GB):” value, it is recommend to reserve at least 60GB disk space, and select “Store virtual disk as a single file”.




The last step is to click “Finish” to complete the CentOS configuration.



VMware will automatically complete reset of the CentOS installation procedures.



A CentOS login window will show up after installation complete. You can login using the username and password set in previous step.



2.4 Install missing packages

Each Linux distribution selects different packages to install. And most distributions do not install all packages mandatory for N9H30 Linux BSP. And also lack of some optional packages which might be useful during development. Below listed some packages that may be missing after installed a Linux distribution but are mandatory or recommend, and could install later manually.

Package name	Function	Mandatory/ Optional
Patch	Application for apply patch file	Mandatory
libc6-dev	Contains required libraries to link with cross compiling tool chain. (i386 version)	Mandatory
libncurses5-dev	Contains required header files to build menuconfig interface	Mandatory
git-all	Software version control tool	Mandatory
Minicom or cutecom	Serial terminal which could display the bootloader message or Linux console output.	Optional

Each Linux distribution has its own package management system. Ubuntu users could use apt-get command or Synaptic Package Manager to install packages. And Fedora users could use rpm command or Package Manager to install packages. Please refer to the manual of the Linux distribution you use to install missing components.

2.5 BSP installation procedures

Linux BSP contains three directories. Content of each directory listed in following table:

Directory name	Content
BSP	A tar ball contains U-Boot, Linux kernel, sample application source code. As

	well as cross compiler and root file system.
Documents	BSP related documents.
Tools	Writer tool and its driver executing in Windows OS.

Please copy the tar ball under BSP directory to Linux machine and use following command to extract the file.

```
$ tar zxvf n9h30bsp.tar.gz
```

After enter n9h30bsp directory, execute the installation script install.sh. This script requires the administrator privilege to execute. You can use “su” command to switch to root and execute the installation script.

```
$ su
Password: (Enter password of root)
# ./install.sh
```

Or execute this script as root by using sudo command. (This method works for those distributions do not open the root account privilege, such as Ubuntu)

```
# sudo ./install.sh
```

The installation script can either extract local source files or clone from remote git repository based on user selection. To clone from git repository, it is necessary to install Git and set up a valid network connection prior to installation, either Github or OSChina could be set as remote. Below is the console output during installation:

```
Now installing arm_linux_4.8 tool chain to /usr/local/
Setting tool chain environment
Installing arm_linux_4.8 tool chain successfully
Install rootfs, applications, u-boot and Linux kernel
Please enter absolute path for installing(eg:/home/<user name>) :
BSP will be installed in /<path you input>/nuc970bsp
/home/someone
Do you want to (C)lone latest source code from Internet or (E)xtract local
copy?
It is strongly recommended to clone latest source code from git repository
Clone from Internet
Check network connecting status...OK
Extract rootfs and pre-built images
which server would you clone from (1)Github or (2)Gitee?
Clone from Github
...
...
N9H30 BSP installation complete
```

If your Linux server has already installed the arm_linux_4.8 tools, the installation script will ask whether or not to overwrite existing tool chain. Otherwise the script will install the tool chain into /usr/local/arm_linux_4.8 without asking. For the first case, if you want to update the tool chain, you can select Y(or yes 、 y 、 YES), then hit Enter key.

After install the tool chain, the installation script will ask for the absolute path for install kernel and applications. The table below listed the item will be installed in the specified location

Directory name	Content
applications	Demo applications and other open source applications, such as busybox, wireless tool...
buildroot	A set of Makefiles and patches that simplifies and automates the process of building a complete and bootable Linux environment for an embedded system
image/kernel	Pre build kernel using default configuration
image/U-Boot	Pre build U-Boot images support either NAND or SPI flash and env.txt file which stores U-Boot's environment variable. The default execution address of U-Boot images is 0xE00000.
linux-3.10.x	Linux kernel source code
rootfs	Root file system
uboot.v2016.11	U-Boot V2016.11 source code

The installation script will try to configured the installed directory with correct owner and group, and add the path of compiler into \$PATH. However, this doesn't work correctly in every Linux distribution. User might need to set the owner/group of installed directory with correct user's name, and add /usr/local/arm_linux_4.8/bin to \$PATH manually.

Note: Please logout and re-login after installation complete to make the changes take effect.

If clone from git repository is selected during installation, users can always sync with latest source code from remote repository with git pull command. Following table list the link to the repositories of each software package. The Git command usage is beyond the scope of this document, please refer to the manuals in <https://git-scm.com/> for the Git command usage.

Software Package	Link to repository
Applications	https://github.com/OpenNuvoton/NUC970_Linux_Applications.git https://gitlab.com/OpenNuvoton/NuMicro-ARM7-ARM9-Family/NUC970_Linux_Applications.git https://git.oschina.net/OpenNuvoton/NUC970_Linux_Applications.git
buildroot	https://github.com/OpenNuvoton/NUC970_Buildroot.git https://gitlab.com/OpenNuvoton/NuMicro-ARM7-ARM9-Family/NUC970_Buildroot.git https://git.oschina.net/OpenNuvoton/NUC970_Buildroot.git
linux-3.10.x	https://github.com/OpenNuvoton/NUC970_Linux_Kernel.git https://gitlab.com/OpenNuvoton/NuMicro-ARM7-ARM9-Family/NUC970_Linux_Kernel.git https://git.oschina.net/OpenNuvoton/NUC970_Linux_Kernel.git
uboot.v2016.11	https://github.com/OpenNuvoton/NUC970_U-Boot_v2016.11.git https://gitlab.com/OpenNuvoton/NuMicro-ARM7-ARM9-Family/NUC970_U-Boot_v2016.11.git https://git.oschina.net/OpenNuvoton/NUC970_U-Boot_v2016.11.git
NuWriter	https://github.com/OpenNuvoton/NUC970_NuWriter.git https://gitlab.com/OpenNuvoton/NuMicro-ARM7-ARM9-Family/NUC970_NuWriter.git https://git.oschina.net/OpenNuvoton/NUC970_NuWriter.git

3 NuWriter Tool

This tool can help users to program their images into the on-board ROM device when the system enters USB ISP mode. On-Board ROM device includes eMMC device, SPI Flash device and NAND Flash. Please refer to NuWriter User's Manual for the usage of NuWriter tool.

4 U-Boot

The U-Boot utility is a multi-platform, open-source, universal boot-loader with comprehensive support for loading and managing boot images, such as the Linux kernel. It supports the following features:

- Network download: TFTP, BOOTP, DHCP
- Serial download: s-record, binary (via Kermit)
- Flash management: erase, read, update, yaffs2
- Flash types: SPI flash, NAND flash
- Memory utilities: dump, compare, copy, write
- Interactive shell: commands with scripting features

N9H30 U-Boot version is 2016.11. It is downloaded from <http://www.denx.de/wiki/U-Boot/SourceCode>

To know more detailed description of U-Boot can visit U-Boot official website <http://www.denx.de/wiki/view/DULG/UBoot>. And please refer to NUC970/N9H30 U-Boot v2016_11 User Manual for the U-Boot configuration of NUC970/N9H30.

5 Linux Kernel

5.1 The Configuration Interface for the Kernel

Linux supports different kinds of configuration. Users can disable some unnecessary functions to save resource of kernel system.

To enter the page of Linux configuration, please type “make menuconfig” command in shell.

It's multi-layer menu in configuration system. In the current page, user can press “up”, “down”, “left”, “right” four keys to control the layer of configuration system. Select kernel function by pressing “up” or “down” key and select menu function in the bottom of page by pressing “left” or “right” key. To enter the next layer of configuration page, user can press “enter” key.

There are five functions at the bottom of menu page. User can disable or enable kernel function by pressing space key when cursor stays at “Select”. The symbol in front of the selection function “[]” stands for this function is disabled, “[*]” stands for this function is enabled and “[M]” stands for this function is built as module and can be loaded dynamically.

Menu page can be returned to upper layer by pressing space key when cursor stays at “Exit” at the bottom of menu page. If it's at the top layer of configuration system, system will inform user if wants to save the configuration and exit.

The help screen will show when cursor is at “Help” by pressing space key. To save current configuration or load old configuration, use can press space key when cursor is at “Save” or “Load” at the bottom of menu page.

The kernel configuration file will be named “.config” and be saved in the linux-3.10.x directory.

5.2 Default Configuration

There is a default configuration for the N9H30 series chips provided by Nuvoton. Before modifying any configuration of kernel, we recommend to load the default configuration of kernel first. User can type “make <mcu name>_defconfig” command to do that. The option “<Mcu name>” can be n9h30f5. For example, type “make n9h30f5_defconfig” to load default configuration of N9H30F5. Sometimes if system can't boot up, user can load the default configuration which is described above to recovery kernel to safe status.

5.3 Linux Kernel Configuration

This section introduces the configuration to enable kernel function according to different N9H30 driver or functions.

5.3.1 Basic Configuration of System

- Mount the module

Some drivers only support dynamic load, for example “USB WiFi driver” or “USB device driver” ... and so on. Please enable the following function to support that. When system is booted up at shell, user can use “insmod <module name>” to load module.

```
[*] Enable loadable module support ---->
```

- Remove module

If some module drivers need to be removed by system, please enable the following function to support module removing. To remove module, user can use “rmmod <module name>” command to do that.

```
[*] Enable loadable module support ---->
```

```
    [*] Module unloading
```

- Boot Options – root file system is based on RAM

Boot option can configure system, including the type of root file system, the size of memory, baud-rate of uart console... and so on. The following example is a simple configuration and there are many commands can be supported by kernel. User can refer to the document which is at Documentation/kernel-parameters.txt.

```
Boot options --->
    (root=/dev/ram0 console=ttyS0, 115200n8 rdinit=/sbin/init mem=64M)
Default kernel command string
    kernel command line type (Use bootloader arguments if available)
--->
```

- Boot Options – root file system is based on YAFFS2 (NAND Flash)

If root file system is at NAND flash and use YAFFS2 file system, user needs to enable YAFFS2 file system (please refer to 5.3.4) and disable RAM file system function.

```
General setup --->
    [ ] Initial RAM filesystem and RAM disk (initramfs/initrd) support
```

The following is an example to boot up YAFFS2 root file system. A YAFFS2 root file system image (please refer to **Error! Reference source not found.**) needs to be done first and write it to the mtdblock2 in Linux system.

```
Boot options --->
    (noinitrd root=/dev/mtdblock2 rootfstype=yaffs2 rootflags=inband-tags
console=ttyS0, 115200n8 rdinit=/sbin/init mem=64M) Default kernel command
string
    kernel command line type (Use bootloader arguments if available)
--->
```

- Boot Options – root file system is based on JFFS2 (SPI Flash)

If root file system is at SPI flash and use JFFS2 file system, user needs to enable JFFS2 file system (please refer to 5.3.4) and disable RAM file system function.

```
General setup --->
    [ ] Initial RAM filesystem and RAM disk (initramfs/initrd) support
```

The following is an example to boot up JFFS2 root file system. A JFFS2 root file system image needs to be done first by mkfs.jffs2 utility and write it to the mtd1 in Linux system

```
Boot options --->
    (root=/dev/mtdblock1 rw rootfstype=jffs2 console=ttyS0,115200n8
rdinit=/sbin/init mem=64M) Default kernel command string
    kernel command line type (Use bootloader arguments if available)
--->
```

- Boot Options – root file system is based on UBIFS (NAND Flash)

If root file system is at NAND flash and use UBIFS file system, user needs to enable UBIFS file system (please refer to 5.3.4) and disable RAM file system function.

```
General setup --->
    [ ] Initial RAM filesystem and RAM disk (initramfs/initrd) support
```

The following is an example to boot up UBIFS root file system. A UBIFS root file system image (please refer to **Error! Reference source not found.**) needs to be done first and write it to the

mtd2 in Linux system

```
Boot options --->
    (noinitrd ubi.mtd=2 root=ubi0:system rw rootfstype=ubifs
console=ttyS0, 115200n8 rdinit=/sbin/init mem=64M) Default kernel command
string
    kernel command line type (Use bootloader arguments if available)
--->
```

- Boot Options – root file system is based NFS (Network File System)
At the development stage of Linux application, user often wants to modify testing application. This method can reduce some development time by mounting NFS roots.

```
Boot options --->
    (noinitrd root=/dev/nfs nfsroot=x.x.x.x:/path_to_nfs_rootfs
ip=y.y.y.y:z.z.z.z:g.g.g.g:m.m.m.m console=ttyS0,115200n8 rdinit=/sbin/init
mem=64M) Default kernel command string
```

x.x.x.x and z.z.z.z is the server ip, y.y.y.y is the client ip, g.g.g.g is the gateway ip and m.m.m.m is the net mask.
And user needs to enable network function (please refer to 5.3.2) and the following item additionally.

```
[*] Networking support --->
    Networking options --->
        [*] IP: kernel level autoconfiguration
```

Of course, NFS function must be enabled.

```
File systems --->
    [*] Network File Systems --->
        <*> NFS client support
    [*] Root file system on NFS
```

- Boot Options – Support device tree
To enable device tree support, please configure kernel as below.

```
[*] Flattened Device Tree support
[*] support for the traditional ATAGS boot data passing
```

- System clock source setting
NUC970/N9H30 supports using Timer 0/1 as system clock source or use ETIMER0/1 as system clock source..

```
System Type --->
    Nuvoton NUC970/N9H30 system clock selection (ETIMER as system clock
source)
```

While using ETIMER as system clock source, kernel can support high resolution timer and tickless idle.

```
General setup --->
    Timer subsystem --->
        Timer tick handling (Idle dynticks system (tickless idle))
        [*] High Resolution Timer Support
```

While using TIMER as system clock source, kernel only supports constant rate tick.

```
General setup --->
  Timer subsystem --->
    Timer tick handling (Periodic timer ticks (constant rate, no
dynticks))
```

5.3.2 Network

- TCP/IP

To enable basic network functions, please enable the following configurations.

```
[*] Networking support --->
  Networking options --->
    <*> Packet socket
    <*> Unix domain sockets
    [*] TCP/IP networking
    [*] IP: multicasting
```

- WiFi Wireless

If wireless device is used, user needs to enable the following functions additionally.

```
[*] Networking support --->
  [*] wireless --->
    <*> cfg80211 - wireless configuration API
    [*] cfg80211 wireless extensions compatibility
Device Drivers --->
  [*] Network device support --->
    [*] Network core driver support
    [*] wireless LAN --->
      <*> IEEE 802.11 for Host AP (Prism2/2.5/3 and
WEP/TKIP/CCMP)
```

5.3.3 Drivers

- Audio Interface

The following is I2S interface configuration:

```
Device Drivers --->
  <*> sound card support --->
    <*> Advanced Linux Sound Architecture --->
      <*> ALSA for SoC audio support --->
        <*> SoC Audio for NUC970/N9H30 series
        <*> NUC970/N9H30 I2S support for demo board
          I2S Mode Selection (Master Mode) --->
```

I2S supports master and slave mode, user can decide which mode is used by selecting in the configuration menu.

If I2S function is enabled, NAU8822 codec driver is also enabled automatically. In order to use I2S with audio codec function well, user needs to enable I2C function at the same time.

If audio application is wrote by old OSS architecture, user can enable the following two functions to do that. User can refer to the example in the BSP which source code is at BSP/applications/demos/alsa_audio.

```
Device Drivers --->
  <*> Sound card support --->
    <*> Advanced Linux Sound Architecture --->
      <*> OSS Mixer API
      <*> OSS PCM (digital audio) API
```

- DMA

DMA function is supported by NUC970/N9H30 series chip. In order to support it in kernel, user needs to enable “NUC970/N9H30 DMA support” in “DMA Engine support” menu page. User can learn DMA functions in kernel by referring to source which is at linux-3.10.x/drivers/dma/dmatest.c. A test client will be also enabled by enabling “DMA Test Client” function, it's a shortcut to understand the procedure of DMA in kernel.

```
Device Drivers --->
  [*]DMA Engine support --->
    <*> NUC970/N9H30 DMA support
    <*> DMA Test client
```

- User space memory management

If user wants to get a physical and virtual address of memory by enabling this user space memory management function.

```
Device Drivers --->
  Character devices --->
    [*] support for /dev/nuc970-mem
```

- Ethernet

NUC970/N9H30 series support two Ethernet ports. They can be enabled simulataniously. To support network port, PHY driver also needs to be enabled additionally.

The PHY chip on the development board is provided by ICPlus, the configuration will need to be modified if different PHY is used.

NUC970/N9H30 Ethernet ports support Wake on Lan (WoL) feature using Magic Packet by configure with ethtool tool. The Magic Packet complies with the format defined in AMD's Magic Packet Technology white paper. For the usage of ethtool, please refer to section 6.1.

```
Device Drivers --->
  [*] Network device support --->
    <*>Dummy net driver support
    [*] Ethernet driver support --->
      <*> Nuvoton NUC970/N9H30 Ethernet MAC 0
      <*> Nuvoton NUC970/N9H30 Ethernet MAC 1
    -*- PHY Device support and infrastructure --->
      <*> Drivers for ICPlus PHYS
```

- EBI

EBI function is supported by NUC970/N9H30 series chip. In order to support it in kernel, user needs to enable "NUC970/N9H30 EBI driver" in "Misc devices" menu page..

```
Device Drivers --->
  Misc devices --->
    <*> NUC970/N9H30 EBI driver
```

- Etimer

NUC970/N9H30 supports four enhanced timers which can output 50% duty cycle or capture function. Four channel of Etimer can be controlled individually.

The following is an example which Etimer channel 0 and channel 1 are as output by general purpose pin PC.6 and PC.8. And channel 2 and channel 3 are as capture pins by PC.11 and PC.13.

If the channel is unused, select the function to "No output" or "No input".

Enable "NUC970/N9H30 Enhance Timer (ETIMER) wake-up support" to support Etimer wake-up function.

```
Device Drivers --->
  Misc devices --->
    <*> NUC970/N9H30 Enhance Timer (ETIMER) support
    <*> NUC970/N9H30 Enhance Timer (ETIMER) wake-up support
    NUC970/N9H30 ETIMER channel 0 toggle output pin (Output to
PC6) --->
    NUC970/N9H30 ETIMER channel 0 capture input pin (No input)
--->
    NUC970/N9H30 ETIMER channel 1 toggle output pin (Output to
PC8) --->
    NUC970/N9H30 ETIMER channel 1 capture input pin (No input)
--->
    NUC970/N9H30 ETIMER channel 2 toggle output pin (No output)
--->
    NUC970/N9H30 ETIMER channel 2 capture input pin (Input from
PC11) --->
    NUC970/N9H30 ETIMER channel 3 toggle output pin (No output)
--->
    NUC970/N9H30 ETIMER channel 3 capture input pin (Input from
PC13) --->
```

Application can control etimer function by ioctl() function. The driver supports etimer wake-up function, periodic, toggle out, tiger counting mode and free counting mode functions now.

The wake-up function use etimer to wake up system from Power-down mode periodically. The value captured by ETIMER at capture mode (trigger counting mode) can be read back by using read() function. The unit of value is us, it stands for time interval between two triggers. Free counting mode can measure the external pin input frequency, the unit of value is Hz. User can refer to example code in the BSP (source code path is at BSP/applications/demos/etimer) to develop the related application.

- Smartcard

NUC970/N9H30 series has two smartcard interfaces that comply with ISO-7816 and EMV 2000 specification. If the system needs to access smartcard, please refer to the kernel configuration below to enable smartcard driver. This driver supports both T = 0 and T = 1 protocols. The card

detection level and power-on level, which is depend on the on board circuit and card slot design can be configured individually. Besides, ether Port I or Port G can be selected for smartcard interface 0. When enable Perform EMV check checkbox, the driver will perform a more strict protocol check comply with EMV 2000, so some smartcards will be reported as faliuare cards.

```
Device Drivers --->
  Misc devices --->
    <*> NUC970/N9H30 Smartcard Interface support
    [ ] Perform EMV check
    [*] NUC970/N9H30 SC0 support
        NUC970/N9H30 SC0 pin selection (Use port I) --->
        NUC970/N9H30 SC0 CD pin config (CD high as card insert)
    --->
    [ ] Inverse SC0 power pin level
    [*] NUC970/N9H30 SC1 support
        NUC970/N9H30 SC1 CD pin config (CD high as card insert)
    --->
    [ ] Inverse SC1 power pin level
```

User applications can control smartcard using ioctl() function call. Below listed the commands support by smartcard driver and their purpose. User can refer to example code in the BSP (source code path is at BSP/applications/demos/sc) for the usage of these commands.

SC_IOC_GETSTATUS: Check slot staus, for example card inserted or removed..

SC_IOC_ACTIVATE: Activate smartcard, report ATR length if success.

SC_IOC_READATR: Read the ATR (Answer to reset) of activated smartcard.

SC_IOC_DEACTIVATE: Deactivate smartcard.

SC_IOC_TRANSACT: Send ADPU command and read response through sc_transact structure.

Please note that before enter power-down mode, all inserted cards will be deactivate. User application needs to activate the cards in order to do transaction.

● GPIO

In order to support GPIO function controlled by kernel, please enable "NUC970/N9H30 GPIO support" and "/sys/class/gpio/..."function.

```
Device Drivers --->
  [*] GPIO Support --->
    [*] /sys/class/gpio/... (sysfs interface)
    <*> NUC970/N9H30 GPIO support
    <*> NUC970/N9H30 external I/O wake-up support
```

The number of each GPIO pin will be described at the following.

Driver will keep 32 numbers for each group of GPIO from port A to port J. So the number for the GPIOA will be 0x000~0x01F, GPIOB will be 0x020~0x03F, GPIOC will be 0x040~0x05F, GPIOD will be 0x060~0x07F, GPIOE will be 0x080~0x09F, GPIOF will be 0x0A0~0x0BF, GPIOG will be 0x0C0~0x0DF, GPIOH will be 0x0E0~0x0FF, GPIOI will be 0x100~0x11F and GPIOJ will be 0x120~0x13F.

Application can control each GPIO port by using sysfs. The following is the description of GPIO action based on sysfs interface.

- /sys/class/gpio/export : which GPIO pin will be exported
- /sys/class/gpio/unexport: which GPIO pin will be un-exported
- /sys/class/gpio/gpio0/direction : set GPIOA0 direction to in or output

- /sys/class/gpio/gpio0/value : set or read the value to/from GPIOA0

The following is an example to let GPIOA0 output high:

```
$ echo 0 > /sys/class/gpio/export
$ echo out > /sys/class/gpio/gpio0/direction
$ echo 1 > /sys/class/gpio/gpio0/value
```

User also can refer to the example which source code is at BSP/applications/demos/gpio.

The driver can also control GPIO pin by the following steps.

- Add #include <linux/gpio.h> in the target driver.
- Decide which GPIO pin will be use according to the definition in the arch/arm/mach-nuc970/include/mach/gpio.h.

Take NUC970_PC7 GPIO pin as example.

Set to input mode	gpio_direction_input(NUC970_PC7);
Set to output mode and value	gpio_direction_output(NUC970_PC7,1);
Set to output high	gpio_set_value(NUC970_PC7, 1);
Set to output low	gpio_set_value(NUC970_PC7, 0);
Read the value	gpio_get_value(NUC970_PC7);
Check if GPIO is in use	gpio_request(NUC970_PC7, "NUC970_PC7");
Get the GPIO interrupt number:	gpio_to_irq(NUC970_PC7);

Example:

```
static irqreturn_t PC7IntHandler(int irq, void *dev_id)
{
    printk(KERN_INFO "PC7IntHandler:irq=%d \n",irq);
    return IRQ_HANDLED;
}

int xxx_init(void)
{
    int ret,irqno;
    ret = gpio_request(NUC970_PC7, "NUC970_PC7");
    if (ret) printk("NUC970_PC7 failed ret=%d\n",ret);
    irqno=gpio_to_irq(NUC970_PC7);
    request_irq(irqno, PC7IntHandler,
                IRQF_TRIGGER_RISING | IRQF_TRIGGER_FALLING,
                "NUC970_PC7",
                NULL);
}
```

- Use GPIO to wakeup system

User can use GPIO to wakeup system. Please enable "NUC970/N9H30 external I/O wake-up support" to do that. User can modify EINT0, EINT1, EINT2, EINT3, EINT4, EINT5, EINT6 and EINT7 on "linux-3.10.x/drivers/gpio/gpio-nuc970.c". Find discription of EINT0 as below

```
/*
 * @brief      External Interrupt 0 Handler
 * @details    This function will be used by EINT0,
 *             when enable IRQ_EXT0_H0 or IRQ_EXT0_F11 in eint0
```

```

*/
/*
static irqreturn_t nuc970_eint0_interrupt(int irq, void *dev_id){
    printk("@0\n");
    return IRQ_HANDLED;
}
*/

/* If enable IRQ_EXT0_H0 or IRQ_EXT0_F11 , linux will enable EINT0
 * User can modify trigger tiypes as below :
 * IRQF_TRIGGER_FALLING / IRQF_TRIGGER_RISING / IRQF_TRIGGER_HIGH /
IRQF_TRIGGER_LOW
 */
struct nuc970_eint_pins eint0[]={
//{IRQ_EXT0_H0, nuc970_eint0_interrupt,IRQF_TRIGGER_FALLING |
IRQF_TRIGGER_RISING,"eint0"},
//{IRQ_EXT0_F11,nuc970_eint0_interrupt,IRQF_TRIGGER_FALLING |
IRQF_TRIGGER_RISING,"eint0"},
{0,0,0,0}
};

```

User can enable nuc970_eintX_interrupt, X=0~7, and set structure of strucnuc970_eint_pins of eintX, X=0~7.

Example, if you want to use PH0 of EINT0 to wakeup and set trigger of PH0 to rising and falling trigger. You can set as bellow.

```

static irqreturn_t nuc970_eint0_interrupt(int irq, void *dev_id){
    printk("@0\n");
    return IRQ_HANDLED;
}

struct nuc970_eint_pins eint0[]={
{IRQ_EXT0_H0, nuc970_eint0_interrupt,IRQF_TRIGGER_FALLING |
IRQF_TRIGGER_RISING,"eint0"},
{0,0,0,0}
};

```

- Use GPIO to simulate I²C interface

User can use GPIO to simulate I2C function. Please enable the following function to do that.

```

Device Drivers  --->
<*> I2C support  --->
I2C Hardware Bus support  --->
<* > GPIO-based bitbanging I2C

```

User can select I2C pin by modifying i2c_gpio_adapter_data structure in arch/arm/mach-nuc970/dev.c. For example, .sda_pin = NUC970_PG1, .scl_pin = NUC970_PG0 will use PG0 as SCL pin and PG1 will be SDA pin.

- I²C

The configuration of I²C is list as following:

```
Device Drivers --->
  <*> I2C support --->
    I2C Hardware Bus support --->
      <*> NUC970/N9H30 I2C Driver for Port 0
      <*> NUC970/N9H30 I2C Driver for Port 1
      NUC970 I2C1 pin selection (Port G) --->
```

There are many groups can be select for I2C port 1, like GPIO port-B, port-G, port-H or port-I. If I2C function support is selected in kernel configuration, kernel will use build in I2C interface of NUC970/N9H30 to communicate with other device.

The BSP builds in five I2C port 0 client devices. There are OV7725, OV5640, NT99050, NT99141 and NAU8822 by default. User can modify those devices to I2C port1 by modifying nuc970_i2c_client1 structure in arch/arm/mach-nuc970/dev.c.

- LCD

To enable LCD function support, please enable the following function in kernel configurations.

```
Device Drivers --->
  Graphics support --->
    <*> Support for frame buffer devices --->
      [*] NUC970/N9H30 LCD framebuffer support
      NUC970/N9H30 LCD panel selection (800x480 5-Inch
Color TFT LCD) --->
      LCD source format (RGB888 support) --->
      Console display driver support --->
      <*> Framebuffer Console support
```

There is a LCD display screen in on development board which resolution is 800x480 and use 24-bit data bus connected with NUC970/N9H30 LCD interface. So the color of this display screen is RGB888(24-bit). Color depth can be adjusted according to user space application.

To display Linux content on the LCD screen, please enable the following functions.

```
[*] Bootup logo --->
[*] Standard 16-color Linux logo
[*] Standard 224-color Linux logo
```

There is an example demonstrated the operations of frame buffer which source code is at BSP/applications/demos/lcm directory.

- 2D Graphic Engine

NUC970/N9H30 supports 2D graphic drawing function like line, rectangle, rotation, scale up/down and BitBlt.

```
Device Drivers --->
  Misc devices --->
    <*> NUC970/N9H30 2D support
```

- MTD NAND flash

To enable NAND flash function, user needs to enable the following function in kernel configuration. There are two groups of pin can be selected when using NAND flash interface. There are GPIO port C and port I, it depends on the connection of hardware on board.

```
Device Drivers --->
  Generic Driver Options --->
    <*> Nuvoton NUC970/N9H30 FMI function selection
      Select FMI device to support (Support MTD NAND Flash) --->
  -*- Memory Technology Device (MTD) support --->
    <*> Command line partition table parsing
    <*> Caching block device access to MTD devices
  -*- NAND Device Support --->
    -*- Nuvoton NUC970/N9H30 MTD NAND --->
      NUC970/N9H30 NAND Flash pin selection (Port C) --->
```

It's necessary to enable "Command line partition table parsing" function when the basic configuration of flash driver is passed from U-Boot.

The default configuration of flash driver will partition MTD into three blocks, there are /dev/mtdblock0, /dev/mtdblock1, /dev/mtdblock2 when system boots up.

The first block is the space for the U-Boot, second one is for the kernel and the last one is for mounting YAFFS2 or UBIFS.

If user wants to modify the block size or increase or decrease number of partition, please modify uboot/include/nuc970_evb.h or drivers/mtd/nand/nuc970_nand.c.

● PWM

To enable PWM function, user needs to enable the following functions. The PWM pin maybe needs to change according to hardware connection.

"No output" is stand for those unused PWM channels.

```
Device Drivers --->
  [*] Pulse-width Modulation (PWM) Support --->
    <*> NUC970/N9H30 PWM support
      NUC970/N9H30 PWM channel 0 output pin (Output from PB2) ---
>
      NUC970/N9H30 PWM channel 1 output pin (Output from PB3) ---
>
      NUC970/N9H30 PWM channel 2 output pin (No output) --->
      NUC970/N9H30 PWM channel 3 output pin (No output) --->
```

This section will descript PWM control method by using sysfs. After system boots up, there are four PWM (pwmchip0~3) in /sys/class/pwm directory. Each group stands for one PWM channel. Before using it, enter target PWM directory and execute "echo 0 > export" command to enable this PWM channel. If enable success, there is a pwm0 directory will be created and user can control this PWM channel.

There are some files in the new created directory, their meaning is list as the following table.

File Name	Purpose
period	Control cycle, which the unit is ns. The shortest time supported by the driver is us. Example (control cycle is 20us) \$ echo 20000 > period
duty_cycle	Set duty cycle of PWM, which the unit is ns. The shortest time

	supported by the driver is us. Example (duty cycle is 15us) \$ echo 15000 > duty_cycle
polarity	Set polarity, it can be normal or inverse output. Example: Normal output: \$ echo normal > polarity Inverse output:\$ echo inversed > polarity
enable	Enable or disable function. Example: Enable function: \$echo 1 > enable Disable function: \$echo 0 > enable

The following is a PWM0 example which control cycle is 300us and duty cycle is 33%.

```
$ cd sys/class/pwm
$ ls
pwmchip0  pwmchip1  pwmchip2  pwmchip3
$ cd pwmchip0
$ ls
device      export      npwm      power      subsystem  uevent      unexport
$ echo 0 > export
$ ls
device      npwm      pwm0      uevent
export      power      subsystem  unexport
$ cd pwm0/
$ ls
duty_cycle  enable      period      polarity    power      uevent
$ echo 1 > enable
$ echo 300000 > period
$ echo 100000 > duty_cycle
```

- Ralink RT3070 802.11 WiFi

To support RT3070 USB WiFi module, user needs to enable wireless network function, USB host, loadable module support and the following function.

Generic Driver Options -->

[*] Contiguous Memory Allocator

And add the additional command in boot command.

coherent_pool=2M

The RT3070 driver source code is in BSP/applications/DPO_RT3070_LinuxSTA_V2.3.0.2_20100412 directory. The output after compiling is kernel module and can be loaded dynamically. Before compiling the source code, user needs to modify Makefile like the following in the source file directory.

```
ifeq ($(PLATFORM),SMDK)
LINUX_SRC = /home/bhushan/itcenter/may28/linux-2.6-samsung
CROSS_COMPILE = /usr/local/arm/4.2.2-eabi/usr/bin/arm-linux-
endif
```

```

ifeq ($(PLATFORM),NUC900)
LINUX_SRC = /home/andy/hdb/linux_kernel/linux-2.6.35.y
CROSS_COMPILE = arm-linux-
endif

ifeq ($(PLATFORM),NUC970)
LINUX_SRC = /PATH_TO_LINUX_KERNEL/linux-3.10.x
CROSS_COMPILE = arm-linux-
endif

```

After compiling, module driver (rt39070sta.ko) will be output. To use this driver, RT2870STA.dat file will also need to copy to root file system etc/Wireless/RT2870STA directory.

```

$ ls
chips                Makefile            rt3070sta.ko
common              os                  sta
include             README_STA_usb      sta_ate_iwpriv_usage.txt
iwpriv_usage.txt     RT2870STACard.dat  tools
LICENSE_ralink-firmware.txt RT2870STA.dat

```

The usage of this driver is described as following,

1. Load driver module by using insmod command.

```
$ insmod rt3070.ko
```

2. Enable wireless interface

```
$ ifconfig ra0 up
```

3. Connect to wireless AP by using wireless utility included in BSP.
4. Use WEP method to connect

```

$ iwconfig ra0 essid "name of AP"
$ iwconfig ra0 key open
$ iwconfig ra0 key "secret key"

```

5. Use WPA-PSK method to connect

```

$ iwpriv ra0 set NetworkType=Infra
$ iwpriv ra0 set AuthMode=WPA2PSK
$ iwpriv ra0 set EncrypType=TKIP
$ iwpriv ra0 set WPA2PSK="secret key"
$ iwpriv ra0 set SSID="name of AP"

```

6. Use WPA2-PSK method to connect

```

$ iwpriv ra0 set NetworkType=Infra
$ iwpriv ra0 set AuthMode=WPA2PSK
$ iwpriv ra0 set EncrypType=AES

```

```
$ iwpriv ra0 set WPAPSK="secret key"
$ iwpriv ra0 set SSID="name of AP"
```

After successful connection with wireless AP, user can set static IP or use following command to get IP from DHCP server.

```
$ udhcpc -i ra0
```

- Realtek RTL8188 802.11 WiFi
To support RTL8188 USB WiFi module, user needs to enable wireless network function, USB host, loadable module support and the following function.

```
[*] Networking support --->
*- wireless --->
<*> Nuvoton external WiFi driver support
```

The usage of this driver is described as following,

1. Load driver module by using insmod command.

```
$ insmod rtl8188eu.ko
```

2. Enable wireless interface

```
$ ifconfig lo up
$ ifconfig wlan0 up
```

3. Use wpa_supplicant utility to connect with wireless AP

```
$ ./wpa_supplicant -Dwext -i wlan0 -c <config file> -B
```

Wpa_supplicant needs configuration file, the following are examples of configuration file for it.

```
network={
    ssid="TESTTEST"
    proto=WPA
    key_mgmt=WPA-PSK
    pairwise=CCMP
    psk="ZZZZZZZZ"
}
```

NOTE: Nuvoton cannot provide RTL8188 driver source code.

- Realtek RTL8192 802.11 WiFi
To support RTL8192 SDIO WiFi module, user needs to enable wireless network function, SDIO host, loadable module support and the following function.

```
[*] Networking support --->
*- wireless --->
<*> Nuvoton external WiFi driver support
```

The usage of this driver is described as following,

4. Load driver module by using insmod command.

```
$ insmod 8192es.ko
```

5. Enable wireless interface

```
$ ifconfig wlan0 up
```


6. Use wpa_supplicant utility to connect with wireless AP

```
$ ./wpa_supplicant -Dwext -i wlan0 -c <config file> -B
```

Wpa_supplicant needs configuration file, the following are examples of configuration file for it.

```
network={
    ssid="TESTTEST"
    proto=WPA
    key_mgmt=WPA-PSK
    pairwise=CCMP
    psk="ZZZZZZZZ"
}
```

NOTE: Nuvoton cannot provide RTL8192 driver source code.

- RS232, RS485, IrDA

NUC970/N9H30 series support 11 serial ports which can be configured individually. Please follow the instruction below to enable serial port function.

User can enable or disable each port on configuration page. Most of the ports have various GPIO pins can be selected except UART0, UART3 and UART5.

User can enable or disable wake-up function on configuration page except UART0, UART3 and UART5, UART7, UART9.

The UART0 is kept for console and user doesn't need to configure it.

```
Device Drivers --->
  Character devices --->
    Serial drivers --->
      [*] NUC970/N9H30 serial support
      [*] NUC970/N9H30 UART1 support
      [*] Enable UART1 CTS wake-up function
      NUC970/N9H30 UART1 pin selection (Tx:PE2, Rx:PE3)
---->
      [*] NUC970/N9H30 UART2 support
      [*] Enable UART2 CTS wake-up function
      NUC970/N9H30 UART2 pin selection (Tx:PF11, Rx:PF12)
---->
      [*] NUC970/N9H30 UART3 support
      [*] NUC970/N9H30 UART4 support
      [*] Enable UART4 CTS wake-up function
      NUC970/N9H30 UART4 pin selection (Tx:PC10, Rx:PC11)
---->
      [*] NUC970/N9H30 UART5 support
      [*] NUC970/N9H30 UART6 support
      [*] Enable UART6 CTS wake-up function
      NUC970/N9H30 UART6 pin selection (Tx:PB2, Rx:PB3)
---->
      [*] NUC970/N9H30 UART7 support
      NUC970/N9H30 UART7 pin selection (Tx:PG4, Rx:PG5)
---->
```

```

[*] NUC970/N9H30 UART8 support
[*] Enable UART8 CTS wake-up function
    NUC970/N9H30 UART8 pin selection (Tx:PE10, Rx:PE11)
---->

[*] NUC970/N9H30 UART9 support
    NUC970/N9H30 UART9 pin selection (Tx:PH2, Rx:PH3)
---->

[*] NUC970/N9H30 UART10 support
[*] Enable UART10 CTS wake-up function
    NUC970/N9H30 UART10 pin selection (Tx:PB10,
Rx:PB11) ---->
[*] Console on NUC970/N9H30 serial port

```

If serial port is configured as IrDA function, user needs to enable serial port function and IrDA function additionally like the following items.

```

[*] Networking support ---->
    <*> IrDA (infrared) subsystem support ---->
        Infrared-port device drivers ---->
            <*> NUC970/N9H30 SIR on UART

```

- SD Card

To enable SD interface, user needs to enable the following functions. NUC970/N9H30 series support two SD card interface. If SD1 is used, user needs to select which GPIO pins to be used. The GPIO pins can be Port E, Port H or Port I.

```

Device Drivers ---->
    <*>MMC/SD/SDIO card support ---->
        <*> MMC block device driver
        <*> Use bounce buffer for simple hosts
        <*> Nuvoton NUC970/N9H30 SD Card support
        <*> SD0 support
        <*> SD1 support
            NUC970/N9H30 SD1 pin selection (Port E) ---->

```

After system booting, if any card is detected the device mmcblk0 will be create in /dev directory. If more than one partition are created in the card, the device will be created sequentially, like mmcblk0, mmcblk1 and so on

- SPI

NUC970/N9H30 series support two SPI interfaces. They can be enabled individually or not. The following is description for configuring two SPI interfaces.

```

Device Drivers ---->
    [*] SPI support ---->
        <*> Nuvoton NUC970/N9H30 Series SPI Port 0
            SPI0 pin selection (Normal mode) ---->
        <*> SPI0 enable pin for the second chip select

```

```

        Pin selection (Use SS1 (PB0))  --->
    <*>  Nuvoton NUC970/N9H30 Series SPI Port 1
        SPI1 transfer mode selection (Normal mode)  --->
        SPI1 IO port selection (Port B)  --->
    < >  SPI1 enable pin for the second chip select

```

There are normal (4-pin) or quad (6-pin) mode or additional second chip select pin (SS1) can be selected for the SPI0.

In SPI1, there also normal or quad mode or additional second chip select pin (SS1) can be selected.

If pins are selected from port B in SPI1 and SS1 will be PB.1.

If pins are selected from port I in SPI1 and SS1 will be PH13.

If SPI flash device is also used, user needs to enable MTD function like the following items.

```

Device Drivers  --->
    <*>  Memory Technology Device (MTD) support  --->
        <*>  Caching block device access to MTD devices
        Self-contained MTD device drivers  --->
            <*>  Support most SPI Flash chips (AT26DF, M25P, W25X, ...)

```

User also needs to enable JFFS2 file system functions in order to use SPI flash device correctly. The configuration of JFFS2 is described in the file system section. User can refer to it for more detail.

If user wants to use new SPI flash device which is not included in BSP, it's necessary to modify id table in driver and it can be identified by kernel correctly.

Please modify the m25p_ids structure in drivers/mtd/devices/m25p80.c file.

```

static const struct spi_device_id m25p_ids[] = {
/* Atmel -- some are (confusingly) marketed as "DataFlash" */
{ "at25fs010", INFO(0x1f6601, 0, 32 * 1024, 4, SECT_4K) },
{ "at25fs040", INFO(0x1f6604, 0, 64 * 1024, 8, SECT_4K) },
...
{ "en25qh16", INFO(0x1c7015, 0, 64 * 1024, 32, 0) },
...
{ "cat25128", CAT25_INFO(2048, 8, 64, 2) },
    { },
};

```

And nuc970_spi_flash_data structure also needs to be modified for the same purpose.

The string (name) at type argument must be the same with the first argument of m25p_ids structure otherwise system can't recognize it correctly.

```

static struct flash_platform_data nuc970_spi_flash_data = {
    .name = "m25p80",
    .parts = nuc970_spi_flash_partitions,
    .nr_parts = ARRAY_SIZE(nuc970_spi_flash_partitions),

```

```
.type = "en25qh16",
};
```

If user wants to modify partition number of SPI flash, nuc970_spi_flash_partitions structure in arch/arm/mach-nuc970/dev.c file also needs to be modified.

```
static struct mtd_partition nuc970_spi_flash_partitions[] = {
{
    .name = "SPI flash",
    .size = 0x0200000,
    offset = 0,
},
};
```

- USB Host

To enable USB Host function, please check "USB support" in "Device Drivers" menu. NUC970/N9H30 USB Host equips with EHCI (USB 2.0) and OHCI (USB1.1) Host controllers. All of the following items must be checked to enable both Host controllers.

```
Device Drivers --->
[*] USB support --->
    <*> Support for Host-side USB
    <*> EHCI HCD (USB 2.0) support
    <*> NUC970/N9H30 EHCI (USB 2.0) support
    NUC970/N9H30 USB Host port power pin select (No USBH_PPWRx and
    USBH_OVRCUR) ---->
    [*] NUC970/N9H30 turn off usb Hots VBUS power while power
    down
    <*> OHCI HCD support
    [*] NUC970/N9H30 OHCI (USB 1.1) support
```

According to target NUC970/N9H30 chip's pin configuration, select the corresponding multi-function pin setting.

```
[ ] PE.14 and PE.15 for USBH_PPWR0/1, PH.1 for USBH_OVRCUR
[ ] PF.10, PH.1 for USBH_OVRCUR
[ ] No USBH_PPWRx, PH.1 for USBH_OVRCUR
[X] No USBH_PPWRx and USBH_OVRCUR
```

If target board's USB port power is controlled by a Power Switch Controller, NUC970/N9H30 must have USBH_PPWRx and USBH_OVRCUR pins to communicate with it. Depend on the target NUC970/N9H30 chip's pin configuration, USB Host port0 and port1 power can be controlled by PE.14 and PE.15 respectively; or both be controlled by PF.10. PH.1 is dedicated assigned to USBH_OVRCUR for over-current detection.

If VBUS of USB Host ports are connected to +5V directly, USBH_PPWRx pins are not required any more. In this condition, USBH_PPWRx can be configured as GPIO pins and user must select "No USBH_PPWRx" items from this menu.

User can also select the last item "No USBH_PPWRx and USBH_OVRCUR" to release USBH_PPWRx and USBH_OVRCUR pins. In this condition, user can obtain 2 or 3 free GPIO

pins, but take the risk of being unaware of over-current dangerous.

NUC970/N9H30 USB Host driver power down function supports option to turn off VBUS while power down.

[*] NUC970/N9H30 turn off usb Hots VBUS power while power down

If this option was not enabled, NUC970/N9H30 USB Host will turn off USB PHY power while power down. USB bus was suspended. The VBUS power will be kept. USB devices can still consume power from NUC970/N9H30. NUC970/N9H30 USB Host can resume USB devices when kernel was waked up.

If this option was selected, NUC970/N9H30 USB Host will turn off both USB PHY power and VBUS power. In this case, all USB devices were disconnected while power down. On kernel waked up, NUC970/N9H30 USB Host turns on the VBUS power again and USB devices will be re-enumerated.

- USB mass storage class device support

Besides selecting NUC970/N9H30 USB Host controller driver, user may have to select supporting device classes. For example, if user want to support mass storage device, it's necessary to enable "SCSI device support" first. After enabled SCSI device support, "USB Mass Storage Support" option will be present in "USB support" menu. Select it to enable Mass Storage Device supporting.

```
Device Drivers --->
  SCSI device support --->
    <*> SCSI device support
    <*> legacy / proc/scsi/ support
    <*> SCSI disk support
    <*> SCSI media changer support
    [*] Asynchronous SCSI scanning
    [*] SCSI low-level drivers
  [*] USB support --->
    <*> USB Mass Storage Support
```

- USB video class device support

To support USB video class (UVC), the following "Media Support" options must be enabled. To show received images from camera onto LCD panel, frame buffer support must be enabled.

```
Device Drivers --->
  Multimedia support --->
    <*> Cameras/video grabbers support
    <*> Media Controller API
    <*> V4L2 sub-device userspace API
    <*> V4L2 int device
    <*> Media USB Apapters --->
      <*> USB video Class (UVC)
      [*] UVC input events device support
    <*> V4L platform device
  Graphics support --->
    <*> Support for frame buffer devices --->
```

[*] NUC970/N9H30 LCD framebuffer support

- USB host and HID device

To support HID class devices, such as USB mouse and USB keyboard, except to enable USB Host function, user must also enable “HID bus support” and “Input device support”. As the following:

```
Device Drivers --->
  HID support --->
    HID bus support --->
      <*> User-space I/O driver support for HID subsystem
      <*> Generic HID driver
    USB HID support --->
      <*> USB HID transport layer
  Input device support --->
    <*> Mouse interface
    [*] Provide legacy /dev/psaux device
    <*> Event interface
    [*] Keyboards --->
      <*> AT keyboard
    [*] Mice --->
      <*> PS/2 mouse
```

- USB Device

```
Device Drivers --->
  [*] USB support --->
    <*> USB Gadget Support --->
      USB Peripheral Controller --->
        <*> NUC970/N9H30 USB Device Controller
      <M> USB Gadget Driver
      <M> Mass Storage Gadget
```

After compiling kernel, three driver module files will be outputted. (fs/configfs/configfs.ko, drivers/usb/gadget/libcomposite.ko and drivers/usb/gadget/g_mass_storage.ko)

User needs to copy those file to rootfs or somewhere they can be accessed by system. (Like USB mass storage device)

The following is an example by using USB mass storage gadget function.

```
$ insmod configfs.ko
$ insmod libcomposite.ko
$ insmod g_mass_storage.ko file=/dev/mmcb1k0p1 stall=0 removable=1
```

- Video Capture

To support video capture function, user needs to enable “Cameras/video grabbers support” item first and enable “NUC970/N9H30 Video-in support” in “Encoders, decoders, sensors and other helper chips” item. Finally, user can select model of video capture device. BSP supports OV7725,

OV5640, NT99050 and NT99141 drivers now.

```
Device Drivers --->
  <*> I2C support --->
    I2C Hardware Bus support --->
      <*> GPIO-based bitbanging I2C
  [*] Multimedia support --->
    [*] Camera/video grabbers support
    [*] Media Controller API
    [*] V4L2 sub-device userspace API
    [*] V4L platform devices --->
      Encoders, decoders, sensors and other helper chips --->
        <*> Nuvoton NUC970/N9H30 video-In Support
        (3) Max frame buffer
        (24000000) video frequency
        Nuvoton NUC970/N9H30 Image Sensor Selection (NT99141)
  --->
```

If I2C interface is used by video capture device to configure arguments, I2C function also needs to be enabled first. User can refer to I2C section to do that.

The V4L2 API is supported by video capture driver in BSP and user can refer to the example in BSP/applications/demos/cap directory. Introduction API in cap sample code as below:

```
xioctl(fd, VIDIOC_S_FMT, &fmt) : Set Image Height, width and format
xioctl(fd, VIDIOC_DQBUF, &buf) : Get Image
xioctl(fd, VIDIOC_QBUF, &buf) : Release Image
xioctl(fd, VIDIOC_STREAMON, &type) : Start CAP
xioctl(fd, VIDIOC_STREAMOFF, &type) : Stop CAP
```

- Watchdog Timer

To support watchdog timer function, please enable the following items.

Timeout period in default is 2.03 seconds and this time can be modified via ioctl() command function (WDIOC_SETTIMEOUT) by application program.

There are three different time cycles can be supported by watchdog driver. If command argument is smaller than 2 and the timeout period will be 0.53 second. If command argument is between 2 to 8 and timeout period will be 2.03 seconds. And if argument is larger than 8 and timeout period will be 8 seconds. There is an example in BSP/applications/demos/wdt directory for user to reference.

To support watchdog timer wake-up function, please enable “NUC970/N9H30 WDT wake-up support” item.

```
Device Drivers --->
  [*] watchdog Timer Support --->
    <*> Nuvoton NUC970/N9H30 watchdog Timer
    <*> NUC970/N9H30 WDT wake-up support
```

- Window Watchdog Timer

Please enable the following items to support window watchdog timer function.

```
Device Drivers --->
  [*] watchdog Timer Support --->
```


<*> Nuvoton NUC970/N9H30 window watchdog Timer

There are three major differences between window watchdog timer and watchdog timer. First, the configuration of window watchdog timer cannot be modified after enabling its function. Second, window watchdog timer only can be reset in specific time slot, but watchdog timer can be reset at any time if timeout doesn't occur. In application, user needs to use `WDIOC_GETTIMELEFT` ioctl() argument to get the available time to reset. If return value is 0 and application can use `WDIOC_KEEPAIVE` argument to let system reset otherwise system will be reset right now. And the third, window watchdog timer does not count while CPU is in idle and power-down mode. Linux kernel automatically put CPU into idle mode between each timer tick if the system is no busy. So the timeout period of window watchdog timer timeout period varies depending on the system loading. An example code is in `BSP/applications/demos/wwdt` for reference.

- Keypad

```
Device Drivers --->
  Input device support --->
    [*] keyboards --->
      <*> NUC970/N9H30 Matrix Keypad support
      <*> NUC970/N9H30 Keypad wake-up support
      NUC970/N9H30 matrix keypad pin selection (Keypad pins
are 4x8 matrix PA pin) --->
        ( ) Keypad pins are 4x2 matrix PA pin
        ( ) Keypad pins are 4x4 matrix PA pin
        (X) Keypad pins are 4x8 matrix PA pin
        ( ) Keypad pins are 4x2 matrix PH pin
        ( ) Keypad pins are 4x4 matrix PH pin
        ( ) Keypad pins are 4x8 matrix PH pin
```

The item "Keypad pins are 4x2 matrix PH pin" must be enabled when user uses the keypad on NUC970/N9H30 develop board. Set "NUC970/N9H30 Keypad wake-up support" can enable wake up function. When the chip is in power down mode, press any key the chip will wake up. An example code is in `BSP/applications/demos/keypad` for reference.

- RTC

User can enable or disable wake-up function on configuration page.

```
Device Drivers --->
  [*] Real Time Clock --->
    <*> NUC970/N9H30 RTC driver
    [*] Enable RTC wake-up function
```

- CAN

NUC970/N9H30 series support 2 CAN ports which can be configured individually. Please follow the instruction below to enable CAN port function.

User can enable or disable each port on configuration page. CAN0 port has various GPIO pins can be selected.

User can enable or disable wake-up function on configuration page

```
-*- Networking support --->
  <*> CAN bus subsystem support --->
```



```

--- CAN bus subsystem support
<*> CAN Gateway/Router (with netlink configuration)
    CAN Device Drivers --->
        <*> Platform CAN drivers with Netlink support
        [*] CAN bit-timing calculation
        <*> NUC970/N9H30 CAN0/CAN1 devices --->
            --- NUC970/N9H30 CAN0/CAN1 devices
            [*] NUC970/N9H30 CAN0 support
            [*] Enable CAN0 wake-up function
                NUC970/N9H30 CAN0 pin selection (Tx:PB11,
Rx:PB10) --->
                    (X) Tx:PB11, Rx:PB10
                    ( ) Tx:PH3, Rx:PH2
                    ( ) Tx:PI4, Rx:PI32
            [*] NUC970/N9H30 CAN1 support
            [*] Enable CAN0 wake-up function
                NUC970/N9H30 CAN1 pin selection (Tx:PH15,
Rx:PH14) --->
                    (X) Tx:PH15, Rx:PH14

```

An example code is in BSP/applications/demos/CAN for reference

- JPEG

Please enable the following items to support to support JPEG CODEC function.

```

Device Drivers --->
    <*> Multimedia support --->
        [*] Cameras/video grabbers support
        NUC970/N9H30 JPEG CODEC --->
            *** NUC970/N9H30 JPEG codec ***
            <*> NUC970/N9H30 JPEG codec support
                (0xC8000) Max Raw data size - w*h*byteperpixel(hex) +
                Max Bistream Size

```

- ADC Battery

Please enable "NUC970/N9H30 ADC battery driver" function in "Power supply class support" item to support ADC battery interface.

```

Device Drivers --->
    [*] Power supply class support --->
        <*> NUC970/N9H30 ADC battery driver --->

```

User can check battery current status in "sys/class/power_supply" directory after system boots up.

User can use "cat" command to read the current status like,

\$ cat voltage_now, → read the current battery voltage

\$ cat present. → read the battery capacity in percentage

```
# cd /sys/class/power_supply
# ls
NUC970 Battery(ADC)
# cd NUC970\ Battery\ (ADC\)
# ls
present          technology      uevent          voltage_now
subsystem        type           voltage_max_design
```

- ADC keypad/touch screen

Please enable the following items to support ADC keypad or touch screen function. If users want to support wakeup function, Please enable ADC keypad wakeup function or touch screens wakeup function.

```
Device Drivers --->
  [*] Input device support --->
    <*> Event interface
    <*> Input NUC970/N9H30 ADC --->
      <*> Keypad support
      <*> Keypad wake-up support
      <*> Touchscreen support
      <*> Touchscreen wake-up support
      (0) ADC Sample Counter
```

When use keypad function, user can adjust return value of each button or ADC threshold value by modifying `nuc970_keycode` or `nuc970_key_th` structure in `drivers/input/nuvoton/nuc970adc.c` driver.

The following is a brief description and example to configure those two structures.

If user wants to have 8 keys via ADC interface and name of them will be "KEY_A", "KEY_B"~ "KEY_H" in `nuc970_keycode` structure. Then try to get reasonable value of ADC range for each key in `nuc970_key_th` structure.

```
static int nuc970_keycode[] = {
    KEY_A,
    KEY_B,
    KEY_C,
    KEY_D,
    KEY_E,
    KEY_F,
    KEY_G,
    KEY_H,
};

static struct key_threshold nuc970_key_th[] = {
    {0x500, 0x5ff},
    {0x600, 0x6ff},
```

```
{0x700,0xaff},
{0xa00,0xb4f},
{0xb50,0xbff},
{0xc00,0xcff},
{0xd00,0xd49},
{0xd50,0xe00},
};
```

- IIO ADC
User can use normal mode ADC via IIO architecture, please refer the following configurations to enable it.

Device Drivers --->

<*> Industrial I/O support --->

- [*] Enable buffer support within IIO
- [*] Enable triggered sampling support

Analog to digital converters --->

<*> Nuvoton NUC970/N9H30 Normal ADC driver

Reference voltage selection (Internal bandgap, 2.5V) --->

There are three reference voltage selections can be chosen, they are internal bandgap 2.5V, internal AVDD 3.3V and VREF input.

Application can use the following command to get the result converted by ADC function.

```
$ cat /sys/bus/iio/devices/iio:device0/in_voltageX_raw
```

X stands for the channel of ADC (X=0~7).

- Touch screen calibration by using tslib utility
When use touchscreen function, user can adjust return Z_TH threshold value by "#define Z_TH" in drivers/input/nuvoton/nuc970adc.c driver. Z_TH can be to avoid pendown detection wrong. ADC Sample Counter can be to adjust touch screen sensitivity. TSLIB-1.1 source code is included in this BSP and can be found in applications/tslib-1.1 directory.
The usage of touch screen library tslib list as below.

1. Compile tslib-1.1
 - ./configure --prefix=\$(pwd)/install --enable-static --enable-shared --host=arm-linux
 - make
 - make install
2. Copy all of files in "install" directory to rootfs directory.
3. Modify rootfs/etc/profile and add the following commands.

```
export TSLIB_CONFFILE=/etc/ts.conf
export TSLIB_PLUGINDIR=/lib/ts
export TSLIB_TSDEVICE=/dev/input/event0
export TSLIB_CALIBFILE="/etc/pointercal"
export TSLIB_CONSOLEDEVICE="none"
```

4. Modify rootfs/etc/ts.conf file.

```
# Uncomment if you wish to use the linux input layer event interface
module_raw input
```

```

Uncomment if you're using a Sharp Zaurus SL-5500/SL-5000d
# module_raw collie

# Uncomment if you're using a Sharp Zaurus SL-C700/C750/C760/C860
# module_raw corgi

# Uncomment if you're using a device with a UCB1200/1300/1400 TS interface
# module_raw ucb1x00

Uncomment if you're using an HP iPaq h3600 or similar
# module_raw h3600

# Uncomment if you're using a Hitachi webpad
# module_raw mk712

# Uncomment if you're using a Hitachi webpad
# module_raw mk712

# Uncomment if you're using an IBM Arctic II
# module_raw arctic2

module pthres pmin=1
module variance delta=30
module dejitter delta=100
module linear

```

5. Please follow the instruction displayed on screen by using ts_calibrate calibration program. After that, can use ts_test to do the test. If result is poor for the test, user can run the calibration program again.

```


# ts_calibrate
xres = 800, yres = 480
Took 26 samples...
Top left : X = 3505 Y = 353
Took 24 samples...
Top right : X = 3421 Y = 3740
Took 37 samples...
Bot right : X = 546 Y = 3736
Took 27 samples...
Bot left : X = 585 Y = 342
Took 30 samples...
Center : X = 1993 Y = 2041

```

```
-20.572632 -0.000537 0.206449
508.422333 -0.131128 -0.002377
Calibration constants: -1348248 -35 13529 33319966 -8593 -155 65536
```

6. The following content will be shown on screen after executing ts_test program.

```
# ts_test
```



- SCUART

There are two smart card interfaces built in NUC970/N9H30 series. They have additional UART function to simulate as basic UART port when there is not enough UART to be used in system. In this mode, the SC_CLK pin will be used to as transmit function and SC_DATA will be receive function. Those two pins can be enabled individually and there are some pin selections at SCUART0 interface.

```
Device Drivers --->
  Character devices --->
    serial drivers --->
      [*] NUC970/N9H30 Smartcard UART mode support
      [*] NUC970/N9H30 SCUART0 support
      NUC970/N9H30 SCUART0 pin selection (Tx:PG11, Rx:PG12) -
-->
      [*] NUC970/N9H30 SCUART1 support
```

The device node for the SCUART is /dev/ttySCU0 or /dev/ttySCU1. The basic operation of SCUART is the same with normal UART but have a lot of limitations, for example, there are only four levels of FIFO and can't support flow control function, can't support RS485 and IrDA transmission mode. It is better to use normal UART only if they are all occupied by system.

- Loopback device

A loop device is a pseudo-device that makes a file accessible as a block device. Before use, a loop device must be connected to an existing file in the file system. Please enable the following items to support loopback device.

```
Device Drivers --->
  Block devices --->
```

<*> Loopback device support

The usage of loopback device lists as the following steps.

1. Create image file for mounting on loopback device.

```
$ dd if=/dev/zero bs=1M count=1 of=fat.img
```

2. Format image (take FATFS for example)

```
$ busybox mkfs.vfat fat.img
```

3. Mount image

```
$ mount -o loop fat.img /mnt/loop
```

5.3.4 File System

- FAT

FAT is common file system and can be seen usually on SD card or USB mass storage device. User can enable the following items to support it.

```
File systems --->
  DOS/FAT/NT Filesystems --->
    <*> MSDOS fs support
    <*> VFAT (windows-95) fs support
    (437) Default codepage for FAT
    (iso8859-1) Default iocharset for FAT
```

Command for mounting the first partition on SD card is list as following.

```
$ mount -t vfat /dev/mmcb1k0p1 /mnt
```

- JFFS2

JFFS2 is one of the file system used on NAND flash. Please enable the following items to support it.

```
File systems --->
  [*] Miscellaneous filesystems --->
    <*> Journalling Flash File System v2 (JFFS2) support
    [*] JFFS2 write-buffering support
```

- ROMFS

ROMFS is one of the file system used on root file system. Please enable the following items to support it.

```
File systems --->
  [*] Miscellaneous filesystems --->
    <*> ROM file system support
    RomFS backing stores (Block device-backed ROM file system support) --->
```

- YAFFS2

YAFFS2 is one of the file system used on NAND flash. Before enabling the following items, user needs to enable MTD item "Caching block device access to MTD devices Device drivers" first.

```
File systems --->
[*] Miscellaneous filesystems --->
    <*> yaffs2 file system support
    <*> Autoselect yaffs2 format
    <*> Enable yaffs2 xattr support
```

Command for mounting YAFFS2 is list as following.

```
$ mount -t yaffs2 -o"inband-tags" /dev/mtdblock2 /flash
```

- **exFAT**
exFAT is a new generation file system created by Microsoft. It is more flexible about size of single file and total capacity of device.

```
File systems --->
DOS/FAT/NT Filesystems --->
    <*> exFAT fs support
```

Command for mounting the first partition on SD card is list as following.

```
$ mount -t exfat /dev/mmcblk0p1 /mnt
```

- **FUSE and NTFS**
FUSE (Filesystem in Userspace) is a kind of file system that is implemented for user space. User can implement much kind of file systems by FUSE. The famous file system that is implement by FUSE are NTFS-3G or SSHFS and so on. The following is an example that implements Microsoft NTFS (NTFS-3G) by FUSE.
Please enable the following item to support FUSE function.

```
File systems --->
    <*> FUSE (Filesystem in Userspace) support
```

NTFS-3G is an open source project developed and implemented by Tuxera. It is a driver which can read and write NTFS on Linux and source code can be downloaded from <http://www.tuxera.com/community/ntfs-3g-download> page. Please refer to user's manual of ntfs-3g to compile it. And mount it by the following command.

```
$ ./ntfs-3g /dev/mmcblk0p1 /mnt/mmc
```

- **UBIFS**
Please enable the following items to support it.

```
Device Drivers --->
-* Memory Technology Device (MTD) support --->
<*> Enable UBI - Unsorted block images --->
File systems --->
    [*] Miscellaneous filesystems --->
        <*> UBIFS file system support
        [*] Advanced compression options
        [*] LZO compression support
```

5.3.5 Speed up SPI boot with JFFS2 file system in SPI flash

The first step is to set SPI to Quad mode.

```
Device Drivers --->
```

```
[*] SPI support --->
<*>  Nuvoton NUC970/N9H30 Series SPI Port 0
      SPI0 pin selection by transfer mode (Quad mode) --->
```

The second step, set page size to 0x1000 while use mkfs.jffs2 to build a JFFS2 root file system

```
$ mkfs.jffs2 -s 0x1000 -e 0x10000 -p 0x800000 -d rootfs_jffs2/ -
o jffs2.img
```

The third step, use sumtool and enable JFFS2_SUMMARY in kernel configuration
Below is an example of sumtool usage

```
$ sumtool -i jffs2.img -o jffs2_sumtool.img -e 0x10000
```

JFFS2_SUMMARY configuration is located as below.

```
-> File systems
    -> Miscellaneous filesystems (MISC_FILESYSTEMS)
    -> Journalling Flash File System v2 (JFFS2) support (JFFS2_FS)
[*]      JFFS2 summary support
```

5.3.6 FIQ

In order to make sure the real time of interrupt, user can use FIQ instead of IRQ. This section includes an example which describes how to use timer2 FIQ.
Please enable the following item to support FIQ in system.

```
Kernel Configuration
  System Type --->
    [*] Nuvoton NUC970/N9H30 FIQ support
```

Example for timer2:

User needs to inster *init_FIQ(0)* code in the initialization function of driver.

```
static int __init xxx_init(void) {
    ...
    init_FIQ(0);
    ...
}
```

And then add the following codes and insert *use_fiq()* function in the suitable position of driver.
(Should replace general irq operation codes.)

```
/*IRQ handler for the timer*/
void nuc970_timer2_interrupt(void) {
    // ... add some code here
    __raw_writel(0x04, REG_TMR_TISR); /* clear timer2 flag */
}

static uint8_t fiqStack[1024];
extern unsigned char fiq_handler, fiq_handler_end;
static struct fiq_handler timer2_fiq = {
```



```

        .name      = "timer2_fiq_handler"
};

void use_fiq(void) {
    int ret;
    struct pt_regs regs;

    ret = claim_fiq(&timer2_fiq);
    if (ret)
        return;
    set_fiq_handler(&fiq_handler, &fiq_handler_end - &fiq_handler);
    // set some registers use in FIQ handler
    regs.ARM_r8 = (long)nuc970_timer2_interrupt;
    regs.ARM_r10 = (long)REG_AIC_IPER;
    regs.ARM_sp = (long)fiqStack + sizeof(fiqStack) - 4;
    set_fiq_regs(&regs);
    /* Enable the FIQ */
    __raw_writel(__raw_readl(REG_AIC_SCR7) & ~0x00070000, REG_AIC_SCR7);
    enable_fiq(IRQ_TMR2);
}

```

Note that, the regs.ARM_r8 must be the address of fiq handler function and regs.ARM_r10 must be the address of REG_AIC_IPER register.
User needs to configure timer2 if necessary additionally.

5.3.7 Power management

Linux kernel also supports power management function. The system can enter power-down mode to save power consumption and wake up later using enabled wake up source(s). To enable power management support, please enable following kernel features before compilation.

Power management options --->

[*] Suspend to RAM and standby

With the kernel with power management function enabled, issue following under shell can put the system enter power-down mode. In power-down mode, all unnecessary clocks will be turned off, and DDR put into self-refresh mode. And only enabled wake up source can bring the system back to normal operation mode.

```
$ echo mem > /sys/power/state
```

Note that to minimize the power consumption, GPIO pin needs extra pull up/down setting before enter power-down mode. This is pretty much depending on the board design, so please add the your control code in at the beginning of nuc970_suspend_enter() function in arch/arm/mach-nuc970/pm.c

5.4 Linux Kernel Compilation

After finish the configuration of kernel, type "make" command to compile kernel in linux-3.10.x directory. If no error happens, the kernel image file and kernel zip file will be output to upper image directory. You can use "make ulmage" command to build an image file that has a U-Boot

wrapper if mkimage tool is installed or use “make dtbs” to generate dtb (device tree blob) file if dtc tool is installed.

```
$ make
.....
Kernel: arch/arm/boot/Image is ready
cp arch/arm/boot/Image    ../image/n9h30image
zip ../image/ n9h30image.zip ../image/ n9h30image
updating: ../image/970image (deflated 31%)
  GZIP    arch/arm/boot/compressed/piggy.gzip
  CC      arch/arm/boot/compressed/misc.o
  AS      arch/arm/boot/compressed/piggy.gzip.o
  LD      arch/arm/boot/compressed/vmlinux
  OBJCOPY arch/arm/boot/zImage
Kernel: arch/arm/boot/zImage is ready
$ ls ../image/
n9h30image  n9h30image.zip
```

6 Linux user applications

6.1 Sample applications

There are some sample applications in the applications/ directory. Content of each directory listed in the following table

Directory	Description
alsa-utils-1.0.23	<p>ALSA command line utilities.*</p> <p>Cross compilation command as below:</p> <pre>\$./configure -host=arm-linux -disable-nls --disable-xmlo PKG_CONFIG_LIBDIR=/usr/local/arm_linux_4.8/usr/lib -disable-alsamixer</pre> <p>\$ make</p> <p>Sample mixer setting for playback:</p> <ul style="list-style-type: none"> ● \$./amixer set PCM 85% ● \$./amixer set Headphone 90% <p>Sample mixer setting for recording:</p> <p>When source is Mic:</p> <ul style="list-style-type: none"> ● \$./amixer set "Mic Bias" on ● \$./amixer set "Input PGA" 100% ● \$./axmier set ADC 90% <p>When source is Line In:</p> <ul style="list-style-type: none"> ● \$./axmier set "Right Input Mixer R2" on ● \$./axmier set "Left Input Mixer L2" on ● \$./axmier set "L2/R2 Boost" 100% ● \$./axmier set ADC 90% <p>Playback command:</p> <ul style="list-style-type: none"> ● \$./aplay <file name> <p>To playback the sample sound file in BSP, please use following command:</p> <pre>\$ cd usr</pre> <pre>\$./aplay -c 2 -f S16_LE alsa/8k2ch.pcm</pre> <p>Recording command:</p> <ul style="list-style-type: none"> ● \$./arecord -d 10 -f S16_LE -c2 -r8000 -t wav -

	<p>D plughw:0,0 <file name></p> <p>Command to record and play simultaneously:</p> <ul style="list-style-type: none"> ● <code>\$/arecord -f S16_LE -r 8000 -c 2 -D plughw:0,0 ./aplay</code>
benchmark/netperf-2.6.0	<p>Network performance benchmarking tool. Cross compilation command below:</p> <p><code>\$/configure --host=arm-linux</code></p>
busybox-1.22.1/	<p>Busybox source code. Cross compilation command below:</p> <ol style="list-style-type: none"> 1. <code>\$ make menuconfig</code> 2. Select applets to be build 3. <code>\$ make</code>
lighttpd-1.4.39	<p>lighttpd source code.</p> <p>Cross compilation commands are as below::</p> <p>If use Toolchain gcc 4.8:</p> <p><code>\$./configure --host arm-linux --build pentium-pc-linux -</code> <code>-without-zlib --without-bzip2 --without-pcre --target</code> <code>arm-linux</code></p> <p><code>\$ make</code></p> <p><code>\$ sudo make install</code></p> <p>If use Toolchain gcc 4.3:</p> <p><code>\$./configure --host arm-linux --build pentium-pc-linux -</code> <code>-without-zlib --without-bzip2 --without-pcre --disable-</code> <code>ipv6 --target arm-linux</code></p> <p><code>\$ make</code></p> <p><code>\$ sudo make install</code></p> <p>The lib/ and/sbin/ of lighttpd are installed in /usr/local/ , user have to copy them to root file system.</p> <p>config_html_sample/ has lighttpd configuration file</p>

	<p>(lighttpd.conf) and homepage html (index.html) example. Please put lighttpd.conf in sbin/ , and create sub-directory www/ under sbin/ , then put index.html in www/ .</p> <p>Besides , Please add below two files for error and access log.</p> <p>/var/log/lighttpd/error.log</p> <p>/var/log/lighttpd/access.log</p> <p>The steps to start lighttpd are as below:</p> <p>\$ ifconfig eth0 192.168.0.100</p> <p>\$ cd /usr/local/sbin</p> <p>\$./arm-linux-lighttpd start -f lighttpd.conf</p>
demos/alsa_audio	Audio sample application. *
demos/cap	Video capture sample application. *
demos/can	CAN bus sample application
demos/etimer	Enhanced timer sample application. *
demos/ebi	External Bus Interface sample application. *
demos/gpio	GPIO sample application. *
demos/irda	IrDA sample application. *
demos/lcm/	LCD sample application. *
demos/thread	Thread sample applications. *
demos/rtc	RTC sample application. *
demos/uart	UART sample application. *
demos/wdt	Watchdog timer sample application. *
demos/wwdt	Window watchdog timer sample application. *
demos/dma	DMA sample application. *
emWin	emWin application source code and documents.
i2c-tools	<p>I2c-tools utility.</p> <p>Simply type make to compile</p> <p>\$ make</p>
DPO_RT3070_LinuxSTA_V2.3.0.2_20100412	RT3070 USB WiFi dongle open source driver.
wireless_tools.29	WiFi configuration tools. Including iwconfig, iwlist, iwpriv...
tslib-1.1	Touch screenlibrary, including calibration and test utilities. *
yaffs2utils.tar.gz	<p>yaffs2 command tool. Simply type make to compile</p> <p>\$ make</p>
lzo-2.09.tar.gz	<p>Compress/decompress utility.</p> <p>Cross compilation command below:</p> <p>\$ cd lzo-2.09</p>

	<pre>\$./configure --host=arm-linux --prefix=\$PWD/../install \$ make \$ make install</pre>
libuuid-1.0.3.tar.gz	<p>Utility to create UUID. Cross compilation command below:</p> <pre>\$ cd libuuid-1.0.3 \$./configure --host=arm-linux --prefix=\$PWD/../install \$ make \$ make install</pre>
mtd-utils.tar.gz	<p>mtd-utils source code. Required to use lzo-2.09.tar.gz and libuuid-1.0.3.tar.gz</p> <p>Cross compilation command below:</p> <pre>\$ cd mtd-utils \$ export CROSS=arm-linux- \$ export WITHOUT_XATTR=1 \$ export DESTDIR=\$PWD/../install \$ export LZOCPPFLAGS=-I/home/install/include \$ export LZOLDFFLAGS=-L/home/install/lib \$ make \$ make install</pre>
Python-2.7.9	<p>Python-2.7.9 source code. Cross compilation command below:</p> <pre>\$./make_python.sh</pre> <p>Note: PC need to install Python-2.7.9.</p> <p>In rootfs, Need export as bellow:</p> <pre>\$ export PYTHONHOME=/lib/python2.7 \$ export PYTHONPATH =/lib/python2.7</pre>
ethtool-4.6	<p>ethtool is the standard Linux utility for controlling network drivers and hardware, particularly for wired Ethernet devices.</p> <p>To cross compile this tool, use “./configure CC=arm-linux-gcc CFLAGS=-mach=armv5te --host=arm-linux;make” command to build ethtool.</p> <p>The command to enable Wake on Lan function is “./ethtool -s eth0 wol g”, and the commad to diable Wake on Lan is “./ethtool -s eth0 wol d”.</p>
Buildroot	<p>Buildroot is a simple, efficient and easy-to-use tool to generate uboot, kernel, application and toolchain for NUC970/N9H30 platform. To build and use the buildroot stuff, do the following:</p> <ol style="list-style-type: none"> 1) run 'make nuvoton_nuc972_defconfig' 2) select the target architecture and the packages you wish to compile 3) run 'make' 4) wait while it compiles 5) find the kernel, bootloader, root filesystem, etc. in output/images 6) If users need to install NUC970/N9H30 bsp, user need to be root to run './install_bsp.sh' to install the bsp.

Detail refer to <https://buildroot.org/docs.html>

*. The execution result will be incorrect if the driver is not enabled in kernel configuration and/or jumper/ switch setting on EV board setting is inconsistent with kernel configuration.

6.2 Cross compilation

Sometimes a project requires porting an application to ARM platform. Many open source projects already supports cross compiling. Simply follow these projects' document to configure for cross compiling to build executable files or libraries for ARM platform.

If the application's Makefile doesn't support cross compilation options, the modification of Makefile is necessary. The Makefile used for cross compiling could be alike with the original one, only part of it needs to be modified

- The prefix of tool chain must be set. For example, the original Makefile use gcc for compiling, the new Makefile use arm-linux-gcc for cross compiling. Other tools for example, as and ld need to change to arm-linux-as and arm-linux-ld respectively.
- The path of library and include files need to be set. The cross compiler doesn't use the glibc or other library using in x86 system. Rather it links with uClibc which consumes less system resource.

Here is a simple Makefile for your reference.

```
.SUFFIXES : .x .o .c .s

ROOT = /usr/local/arm_linux_4.8/usr
LIB=$(ROOT)/lib
INC:=$(ROOT)/include

CC=arm-linux-gcc -O2 -I$(INC)
WEC_LDFLAGS=-L$(LIB)
STRIP=arm-linux-strip

TARGET = hello

SRCS := hello.c

LIBS= -lc -lgcc -lc
all:
    $(CC) $(WEC_LDFLAGS) $(SRCS) -o $(TARGET) $(LIBS)
    $(STRIP) $(TARGET)

clean:
    rm -f *.o
    rm -f $(TARGET)
    rm -f *.gdb
```

7 Revision Hisotry

Verison	Date	Description
1.00.000	Sept. 7, 2018	1. Initial release

Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

*Please note that all data and specifications are subject to change without notice.
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.*