

relocate  
polycarbonate to  
2nd phase

28ft +/- (keep in  
2nd phase)

20ft +/- (keep in  
2nd phase)

12ft +/- (keep in  
2nd phase)

8ft +/-  
(remove/relocate  
on 2nd phase)

4ft  
+/- (remove/reloca  
te on 2nd phase)

RELOCATE  
INSULATION AND  
METAL PANEL ON  
2ND PHASE

RELOCATE  
INTERIOR  
PLYWOOD ON 2ND  
PHASE

