



frequently asked questions

H2000 Systems

What are the network node addresses?

Node Address

01_H05_H09_H0D_H10_H11_H to 12_H (Typ. 12_H)20_H to 2F_H30_H to 3F_H40_H to 4F_H50_H to 5F_H60_H to 6E_H6F_H112_H to 127_H128_H

Function

Depth

Wind

Performance

Expansion

Halcyon 2000 Compass

Auto-Pilot

FFDs

Halcyon FFDs

20/20's

Pilot FFDs

NMEA FFDs

RemoteVision Wireless Port

Loadcell Amplifiers

Tank Level Sensor

Collective Addresses

FA_HFB_HFC_HFD_HFE_HFF_H

All 20/20s

All Halcyon FFDs

All Pilot FFDs

All Processor Nodes

All FFDs

Entire System