



frequently asked questions

RESETTING THE HYDRA DEPTH BOARD (Node 1)

Following the procedure detailed below will reset the 'Depth Board' PCB in the main processor to the factory default settings. The procedure is as follows:

WARNING

Resetting the depth board will erase any calibration values you may have entered; for example, Boat Speed Calibration, Depth Alarms, Stored Log and Depth Datum.

1. Perform a 'software' power down by pressing and holding the **LIGHTS** key.
2. Press and hold the **ENTER/RESET** key and the **LIGHTS** key simultaneously until the display shows "Diagnost".
3. Press the **ENTER/RESET** key once, the display will show "Key Test".
4. Press the ▼ (DOWN ARROW) key repeatedly to scroll through the menu until the display shows "Res Sys".
5. Press the **ENTER/RESET** key once to enter the reset menu.
6. Press the ▲ (UP ARROW) key until the display reads 0001 (Node 1).
7. Press the **ENTER/RESET** key once to confirm reset.
8. Press the **PAGE** key 3 times to exit the test mode.

This concludes the DEPTH BOARD reset procedure.