



frequently asked questions

I cannot get Wind data from the Wind key on my FFD

“When I press the Wind key on my FFD, the display shows Sea Temp, Depth and Heading”

- The B&G FFD ‘Wind’ key is designed to work in both a wind function mode or, for systems without the Wind system installed, in a ‘Power’ mode only.
- The different modes are toggled by holding and pressing the ‘Wind’ key while powering up the system.
- Occasionally ‘Power’ mode is selected accidentally if the ‘Wind’ key is accidentally held when powering up, or if the ‘Wind’ key is sticking on the FFD.
- When toggling the Wind/Power mode, only the FFD that has the Wind key depressed upon power up will change modes. No other FFD’s on the system will be affected.

--ends--