



frequently asked questions

h2000 Autopilot Software Upgrade

Software upgrade procedure for h2000 Autopilots

1. Make a note of all important calibration values including:

Setting	Description	Original Setting
B TYPE	Select boat type: Sail, Power P, Power D	
H SRC	Heading Source, compass data selection	
H OFF	Heading Offset, compass alignment correction	
DIP	Magnetic DIP Angle compensation	
DRIVE	Rudder drive type selection	
RUD P	Rudder end stop Port	
RUD S	Rudder end stop Starboard	
RUD M	Rudder mid position	
RUD T	Rudder hard-over Time	
B LEN	Boat waterline length in metres	
B LAG	Boat Lag Value	
R GAN	Rudder Gain Value	

2. Switch off the 12Vdc supply and heavy-duty drive supplies at the circuit breaker.
3. Open up the ACP.
4. Carefully remove the memory cartridge noting orientation and place safely to one side.
5. Insert Pilot Programming cartridge.
6. Switch on light-duty power supply to instruments. The software will now start to update automatically. During the programming stage, the Pilot FFD will display "No Pilot".
7. After approximately one minute, the display will now show heading data. This signifies the completion of the programming stage.
8. Switch off the light-duty power supply and remove the programming cartridge.
9. Replace the original memory cartridge, and then re-enter the commissioning values, and then perform a dockside commission to test functionality.

--ends--