



frequently asked questions

Hydra Hercules Systems

"How do I switch the Heading Data from °M to °T?"

This document refers to B&G Hydra and Hercules systems that are interfaced to an NMEA Heading Source using an NMEA FFD.

1. Press the **SCROLL UP** key repeatedly to scroll through the menu until the display shows **NAVIGATE**.
2. Press the **ENTER/RESET** key once to select this directory.
3. Press the **SCROLL UP** key repeatedly to scroll through the menu until the display shows **HEADING**.
4. Press the **ENTER/RESET** key once to display this function.
5. Press the **SCROLL DOWN** key repeatedly until the display shows **CALBRATE** flashing and then press the **ENTER/RESET** key once. The display now shows **CAL VAL 1** flashing.
6. Press the **ENTER/RESET** key again and the display shows **CAL VAL 1** and a data value.
7. Press the **ENTER/RESET** key once and the data value will start to flash.
8. Use the **SCROLL UP/DOWN** keys to toggle the data value between **0** and **1**.
 - 0: display Heading in Magnetic (°M)
 - 1: display Heading in True (°T)
9. Press the **ENTER/RESET** key to store the value.
10. Press the **PAGE** key once to exit this procedure.

--ends--