



ALL SIGNAL LEVELS  
ARE BETWEEN +5 V and GND

TO Use TXD3/RXD3 a RS232 Level  
A Level Translator is Needed  
TO Use TXD0/RXD0 a RS232 Level  
A Level Translator is Needed  
Both Serial Ports are supported by software