



Toolkit DocXX Prosilica Focusing
June 27, 2011




Prosilica Camera Focusing


Parts Needed: 0.9mm allen wrench required
(Available from McMaster-Carr P/N 7289A32)

- Refer to the PR2 Overview document for additional information.


- With two hands give the front head bezel a gentle tug (Fig. 1). If the bezel comes off proceed to the next step. If not remove the Head Bezel Front (see [Head Bezel R/R](#) - pg5)



- Locate the iris (Red arrow) and focus ring (Yellow arrow) on the prosilica camera (robot right)



- Loosen the set screws on the iris (0.9mm hex)
- Set the iris to be wide open (look into the lens and see how open the iris is)
- Tighten the iris screw
- Loosen the focus set screw (0.9mm hex)




7. Bring up the Prosilica camera image

- Power up your robot
- SSH -X into your robot
- Type 'screen'
- 'Ctrl A' then 'Ctrl C' a couple times to open multiple screens
- 'Ctrl A' + 0,1,2... will open the corresponding screen
- In screen 0 type 'roscore'
- In screen 1 type 'roslaunch /etc/ros/robot.launch'
- In screen 3 copy paste both lines of code below for bringing up the prosilica camera image:
 - 'roslaunch dynamic_reconfigure dynparam set /prosilica_driver trigger_mode streaming'
 - 'roslaunch image_view image_view image:=/prosilica/image_raw'

Prosilica Camera Focusing

8. Focus the prosilica camera to your liking



9. Tighten the focus set screw without changing the focus (torque to 0.17Nm) NO Loctite.

10. Type 'roslun dynamic_reconfigure dynparam set /prosilica_driver trigger_mode polled' to set the camera back to polling mode

11. If the focus changes while you are tightening the set screw, return to step #6

12. Loosen the iris set screw

13. Set the iris to the 8 marking

14. Tighten the iris screw being careful no to over tighten. Excessive torque can strip the setscrew. NO Loctite.

15. Reinstall the front head bezel