

Connection with personal computer[RS-232C/Ethernet]

Revision V: Nov 15, 2018
Revision U: May 29, 2018
Revision T: Nov 30, 2016
Revision S: Oct 21, 2015
Revision R: Oct 9, 2014
Revision Q: Jun 16, 2014
Revision P: Aug 28, 2013
Revision N: Oct 11, 2011
Revision M: Mar 26, 2009
Revision L: Oct 23, 2008
Revision K: Feb 15, 2005
Revision J: Jul 7, 2004
Revision H: Feb 10, 2004
Revision G: Jan 23, 2004
Revision F: Aug 19, 2003

-NOTICE-

This is a preliminary printing.

Contents

1	INTRODUCTION.....	5
2	CONFIGURATION	5
3	PROTOCOL.....	6
3.1	NON-PROCEDURAL	6
3.2	PROCEDURAL (FOR RS-232).....	6
3.3	PROTOCOL FORMAT.....	8
3.3.1	Transmit data	8
3.3.2	Receive data	8
3.3.3	Communication interval	8
4	COMMAND EXAMPLE.....	10
4.1	CONNECT AND DISCONNECT	10
4.2	JOG OPERATION	10
4.3	PROGRAM EDIT	11
4.4	TEACHING.....	11
4.5	STEP RUNNING	12
4.6	RUN	12
4.7	VARIABLE MONITOR AND WRITE	13
5	COMMAND SPECIFICATION.....	14
5.1	COMMAND LISTS	14
5.2	DETAILS EXPLANATION OF COMMAND WORDS.....	17
5.2.1	OPEN= (Communication open)	17
5.2.2	CLOSE (Communication close)	18
5.2.3	CNTL (Operation enable or disable)	18
5.2.4	LOAD= (Program open).....	19
5.2.5	SAVE (Program save and close).....	19
5.2.6	NEW (Program quit and close)	20
5.2.7	EDATA (Edit program).....	20
5.2.8	EMDAT (More line edit program).....	21
5.2.9	EDINS (Insert program).....	21
5.2.10	VAL= (Variable data write).....	22
5.2.11	LISTI (Program list read)	23
5.2.12	LISTL (Program more list read).....	23
5.2.13	LISTP (Program position read).....	24
5.2.14	VTYPRD (Variable type read).....	25
5.2.15	LISTCNT (Count program lines).....	25
5.2.16	EXEC * (Direct execution)	26
5.2.17	EXEC2= * (Direct execution)	26
5.2.18	STEP * (Step execution).....	27
5.2.19	ECLR (Clear program contents).....	27
5.2.20	DELETE (Delete program lines)	28
5.2.21	RENUM (Renumber).....	28
5.2.22	PDIR (Program directory).....	29
5.2.23	FDIR (File directory).....	30
5.2.24	FCHECK (File check).....	31
5.2.25	FPATH= (File path)	31
5.2.26	FCOPY (File copy)	32
5.2.27	FDEL (File delete)	32
5.2.28	FRENAME (File rename)	33
5.2.29	FATTRIB (File attribute)	33
5.2.30	FINIT (File init).....	34
5.2.31	FOPEN (File block open).....	34
5.2.32	FCLOSE (File block close)	35
5.2.33	FREAD (Block read).....	35

5.2.34	<i>FWRITE (Block write)</i>	36
5.2.35	<i>EFREE (Read file size)</i>	36
5.2.36	<i>ESEARCH (Search string)</i>	37
5.2.37	<i>PRGLOAD= * (Program load)</i>	37
5.2.38	<i>PRG<UP/DOWN> * (Program select)</i>	38
5.2.39	<i>PRGRD (Execution program name read)</i>	38
5.2.40	<i>LINENO= * (Execution line number change)</i>	39
5.2.41	<i>LINENO (Execution Line number read)</i>	39
5.2.42	<i>LINERD (Execution Line contents)</i>	40
5.2.43	<i>LINESRD (Execution more Line contents)</i>	40
5.2.44	<i>SRV<ON/OFF> * (Servo ON or OFF)</i>	41
5.2.45	<i>OVRD= * (OP override change)</i>	42
5.2.46	<i>OVRD (OP override read)</i>	42
5.2.47	<i>RUN * (Program start)</i>	43
5.2.48	<i>STOP (STOP)</i>	43
5.2.49	<i>STOP<ON/OFF> (STOP ON or OFF)</i>	44
5.2.50	<i>CSTOP (Cycle STOP)</i>	44
5.2.51	<i>RSTALRM (Error reset)</i>	45
5.2.52	<i>SLOTINIT (All program reset)</i>	45
5.2.53	<i>RSTPRG (Each program reset)</i>	45
5.2.54	<i>RSTIO (Output signal reset)</i>	46
5.2.55	<i>MLOCK<ON/OFF> (Machine lock ON or OFF)</i>	46
5.2.56	<i>HND<ON/OFF> (HAND open or close)</i>	47
5.2.57	<i>ALIGN * (Aligning the hand)</i>	47
5.2.58	<i>MOVSP * (MOVE safe position)</i>	48
5.2.59	<i>JOG * (JOG operation)</i>	48
5.2.60	<i>JOG * (JOG operation for Multifunctional Electric Hand)</i>	49
5.2.61	<i>LS<ON/OFF> (Limit switch ON or OFF)</i>	50
5.2.62	<i>AUE<ON/OFF> (Program start enable or disable)</i>	50
5.2.63	<i>ATENA (Status can be start)</i>	51
5.2.64	<i>BRKPTSET (Set breakpoint)</i>	51
5.2.65	<i>BRKPTCLR (Delete breakpoint)</i>	52
5.2.66	<i>BRKPTGET (List breakpoint)</i>	52
5.2.67	<i>TOOLSET (Set Tool number)</i>	53
5.2.68	<i>TOOLRD (Read Tool number)</i>	54
5.2.69	<i>SAFE= (Low speed mode)</i>	54
5.2.70	<i>STATE (Read run status)</i>	55
5.2.71	<i>DSTATE (Read stop status)</i>	56
5.2.72	<i>CALIB (Install status)</i>	57
5.2.73	<i>IOSIGNAL (Input and output signal read)</i>	57
5.2.74	<i>IN (Input signal read)</i>	58
5.2.75	<i>OUT (Output signal read)</i>	58
5.2.76	<i>OUT= (Output signal write)</i>	59
5.2.77	<i>DIN (CC-Link's input register data read)</i>	59
5.2.78	<i>DOUT (CC-Link's output register data read)</i>	60
5.2.79	<i>DOUT= (CC-Link's output register data write)</i>	60
5.2.80	<i>INDMY (Set pseudo input)</i>	61
5.2.81	<i>INSET (Reset pseudo input)</i>	61
5.2.82	<i>IN= (Write pseudo input data)</i>	62
5.2.83	<i>DIN= (Write pseudo input register)</i>	62
5.2.84	<i>STPSIG (Stop signal read)</i>	63
5.2.85	<i>HNDSTS (Hand output signal read)</i>	63
5.2.86	<i>USERAREASTS (User specified area read)</i>	64
5.2.87	<i>JPOS,PPOS,XPOS,RPOS (Current position read)</i>	64
5.2.88	<i>GJPOS,GPPOS (Destination position read)</i>	65
5.2.89	<i>TIME (Time read)</i>	66
5.2.90	<i>TIME= (Time change)</i>	67
5.2.91	<i>PTIME (Hour meter read)</i>	67

5.2.92	<i>PTIMEDEL= (Hour meter clear)</i>	68
5.2.93	<i>CYCLETIME (Cycle time read)</i>	69
5.2.94	<i>CYCLECLR (Cycle time clear)</i>	69
5.2.95	<i>ERROR (Error number read)</i>	70
5.2.96	<i>ERRORMES (Error contents read)</i>	70
5.2.97	<i>ERRORLOG (Error history read)</i>	71
5.2.98	<i>ERRLOG2= (Error history reading. / Error details number narrowing seeing.)</i>	72
5.2.99	<i>ERRLOGCLR (Error history clear)</i>	73
5.2.100	<i>ERRSUM (Error summary)</i>	73
5.2.101	<i>ERRSUM2= (error summary)</i>	74
5.2.102	<i>ERRSUMCLR (Clear error summary)</i>	75
5.2.103	<i>SUMDATE (Date when error logging function began)</i>	76
5.2.104	<i>VAL (Variable data read)</i>	76
5.2.105	<i>VALS (More Variable data read)</i>	77
5.2.106	<i>GVAL (Global variable data read)</i>	78
5.2.107	<i>GVALS (More Variable data read)</i>	78
5.2.108	<i>HOT (Variable data write)</i>	79
5.2.109	<i>OPNUMRD (Option slot number read)</i>	80
5.2.110	<i>OPSTSRD (Option information read)</i>	80
5.2.111	<i>THMRD (Controller temperature read)</i>	81
5.2.112	<i>ETEMP (Encoder temperature read)</i>	81
5.2.113	<i>EMISS (Encoder miscount read)</i>	82
5.2.114	<i>SRVENC (Servo encoder read)</i>	82
5.2.115	<i>SRVDRP (Servo droop read)</i>	83
5.2.116	<i>SRVSPD (Servo speed read)</i>	84
5.2.117	<i>SRVCUR (Servo current read)</i>	84
5.2.118	<i>SRVLCR (Servo load current)</i>	86
5.2.119	<i>SRVVOL (Servo voltage)</i>	86
5.2.120	<i>SVMONRST= (Reset servo monitor maximum)</i>	87
5.2.121	<i>RAREAD= (Read serial number)</i>	87
5.2.122	<i>PRMINIT (Parameter initial)</i>	88
5.2.123	<i>PNR (Parameter read)</i>	88
5.2.124	<i>PRM= (Parameter write)</i>	89
5.2.125	<i>PAR (Parameter read)</i>	89
5.2.126	<i>PAW= (Parameter write)</i>	90
5.2.127	<i>PAW2= (Parameter write (need to reboot.))</i>	90
5.2.128	<i>PRMUNDO (Parameter undo)</i>	91
5.2.129	<i>PRM= (Read change parameter list)</i>	92
5.2.130	<i>KEYWD (Keyword input)</i>	92
5.2.131	<i>SLOTTRD (Slot table read)</i>	93
5.2.132	<i>SLOTSET (Slot table write)</i>	93
5.2.133	<i>ENCBATTM (Battery remain time)</i>	94
5.2.134	<i>BREAKON * (Release brake)</i>	94
5.2.135	<i>BREAKONF * (Release brake)</i>	95
5.2.136	<i>HOME * (Setting the origin)</i>	96
5.2.137	<i>AXDATINST * (Additional axis add for DATINST and DATRD)</i>	96
5.2.138	<i>DATINST * (Data input origin set)</i>	97
5.2.139	<i>DATRD (Data input origin set)</i>	97
5.2.140	<i>RSTPWR (Reset power)</i>	98
5.2.141	<i>RPWRCHK= (Reset power check)</i>	98
5.2.142	<i>MFTIME= (Maintenance forecast date)</i>	99
5.2.143	<i>MFRST= (Maintenance forecast reset)</i>	100
5.2.144	<i>MFFCST= (Maintenance forecast read)</i>	100

1 Introduction


In this book, the communication specification to do peripherals such as personal computers and the communication between robot controllers is described.

The robot controller reacts only to the command demand by peripherals, and returns the answer of the command. Therefore, the thing to lodge the command demand from the robot controller voluntarily is not done.

The kind of the protocol is as follows.

- (1) Non-Procedural
- (2) Procedural

2 Configuration



3 Protocol

3.1 Non-Procedural


[Data syntax]

The terminal character can be set according to the parameter. (CR or CR+LF)

Maximum command size is 255 bytes.


3.2 Procedural (for RS-232)

[Data syntax]



Maximum command size is 255 bytes.

[Communication procedure]



[State chart]

	I D	State Status	ENQ	Cmd. OK	Cmd. ERR	ACK	NAK	EOT	Time out	Retry error
Receive	1	Wait ENQ	State 2	State 3	State 3	State 3	State 3	State 3	---	---
	2	Send ACK and Wait	State 3	State 2	State 3	State 3	State 3	State 1	State 1	---
	3	Send NAK and Wait	State 3	State 2	State 3	State 3	State 3	State 1	State 1	State 1
Send	4	Send ENQ Wait ACK	State 6	State 6	State 6	State 5	State 4	State 6	---	---
	5	Send Command Wait ACK	State 6	State 6	State 6	State 5	State 5	State 6	---	---
	6	Send NAK Wait ACK	State 6	State 6	State 6	State 5	State 6	State 6	---	---

3.3 Protocol format

3.3.1 Transmit data

[<Robot No.>]; [<Slot No>]; <Command><Argument>

<Robot No.>: The robot number to be operated is specified. (0, 1, 2 or 3)

It is possible to omit it. Omitting it is 1.

There are commands that influences all robots if 0 is specified.

< Slot No >: The slot number to be operated is specified. (0, 1 - 33)

Parameter "TASKMAX" is a number of task slots used by the multitask. When the program is edited from the PC, the edit slot is used. The slot number of the edit slot is parameter TASKMAX+1. In this case, because an initial value of TASKMAX is 8, the number of the edit slot is 9.

It is possible to omit it. Omitting it is 1.

There are commands that influences all slots if 0 is specified.

< Command >< Argument >: It differs in each command, and refer to the explanation of each command, please.

<Argument>: There are ',' or VT(0b) delimiters for argument.

Example1) 1;1; DELETE10;50 ... Command DELETE

1	;	1	;	D	E	L	E	T	E	1	0	;	5	0	
31	3B	31	3B	44	45	4C	45	54	45	31	30	3B	35	30	

Example2) 1;1;EMDAT10 MOV P10b20 MOV P2 ... EMDAT Command

1	;	1	;	E	M	D	A	T	1	0		M	O	V	
31	3B	31	3B	45	4D	44	41	54	31	30	20	4D	4F	56	20
P	1	VT	2	0		M	O	V		P	2				
50	31	0B	32	30	20	4D	4F	56	20	50	32				

3.3.2 Receive data

QoK<Answer>

or

QeR<Error No.>

< Answer >: It differs in each command, and refer to the explanation of each command, please.

There are ',' or VT(0b) delimiters for answer.

Example1) QoK09060;17;1 ... DSTATE answer

Q	O	K	0	9	0	6	0	;	1	7	;	1			
51	6F	4B	30	39	30	36	30	3B	31	37	3B	31			

Example2) QoK10 MOV P10b20 MOV P2 ... LISTL answer

Q	O	K	1	0	M	O	V		P	1	VT	2	0		M
51	6F	4B	31	30	4D	4F	56	20	50	31	0B	32	30	20	4D
O	V		P	2											
4F	56	20	50	32											

< Error No.>: It replies the error number when the command cannot be executed. Please refer to the troubleshooting manual of the robot for the number.

3.3.3 Communication interval

When receiving the next data after receiving the received data while operating the robot program, please communicate at an interval (recommended value 100 ms or more).

Example)


1;1;DSTATE
QoK09060;17;1
(Interval of 100 ms or more)
1;1;DSTATE

QoK09060;17;1
:


4 Command example

Two or more commands are combined and the example of using the command is shown about the operation used.


4.1 Connect and disconnect




4.2 JOG operation




4.3 Program edit




4.4 Teaching



4.5 STEP running




4.6 RUN



* When the program pausing, neither the program loading(PRGLOAD=) nor the program selection(PRGUP) can be done. Please do after doing program reset (SLOTINIT).

4.7 Variable monitor and write



5 Command specification

5.1 Command lists

Class	Functions	Command * is enable commands	Only FR/F/SD/SQ
Communication	Communication open	OPEN=	
	Communication close	CLOSE	
	Operation enable or disable	CNTL<ON/OFF>	
Program edit	Program open	LOAD=	
	Program save and close	SAVE	
	Program quit and close	NEW	
	Edit program	EDATA	
	More line edit program	EMDAT	
	Insert program	EDINS	o
	Variable data write	VAL=	
	Program list read	LISTI	
	Program more list read	LISTL	
	Program position read	LISTP	
	Variable type read	VTYPRD	
	Count program lines	LISTCNT	
	Direct execution	EXEC *	
	Direct execution	EXEC2= *	
	Step execution	STEP *	
	Clear program contents	ECLR	
	Delete program lines	DELETE	
	Renumber	RENUM	
File operation	Program directory	PDIR	
	File directory	FDIR	
	File check	FCHECK	
	File path	FPATH=	o
	File copy	FCOPY	
	File delete	FDEL	
	File rename	FRENAME	
	File attribute	FATTRIB	
	File init	FINIT	
	File block open	FOPEN	
	File block close	FCLOSE	
	Block read	FREAD	
	Block write	FWRITE	
	Read file size	EFREE	
	String search	ESEARCH	
Running	Program load	PRGLOAD= *	
	Program select	PRG<UP/DOWN> *	
	Execution program name read	PRGRD	
	Execution line number change	LINENO= *	
	Execution Line number read	LINENO	
	Execution Line contents	LINERD	
	Execution more Line contents	LINESRD	
	Servo ON or OFF	SRV<ON/OFF> *	
	OP override change	OVRD= *	
	OP override read	OVRD	
	Program start	RUN *	
	STOP	STOP	
	STOP ON or OFF	STOP<ON/OFF>	

	Cycle STOP	CSTOP	
	Error reset	RSTALRM	
	All program reset	SLOTINIT	
	Each program reset	RSTPRG	
	Output signal reset	RSTIO	
	Machine lock ON or OFF	MLOCK<ON/OFF>	
	HAND open or close	HND<ON/OFF>	
	Aligning the hand	ALIGN *	
	MOV safe position	MOVSP *	
	JOG operation	JOG *	
	Limit switch ON or OFF	LS<ON/OFF>	
	Program start enable or disable	AUE<ON/OFF>	
	Status can be start	ATENA	
	Set breakpoint	BRKPTSET	0
	Delete breakpoint	BRKPTCLR	0
	List breakpoint	BRKPTGET	0
	Set Tool number	TOOLSET。	0
	Read Tool number	TOOLRD。	0
	Low speed mode	SAFE=	0
Monitor	Read run status	STATE	
	Read stop status	DSTATE	
	Install status	CALIB	
	Input and output signal read	IOSIGNAL	
	Input signal read	IN	
	Output signal read	OUT	
	Output signal write	OUT=	
	CC-Link's input register data read	DIN	
	CC-Link's output register data read	DOUT	
	CC-Link's output register data write	DOUT=	
	Set pseudo input	INDMY	
	Reset pseudo input	INSET	
	Write pseudo input data	IN=	
	Write pseudo input register	DIN=	
	Stop signal read	STPSIG	
	Hand output signal read	HNDSTS	
	User specified area read	USERAREASTS	
	Current position read	JPOS, PPOS, XPOS, RPOS	
	Destination position read	GJPOS, GPPOS。	0
	Time read	TIME	
	Time change	TIME=	
	Hour meter read	PTIME	
	Hour meter clear	PTIMEDEL=	
	Cycle time read	CYCLETIME	
	Cycle time clear	CYCLECLR	
	Error number read	ERROR	
	Error contents read	ERRORMES	
	Error history read	ERRORLOG	
	Error history read 2	ERRLOG2=	
	Error history clear	ERRORLOGCLR	
	Error summary	ERRSUM	
	Error summary 2	ERRSUM2=	
	Clear error summary	ERRSUMCLR	
	Date when error logging function began	SUMDATE	
	Variable data read	VAL	

	More Variable data read	VALS	
	Global variable data read	GVAL	
	More Global variable data read	GVALS	
	Variable data write	HOT	
	Option slot number read	OPNUMRD	
	Option information read	OPSTSRD	
	Controller temperature read	THMRD	
	Encoder temperature read	ETEMP	
	Encoder miscount read	EMISS _o	0
	Servo encoder read	SRVENC _o	0
	Servo droop read	SRVDRP _o	0
	Servo speed read	SRVSPD _o	0
	Servo current read	SRVCUR _o	0
	Servo load current read	SRVLCR _o	0
	Servo voltage read	SRVVOL _o	0
	Reset servo monitor maximum	SVMONRST= _o	0
	Read serial number	RAREAD= _o	0
Maintenance	Parameter initial	PRMINIT	
	Parameter read	PNR	
	Read change parameter list	PRM=	
	Parameter compulsion read	PAR	
	Parameter compulsion write	PAW=	
	Parameter write (need to reboot)	PAW2=	
	Parameter undo	PRMUNDO	
	Read change parameter list	PRM=	
	Keyword input	KEYWD	
	Slot table read	SLOT RD	
	Slot table write	SLOT SET	
	Battery remain time	ENCBAT TM	
	Release brake	BREAKON *	
	Release brake (No operation right required)	BREAKON F	
	Setting the origin	HOME *	
	Additional axis add for DATINST and DATRD	AXDATINST *	
	Data input origin set	DATINST *	
	Data input origin read	DATRD	
	Reset power	RSTPWR	0
	Reset power check	RPWRCHK= _o	0
	Maintenance forecast date	MFTIME= _o	
	Maintenance forecast reset	MFRST= _o	
	Maintenance forecast read	MFFCST= _o	

5.2 Details explanation of command words

5.2.1 OPEN= (Communication open)

[Function]

Communication open. The commands sent most first when communicating from the peripheral equipment such as personal computers.

[Format]

OPEN=<Device name>[;<LANG>]

<Device name> An arbitrary name is specified in the alphanumeric character.

<LANG> Specify the display language of the error message.

[Answer]

QoK<XYZ axes pattern>;<JOINT axes pattern>;<Structure flag1>,< Structure flag2>;
 <JOG speed>;
 <Program ext.>;<Parameter ext.>;<Robot type>;<Controller>;<Series>;<DATE>;
 <Version>;<Language>;<Copyright>;<Robot info.>;<Serial No>;
 <Multitask No>

<XYZ axes pattern> XYZ axes pattern of HEX number. (00~FF)

<JOINT axes pattern> JOINT axes pattern of HEX number. (00~FF)

axis pattern		
00000000B	XYZ / JOINT	
_____1	X	J1
____1_	Y	J2
___1__	Z	J3
__1___	A	J4
_1____	B	J5
__1___	C	J6
_1____	L1	J7
1_____	L2	J8

< Structure flag1> Default structure flag1

< Structure flag2> Default structure flag2

<JOG speed> The JOG speed of the HEX number is 7 pieces. (00~FF)

<Program ext.> Program extension (MB4, MB5 or MB6)

<Parameter ext.> Parameter extension (PRM)

<Robot type> Robot name

<Controller> "CRn-5xx", "CRn-7xx", "CR75x" or "CR800"

<Series> "MELFA" (fix)

<DATE> Release data

<Version> System software version

<Language> JPN(Japanese) or ENG(English)

<Copyright> Copyright message

<Robot info.> Multi robot information

<Serial No> 1 (fix)
 <Multitask No> Value of parameter "TASKMAX"

[Reference command]

1;1;OPEN=USERTOOL
QoK3F;3F;7,0;3,5,A,1E,32,46,64;MB5;PRM;RV-4A;CRn-5xx;MELFA;03-11-19;Ver.J4;ENG; COPYRIGHT(C)1999-2003 MITSUBISHI ELECTRIC CORPORATION ALL RIGHTS RESERVED;1;1;8;

[Related commands]

CLOSE

5.2.2 CLOSE (Communication close)

[Function]

Communication close. The command sent when the communication is ended from the peripheral equipment such as personal computers.

[Format]

CLOSE

[Answer]

QoK

[Reference command]

1;1;CLOSE
QoK

[Related commands]

OPEN=

5.2.3 CNTL (Operation enable or disable)

[Function]

Operation enable or disable. When the command which needs the operation right such as Program start, Servo ON and more is used, the operation right should be made effective.

[Format]

CNTL<ON/OFF>

<ON/OFF>

Select ON or OFF

[Answer]

QoK

[Reference command]

1;1;CNTLON

QoK

[Related commands]

5.2.4 LOAD= (Program open)

[Function]

Open the program for edit.

[Format]

LOAD=<Program name>

<Program name> Edit program name

[Answer]

QoK

[Reference command]

1;1;LOAD=100

QoK

[Related commands]

SAVE, NEW

5.2.5 SAVE (Program save and close)

[Function]

The content of the edit is preserved and the program is closed.

[Format]

SAVE

[Answer]

QoK

[Reference command]

1;1;SAVE
QoK

[Related commands]

LOAD=, NEW

5.2.6 NEW (Program quit and close)

[Function]

The program is closed annulling the content of the edit.

[Format]

NEW

[Answer]

QoK

[Reference command]

1;1;NEW
QoK

[Related commands]

LOAD=, SAVE

5.2.7 EDATA (Edit program)

[Function]

The line and the position are registered in the program. It is effective in the edit slot.

[Format]

EDATA<Line or Position>

<Line or Position> Line data and positional data are specified.

[Answer]

QoK or

Qer<Error no>;<Error character>

<Error no> Error number when registering

<Error character> Character position of cause of error

[Reference command]

1;1;EDATA10 MOV P1

QoK

[Related commands]

EMDAT

5.2.8 EMDAT (More line edit program)

[Function]

More line and position are registered in the program. It is effective in the edit slot.

[Format]

EMDAT<Line or Position>[0b]<Line or Position>...
--

<Line or Position> Line data and positional data are specified.

[Answer]

QoKor

Qer<Error no>;<Error line no>;<Error character>

<Error no> Error number when registering

<Error line no> The error line is piece how many.

<Error character> Character position of cause of error

[Reference command]

1;1;EMDAT10 MOV P1[0b]20 MOV P2[0b]30 MOV P3
--

QoK

[Related commands]

EDATA

5.2.9 EDINS (Insert program)

[Function]

The line is inserted in the program. It is effective in the edit slot.

[Format]

EDINS=<Insert line>;<Line data>

<Insert line>	Insert line number
<Line data>	Line data are specified.

[Answer]

QoK
or
Qer<Error no>;<Error character>

<Error no>	Error number when registering
<Error character>	Character position of cause of error

[Reference command]

1;1;EDINS=3;MOV P1

QoK

[Related commands]

EMDAT

5.2.10VAL= (Variable data write)

[Function]

The value of the variable is changed. It is effective in the edit slot.

[Format]

VAL=<Variable name>=<Value>

<Variable name>	Variable name
<Value>	Changed value

[Answer]

QoK

[Reference command]

1;9;VAL=M1=3

QoK

[Related commands]

5.2.11 LISTI (Program list read)

[Function]

The line data is read from the program. It is effective in the edit slot.

[Format]

LISTI<Line posi.>

<Line posi.>

The read line is specified.

TOP: Top line

END: Bottom line

+1: Next line

-1: Previous line

Line number: Specified line

[Answer]

QoK[<Line contents>]

<Line contents>

Specified line data

Only QoK is red when there is no specified line.

[Reference command]

1;1;LISTITOP

QoK10 MOV P1

[Related commands]

LISTL

5.2.12 LISTL (Program more list read)

[Function]

More line data is read from the program. It is effective in the edit slot. .

[Format]

LISTL<Line pos.>

<Line pos.>

The read line is specified.

TOP: Top line

END: Bottom line

+1: Next line

-1: Previous line

Line number: Specified line

[Answer]

QoK<Line contents>[0b]<Line contents>...];<Count>;<Continue>
--

<Line contents>	Specified line data Only QoK is red when there is no specified line.
<Count>	The read number of lines.
<Continue>	1: There is a continuation line. 0: Continuation line none

[Reference command]

1;1;LISTLTOP
QoK10 MOV P1[0b]20 MOV P2[0b]30 M1=1;3;0

[Related commands]

LISTI

5.2.13LISTP (Program position read)

[Function]

Positional data is read from the program. It is effective in the edit slot.

[Format]

LISTP<Position posi.>

<Position posi.>	The read position is specified. TOP: Top position END: Bottom position +1: Next position -1: Previous position Position name: Specified position
------------------	---

[Answer]

QoK<Position contents>

<Position contents>	Specified Positional data Only QoK is red when there is no specified position.
---------------------	---

[Reference command]

1;1;LISTPTOP
QoKP1=(+400.13,+0.00,+644.62,+180.00,+0.00,+180.00)(7,0)

[Related commands]

5.2.14 VTYPRD (Variable type read)

[Function]

The type of the variable is read. It is effective in the edit slot.

[Format]

VTYPRD<Variable name>

<Variable name> Variable name

[Answer]

QoK<Type>

<Type> Variable type. (M:Integer, C:Character, P:Position, J:Joint)

Only QoK is red when there is no specified variable.

[Reference command]

1;9;VTYPRDP1

QoKP

[Related commands]

5.2.15 LISTCNT (Count program lines)

[Function]

The number of lines from the start line to the end line are counted.

[Format]

LISTCNT<Start line>;<End line>

<Start line> Counted start line number

<End line> Counted end line number

[Answer]

QoK<Number >

< Number > Number of lines

[Reference command]

1;1;LISTCNT10;50

QoK0005

[Related commands]

5.2.16 EXEC * (Direct execution)

[Function]

The instruction is executed directly.

Returns the response when you accepted.

[Format]

EXEC<Instruction>

<Instruction>

Instruction of MELFA-BASIC IV to VI or MOVEMASTER commands.

[Answer]

QoK

[Reference command]

1;9;EXECMOV P1

QoK

[Related commands]

EXEC2=

5.2.17 EXEC2= * (Direct execution)

[Function]

The instruction is executed directly.

Returns the response when you work completed.

[Format]

EXEC2=<Instruction>

<Instruction>

Instruction of MELFA-BASIC IV to VI or MOVEMASTER commands.

[Answer]

QoK

[Reference command]

1;9;EXEC2=MOV P1

QoK

[Related commands]

EXEC

5.2.18 STEP * (Step execution)

[Function]

The step is executed. It is effective in the edit slot.

[Format]

STEP<Method>

<Method>

1: Execute 1 step forward

R: Execute continuous step forward

B: Execute 1 step backward

S: Execute step stop

[Answer]

QoK

[Reference command]

1;9;STEP1

QoK

[Related commands]

5.2.19 ECLR (Clear program contents)

[Function]

Clear program contents. It is effective in the edit slot.

[Format]

ECLR

[Answer]

QoK

[Reference command]

1;9;ECLR

QoK

[Related commands]

DELETE

5.2.20DELETE (Delete program lines)

[Function]

The line from the start line to the end line is deleted.

[Format]

DELETE<Start line>;<End line>

<Start line>	Deleted start line number
--------------	---------------------------

<End line>	Deleted end line number
------------	-------------------------

[Answer]

QoK

[Reference command]

1;1;DELETE10;50

QoK

[Related commands]

ECLR

5.2.21RENUM (Renum)

[Function]

Renum for program. It is effective in the edit slot.

[Format]

RENUM<New line no>;<Old start line no>;<Step>;<Old end line no>

<New line no>	New line number. (0:10)
---------------	-------------------------

<Old start line no>	Old start line number. (0:Top)
---------------------	--------------------------------

<Step>	Step of line number. (0:10)
--------	-----------------------------

<Old end line no>	Old end line number. (0:Bottom)
-------------------	---------------------------------

[Answer]

QoK

[Reference command]

1;9;RENUM100;0;0;0
QoK

[Related commands]

5.2.22 PDIR (Program directory)

[Function]

Read program directories.

[Format]

PDIR<Posi.>

<Posi.> The place read is specified.
TOP: First information
Value: Information at specified position

[Answer]

QoK<Program name>;<Size>;<DATE><TIME>;<Count>;<Remain size>;<Attrib>; <Line count>;<Position Count>;<Operation time>;<Latest tact>;<Avg.tact>;<Cycle count> or QoK<Program name>;<Size>;<DATE><TIME>;<Attrib>;<Line count>;<Position Count>; <Running>;<Latest tact>;<Avg.tact>;<Cycle count>

<Program name>	Program name
<Size>	Number of bytes used by program.
<DATE>	Last update date. (yy-mm-dd)
<TIME>	Last update time (hh:mm:ss)
<Count>	Program count in robot.
<Remain size>	Remain size of file system.
<Attrib>	Program attrib
<Line count>	Line count in program
<Position count>	Position count in program
<Operation time>	Operation time. (msec)
<Latest.tact>	Latest of tact time. (msec)
<Avg.tact>	Average of tact time. (msec)
<Cycle count>	Operation count

[Reference command]

1;1;PDIRTOP
QoK1.MB5;235;04-02-0519:31:28;34;105984;12;;2;0;115850;60;60;1903
1;1;PDIR1
QoK1.MB5;235;04-02-0519:31:28;12;;2;0;115850;60;60;1903

[Related commands]

FDIR

5.2.23FDIR (File directory)

[Function]

Read file directories.

[Format]

FDIR<Posi.>

<Posi.> The place read is specified.
TOP: First information
Value: Information at specified position
<*.*: First information for all files

[Answer]

QoK<File name>;<Size>;<DATE><TIME>;<Count>;<Remain size>;<Attrib> or QoK<File name>;<Size>;<DATE><TIME>;<Attrib>
--

<File name> File name
<Size> Number of bytes used by file.
<DATE> Last update date. (yy-mm-dd)
<TIME> Last update time (hh:mm:ss)
<Count> File count in robot.
<Remain size> Remain size of file system.
<Attrib> Program attrib

[Reference command]

1;1;FDIRTOP
QoK1.MB5;235;04-02-0519:31:28;46;105984;12
1;1;FDIR1
QoK1.MB5;235;04-02-0519:31:28;12
1;1;FDIR<*.*

QoK1.MB5;235;04-02-0519:31:28;46;105984;12
--

[Related commands]

PDIR

5.2.24FCHECK (File check)

[Function]

The existence of the file is confirmed.

[Format]

FCHECK<File name>

<File name>

The checked file is specified.

When the extension is omitted, it becomes MB5.

[Answer]

QoK<Status>

<Status>

N:Exist,F:No-exist

[Reference command]

1;1;FCHECK100

QoKN

[Related commands]

5.2.25FPATH= (File path)

[Function]

Get the save path name of the file.

[Format]

FPATH<File name>

<File name>

Specifies the file to obtain the path name.

When the extension is omitted, it becomes MB5.

[Answer]

QoK<File name>

< File name >

File name in the path name with

[Reference command]

1;1;FPATH=1.MB5

QoK/robprg/dat/1.MB5

[Related commands]

5.2.26FCOPY (File copy)

[Function]

The file is copied.

[Format]

FCOPY<Src.file>;<Dst.file>

<Src.file> Source file name is specified.

<Dst.file> Destination file name is specified.

When the extension is omitted, it becomes MB5.

[Answer]

QoK

[Reference command]

1;1;FCOPY1;2

QoK

[Related commands]

5.2.27FDEL (File delete)

[Function]

The file is deleted.

[Format]

FDEL<File name>

<File name> The deleted file is specified

When the extension is omitted, it becomes MB5.

[Answer]

QoK

[Reference command]

1;1;FDEL1
QoK

[Related commands]

5.2.28 FRENAME (File rename)

[Function]

The file name is renamed.

[Format]

FRENAME<Src.file>;<Dst.file>

<Src.file> Source file name is specified.

<Dst.file> Destination file name is specified.

When the extension is omitted, it becomes MB5.

[Answer]

QoK

[Reference command]

1;1;FRENAME1;2
QoK

[Related commands]

5.2.29 FATTRIB (File attribute)

[Function]

The attribute of the file is changed.

[Format]

FATTRIB<File name>;<Attrib>

<File name> File name

<Attrib> Attribute

+p:Read only lines

-p:Read and write lines

+q:Read only variable

-q:Read and write variable

[Answer]

QoK

[Reference command]

1;1;FATTRIB1;+p

QoK

[Related commands]

5.2.30 FINIT (File init)

[Function]

The file is initialized.

[Format]

FINIT

[Answer]

QoK

[Reference command]

1;1;FINIT

QoK

[Related commands]

5.2.31 FOPEN (File block open)

[Function]

The file is opened for the block reading and writing.

[Format]

FOPEN<File name>;<Mode>

<File name>

File name

<Mode>

w:Block write

r:Block read

[Answer]

QoK

[Reference command]

1;1;FOPEN1.MB5;r

QoK

[Related commands]

FCLOSE, FREAD, FWRITE

5.2.32FCLOSE (File block close)

[Function]

The file which does the block reading and writing is closed.

[Format]

FCLOSE

[Answer]

QoK

[Reference command]

1;1;FCLOSE

QoK

[Related commands]

FOPEN, FREAD, FWRITE

5.2.33FREAD (Block read)

[Function]

It block reads it from the file.

[Format]

FREAD

[Answer]

QoK<Contents>;<Continue>

<Contents>

The content of the file is returned with HEX ASCII.

<Continue>

1: There is a continuation data.

0: Continuation data none

[Reference command]

[illegible]

[Related commands]

FOPEN, FCLOSE, FWRITE

5.2.34 FWRITE (Block write)

[Function]

It blocks and it writes it in the file.

[Format]

FWRITE<Data size>;<Contents>

<Data size>	The size of the content is specified.
-------------	---------------------------------------

<Contents> The content is specified with HEX ASCII.

[Answer]

QoK

[Reference command]

[illegible]

[Related commands]

FOPEN, FCLOSE, FWRITE

5.2.35EFREE (Read file size)

[Function]

The size of the file system is read.

[Format]

EFREE

[Answer]

QoK<Total size>;<Used size>;<Use rate>
--

<Total size> Total sizes of file system.

<Used size> Used size.

<Use rate> Use rate. (%)

[Reference command]

1;1;EFREE

QoK125696;15616;12

[Related commands]

5.2.36ESEARCH (Search string)

[Function]

Find the specified string from the editing program.

[Format]

ESEARCH<String>

<String> Specify a search string.

[Answer]

QoK<Contents>;<Column>

<Contents> The content of the line.

<Column> Column of find a string.

[Reference command]

1;9;ESEARCHMov

QoK3 Mov P1;2

[Related commands]

5.2.37PRGLOAD= * (Program load)

[Function]

The program is loaded into the task slot.

[Format]

PRGLOAD=<Program name>

<Program name> Program name.

[Answer]

QoK

[Reference command]

1;1;PRGLOAD=100

QoK

[Related commands]

PRG<UP/DOWN>

5.2.38 PRG<UP/DOWN> * (Program select)

[Function]

The program of the task slot is selected.

[Format]

PRG<UP/DOWN>

<UP/DOWN>

Select UP or DOWN

[Answer]

QoK

[Reference command]

1;1;PRGUP

QoK

[Related commands]

PRGLOAD

5.2.39 PRGRD (Execution program name read)

[Function]

The program name of the task slot is read.

[Format]

PRGRD

[Answer]

QoK<Program name>

<Program name> Program name.

[Reference command]

1;1;PRGRD

QoK100.MB5

[Related commands]

5.2.40 LINENO= * (Execution line number change)

[Function]

The execution line number is changed.

[Format]

LINENO=<Line no.>

<Line no.> Line number

[Answer]

QoK

[Reference command]

1;1;LINENO=100

QoK

[Related commands]

LINENO

5.2.41 LINENO (Execution Line number read)

[Function]

The execution line number is read.

[Format]

LINENO

[Answer]

QoK<Line no.>

< Line no.>

Line number

[Reference command]

1;1;LINENO

QoK100

[Related commands]

LINENO=

5.2.42LINERD (Execution Line contents)

[Function]

The content of the line execution is read.

[Format]

LINERD

[Answer]

QoK<Contents>

<Contents>

The content of the line.

[Reference command]

1;1;LINERD

QoK10 MOV P1

[Related commands]

LINESRD

5.2.43LINESRD (Execution more Line contents)

[Function]

More content of the line under execution is read.

[Format]

LINESRD<Continue>;<Prev.line>;<Next line>

<Continue>	0:New read, 1:Continuous read
<Prev.line>	Previous line count of the execution line
<Next line>	Next line count of the execution line

[Answer]

QoK<Continue>;<Line count>;<Contents>[0b]< Contents >...];<Line no.>
--

<Continue>	1: There is a continuation line. 0: Continuation line none
<Line count>	The read count of lines
<Contents>	The content of the line.
<Line no.>	Execution line number

[Reference command]

1;1;LINESRD0;2;2

QoK0;5;10 '### Program ###[0b]20 [0b]30 *SMAIN[0b]40 MOV P0[0b]50 DLY 1;0010
--

[Related commands]

LINERD

5.2.44SRV<ON/OFF> * (Servo ON or OFF)

[Function]

The servo power supply is turned on and off.

[Format]

SRV<ON/OFF>

<ON/OFF>	Select ON or OFF
----------	------------------

[Answer]

QoK

[Reference command]

1;1;SRVON

QoK

[Related commands]

5.2.45 OVRD= * (OP override change)

[Function]

The OP override is changed.

[Format]

OVRD=<Override>

<Override>

The set override is specified by 1-100.

[Answer]

QoK<Override>

<Override>

The set override value is returned.

[Reference command]

1;1;OVRD=50

QoK50

[Related commands]

OVRD

5.2.46 OVRD (OP override read)

[Function]

The OP override is read.

[Format]

OVRD

[Answer]

QoK<Override>

<Override>

A present override value is read.

[Reference command]

1;1;OVRD

QoK50

[Related commands]

OVRD=

5.2.47 RUN * (Program start)

[Function]

The program is started.

[Format]

RUN[<Program name>;<Mode>]

<Program name> Program name

When omitting it, the program under the selection is started.

<Mode> 0:Repeat start

1:Cycle start

When omitting it, repeat start.

[Answer]

QoK

[Reference command]

1;1;RUN100;1

QoK

[Related commands]

STOP, CSTOP

5.2.48 STOP (STOP)

[Function]

The start is stopped.

[Format]

STOP

[Answer]

QoK

[Reference command]

1;1;STOP

QoK

[Related commands]

STOP<ON/OFF>,RUN

5.2.49 STOP<ON/OFF> (STOP ON or OFF)

[Function]

The start is stopped. After it STOPON it, it is not possible to start until the STOPOFF.

[Format]

STOP<ON/OFF>
<ON/OFF> Select ON or OFF

[Answer]

QoK

[Reference command]

1;1;STOPON
QoK

[Related commands]

STOP, CSTOP, RUN

5.2.50 CSTOP (Cycle STOP)

[Function]

The program under the start stops at the cycle.

[Format]

CSTOP

[Answer]

QoK

[Reference command]

1;1;CSTOP
QoK

[Related commands]

STOP, STOP<ON/OFF>, RUN

5.2.51 RSTALRM (Error reset)

[Function]

The error is reset.

[Format]

RSTALRM

[Answer]

QoK

[Reference command]

1;1;RSTALRM

QoK

[Related commands]

5.2.52 SLOTINIT (All program reset)

[Function]

The program resets all slots.

[Format]

SLOTINIT

[Answer]

QoK

[Reference command]

1;1;SLOTINIT

QoK

[Related commands]

RSTPRG

5.2.53 RSTPRG (Each program reset)

[Function]

The program resets a specified slot.

[Format]

RSTPRG

[Answer]

QoK

[Reference command]

1;1;RSTPRG

QoK

[Related commands]

SLOTINIT

5.2.54 RSTIO (Output signal reset)

[Function]

The general-purpose output signal is reset.

[Format]

RSTIO

[Answer]

QoK

[Reference command]

1;1;RSTIO

QoK

[Related commands]

5.2.55 MLOCK<ON/OFF> (Machine lock ON or OFF)

[Function]

The machine lock is set.

[Format]

MLOCK<ON/OFF>

<ON/OFF>

Select ON or OFF

[Answer]

QoK

[Reference command]

1;1;MLOCKON

QoK

[Related commands]

5.2.56HND<ON/OFF> (HAND open or close)

[Function]

The hand is opened and close.

[Format]

HND<ON/OFF><Hand no.>

<ON/OFF>

Select ON or OFF

<Hand no.>

Hand number 1-8 is specified.

[Answer]

QoK

[Reference command]

1;1;HNDON1

QoK

[Related commands]

5.2.57ALIGN * (Aligning the hand)

[Function]

Aligning the hand.

[Format]

ALIGN

[Answer]

QoK

[Reference command]

1;1;ALIGN
QoK

[Related commands]

5.2.58MOVSP * (MOVE safe position)

[Function]

It moves to the safe position (the parameter "JSAFE").

[Format]

MOVSP

[Answer]

QoK

[Reference command]

1;1;MOVSP
QoK

[Related commands]

5.2.59JOG * (JOG operation)

[Function]

The jog operates. If the command is not received between about 140msec, the jog operation is automatically stopped.

[Format]

JOG<Jog mode>;<Reserve>;<-Dire.>;<+Dire.>;<Inch>
--

<Jog mode>	00:JOINT 01:XYZ 02:TOOL 03:Reserve 04:3-axis XYZ 05:CYLNDER
<Reserve>	00:fix
<-Dire.>	The direction of operation is specified by the axis pattern.

<+Dire.>	00000000B	XYZ / JOINT
	_____1	X J1
	_____1_	Y J2
	_____1__	Z J3
	_____1___	A J4
	_____1____	B J5
	_____1_____	C J6
	_____1_____ 1_____	L1 J7
		L2 J8

<Inch>	00:Incing OFF
	01:Inching High
	02:Incing Low

[Answer]

QoK

[Reference command]

JOG01;00;01;00;00;00

QoK

[Related commands]

5.2.60 JOG * (JOG operation for Multifunctional Electric Hand)

[Function]

The jog operation for Multifunctional Electric Hand. If the command is not received between about 140msec, the jog operation is automatically stopped.

[Format]

JOG<Jog mode>;<Reserve>;<Speed>;<Force>;<Point No>

<Jog mode>	00000000B
	_____1 bit0
	_____1_ bit1
	_____1__ bit2
	_____1___ bit3
	_____1____ bit4
	_____1_____ bit5
	_____1_____ 1_____ bit6
	1_____ bit7

Bit0 to bit2 : Mode

000B : Origin setting (Equivalent to EHOrg command)
001B : Hand open (Equivalent to EHOpen command)
010B : Hand close (Equivalent to EHCclose command)
011B : Hand move (Equivalent to EHMov command)
100B : Hand hold (Equivalent to EHHold command)

<Reserve> 00:fix

<Speed> Specify the movement speed

The range of values is 01 to 64 (Hex).

<Force> Specify the holding force

The range of values is 01 to 64 (Hex).
 <Point No> Specify the point number
 The range of values is 00 to 20 (Hex).

[Answer]

QoK

[Reference command]

JOG44;00;46;32;0A

QoK

[Related commands]

5.2.61LS<ON/OFF> (Limit switch ON or OFF)

[Function]

The limit switch is turned on and off.

[Format]

LS<ON/OFF>

<ON/OFF>

Select ON or OFF

ON:LS enable, OFF:LS disable

[Answer]

QoK

[Reference command]

1;1;LSON

QoK

[Related commands]

5.2.62AUE<ON/OFF> (Program start enable or disable)

[Function]

The program start is made enable or disable..

[Format]

AUE<ON/OFF>

<ON/OFF>

Select ON or OFF

ON: Enable, OFF: Disable

[Answer]

QoK

[Reference command]

1;1;AUEON

QoK

[Related commands]

ATENA

5.2.63 ATENA (Status can be start)

[Function]

The state which can be started is read.

[Format]

ATENA

[Answer]

QoK<Status>

< Status >

0:Start enable, 1:Start disable

[Reference command]

1;1;ATENA

QoK1

[Related commands]

AUE<ON/OFF>

5.2.64 BRKPTSET (Set breakpoint)

[Function]

The breakpoint is set. It is not possible to set it while running.

[Format]

BRKPTSET=<Program name>;<Line number>;<Breakpoint type>

<Program name> Program name

<Line number> Breakpoint line number

< Breakpoint type > 0: Continues breakpoint, 1: One time breakpoint

When the plural is set to the same line, the breakpoint type set later is effective.

[Answer]

QoK

[Reference command]

1;1; BRKPTSET10;20;0

QoK1

[Related commands]

BRKPTCLR, BRKPTGET

5.2.65 BRKPTCLR (Delete breakpoint)

[Function]

The breakpoint is deleted.

[Format]

BRKPTCLR=<Program name>;<Line number>

<Program name> Program name

<Line number> Breakpoint line number

0 is all deleted.

[Answer]

QoK

[Reference command]

1;1; BRKPTCLR10;20

QoK1

[Related commands]

BRKPTSET, BRKPTGET

5.2.66 BRKPTGET (List breakpoint)

[Function]

The breakpoint lists is read.

[Format]

BRKPTGET=<Program name>;<Breakpoint number>;<Stat line>;<End line>
--

<Program name>

Program name

When the program name is omitted, it is all program.

< Breakpoint number>

Breakpoint number 1 to 128

<Start line>

Reading start line number

<End line>

Reading end line number

[Answer]

QoK<Program name>;<Line number>;<Breakpoint type>

<Program name> Program name

<Line number> Breakpoint line number

<Breakpoint type> 0: Continues breakpoint, 1: One time breakpoint

[Reference command]

1;1; BRKPTSET

QoK1

[Related commands]

BRKPTSET, BRKPTCLR

5.2.67 TOOLSET (Set Tool number)

[Function]

The tool number is set.

[Format]

TOOLSET=<Tool number>

<Tool number>

Tool number (0 to 16)

[Answer]

QoK

[Reference command]

1;1;TOOLSET2

QoK

[Related commands]

TOOLRD

5.2.68 TOOLRD (Read Tool number)

[Function]

The tool number is read.

[Format]

TOOLRD

[Answer]

QoK<Tool number>

<Tool number> Tool number (0 to 16)

[Reference command]

1;1;TOOLRD

QoK2

[Related commands]

TOOLSET

5.2.69 SAFE= (Low speed mode)

[Function]

Set low speed operation mode.

[Format]

SAFE=<1/0>

[Answer]

QoK<Tool number>

<1/0> 1: Setting valid or 0: setting invalid

[Reference command]

1;1;SAFE=1

QoK2

[Related commands]

5.2.70 STATE (Read run status)

[Function]

The run state is read.

[Format]

STATE

[Answer]

QoK< Program name >;<Line no.>;<Override>;<Edit sts.>;<Run sts.>;<Stop sts.>;<Error no.>;
 <Step no.>;<Mech info.>;<Task prg.name>;<Task mode>;<Task cond.>;
 <Task pri.>;<Mech no.>

<Program name>	Program name loaded into task slot
<Line no.>	Execution line number
<Override>	A present override value is read.
<Edit sts.>	Edit status 00000000B _____1 Editing _____1 Running _____1 Changed
<Run sts.>	Run status by 2 HEX number fixation 00000000B 0 / 1 _____1 Cycle / Repeat _____1 Cycle stop ON / OFF _____1 MLOCK OFF / ON _____1 Auto / Teach _____1 Running of Teach mode _____1 Servo OFF / ON _____1 STOP / RUN _____1 Operation disable / enable
<Stop sts.>	Stop status by 2 HEX number fixation 00000000B _____1 EMG STOP _____1 STOP _____1 WAIT _____1 STOP signal ON / OFF _____1 Program select enable _____1 (reserve) _____1 Pseudo input
<Error no.>	Error number. (0:No error)
<Step no.>	Execution step number
<Mech info.>	00000000B _____1 Mech 1 _____1 Mech 2 _____1 Mech 3
<Task prg.name>	Program name of slot table.
<Task mode>	Operation mode of slot table. (REP/CYC)
<Task cond.>	Stating conditions of slot table. (START/ALWAYS/ERROR)
<Task pri.>	Priority of slot table. (1 – 31)

<Mech no.> Mech number under use

[Reference command]

1;1;STATE
Qok2.MB5;100;100;5;A1124220;1;1;;;;;;;;;REP;START;1;0

[Related commands]

5.2.71 DSTATE (Read stop status)

[Function]

The stop state is read.

[Format]

DSTATE

[Answer]

QoK<Run sts.><Stop sts.><Error no.>;<Step no.>;<Mech no.>

<Run sts.>	Run status by 2 HEX number fixation 00000000B 0 / 1 ____1 Cycle / Repeat ____1_ Cycle stop ON / OFF ____1_ MLOCK OFF / ON ____1_ Auto / Teach __1____ Running of Teach mode __1____ Servo OFF / ON _1_____ STOP / RUN 1_____ Operation disable / enable
<Stop sts.>	Stop status by 2 HEX number fixation 00000000B ____1 EMG STOP ____1_ STOP ____1_ WAIT ____1_ STOP signal ON / OFF __1____ Program select enable __1____ (reserve) _1_____ Pseudo input
<Error no.>	Error number. (0:No error)
<Step no.>	Execution step number
<Mech no.>	Mech number under use

[Reference command]

1;1;DSTATE
QoK09060;17;1

[Related commands]

5.2.72 CALIB (Install status)

[Function]

The install status is read.

[Format]

CALIB

[Answer]

QoK<Status><Axis pattern><Reserve>

<Status>	Install status (N:Defined、F:Not defined)
<Axis pattern>	Completion axis pattern by 2 HEX number fixation
	00000000B
_____1	J1
_____1_	J2
_____1_	J3
_____1_	J4
_____1_	J5
_____1_	J6
_____1_	J7
1_____	J8

[Reference command]

1;1; CALIB

QoKN3F3F

[Related commands]

5.2.73 IOSIGNAL (Input and output signal read)

[Function]

The state of the input signal and the state of the output signal are read.

[Format]

IOSIGNAL<IN no.>;<OUT no.>

<IN no.>	Input signal number.
<OUT no.>	Output signal number.

[Answer]

QoK<IN state><OUT state>

<IN state>	Input signal state by 4 HEX number fixation
<OUT state>	Output signal state by 4 HEX number fixation

[Reference command]

1;1;IOSIGNAL0;0

QoK00000002

[Related commands]

5.2.74 IN (Input signal read)

[Function]

The state of the input signal is read.

[Format]

IN<IN no.>

<IN no.>

Input signal number.

[Answer]

QoK<IN state>

<IN state>

Input signal state by 4 HEX number fixation

[Reference command]

1;1;IN0

QoK0000

[Related commands]

5.2.75 OUT (Output signal read)

[Function]

The state of the output signal is read.

[Format]

OUT<OUT no.>

<OUT no.>

Output signal number.

[Answer]

QoK<OUT state>

<OUT state>

Output signal state by 4 HEX number fixation

[Reference command]

1;1;OUT0
QoK0001

[Related commands]

5.2.76OUT= (Output signal write)

[Function]

The output signal is compelling output.

[Format]

OUT=<OUT no.>;<OUT val.>	
<OUT no.>	Output signal number.
<OUT val.>	Output signal value by 4 HEX number fixation

[Answer]

QoK

[Reference command]

1;1;OUT=0;0802
QoK

[Related commands]

5.2.77DIN (CC-Link's input register data read)

[Function]

The state of the CC-Link's input register is read. It is effective only to install the CC-Link option.

[Format]

DIN<IN no.>	
<IN no.>	CC-Link's input register number.

[Answer]

QoK<IN reg.state>;...(16 pieces)	
<IN reg.state>	The input register is returned by the DEC.

[Reference command]

1;1;DIN6000
QoK0;0;0;0;0;0;0;0;0;0;0;0;0;0;0;0

[Related commands]

DOUT

5.2.78 DOUT (CC-Link's output register data read)

[Function]

The state of the CC-Link's output register is write. It is effective only to install the CC-Link option.

[Format]

DOUT<OUT no.>
<OUT no.> CC-Link's output register number.

[Answer]

QoK<OUT reg.state>;... (16 pieces)
<OUT reg.state> The output register is returned by the DEC.

[Reference command]

1;1;DOUT6000
QoK0;0;0;0;0;0;0;0;0;0;0;0;0;0;0;0

[Related commands]

DIN

5.2.79 DOUT= (CC-Link's output register data write)

[Function]

The CC-Link's output register is compelling output. It is effective only to install the CC-Link option

[Format]

DOUT=<OUT no.>;<OUT val.>
<OUT no.> CC-Link's output register number.
<OUT val.> Output register value by 4 HEX number fixation

[Answer]

QoK

[Reference command]

1;1;DOUT=6000;0002

QoK

[Related commands]

DIN, DOUT

5.2.80 INDMY (Set pseudo input)

[Function]

A pseudo-input of the input signal is set.

[Format]

INDMY

[Answer]

QoK

[Reference command]

1;1;INDMY

QoK

[Related commands]

INSET, IN=, DIN=

5.2.81 INSET (Reset pseudo input)

[Function]

A pseudo-input of the input signal is reset.

[Format]

INSET

[Answer]

QoK

[Reference command]

1;1;INSET

QoK

[Related commands]

INDMY, IN=, DIN=

5.2.82 IN= (Write pseudo input data)

[Function]

The input signal is pseudo-input.

[Format]

IN=<IN no.>;<IN val.>

<IN no.> Input signal number.

<IN val.> Pseudo-input signal value by 4 HEX number fixation

[Answer]

QoK

[Reference command]

1;1;IN=0;0802

QoK

[Related commands]

INDMY, INSET, DIN=

5.2.83 DIN= (Write pseudo input register)

[Function]

The CC-Link's input register is pseudo-input. It is effective only to install the CC-Link option.

[Format]

DIN=<IN no.>;<IN reg.val>

<IN no.> Input register number.

<IN reg.val> Pseudo-input register value by 4 HEX number fixation

[Answer]

QoK

[Reference command]

1;1;DIN=6000;0001

QoK

[Related commands]

INDMY, INSET, IN=

5.2.84STPSIG (Stop signal read)

[Function]

The state of the stop signal is read.

[Format]

STPSIG

[Answer]

QoK<Stop sts.>;<EMG sts.>

<Stop sts.>

The state of the stop signal is returned by the HEX.

00000000B

_____1 T/B(RS-422)

_____1_ P/C(RS-232C)

_____1_ I/O

_____1_ O/P

<EMG sts.>

The state of the EMG stop signal is returned by the HEX.

00000000B

_____1 I/O EMG

_____1_ O/P EMG

_____1_ T/B EMG

[Reference command]

1;1;STPSIG

QoK0;0

[Related commands]

5.2.85HNDSTS (Hand output signal read)

[Function]

The setting and the output of the hand are read.

[Format]

HNDSTS

[Answer]

QoK<Output no.>;<Hand sts.>;<ハンドタイプ>;... (8 pieces)

<Output no.>	Signal number allocated in hand. -1:not used
<Hand sts.>	Hand output status. (1:Hand open, 2:Hand close)
<Hand type>	Hand type (0:Single-solenoid, 1:Double-solenoid)

[Reference command]

1;1;HNDSTS

QoK900;2;1;902;1;1;904;1;1;906;1;1;-1;-1;-1;-1;-1;-1;-1;-1;-1;-1;-1

[Related commands]

5.2.86USERAREASTS (User specified area read)

[Function]

The state of the user specified area is read.

[Format]

USERAREASTS

[Answer]

QoK<Status>

<Status>	The state of the user specified area by the HEX.
	00000000B
_____1	Area 1
_____1_	Area 2
_____1__	Area 3
_____1___	Area 4
_____1____	Area 5
_____1_____	Area 6
_____1_____ _____1_____	Area 7
_____1_____	Area 8

[Reference command]

1;1;USERAREASTS

QoK0

[Related commands]

5.2.87JPOS,PPOS,XPOS,RPOS (Current position read)

[Function]

The current position of the robot is read.

[Format]

<Type>POS<Axis info.>

<Type> Type at read position
 J:JOINT, P:XYZ, X:3axis-XYZ, R:CYLNDER
 <Axis info.> Read axis (1 – 8:Single axis, F:Full axis)

[Answer]

QoK<Axis name>;<Axis data>;... (Repeat axis number)
 ;<Flag1>;<Flag2>;<Override>;<End speed>;<+Limit><-Limit><reserve>

<Axis name> Name of axis
 <Axis data> Data of axis
 <Flag1> Structure flag 1 and 2.
 <Flag2> Only XYZ is significant.
 <Override> A present override value is read.
 <End speed> Speed in robot end. (mm/sec)
 <+Limit> Limit status by 2 HEX number fixation.
 <-Limit> 00000000B XYZ / JOINT
 _____1 X J1
 _____1_ Y J2
 _____1_ Z J3
 _____1_ A J4
 _____1_ B J5
 _____1_ C J6
 _____1_ L1 J7
 1_____ L2 J8

[Reference command]

1;1;PPOSF

QoKX;290.62;Y;-0.09;Z;11.26;A;-179.94;B;-0.26;C;179.93;L1;0.00;;6,0;100;0.00;00000000

[Related commands]

5.2.88GJPOS,GPPOS (Destination position read)

[Function]

The current position of the robot is read.

[Format]

G<Type>POS<Axis info.>

<Type> Type at read position
 J:JOINT, P:XYZ

<Axis info.> Read axis (1 – 8:Single axis, F:Full axis)

[Answer]

QoK<Axis name>;<Axis data>;... (Repeat axis number)
 ;<Flag1>;<Flag2>;<Override>;<End speed>;<+Limit><-Limit><reserve>

<Axis name>	Name of axis	
<Axis data>	Data of axis	
<Flag1>	Structure flag 1 and 2.	
<Flag2>	Only XYZ is significant.	
<Override>	A present override value is read.	
<End speed>	Speed in robot end. (mm/sec)	
<+Limit>	Limit status by 2 HEX number fixation.	
<-Limit>	00000000B	XYZ / JOINT
	_____1	X J1
	_____1_	Y J2
	_____1__	Z J3
	_____1___	A J4
	_____1____	B J5
	_____1_____	C J6
	_____1_____ _1_____	L1 J7
	_____1_____ 1_____	L2 J8

[Reference command]

1;1;GPPOSF
 QoKX;290.62;Y;-0.09;Z;11.26;A;-179.94;B;-0.26;C;179.93;L1;0.00;;6,0;100;0.00;00000000

[Related commands]

5.2.89TIME (Time read)

[Function]

Time is read.

[Format]

TIME

[Answer]

QoK<DATE><TIME>

<DATE>	DATE (yy-mm-dd)
<TIME>	TIME (hh:mm:ss)

[Reference command]

5.2.93 CYCLETIME (Cycle time read)

[Function]

The operating time of the program is read.

[Format]

CYCLETIME<Program name>

<Program name> Program name

[Answer]

QoK<Operation time>;<Latest tact>;<Avg.tact>;<Cycle count>
--

<Operation time> Operation time. (msec)

<Latest.tact> Latest of tact time. (msec)

<Avg.tact> Average of tact time. (msec)

<Cycle count> Operation count

[Reference command]

1;1;CYCLETIME100

QoK224745;156;154;1454

[Related commands]

PDIR, CYCLECLR

5.2.94 CYCLECLR (Cycle time clear)

[Function]

The operating time of the program is cleared.

[Format]

CYCLECLR<Program name>

<Program name> Program name

[Answer]

QoK

[Reference command]

1;1;CYCLECLR100

QoK

[Related commands]

PDIR, CYCLETIME

5.2.95ERROR (Error number read)

[Function]

The error number is read.

[Format]

ERROR

[Answer]

QoK[<Error no.>;<Error level>]

<Error no.>

Error number

When the error does not occur, only QoK is returned.

<Error level>

Error level (1:High, 2:Low, 3:Caution)

[Reference command]

1;1;ERROR

Qok4140;2

[Related commands]

ERRORMES

5.2.96ERRORMES (Error contents read)

[Function]

The content of the error is read.

[Format]

ERRORMES<Error no.>

<Error no.>

Error number

[Answer]

QoK<Contents>

<Contents>

Content of the error.

[Reference command]

1;1;ERRORMES4140

QoKThe program was not found

[Related commands]

ERROR

5.2.97ERRORLOG (Error history read)

[Function]

The error history is read.

[Format]

ERRORLOG<Hist.no.>

<Hist.no.> Position of history
TOP: The newest history
END: The oldest history
+1: Previous history
-1: Next history

[Answer]

QoK<DATE>;<TIME>;<Error no.>;<Error contents>;<Error level>;<Program name >;
<Line no.>;<Error detail no.>

<DATE> Date when error occurs (yy-mm-dd)
<TIME> Time when error occurs (hh:mm:ss)
<Error no.> Error number
<Error contents> Content of the error
<Error level> Error level
1:High,2:Low,3:Caution
<Program name> Program name when error occurs
<Line no.> Line number when error occurs
<Error detail no.> Error detail number
Only QoK is returned when there is no error history.

[Reference command]

1;1;ERRORLOGTOP

QoK04-02-09;18:49:52;4140;The program was not found;2;S1;0;414000000

[Related commands]

ERRLOGCLR, ERRLOG2=

5.2.98ERRLOG2= (Error history reading. / Error details number narrowing seeing.)

[Function]

It narrows by the error level and error details number, and error history information is read.

(It is not possible to use by the CRn-500 series.)

(It is possible to use since the edition of main S/W of the CRnQ-700/CRnD-700 series version R2/S2.)

[Format]

ERRLOG2=<Hist. No.>;<Error level >;<Error details number>

<Hist. No.> Position of history

TOP: The newest history

END: The oldest history

+1: Previous history

-1: Next history

<Error level> Error level (The range of the extraction is narrowed.)

0:All level, 1:High, 2: Low, 3:Caution, 0 when omitting it

When < history number > is "+" and "-" specification, the last specification is used.

<Error details number> Narrowed error details number (6-9 digit).

[Answer]

QoK<DATE>;<TIME>;<Error no.>;<Error contents>;<Error level>;<Program name >; <Line no.>;<Error detail no.>

<DATE> Date when error occurs (yy-mm-dd)

<TIME> Time when error occurs (hh:mm:ss)

<Error no.> Error number

<Error contents> Content of the error

<Error level> Error level

1:High,2:Low,3:Caution

<Program name> Program name when error occurs

<Line no.> Line number when error occurs

<Error detail no.> Error detail number

Only QoK is returned when there is no error history.

[Reference command]

1;1;ERRLOG2=TOP;0;414000000

QoK04-02-09;18:49:52;4140;The program was not found;2;S1;0;414000000
--

[Related commands]

ERRLOGCLR, ERRORLOG

[Note]

When "+" and "-" are specified for < history number >, referring the last positional and last reference error number is used common of the communication command "ERRORLOG" and "ERRORRD".

5.2.99ERRLOGCLR (Error history clear)

[Function]

The error history is cleared.

[Format]

ERRLOGCLR<Error level>

<Error level>

Error level

1:High,2:Low,3:Caution,0:All

[Answer]

QoK

[Reference command]

1;1;ERRLOGCLR1

QoK

[Related commands]

ERRLOG

5.2.100 ERRSUM (Error summary)

[Function]

The error summary data is read.

[Format]

ERRSUM<No.>

<No.>

number (1-100)

(in numerical order)

[Answer]

QoK<Number of errors>;<Detailed error number>;<Error level>;<Error contents>;<Cause>; <Treat>;<Count of error >
--

<Number of errors>

Number of error total data

<Detailed error number>	Detailed error number
	"000000000" is returned when there is no error history.
<Error level>	Error level (H:High, L:Low, C:Caution) *
<Error contents>	Error contents*
<Cause>	Error cause *
<Treat>	Error treat *
<Count of error >	Count of error generation

* Note : ""(NULL) is returned when there is no error history.

[Reference command]

1;1;ERRSUM1
QoK4;006000000;H; EMG signal is input. (O.Panel); EMG signal is input. (O.Panel); Check the O.Panel emergency stop;4
1;1;ERRSUM5
QoK4;000000000;;;;;0

[Reference command]

ERRSUMCLR, SUMDATE, ERRSUM2=

5.2.101 ERRSUM2= (error summary)

[Function]

The error summary data is read.

(It is not possible to use by the CRn-500 series.)

(It is possible to use since the edition of main S/W of the CRnQ-700/CRnD-700 series version R2/S2.)

[Format]

ERRSUM2=<Hist. no.>
<Hist.no.> number (1-100) (in numerical order)

[Answer]

QoK<Number of errors>;<Detailed error number>;<Error level>;<Error contents>;<Cause>;<Treat>;<Count of error >;<date>;<time>
--

<Number of errors>	Number of error total data
<Detailed error number>	Detailed error number
	"000000000" is returned when there is no error history.
<Error level>	Error level (H:High, L:Low, C:Caution) *

<Error contents>	Error contents*
<Cause>	Error cause *
<Treat>	Error treat *
<Count of error >	Count of error generation
<date>	The last date when error occurred.
<time>	The last time when error occurred.

* Note : ""(NULL) is returned when there is no error history.

[Reference command]

1;1;ERRSUM2=1
QoK4;006000000;H; EMG signal is input. (O.Panel); EMG signal is input. (O.Panel); Check the O.Panel emergency stop;4;10-08-19;18:49:52
1;1;ERRSUM5
QoK4;000000000;;;;;0;;

[Reference command]

ERRSUMCLR, SUMDATE, ERRSUM

5.2.102 ERRSUMCLR (Clear error summary)

[Function]

The error summary is cleared.

[Format]

ERRLOGCLR

[Answer]

QoK

[Reference command]

1;1;ERRLOGCLR
QoK

[Reference command]

ERRSUM, ERRSUM2=

5.2.103 SUMDATE (Date when error logging function began)

[Function]

The beginning date of the error logging function (error log / error summary) is read.

[Format]

SUMDATE<function no.>

<function no.>	Data of the acquired beginning date is specified.
0:	Error log function
1:	Error summary function

[Answer]

QoK<date>;<time >

<date>	Date when data acquisition was begun (yy-mm-dd)
<time>	Tiem when data acquisition was begun (hh:mm:ss)

[Reference command]

1;1;SUMDATE0

QoK10-08-09;20:23:46

[Reference command]

ERRLOGCLR, ERRSUMCLR

5.2.104 VAL (Variable data read)

[Function]

The value of the variable is read.

[Format]

VAL<Variable posi.>;<Class>

<Variable posi.>	The read position is specified.
<:	Top variable
>:	Bottom variable
+1:	Next variable
-1:	Previous variable
	Variable name: Specified Variable
<Class>	Variable class
	(M: Integer, C: Character, P: Position, J: JOINT)

[Answer]

QoK<Variable name>=<Value>

<Variable name> Variable name

<Value> Value of the variable

[Reference command]

1;1;VAL<;M

QoKM1=+3

[Related commands]

VALS

5.2.105 VALS (More Variable data read)

[Function]

The value of more variables is read.

[Format]

VALS<Variable posi.>;<Class>

<Variable posi.> The read position is specified.

<: Top variable

>: Bottom variable

+1: Next variable

-1: Previous variable

<Class> Variable class

(M: Integer, C: Character, P: Position, J:JOINT)

[Answer]

QoK<Variable name>=<Value>[0b]<Variable name>=<Value>...];<Count>;<Continue>
--

<Variable name> Variable name

<Value> Value of the variable

<Count> Count of read variables

<Continue> 1: There is a continuation variable.

0: Continuation variable none

[Reference command]

1;1;VALS<;M

QoKM1=+1;0bM2=+2;0bM3=+3;3;0

[Related commands]

VAL

5.2.106 GVAL (Global variable data read)

[Function]

The value of the global variable is read.

[Format]

GVAL<Variable posi.>;<Class>

<Variable posi.> The read position is specified.

<: Top variable

>: Bottom variable

+1: Next variable

-1: Previous variable

Variable name: Specified Variable

<Class>

Variable class

(M: Integer, C: Character, P: Position, J: JOINT)

[Answer]

QoK<Variable name>=<Value>

<Variable name> Variable name

<Value> Value of the variable

[Reference command]

1;1;GVAL<;M

QoKM_01=+3

[Related commands]

GVALS

5.2.107 GVALS (More Variable data read)

[Function]

The value of more global variables is read.

[Format]

GVALS<Variable posi.>;<Class>

<Variable posi.> The read position is specified.

<: Top variable
 >: Bottom variable
 +1: Next variable
 -1: Previous variable
 <Class> Variable class
 (M: Integer, C: Character, P: Position, J:JOINT)

[Answer]

QoK<Variable name>=<Value>[0b<Variable name>=<Value>...];<Count>;<Continue>

<Variable name> Variable name
 <Value> Value of the variable
 <Count> Count of read variables
 <Continue> 1: There is a continuation variable.
 0: Continuation variable none

[Reference command]

1;1;GVALS<;M

QoKM_01=+1;0bM_02=+2;0bM_03=+3;3;0

[Related commands]

GVAL

5.2.108 HOT (Variable data write)

[Function]

The value of the variable is changed. A integer variable is revocable while even starting.

[Format]

HOT<Program name>;<Variable name>=<Value>

<Program name> Program name
 <Variable name> Variable name
 <Value> Changed value

[Answer]

QoK

[Reference command]

1;1;HOT100;M1=1

QoK

[Related commands]

5.2.109 OPNUMRD (Option slot number read)

[Function]

The number of option slots is read.

[Format]

OPNUMRD

[Answer]

QoK<Slot no.>

<Slot no.> Number of option slots.

[Reference command]

1;1;OPNUMRD
QoK3

[Related commands]

OPSTSRD

5.2.110 OPSTSRD (Option information read)

[Function]

Option slot information is read.

[Format]

OPSTSRD<Slot no.>

<Slot no.> Number of option slots. (1,2 or 3)

[Answer]

QoK<Option info.>

<Option info.> Option information

[Reference command]

1;1;OPSTSRD
QoKEthernet;IP Addr 192.168.0.1 bb PortNo(R-time) 10000 bb

PortNo(OPT11-19) 10001/10002/10003/10004/10005/10006/10007/10008/10009**0b**
Connect Count(OPT11-19) 2/0/0/0/0/0/0/0/0**0b** MAC Addr 00:00:00:00:00:00**0b** H/W Ver: 0

[Related commands]

OPSTSRD

5.2.111 THMRD (Controller temperature read)

[Function]

Read the temperature internal the controller.

[Format]

THMRD

[Answer]

QoK<Temperature>

<Temperature>

Temperature internal the controller

[Reference command]

1;1;THMRD

QoK39.5

[Related commands]

ETEMP

5.2.112 ETEMP (Encoder temperature read)

[Function]

Read the temperature the encoder.

[Format]

ETEMP

[Answer]

QoK<J1 Temperature>;<J2 Temperature>;<J3 Temperature>;<J4 Temperature>;
<J5 Temperature>;<J6 Temperature>;<J7 Temperature>;<J8 Temperature>;
<J1 Max.Temperature >;<J2 Max.Temperature>;<J3 Max.Temperature>;
<J4 Max.Temperature>;<J5 Max.Temperature>;<J6 Max.Temperature>;
<J7 Max.Temperature>;<J8 Max.Temperature>

<code><Jn Temperature></code>	Temperature the encoder (n indicate the axis no.)
<code><Jn Max.Temperature></code>	Maximum value of the temperature of the encoder after power ON (n indicate the axis no.)

[Reference command]

1;1;ETEMP
QoK38;39;41;39;36;36;0;0;41;42;44;41;38;37;0;0

[Related commands]

THMRD

5.2.113 EMISS (Encoder miscount read)

[Function]

Read the miscount the encoder.

[Format]

EMISS

[Answer]

QoK<J1 Miscount>;<J2 Miscount >;<J3 Miscount >;<J4 Miscount >; <J5 Miscount >;<J6 Miscount >;<J7 Miscount >;<J8 Miscount >

<code><Jn Temperature></code>	Miscount the encoder (n indicate the axis no.)
-------------------------------------	--

[Reference command]

1;1;EMISS
QoK0;1;1;0;0;0;0;0

[Related commands]

5.2.114 SRVENC (Servo encoder read)

[Function]

Data concerning the position of each axis motor can be monitored.

[Format]

SRVENC

[Answer]

QoK<J1 pos. feedback>;<J1 pos. in 1 rot.>;<J1 Fdt command>;<J1 pos. command>;
 <J2 pos. feedback >;<J2 pos. in 1 rot.>;<J2 Fdt command>;<J2 pos. command>;
 <J3 pos. feedback>;<J3 pos. in 1 rot.>;<J3 Fdt command>;<J3 pos. command>;
 <J4 pos. feedback>;<J4 pos. in 1 rot.>;<J4 Fdt command>;<J4 pos. command>;
 <J5 pos. feedback >;<J5 pos. in 1 rot.>;<J5 Fdt command>;<J5 pos. command>;
 <J6 pos. feedback >;<J6 pos. in 1 rot.>;<J6 Fdt command>;<J6 pos. command>;
 <J7 pos. feedback>;<J7 pos. in 1 rot.>;<J7 Fdt command>;<J7 pos. command>;
 <J8 pos. feedback>;<J8 pos. in 1 rot.>;<J8 Fdt command>;<J8 pos. command>

<Jn pos. feedback>	Position feedback the encoder (n indicate the axis no.)
<Jn pos. in 1 rot.>	Position in 1 rotation the encoder (n indicate the axis no.)
<Jn Fdt command>	Fdt command the encoder (n indicate the axis no.)
<Jn pos. command>	Position command the encoder (n indicate the axis no.)

[Reference command]

1;1;SRVENC
QoK-4475890;0;0;-4487192;4912356;0;0;4892959;10225275;0;0;10323293;-940046;0;0;-947494;-3330789;0;0;-3358040;6508941;0;0;6502064;0;0;0;0;0;0

[Related commands]

5.2.115 SRVDRP (Servo droop read)

[Function]

Data concerning the droop of each axis motor can be monitored.

[Format]

SRVDRP

[Answer]

QoK<J1 pos. droop>;<J1 max. pos. droop>;<J2 pos. droop>;<J2 max. pos. droop>; <J3 pos. droop>;<J3 max. pos. droop>;<J4 pos. droop>;<J4 max. pos. droop>; <J5 pos. droop>;<J5 max. pos. droop>;<J6 pos. droop>;<J6 max. pos. droop>; <J7 pos. droop>;<J7 max. pos. droop>;<J8 pos. droop>;<J8 max. pos. droop>
--

<Jn pos. droop>	Position droop the encoder (n indicate the axis no.)
<Jn max. pos. droop>	Maximum position droop the encoder (n indicate the axis no.)

[Reference command]

1;1;SRVDRP
QoK16860;1525531;22463;-1686967;126622;-543044;-11984;-318476;36426;2421963;9865;-2205319;0;0;0;0

[Related commands]

5.2.116 SRVSPD (Servo speed read)

[Function]

The following data concerning the rotational speed of each axis motor can be monitored.

[Format]

SRVSPD

[Answer]

QoK<J1 spd. feedback>;<J1 speed max.>;<J1 speed command>; <J2 spd. feedback>;<J2 speed max.>;<J2 speed command>; <J3 spd. feedback>;<J3 speed max.>;<J3 speed command>; <J4 spd. feedback>;<J4 speed max.>;<J4 speed command>; <J5 spd. feedback>;<J5 speed max.>;<J5 speed command>; <J6 spd. feedback>;<J6 speed max.>;<J6 speed command>; <J7 spd. feedback>;<J7 speed max.>;<J7 speed command>; <J8 spd. feedback>;<J8 speed max.>;<J8 speed command>
--

<Jn spd. feedback>	Speed feedback the encoder (n indicate the axis no.)
<Jn speed max.>	Speed maximum the encoder (n indicate the axis no.)
<Jn speed command>	Speed command the encoder (n indicate the axis no.)

[Reference command]

1;1;SRVSPD
QoK16;3755;68;29;-4148;115;147;-1150;-587;-11;-783;45;41;5964;163;10;-5429;41;0;0;0;0;0

[Related commands]

5.2.117 SRVCUR (Servo current read)

[Function]

Data concerning the current value of each axis motor can be monitored.

[Format]

SRVCUR<type>

<type>

Read type (0:command, 1:feedback)

[Answer]

type1

QoK<J1 cur. feedback>;<J1 max. curr. cmd1>;<J1 max. curr. cmd2>;
 <J2 cur. feedback>;<J2 max. curr. cmd1>;<J2 max. curr. cmd2>;
 <J3 cur. feedback>;<J3 max. curr. cmd1>;<J3 max. curr. cmd2>;
 <J4 cur. feedback>;<J4 max. curr. cmd1>;<J4 max. curr. cmd2>;
 <J5 cur. feedback>;<J5 max. curr. cmd1>;<J5 max. curr. cmd2>;
 <J6 cur. feedback>;<J6 max. curr. cmd1>;<J6 max. curr. cmd2>;
 <J7 cur. feedback>;<J7 max. curr. cmd1>;<J7 max. curr. cmd2>;
 <J8 cur. feedback>;<J8 max. curr. cmd1>;<J8 max. curr. cmd2>

<Jn cur. feedback>

Current feedback the encoder (n indicate the axis no.)

<Jn max. curr. cmd1>
 axis no.)

Maximum current command the encoder (n indicate the

<Jn max. curr. cmd2>
 axis no.)

Maximum current command the encoder (n indicate the

type0

QoK<J1 cur. command>;<J1 tolerable cmd+>;<J1 tolerable cmd->;<J1 RMS Current>;
 <J2 cur. command >;<J2 tolerable cmd+>;<J2 tolerable cmd->;<J2 RMS Current>;
 <J3 cur. command >;<J3 tolerable cmd+>;<J3 tolerable cmd->;<J3 RMS Current>;
 <J4 cur. command >;<J4 tolerable cmd+>;<J4 tolerable cmd->;<J4 RMS Current>;
 <J5 cur. command >;<J5 tolerable cmd+>;<J5 tolerable cmd->;<J5 RMS Current>;
 <J6 cur. command >;<J6 tolerable cmd+>;<J6 tolerable cmd->;<J6 RMS Current>;
 <J7 cur. command >;<J7 tolerable cmd+>;<J7 tolerable cmd->;<J7 RMS Current>;
 <J8 cur. command >;<J8 tolerable cmd+>;<J8 tolerable cmd->;<J8 RMS Current>

<Jn cur. command>

Current command the encoder (n indicate the axis no.)

<Jn tolerable cmd+>

tolerable command+ the encoder (n indicate the axis no.)

<Jn tolerable cmd->

tolerable command- the encoder (n indicate the axis no.)

<Jn RMS Current>

RMS Current the encoder (n indicate the axis no.)

[Reference command]

1;1;SRVCUR1

QoK-0.42;0.49;3.30;0.80;1.73;2.63;-0.57;0.67;0.83;0.24;0.24;0.86;0.13;0.39;0.87;-0.24;0.24;0.93;0.00;0.00;0.00;0.00;0.00;0.00

[Related commands]

5.2.118 SRVLCR (Servo load current)

[Function]

The load state of each axis motor and the temperature of the encoder can be monitored.

[Format]

SRVLCR

[Answer]

QoK<J1 load level>;<J1 max. load level>;<J2 load level>;<J2 max. load level>; <J3 load level>;<J3 max. load level>;<J4 load level>;<J4 max. load level>; <J5 load level>;<J5 max. load level>;<J6 load level>;<J6 max. load level>; <J7 load level>;<J7 max. load level>;<J8 load level>;<J8 max. load level>
--

<Jn load level>

Load level the encoder (n indicate the axis no.)

<Jn max. load level>

Maximum load level the encoder (n indicate the axis no.)

[Reference command]

1;1;SRVLCR

QoK3.00;3.00;35.00;35.00;30.00;30.00;14.00;14.00;32.00;32.00;8.00;8.00;0.00;0.00;0.00;0.0
0

[Related commands]

5.2.119 SRVVOL (Servo voltage)

[Function]

The following data concerning robot controller's main circuit power supply can be monitored.

[Format]

SRVVOL

[Answer]

QoK<Power voltate>;<Power voltate (max)>;< Power voltate(min) >; <J1 regen. level>;<J2 regen. level>;<J3 regen. level>;<J4 regen. level>; <J5 regen. level>;<J6 regen. level>;<J7 regen. Level>;<J8 regen. level>

<Power voltate >

Power voltage the encoder

<Power voltate (max)>	Power voltage the encoder
<Power voltate (min)>	Power voltage the encoder
<Jn regen. level >	Regeneration level the encoder (n indicate the axis no.)

[Reference command]

1;1;SRVVOL
QoK0;0;0;0;0;0;0;0;0;0

[Related commands]

5.2.120 SVMONRST= (Reset servo monitor maximum)

[Function]

The servo monitor data is cleared.

[Format]

SVMONRST=

[Answer]

QoK

[Reference command]

1;1;SVMONRST=
QoK

[Related commands]

5.2.121 RAREAD= (Read serial number)

[Function]

Read the robot serial number and controller serial number.

[Format]

RAREAD=

[Answer]

QoK<Number>;<Serial number >;<Set date>

<Number>

Robot number

<Serial number>	Robot serial number or controller serial number
< Set date >	Setting date of serial number

[Reference command]

1;1; RAREAD=
QoK1;xxxxxxxxxx;2014/04/09 17:14:02

[Related commands]

5.2.122 PRMINIT (Parameter initial)

[Function]

The parameter is initialized, and it puts it into the state when shipping it.

[Format]

PRMINIT

[Answer]

QoK

[Reference command]

1;1;PRMINIT
QoK

[Related commands]

5.2.123 PNR (Parameter read)

[Function]

The parameter is read. The parameter at the level corresponding to keyword (KEYWD) is read.

[Format]

PNR<Parameter name>
<Parameter name> Parameter name

[Answer]

QoK<Parameter names>;<Value>;<Value count>
<Parameter name> Parameter name
<Value> Value of parameter

<Value count> Count of value

[Reference command]

1;1;PNRBZR
QoKBZR;1;1

[Related commands]

PRM=

5.2.124 PRM= (Parameter write)

[Function]

The parameter is changed. The parameter at the level corresponding to keyword (KEYWD) is changed.

[Format]

PRM=<Parameter name>;<Value>
<Parameter name> Parameter name
<Value> Value of parameter

[Answer]

QoK

[Reference command]

1;1;PRM=BZR;1
QoK

[Related commands]

PNR

5.2.125 PAR (Parameter read)

[Function]

The parameter is able to read. All parameters are able to read regardless of keyword (KEYWD).

[Format]

PAR<Parameter name>
<Parameter name> Parameter name

[Answer]

QoK<Parameter name>;<Value>;<Value count>

<Parameter name> Parameter name

<Value> Value of parameter

<Value count> Count of value

[Reference command]

1;1;PARBZR

QoKBZR;1;1

[Related commands]

PAW=

5.2.126 PAW= (Parameter write)

[Function]

The parameter is changed. All parameters are changed regardless of keyword (KEYWD).

[Format]

PAW=<Parameter name>;<Value>

<Parameter name> Parameter name

<Value> Value of parameter

[Answer]

QoK

[Reference command]

1;1;PAW=BZR;1

QoK

[Related commands]

PAR

5.2.127 PAW2= (Parameter write (need to reboot.))

[Function]

The parameter is able to write. All parameters are able to write regardless of keyword (KEYWD). However, turning the power off-on is needed without fail for the reflection of the parameter setting value.

(It is not possible to use by the CRn-500 series.)

(It is possible to use since the edition of main S/W of the CRnQ-700/CRnD-700 series version R2/S2.)

[Format]

PAW2=<name>;<value>

<name> parameter name to write

<value> parameter value to write

[Answer]

QoK

[Reference command]

1;1;PAW2=BZR;1

QoK

[Related commands]

PAR、PAW=

5.2.128 PRMUNDO (Parameter undo)

[Function]

It returns it to the value when the parameter is shipped.

[Format]

PRMUNDO<Mech No.>;<Parameter name>

<Mech no.> Mech number. (0:Common parameter)

<Parameter name> Parameter name

[Answer]

QoK

[Reference command]

1;1;PRMUNDO0;BZR

QoK

[Related commands]

PRMINIT

5.2.129 PRM= (Read change parameter list)

[Function]

The list of the parameter name that has been changed is read.

(It is possible to use it since the edition of main S/W version N6/P6.)

[Format]

PMR=<Continuation specification>

< Continuation specification >

The reading method is specified.

0: Newly reading

1: Continuance reading.

[Answer]

QoK<Continuation>;<num>;<name>[0b<name>...]

<Continuation> 0: Continuation - off , 1: Continuation - on

<num> number of read parameters

<name> parameter name

It is delimited with 0x0b code between parameter name.

[Answer]

1;1;PMR=0

QoK0;6;SVSSFR0bMEOFFZ0bMEINST0bMEINSZ0bMEINSD0bMEJAR

[Related commands]

5.2.130 KEYWD (Keyword input)

[Function]

The level of opening to the public of the parameter is changed.

[Format]

KEYWDp<Keyword>

<Keyword>

Keyword

[Answer]

QoK

[Reference command]

1;1;KEYWDpMELFA

QoK

[Related commands]

PNR, PRM=

5.2.131 SLOTRD (Slot table read)

[Function]

The slot table is read.

[Format]

SLOTRD

[Answer]

QoK<Task prg.name>;<Task mode>;<Task cond.>;<Task pri>
--

<Task prg.name> Program name of slot table.

<Task mode> Operation mode of slot table. (REP/CYC)

<Task cond.> Stating conditions of slot table. (START/ALWAYS/ERROR)

<Task pri.> Priority of slot table. (1 – 31)

[Reference command]

1;2;SLOTRD

QoK2;REP;START;1

[Related commands]

SLOTSET

5.2.132 SLOTSET (Slot table write)

[Function]

The slot table is changed. ("SLTn" parameter is changed. It is necessary to reboot.)

[Format]

SLOTSET<Task prg.name>;<Task mode>;<Task cond.>;<Task pri>
--

<Task prg.name> Program name of slot table.

<Task mode> Operation mode of slot table. (REP/CYC)

<Task cond.> Stating conditions of slot table. (START/ALWAYS/ERROR)

<Task pri.> Priority of slot table. (1 – 31)

[Answer]

QoK

[Reference command]

1;2;SLOTSET2;REP;START;1

QoK

[Related commands]

SLOT RD

5.2.133 ENCBATTM (Battery remain time)

[Function]

The battery remain time is read.

[Format]

ENCBATTM

[Answer]

QoK<Power time>;<Remain time>

<Power time> Power on time (Hr)

<Remain time> Battery remaining time. (Hr)

[Reference command]

1;1;ENCBATTM

QoK51;11885

[Related commands]

PTIMEDEL=

5.2.134 BREAKON * (Release brake)

[Function]

The brake is released.

[Format]

BREAKON<Axis pattern>

<Axis pattern> Axis pattern by the HEX

00000000B

____1 J1

____1_ J2

____1_ J3

____1____ J4

___1___	J5
___1___	J6
___1___	J7
1___	J8

When 00 is specified, the brake is locked.

[Answer]

QoK

[Reference command]

1;1;BREAKON3F

QoK

[Related commands]

BREAKONF

5.2.135 BREAKONF * (Release brake)

[Function]

The brake is released. (No operation right required)

[Format]

BREAKONF<Axis pattern>

<Axis pattern> Axis pattern by the HEX

00000000B

___1___ J1

___1___ J2

___1___ J3

___1___ J4

___1___ J5

___1___ J6

___1___ J7

1___ J8

When 00 is specified, the brake is locked.

[Answer]

QoK

[Reference command]

1;1;BREAKONF3F

QoK

[Related commands]

BREAKON

5.2.136 HOME * (Setting the origin)

[Function]

The origin is set.

[Format]

HOME<Org.type>;<Axis pattern>

<Org.type>	0: User origin 1: Mechanical stopper 2: (reserve) 3: Calibration jig 4: ABS 5: Eye mark (6: Origin data input) 7: User ABS																
<Axis pattern>	Axis pattern by the HEX 00000000B <table> <tr><td>_____1</td><td>J1</td></tr> <tr><td>_____1</td><td>J2</td></tr> <tr><td>_____1</td><td>J3</td></tr> <tr><td>_____1</td><td>J4</td></tr> <tr><td>_____1</td><td>J5</td></tr> <tr><td>_____1</td><td>J6</td></tr> <tr><td>_____1</td><td>J7</td></tr> <tr><td>1_____</td><td>J8</td></tr> </table>	_____1	J1	_____1	J2	_____1	J3	_____1	J4	_____1	J5	_____1	J6	_____1	J7	1_____	J8
_____1	J1																
_____1	J2																
_____1	J3																
_____1	J4																
_____1	J5																
_____1	J6																
_____1	J7																
1_____	J8																

[Answer]

QoK

[Reference command]

1;1;HOME3;3F

QoK

[Related commands]

DATINST

5.2.137 AXDATINST * (Additional axis add for DATINST and DATRD)

[Function]

The addition axis is added to the origin setting data by the data input. The argument of DATINST after the AXDATINST command is executed and the DATRD command becomes it with the

addition axis.

[Format]

AXDATINST

[Answer]

QoK

[Reference command]

1;1;AXDATINST

QoK

[Related commands]

DATINST, DATRD

5.2.138 DATINST * (Data input origin set)

[Function]

The origin is set by the data input.

[Format]

DATINST<J1 data>;<J2 data>;<J3 data>;<J4 data>;<J5 data>;<J6 data>;<Checksum> or DATINST<J1 data>;<J2 data>;<J3 data>;<J4 data>;<J5 data>;<J6 data>;<J7 data>; <J8 data>;<Checksum>
--

[Answer]

QoK

[Reference command]

1;1;DATINSTZ2UOGQ;Z2VX5I;Z2#46Z;Z2NXW5;004QA5;0XB462;Y91%K5

QoK

[Related commands]

AXDATINST, DATRD

5.2.139 DATRD (Data input origin set)

[Function]

The origin data value by the data input is read.

[Format]

DATRD

[Answer]

QoK<J1 data>;<J2 data>;<J3 data>;<J4 data>;<J5 data>;<J6 data>;<Checksum> or QoK<J1 data>;<J2 data>;<J3 data>;<J4 data>;<J5 data>;<J6 data>;<J7 data>; <J8 data>;<Checksum>
--

[Reference command]

1;1;DATRD
QoKZ2UOGQ;Z2VX5I;Z2#46Z;Z2NXW5;004QA5;0XB462;Y91%K5

[Related commands]

AXDATINST, DATINST

5.2.140 RSTPWR (Reset power)

[Function]

Power supply reset (reboot) of the controller is executed.

[Format]

RSTPWR

[Answer]

QoK

[Reference command]

1;1;RSTPWR
QoK

[Related commands]

RPWRCHK=

5.2.141 RPWRCHK= (Reset power check)

[Function]

Check Power supply reset (reboot) of the controller.

[Format]

RPWRCHK=

[Answer]

QoK<Status>

<Status>

0:Impossible, 1:Possible

[Reference command]

1;1;RPWRCHK=

QoK1

[Related commands]

RSTPWR

5.2.142 MFTIME= (Maintenance forecast date)

[Function]

Read Maintenance forecast reset date.

[Format]

MFTIME=<Type>

<Type>

Read type.

1: Battery, 2: Grease, 3: Belt

[Answer]

QoK<J1 reset date>;<J2 reset date>;<J3 reset date>;<J4 reset date>;
<J5 reset date>;<J6 reset date>;<J7 reset date>;<J8 reset date>;
<J1 reset count>;<J2 reset count>;<J3 reset count>;<J4 reset count>;
<J5 reset count>;<J6 reset count>;<J7 reset count>;<J8 reset count>

<Jn reset date> Reset date.

<Jn reset count> Reset count.

[Reference command]

```
1;1;MFTIME=1
```

QoK2014/04/09;17:06:16;2014/04/09;17:06:16;2014/04/09;17:06:16;2014/04/09;17:06:16;201
4/04/09;17:06:16;2014/04/09;17:06:16;2014/04/09;17:06:16;2014/04/09;17:06:16;0;0;0;0;0;

0;0

[Related commands]

5.2.143 MFRST= (Maintenance forecast reset)

[Function]

Reset Maintenance forecast data.

[Format]

MFRST=<Axis bit>;<Reset bit>

<Axis bit>

Axis bit pattern of HEX number. (00~FF)

axis pattern

00000000B JOINT

_____1 J1

_____1_ J2

_____1__ J3

_____1___ J4

_____1____ J5

_____1_____ J6

_____1______ J7

_____1_______ J8

<Reset bit>

Reset bit pattern of HEX number. (00~FF)

reset pattern

00000000B

_____1 Grease

_____1_ Belt

[Answer]

QoK

[Reference command]

1;1;MFRST=20;1

QoK

[Related commands]

5.2.144 MFFCST= (Maintenance forecast read)

[Function]

Read Maintenance forecast data.

[Format]

MFFCST=<Type>

<Type>

Read type.

0: Battery, 1: Grease, 2: Belt

[Answer]

QoK<J1 forecast hour>;<J2 forecast hour>;<J3 forecast hour>;<J4 forecast hour>; <J5 forecast hour>;<J6 forecast hour>;<J7 forecast hour>;<J8 forecast hour>
--

<Jn forecast hour> Maintenance forecast hour.

[Reference command]

1;1;MFFCST=1

QoK23999;23999;23999;23999;23999;23999;0;0
--

[Related commands]

Index

ALIGN, 47	FATTRIB, 33	OPSTSRD, 80
ATENA, 51	FCHECK, 31	OUT, 58
AUE<ON/OFF>, 50	FCLOSE, 35	OUT=, 59
AXDATINST, 96	FCOPY, 32	OVRD, 42
BREAKON, 94, 95	FDEL, 32	OVRD=, 42
BRKPTCLR, 52	FDIR, 30	PAR, 89
BRKPTGET, 52	FINIT, 34	PAW=, 90
BRKPTSET, 51, 53, 54	FOPEN, 34	PAW2=, 90
CALIB, 57	FREAD, 35	PDIR, 29
CLOSE, 18	FRENAME, 33	PNR, 88
CNTL, 18	FWRITE, 36	PPOS, 64, 65
CSTOP, 44	HND<ON/OFF>, 47	PRG<UP/DOWN>, 38
CYCLECLR, 69	HNDSTS, 63	PRGLOAD=, 37
CYCLETIME, 69	HOME, 96	PRGRD, 38
DATINST, 97	HOT, 79	PRM=, 89, 92
DATRD, 97	IN, 58	PRMINIT, 88
DELETE, 28	IN=, 62	PRMUNDO, 91
DIN, 59	INDMY, 61	PTIME, 67
DIN=, 62	INSET, 61	PTIMEDEL=, 68
DOUT, 60	IOSIGNAL, 57	RENUM, 28
DOUT=, 60	JOG, 48, 49	RPOS, 64, 65
DSTATE, 56	JPOS, 64, 65	RSTALRM, 45
ECLR, 27	KEYWD, 92	RSTIO, 46
EDATA, 20	LINENO, 39	RSTPRG, 45
EDINS, 21	LINENO=, 39	RSTPWR, 98
EFREE, 36, 37	LINERD, 40	RUN, 43
EINS, 21	LINESRD, 40	SAVE, 19
EMDAT, 21	LISTCNT, 25	SLOTINIT, 45
ENCBATTM, 94	LISTI, 23	SLOTRD, 93
ERRLOG2=, 72	LISTL, 23	SLOTSET, 93
ERRLOGCLR, 73	LISTP, 24	SRV<ON/OFF>, 41
ERROR, 70	LOAD=, 19	STATE, 55
ERRORLOG, 71	LS<ON/OFF>, 50	STEP, 27
ERRORMES, 70	MLOCK<ON/OFF>, 46	STOP, 43
ERRSUM, 73	MOVSP, 48	STOP<ON/OFF>, 44
ERRSUM2=, 74	NEW, 20	STPSIG, 63
ERRSUMCLR, 75	OPEN=, 17	SUMDATE, 76
EXEC, 26	OPNUMRD, 80	TIME, 66

TIME=, 67

USERAREASTS, 64

VAL, 76, 78

VAL=, 22

VALS, 77, 78

VTYPRD, 25

XPOS, 64, 65