



Operator

Locked

Log In

Log in from the **Operator** box on **Home**.

When no-one is logged in, the **Operator** function is **Locked**.

When a user is logged in, the user name appears in the **Operator** box.

Only one user at a time can be logged into the STS.