

3. Disconnect secondary wiring at top of fuse compartment.

Remove the fuses.

