

Select **Preferred Source** (can force transfer).
See Chapter **Operational Modes**.

Input Source 1 and 2 measurements are voltage and
degrees of phase angle between sources.

